R6000-Robot



2012/03 ver. : V01.00 (4408990058)

Leading Numerical Controller





Table of content

Ta	ble c	of content	I
1	Ор	eration Interface	1
2	Но	ne	2
	2.1	How to return home	2
3	MA	NUAL	3
	3.1	ΜΑΝΙΙΑΙ	
	011	3.1.1 Output	
		3.1.2 Manual continuous axis move mode	
		3.1.3 JOG	5
		3.1.4 Return to standby	5
	3.2	IO status	6
	3.3	Standby tuning	7
4	Διι	·O	8
Т	/(4)		
	4.1	Monitor	8
		4.1.1 Button Description	9
	4.0	4.1.2 Modify program under auto running.	9
	4.2		10
	4.3	Stack setting	10
	4.4		10
	4.5		11
		4.5.1 Conveyor setting	12
_	_	4.5.2 Process machine setting	12
5	lea	ich	.13
	5.1	Edit	13
		5.1.1 Function key	13
		5.1.2 Program command detail	14
		5.1.3 Axis	14
		5.1.4 Speed	16
		5.1.5 Delay	17
		5.1.6 Robot I/O	18
		5.1.7 Injection molding machine I/O	19
		5.1.8 Vacuum/gripper I/O	21

		5.1.9 Peripheral device I/O	22
		5.1.10 Call stack	
		5.1.11 Call MACRO	
		5.1.12 Stop 26	
		5.1.13 Calculating	
		5.1.14 Jump 28	
		5.1.15 Loop 31	
	5.2	IO Status	
	5.3	Stack setting	
	5.4	Sample/reject	
		5.4.1 Sample check	
		5.4.2 Reject give up	
	5.5	File manage	
		5.5.1 Open a new mold file	
		5.5.2 Read old mold file	
		5.5.3 Copy current mold file	
		5.5.4 Delete mold file	40
		5.5.5 Upload/download mold file via USB	40
	5.6	Safe area	41
		5.6.1 No go area setting for 3 axes	41
		5.6.2 No go area setting for 5 axes	44
	5.7	@Variables	46
	5.8	MACRO	47
6	Par	ameter	48
	6.1	General parameter	
	6.2	Language	
	6.3	Common parameter	
	6.4	Machine parameter	
	6.5	, Maintain	52
		6.5.1 Maintain setting	52
		6.5.2 Maintain status	52
		6.5.3 Maintain history	53
	6.6	- Network	
7	Sys	stem	55
	7.1	About	55
	7.2	System info	56

	7.3	Ladder	57					
	7.4	R bit	58					
	7.5	System parameter	58					
	7.6	I/O Мар	59					
		7.6.1 DI Map	59					
		7.6.2 DO Map	60					
		7.6.3 DI Map DO Map setting	60					
	7.7	Backup	62					
		7.7.1 Parameter backup	62					
		7.7.2 Parameter restore	64					
	7.8	Upgrade	68					
	7.9	Operator authority	71					
	7.10	I/O	72					
	7.11	Change password	73					
	7.12	Monitor tuning	75					
8	Alar	m record	. 77					
	8.1	Alarm	77					
	8.2	Warning	78					
	8.3	Alarm/warning history	79					
	8.4	Operation history	80					
9	Swi	tch users	. 81					
10	Parameter							
	10.1	General parameter	82					
	10.2	Common parameter→Mutual parameter	83					
	10.3	Common parameter → Axis parameter	86					
11	Troi	ubleshooting	. 88					
	11 1		88					
	11.1	Warning troubleshooting	00					
	0 0							
12	Q&/	A	. 95					
	12.1	How to write note of movement command of mold document	95					
		12.1.1 Add one line note for movement command	95					
		12.1.2 Modify note	96					
		12.1.3 Delete note	97					
		12.1.4 Add note that you want to note	98					



Introduction of LNC-R6000 injection molding machine robot

LNC-R6000 is the controller for cartesian coordinate robot which is used on injection molding machine pick and put movement. This controller is based on real-time Linux kernel platform to create, it can control 3~5 axis servo systems, other features are

- Linux real time kernel.
- □ All-graphic simulation HMI.
- Group type selection, easy to control and use.
- □ Via USB to upload/download program.
- Offer special robot command.
- Embeded in PLC, for users to do self development.

3 axis servo system axis name and definition

Horizontal axis : X •

Pull axis : MY •

Vertical axis : MZ •

Direction as below •





5 axis servo system axis name and definition

- Horizontal axis : X •
- Main arm pull axis : MY •
- Main arm vertical axis : MZ ${\scriptstyle \circ}$
- Sub arm pull axis : SY \circ
- Sub arm vertical axis : SZ ${\scriptstyle \circ}$
- Direction as below .





1 Operation Interface



- A : Page Name : Show current page name.
- B : Mode : Current mode, there are HOME, MDI, AUTO, TEACH.
- C: Situation : Current situation, there are READY, RUNNING, PAUSE.
- D: Message hint: System will show hint message at this line.
- E: Coordinate of axis.
- F: Alarm/warning hint message, where there is a alarm/warning, the area will be twinkling.
- G: Reset : Press this button to make robot to be ready and clear alarm.
- H: Function key: Switch mode, page. Those with green arrow have further function keys.



2 Home

2.1 How to return home

When entering system, you will see Home page.

	Ноте	Home Ready	MY 200.00 MZ 0.00) SY 200.0) SZ 0.0	X0 X0	0.00	Alarm	Reset	
							WARNING		
Sequence		Main A	Arm Pose	Mold NO.		C	Current User		
			Back				99		
1.мz 2.му		2	Swivel						
3.x									
	\checkmark						ReturnI	łome	
				Press [ZR]	N] Button to 1	HOME			
Home	Nanual	3 Auto	14 Teach	15 Parameter	F6 Maintain	k 177	Alarm	User	

- 1. Return posture can be selected before going back, with **[vertical]** or **[horizontal]**.
- 2. Select axis and press or to adjust order to return home.
- 3. Press **I** to return home.
- 4. If there is error, press **[RESET]** or EMG to stop return HOME.
- 5. When returning home, buttons on this page will be lock. After returning, buttons will be recovered to prevent wrong operation.



3 MANUAL

Press [MANAUL] to go to manual mode.

3.1 MANUAL

			Action	Manual Ready	MY MZ	200.00 0.00	SY SZ	200.00 0.00	х	0.00	Alarm	Reset
(H)	V										WARNING	3
IN	OU	т	Description		Pneumatic	Jog	FeedRat	le				
0	0 (0	M-arm Horizo	ntal	Gripper/Va	a	1%	10	%	25%		Running
0	1 (3	M-arm Vertica	1	ccum		50 %	75	%	100 %		Jog
۲	2 (3	S-arm Horizon	tal	Auxiliar y							
۲	3 (•	S-arm Vertical					MZ-		Main	Am	Sub-arm
0	4 (9										
0	5 (9										
0	6 (9					Υ+		MY			X +
0	7 (9			01	1			01 01		X-	
۲	8 (9					N	ΛZ+	-		Ret	umHome
0	9 (9			OFF						Ku	
	<	E	2	F3	F4							
	<-		Action	IO status	Set H	OME						

3.1.1 Output

- 1. There are 3 groups of OUTPUT, air axis, gripper/vacuumer, and peripheral devices. You need to choose group and select OUTPUT you want to open or close.
- 2. When OUTPUT amount is bigger then 1 page, you can press and with to change.
- 3. After selecting, press **I** to make this OUTPUT, or **I** to close.



3.1.2 Manual continuous axis move mode

Press axis move button to move continously, release button to stop.



- 1. Press [Continue] button.
- 2. Select speed that you want this robot to move.
- 3. Press corresponding axis t move continuously, release to stop.





3.1.3 JOG

Press axis move button to move by 0.1mm · 1mm or 10mm. If you release the button, the axis will stop immediatelly.

- 1. Press [JOG] button.
- 2. Press 0.1mm

 10mm to change movement distance.
- 3. Axis movement speed is the same to the one continously.
- 4. Press the button of the axis you want to move, release button to stop.

3.1.4 Return to standby

- 1. Robot can only return standby point when under [READY].
- 2. Press [Return standby] button.
 - a. X axis is inside mold : the order is $Y \rightarrow Z \rightarrow$ vertical/horizontal $\rightarrow X$.
 - b. X axis is not inside mold : the order is $Z \rightarrow$ vertical/horizontal $\rightarrow Y \rightarrow X$.
- 3. Standby point can be adjusted at [Adjust standby point] page.



3.2 IO status

- 1. INPUT and OUTPUT are devided into group type, press corresponding group button to select I/O list.
- 2. You can check INPUT and OUTPUT at the same time.

IO status	Manual Read y	MY 200.00 MZ 0.00	SY SZ	200.00 0.00	Х	0.00	Alarm	Reset
							WARNING	
IN STA. Description			OUT ST	TA. De	scription			
000		Robot	000	M-ar	m Horizor	ıtal		Robot
001			001					
002	002			S-an	n Horizon	al		nov
003 🥥		IMIM	003	S-arr	n Vertical			IMM
004	<u> </u>		004					
005 🥥								PeriPh.
006 🥑 MY-Hardware L	6 🥑 MY-Hardware Limit			006				
007 🥑 MY+ Hardware I	<i>.</i> imit	Other	007					Other
008 🥑 MZ-Hardware L	imit	Omer	008					Omer
009 🥑 MZ+ Hardware L	imit		009					
010 🥑 SY-Hardware Li	mit		010	Grip	per 1			
011 🥑 SY+ Hardware L	imit		011	Grip	per 2			
012 🥑 SZ- Hardware Lin	nit		012	Grip	per 3			
013 🥑 SZ+ Hardware Li	013 🥑 SZ+ Hardware Limit				per 4			PgDn
014 🥝 X-Hardware Lin	uit		014		um 1			
<- Action	F3 IO status	14 Set HOME						



3.3 Standby tuning

How to adjust program ZERO location.

When the program zero point is not the one you want, you can adjust standby point to the program starting point. When pressing [return standby], every axis will move to pre-set position.

	HomeSetting	Manual Ready	MY 200.00 MZ 0.00) SY 200.00) SZ 0.00	X 0.00 Ala	m. Posst
		C	8		WAR	VING
	Machine Pos.	Сипен	t Position	Jog 0.1mm	1 mm 10 mm	ReturnHome
мү	0.00	МҮ	-200.00	MY-	MY+	
MZ	0.00	MZ	0.00	MZ-	MZ+	
SY	0.00	SY	-200.00	SY-	SY+	
sz	0.00	3Z	0.00	SZ-	SZ+	
x	0.00	x	0.00	X-	X+	
<-	72 Action	F3 IO status	M Set HOME			

Home tuning value will be saved at mold file, when opening a new mold file, previous setting will be loaded in, so the previous offset will be loaded in too.



4 Auto

Press [Auto] to go auto mode.

4.1 Monitor

Show auto running situation under auto mode.





4.1.1 Button Description



Stop Auto

: When the step is at [complete open mold], press this button to stop. But if you press this button when the step is at middle travel, system will complete the whole travel and stop.

Return Home

: Let robot return to standby point.

Modify

: Under auto running, page and cursor will be moved by current program. If you want to modify program, you can press modify key to stop auto mode.

— 30 % **—**

: Running speed adjustment under auto mode.

4.1.2 Modify program under auto running.

Under auto mode, you can only modify movement speed, delay time and small tuning of axis location.



1. Move cursor to the place you want to change.



2. Press [modify] to see right side selections and key in dealy time to see below small tablet.



- 3. Key in value and press [OK]
- 4. Press [REPLACE] at right down side to take over old program.

4.2 IO status

Refer to chapter 3.2.

4.3 Stack setting

Refer to chapter 5.3.

4.4 Sample/reject

Refer to chapter 5.4.

4.5 Cycle monitor

You can see time and parts setting under auto mode.



Mold number : Mold file name.

Total time : Accumulated operation time.

Take time : The take out time is from completing open mold, robot pick goods to returning to original location.

Mold time : The time for injection molding machine to complete a part.

Cycle time : The time that robot to complete to pick a part.

Total count : The total auto loop times for robot to running.

Finish count : If the setting is 100, when the auto loop meets 100 times, system will send warning to notice. If the setting is 0, this function will be fail.

Good count : Acceptable parts total numbers.

Bad count : Total times of rejecting parts signals.

Produce : The total amount of injection parts, including good and bad parts.



4.5.1 Conveyor setting



Moving time : This is to set up converyor stop time. When this is 0 and parts also arrived, conveyor will not stop.
Setting count : After how many molds, conveyor will start to move. When this is 0, conveyor will not move.
Current count : Show current put times. You can press [return zero] to reset this value and force conveyor to move.

The way to use conveyor is to write command for conveyor in the program and set up moving time and interval mode at this page. When running times arrive, conveyor will move for some time and stop.

4.5.2 Process machine setting

Process Machine Option										
Moving Time	0.0	Sec	Sec							
Setting Count	0	pcs	Zero							
Current Count	0	pcs								

Moving time : This is to set up working machine stop time. When this is 0 and parts also arrived, conveyor will not stop.

Setting count : After how many molds, working machine will start to move. When this is 0, working machine will not move.

Current count : Show current put times. You can press [return zero] to reset this value and force working machine to move.

The way to use working machine is to write command for conveyor in the program and set up moving time and interval mode at this page. When running times arrive, conveyor will move for some time and stop.



5 Teach

Press [Teach] to go to teach mode.

This mode is to do mold file editing and running test.

5.1 Edit

User default level is 99, this level can only open file and do cycle start. If you want to edit or modify program, you will need to change to level 29 and above.



5.1.1 Function key

Delete : Delete cursor current program.

Cut : Cut cursor current program.

Copy: Copy cursor current program.

Paste: Insert the program that you copy or cut.



running speed tuning : running speed tuning under teach mode. Default is 30%.

Single : Run total program one time and stop. At the next step, press this function to do single cycle. **Stop Auto** : Stop robot running and go to stop status.



Show index page.





Show previous page.









Show last page.

Command : Return to command list page.

Add : Add right side setting info to the left side's next line.

Replace : Make left side blue line to replace to current setting info.

Program command detail 5.1.2

Go to TEACH and press [command], you will see teach command as below. Press below button to go to this command's page.

		Dela y		
Robot IO	IMM IO	Gripper		
PeriPh.	Call Stack	Call Macro		
Stop				

5.1.3 Axis

Press axis to see below.



	Edit	Semi Ready	MY MZ	0.00 0.00		x	0.00	Alarm	Pagat
	Move to X=0.00							WARNING	TCOCI
Mold 1	NO. 45		Save	-	Comma	nd: Axis	-Moving		Comment
1	Speed 100%		_	Ā	Running	2 –			
2	Move to MZ=0.00				МҮ		mm	MY-	MY+
3	Move to MY=0.00				MZ		- mm	MZ-	MZ+
4	Move to X=0.00						_		
5	M-arm Vertical DE	LAY 1.0 Sec		V	х	0.0) mm	X-	X +
6	Mould Open								
7	Move to MZ=800.	00							
8	Move to MY=-100	0.00	•						
Del Line	Cut Copy	Paste Г	Single						
	80 % France Retu	mHom Stop A	Auto	Com	nand	Add		Replace	
<-	F2 Edit	13 IO status	F4 St	ack	6 Sample/Rejec	FileMan		@ Var	

This command is to move to certain location.



There are two ways to input location.

Press [location] to see small keypad and key in directly.

Press [axis direction] to move axis to target location and press [location], [axis name] will pet current location into location column.



5.1.4 Speed

	Edit	Semi Read y	MY MZ	0.00 0.00		x		0.00	Alarm	Popot
	Move to X=0.00								WARNIN	G
Mold 1	NO. 45		Save	4	Command	: :	Speed	1		
1	Speed 100%		^	$\overline{\mathbf{A}}$	FeedRate	:	100	%		
2	Move to MZ=0.00)								
3	Move to MY=0.0)								
4	Move to X=0.00									
5	M-arm Vertical DI	ELAY 1.0 Sec		*						
6	Mould Open			X						
7	Move to MZ=800	.00						•		
8	Move to MY=-10	0.00	•					•		
Del Line	Cut Copy	Paste 🗖	Single	2						
	30 % ReturnHom e Stop Auto Single Command Add Replace									Replace
<-	F2 Edit	13 — IO status —	14 Si	tack	5 Sample/Reject	Filel	Manage	17	@ Var	

- 1. You can set up moving speed for every axis, if you didn't renew the speed, this speed will be the previous setting.
- 2. Range is 1~100.



5.1.5 Delay

	Edit	Semi Ready	MY MZ	0.00 0.00		х	0.00	Alarm	Popot
	Move to X=0.00				-			WARNING	- KCaCi
Mold N	10. 45		Save		Command	l: Delay			
1	Speed 100%		^	$\overline{\mathbf{A}}$	DelayTim	e	1 Sec	:	
2	Move to MZ=0.00)							
3	Move to MY=0.00)							
4	Move to X=0.00								
5	M-arm Vertical DI	ELAY 1.0 Sec		V					
6	Mould Open								
7	Move to MZ=800	.00			•				
8	Move to MY= -10	0.00	•	⊻					
Del Line	Cut Copy	Paste 🗖	Single	:					
3	0 % Frank	umHom Stop #	Auto	Comma	nd	Add		Replace	
<-	Edit	IO status	M SI	ack	5 Sample/Reject	F6 FileManag	e 77	@ Var	

- 1. You can set up the delay time to run the next command.
- 2. Setting range 0~9.9.



5.1.6 Robot I/O

OUTPUT action.

- 1. Robot I/O command are output main arm vertical/horizontal, sub-arm move forward/backward, sub-arm vertical/horizontal, sub-arm move down/move up output points.
- 2. [Check/Not check] item is for you to set up a check system. If [Check], then after an output, system need to receive an input signal and go next step. If [Not check]], then after an output, system will run next step immediately.
- 3. After completing output signal setting, press [add] to add this command to the next line or press [replace] to replace cursor line info.
- 4. Press [add] or [replace] to return to command list.





5.1.7 Injection molding machine I/O

[Check INPUT]

- 1. When running to check injection molding machine input signal, system will stop at this step. Until corresponding input signal has been trigger and system will go next step.
- 2. Click [check I] to see below command
- 3. Select the signal you want to check and press[add] to add command to the next line or press[replace] to replace cursor info.
- 4. Press [add] or [replace] to return to command list.

NA	Edit	Semi Ready	MY MZ	0.00 0.00			x	0.00	Alarm	– Reset
	M-arm Verti	cal DELAY 1.0 S	x						WARNING	3
Mold NO. 45			Save		Comm	and:	IMM IO	۲	Check I	Output O
1	Speed 100%		-	Ā	No.	Desc	cription			-
2	Move to MZ=	=0.00			66	Mou	ld Open			
3	Move to MY:	=0.00			67	14-12				
4	Move to X=0).00			67	Molo	d Mid-place			
5	M-arm Vertic	al DELAY 1.0 Sec	:	V	69	Eject	tor Backware	1		
6	Mould Open				70	Eject	tor Forward			
7	Move to MZ=	= 800.00								
8	Move to MY:	= -100.00		▶						
Del Line Cut Copy Paste Single										
- 3	omman	d	Add		Replace					
 Edit IO status Stack Sample/Reject FileManage Var 										



[Check OUTPUT]

- 1. When running to injection molding machine output signal steps, certain output signal will run next step immediately. Until output delay time arrives, system will output exact signal.
- 2. Click [check O] to see below command
- 3. Select the signal you want to check and press [add] to add command to the next line or press [replace] to replace cursor info.
- 4. Press [add] or [replace] to return to command list.

NA	Edit	Semi Ready	MY MZ	0.00 0.00				х	0.00	Alarm	Repot		
	M-arm Vertical D	ELAY 1.0 Sec								WARNIN	G		
Mold N	10. 45		Save			Comma	ind:	I MM IO	С	Check I	• Output O		
1	Speed 100%			Ā		No.	Desc	ription			-		
2	Move to MZ=0.00						Enab	ole Mould (
3	Move to MY=0.00						Enab						
4	Move to X=0.00						спан						
5	M-arm Vertical DF		67	Enab	Enable Ejector Forward								
6	Mould Open		68	Enable Core Mot(Core1, Pos1)									
7	Move to MZ=800.												
8	Move to MY=-100).00	-										
Del Line Cut Copy Paste Single Counting Timer 0.0 Sec													
3	30 % ReturnHom Stop Auto Single							Command Add Replace					
<-	F2 Edit	FO IO status	F4 S	tack	-5 Sar	nple/Rej	ect [R	FileManag	e	@ Var			



5.1.8 Vacuum/gripper I/O

Output certain action.

- 1. Select the vacuumer or gripper valve.
- When choosing vacuumer or gripper valve, if you do not want to check corresponding I point, cancel
 [vacuumer/gripper valve check].
- 3. ON is output signal, OFF is close the signal.
- 4. Set up delay time, and then run output signal.
- 5. Under auto mode, click [vacuumer/gripper check], while robot arm moved up to safety position, the corresponding Input signal did not trigger, system will send warning and stop robot. After clearing this trouble, you can press auto cycle to run, but under signal cycle, this situation will not trigger warning.
- 6. Press [add] to add command to the next line or press [replace] to replace cursor info.
- 7. Press [add] or [replace] to return to command list.





5.1.9 Peripheral device I/O

[Check I]

- 1. When running to steps of check peripheral device I/O, system will wait corresponding Input signal to be triggered and then go next step. But if the waiting time is bigger than the setting maximum time, system will send warning. Under check mode, if you press running function key again, system will still send warning, but if under not check mode, program will run next step.
- 2. Select [check I] to see below command.
- 3. Press [add] to add command to the next line or press [replace] to replace cursor info.
- 4. Press [add] or [replace] to return to command list.





[Output O]

These are the peripheral device output.

- 1. Choose output signal and choose signal status is ON/OFF.
- 2. Set up how long you want to delay and run this output.
- 3. Press [add] to add command to the next line or press [replace] to replace cursor info.
- 4. Press [add] or [replace] to return to command list.





5.1.10 Call stack

Array number is $0 \sim 9$, array setting content is based on [stack setting] page.



5.1.11 Call MACRO

This macro will be edited by machine makers, is for main program to call. System offers total 100 groups of MACRO for you to write. Refer to [MACRO] chapter.

	Edit	Semi Ready	MY MZ	0.00 0.00				x	0.00	Alarm	Reset
										WARNIN	G
Mold NO. 45				e		Сош	nand	: Call M			
1	Speed 100%		_	Ā		Маст	0	0			
2	Move to MZ=0.00				No Description					- h	
3	Move to MY=0.00				NO.	Dea					
4	Move to X=0.00			0	San						
5	M-arm Vertical DE	V		1	теје	ctive part al					
6	Mould Open					2	та				
7	Move to MZ=800.				2	m 2/					
8	Move to MY= -100	•			3	шач	.105				
Del Line	Cut Copy	Paste	Single			4	та	c104			-
30 % ReturnHom Stop Auto Sing						Cor	Replace				
<-	Edit	13 — IO status —	F4 St	ack	i5 Sa	mple/Re	ject	6 FileManag	ge F7	@ Var	

Self-defined MACRO file name list

- 1. Run [backup] to backup file to USB drive, backup info should include MACRO. Refer to [backup] chapter to know more.
- 2. Use word editing program (EX:Word) to open file under this link, backup\ncfiles\macro0000.str in the USB drive. (Simplified Chinese=modify this file, macro0001.str, English=modify this file, macro0002.str).

3. File content is as below

[HMIstring]

2300=sampling check program

2301=rejecting item give up program

2302=sub program 2

- 2303=sub program 3
- 2304=sub program 4
- 2305=sub program 5

2306=sub program 6

•••

2398=sub program 98

2399=sub program 99



- [HMIstring]<==first line is system setting keyword; this line should be exist no matter any language.
- File format content must be [number=sub program name].
- Number range 2300~2399 to correspond to sub program 0~sub program 99, total 100 groups of sub program.
- 4. After modification, via [backup] function to upload this new file into USB drive. Upload to file to controller, reboot to see the new modification.

5.1.12 Stop

How to set up program ending.



- 1. Teach program's last step must be (also call main program) program end. When runs to this step, there will have below situation.
 - a. Teach mode : program ends and stops.
 - b. Auto mode : Running from the first line of program.
- 2. Sub program's last line could be
 - a. Sub program return : after sub program completing, it will continue to call later program.
 - b. Program ends : after sub program ending, it will start from the first line of main program.
- 3. When running to program ends or sub program return, later command will not be run.

5.1.13 Calculating

There are 1100 mutual variables in the system. Mutual variable can be read and set up in main program and sub program. You can use mutual variable to meet special function in the program. There are calculating type, logic type and setting type.

- Calculating type : add, subtract, multiply, and divide.
- Logic type : system offers 32 bit variables, there are AND \ OR \ NOT \ XOR for bit processing.
- Setting type : MOV will make variable to be certain value ; SET will make variable to be 1 ; CLR will make variable to be 0.





5.1.14 Jump

Press [Jump] to go to below. Jump function can be certain line number or certain tag.



Jump to line number

- 1. Click line number.
- 2. Key in line number.
- 3. Choose jump by variable calculating or I status.
 - a. calculating : determine@variable value status.
 Conditional are as below
 - unconditional
 - less than (<)
 - bigger than (>)
 - equal to (=)
 - is not equal to (<>)
 - bigger than or equal to (<=)
 - less than or equal to (> =)
 - b. I : determine current I signal is ON or OFF.


	Edit	Semi Ready	MY MZ	0.00 0.00		x	0.00 Alar	III Reset
CINC							WARM	IING
Mold N	ю.		Save	-	Comma	and: Jump	• Conditio	n 🔿 Label
1	Mould Open		^	Ā			1	
2	Enable Mould Clos	æ				ie	1	• Operate
3	PROCEDURE ENI)			• Lal	bel Status	ON OFF	• I
4					No.	Description		
5				V			•	
6					20	Product Chec	ĸ	
7				V V	64	Rej-parts Sign	nal	
8			•	Y	80	Conveyor Pho	otocell	
Del Line	Cut Copy	Paste 🗖	Single	2	81	Safety Placing	g Photocell	- X
3	0 %	mHom Stop 4	luto	Single	Cor	mmand	Add	Replace
<-	F2 Edit	F3 IO status	F4 Si	tack s	5 Sample/Rej	ject FileMana	ige Safe area	a >>

- 4. Presses [add] to add to the next line or press replace to rewrite this line.
- 5. After pressing, return to command list.

Jump to tag

- 1. Choose tag item.
- 2. Key in tag number you want to jump to.
- 3. Choose jump by variable calculating or I status
 - a. calculating : determine@variable value status. Conditional are as below
 - unconditional
 - less than (<)
 - bigger than (>)
 - equal to (=)
 - is not equal to (<>)
 - bigger than or equal to (<=)
 - less than or equal to (> =)
 - b. I: determine current I signal is ON or OFF
- 4. Press [add] to add to the next line or press replace to rewrite this line
- 5. After pressing, return to command list
- 6. Move to the target location and press jump button.



7. Choose label selection.

NA	Edit	Semi Ready	MY MZ	0.00 0.00		x	0.00 Alarm	Reset
							WARNI	NG
Mold N	ю.		Save		Command:	Jump	• Condition	• Label
1	Mould Open		•	$\overline{\mathbf{A}}$	Label	1		
2	Enable Mould Clos	se				1		ĸ
3	PROCEDURE EN	D						
4								
5				*				
6				X				
7								
8			-					
Del Line	Cut Copy	Paste 🗖	Single					
3	0 % Frank	ImHom Stop A	Auto	Single	Comma	nd	Add	Replace
<-	F2 Edit	13 IO status	F4 Sta	ack	5 Sample/Reject	FileManage	e Safe area	>>

- 8. Key in label number, label number definition cannot be repeated.
- 9. Press [add] to add to the next line or press [replace] to rewrite this line.

5.1.15 Loop

From certain line number or label location to repeat running certain times. EX : line number=10, repeat times=3, then the cursor will move from current location to line 10 and run down for 3 times. It means the same area's command was run for 4 times.

NA	Edit	Semi Ready	MY MZ	0.00 0.00		x	0.00	Alarm	Reset
					_			WARNING	
Mold N	10.		Save	-	Command	: Loop			
1	Mould Open		^	$\overline{\mathbf{A}}$	• Line				
2	Enable Mould Clo	se			C Label		1		
3	PROCEDURE EN	D							
4					Count		2		
5				*					
6									
7								•	
8			•					7	
Del Line	Cut Copy	Paste [Single	•					
- 3	80 % Frank Return	ImHom Stop	Auto	Single	Comma	nd	Add		Replace
<-	F2 Edit	F3 IO status	F4 SI	tack	5 Sample/Reject	ð FileManage	• • • • •	Safe area	>>

5.2 IO Status

Refer to chapter 3.2.



5.3 Stack setting

Press [stack setting] to go current mold document stack setting.

Function Description :

When program runs to [call x number stack], horizonal axis and pull axis will move to target location and move down to Z axis location. When comple Z axis, system will continue the next command. As for vacuumer release and

move-up to safe location, you will need to edit this by yourself.

Notice :

- 1. Before ssetting stack, confirm current mold name again.
- 2. Mold document name can not be blank.
- 3. Before stacking, you will need to move Z axis to certain safe height; after completing, you will also need to do the same step to prevent collision.





Operation



Pick number list to switch stack numbers, system offers 10 sets of stack for setting. The number here and teach mode is corresponding.

First part position :

Set up the first part location, click the colum and input coordinate or press left down side button to make current location to the setting.

Putting axis order :

Set up axis order of part, press the order directly.

Main arm or sub arm.

Arm choose :

1.The speed to put location(%)

When running stacking, the speed of horizonal axis and pull axis.

2. Z axis goes down 1 section speed(%)

Horizontal axis and pull axis will need to position to the product to be placed above and Z axis will use 1 section speed to go down to R, EX : part putting location is 500, R distance is 30, Z axis goes down in 1 section speed with 100%, machine will use 100% to move to 470.

3. Moving distance to go down in 2 section speed(mm)

4.Before going down delay time in 2 section speed(second)

5. Z axis goes down in 2 section speed(%)

When putting parts, if you want to use slow speed to move to target place, ex, moving distance=50, delay time 0.5 second, Z down in 2 section speed=30, if this Z axis target=300, then Z axis will go down in 1 section speed to 250 (250=300-50), then delay 0.5 second and use 30% speed to move to Z=300.

Interval

Setting interval of products.

Parts

Left line is to show the complete parts, 0 is the first layer, 1 is the second layer and so on. When running, system will add up the value. If you want to reset the location, EX, from 3 layer to put, set up value to be 2, from 4 layer to



put, set up value to be 3, and so on, right side is the parts that every axis needs to put.

5.4 Sample/reject



5.4.1 Sample check

Sample check cycle :

If you set up this value to be 100 under auto running, every 100 mold, system will put one product to sampling desk, if you set this to be 0, there is no check.

Manual sample :

Press" + "button to add 1 on manual sampling. When the value is bigger than 0, system will put current product to sampling check desk and minus value with 1.

@variable number

410	Use main arm or sub arm when sampling	0 : Main arm ; 1 : sub arm
411	Traverse axle coordinate when sampling	Unit:mm
412	Crosswise axle coordinate when sampling	Unit:mm
413	Vertical axle coordinate when sampling	Unit : mm

Sampling function running content should be based on machine maker MACRO 0, moving target location should be based on above @ variable numbers.



5.4.2 Reject give up

Give up mold when running :

You can set up this value as 10 under auto mode, previous 10 molds will trigger rejecting good signal, value 0 is invalid for this function.

Give up mold when good shape :

When bad shape signal was triggered, you can set up give up goods numbers.

@Variable number

400	Use main arm or sub arm when putting rejecting	0:Main arm;1:sub arm
401	Traverse axle coordinate when putting rejecting	Unit:mm
402	Crosswise axle coordinate when putting rejecting	Unit : mm
403	Vertical axle coordinate when putting rejecting	Unit:mm

This give up function will need to base on machine maker MACRO 1. Moving target in MACRO will need to use@to use.



5.5 File manage

Press file to see below.

N	FileManage	Semi Ready	MY 0.00 MZ 0.00		X 0	.00 Alarm		Popot
CIV	There is not this	function				WARNING	3	React
No.	Filename		Date		Remark		4	l
1	45	2012-02-2	9 13:53:44					
2	46	2012-03-1	0 16:37:26					
3	1212	2012-03-1	0 09:38:02					
4	test	2012-03-1	0 10:10:23	<u>,</u>				
								V
								Ť
							~	
Fil	ename 1212							
<	- Ne w	F3 Load	ра Сору	E5 Delete	F6 Transfer	F7 Remark		



5.5.1 Open a new mold file

1. Press [New] to open a new mold document, as below.

NA	Edit		Semi Ready	MY MZ	0.00 0.00				x	0.00) Alarm	Repet
											WARNIN	G
Mold N	10.			Save	-		Comma	and:	IMM IO	6	• Check I	○ Output O
1	Mould Ope	n		_	$\overline{\mathbf{A}}$		No.	Desc	cription			-
2	Enable Mo	uld Clos	e				66	Mou	ld Open			
3	PROCEDU	RE ENI)				67	Mold	d Mid-place	`		
4							67					
5					V		69	Eject	tor Backwa	Id		
6							70	Eject	tor Forward	1		Ţ
7												
8				•								
Del Line	Cut	Сору	Paste 🗖	Single	÷							
3	0 % 🕂	Retu e	mHom Stop 4	Auto	Single		Сог	nman	d	Add	i	Replace
<-	F2 E	dit	F3 IO status	F4 Si	tack	F5 Sai	mple/Rej	ject	6 FileManag	e F7	Safe area	>>

- 2. Before editing program, you will need to key in mold number.
- 3. After opening new file, program will have defaul steps, complete open mold, allow close mold, program end. These command must be exist.



5.5.2 Read old mold file

- 1. Select the file you want to open, press [load].
- EX, if you choose 45 mold document and press [load], you will see below confirm window, you can press [OK] to open this old file.

N	<u>}</u>	FileManage	Semi Ready	MY 0.00 MZ 0.00		X ().00 Alarm	Reset
	<u> </u>						WARNING	
No.		Filename		Date		Remark		<u> </u>
1	45		2012-02-	29 13:53:44				
2	46		2012-03-	10 16:37:26				
3	1212		2	CON	FIRM			
4	test		2					
	1			Are you sure t	o input 1212 ?			◆
				ОК	CANCEL			
File	ename	1212						
ج،	-	New	13 Load	14 Сору	F5 Delete	F6 Transfer	F7 Remark	

5.5.3 Copy current mold file

1. Choose the file you want to copy, press [copy], as below.

N	<u>}</u>	FileManage	Semi Ready	MY 0.00 MZ 0.00		X 0	.00 Alarm		Popot
	Pl e	s click target file	name text box &	& enter filename	?		WARNING	•	RUSCI
No.		Filename		Date		Remark		4	
1	45		2012-02-2	9 13:53:44					-
2	46		2012-03-1	0 16:37:26					
3	1212		2012-03-1	0 09:38:02					
4	test		2012-03-1	0 10:10:23					
									\
									X
								~	
File	ename	1212			Target File				
		172	73	FA 📐	85		F 1		
<-	-	New	Load	Сору	Delete	Transfer	Remark		

2. Key in target file name, you will see the new copy file with new name.

		Fi	leManage	;	Semi Ready	MY MZ	0.00 0.00			х	0.00	Alarm	Papat
E	V	Pls o	click targe	et filenam	e text box	& enter	filename?)				WARNING	KCOCI
No	».		Filename			Date				Remark			<u>~</u>
1	45	5			2012-02-	29 13:5	3:44						
							Keybi	oard					
3		HO	ME	-	2				>	END		CA	NCEL
4	1		2	3	4	5	6	7	8	9	0	Bacl	kspace
	C	5	w	E	R	Т	Y	U	I	0	Р	I	Del
		A	S	D	F	G	Н	1	K	L		SI	pace
		Z	x	С	v	В	N	М	-			(ЭК
	Filena	ше	1212					Target	File		k		
	<-	E	2 New	F3	Load	F4 Co	ру	Delete	FO	Transfer	F7 F	Remark	

3. After inputing, press OK to complete.



5.5.4 Delete mold file

1. Choose the file you want to delete, press [delete], there will be a confirm window to confirm with you.



2. Press [OK] to delete this file, if no, press [cancel].

5.5.5 Upload/download mold file via USB

Notice

- 1. Current, only support 4GB and below USB drive.
- 2. Import/export file should be under root directoty ncfiles.
- 3. Directory is as below.





5.6 Safe area

Function :

In order to prevent collision risk of arm, every mold document has its own safety area setting. When setting up a new mold document, you will need to confirm the safety area again to meet current mold status.

Notice :

If you set up a new mold file, [No go area] and [safe area] will use previous mold setting for users to setup quickly.

5.6.1 No go area setting for 3 axes

MA	Safe area	Semi Ready	MY 0. MZ 0.	00	x	0.00	Alarm	Ponot
							WARNING	Keaci
		No-go Area	Sal	e Area	Icon			
SET	215.00	(P1): Mold-open, th	he max. MY i	n-mold				
SET	-200.00	(P2): Mold-open, th	he min. MY ir	-mold				
SET	210.00	(P3): Mold mid-pla	ce,the max. N	(Y in-mold				
SET	50.00	(P4): The max. MZ	safe mold-cle	se				
	-							
				ĸ				
	172	R	FA	15	165	177		
<-	Edit	IO status	Stack	Sample/Reject	FileManage	5	Safe area	>>







- (P1): When completing open mold, max. location of MY axis inside the mold : When completing open mold, main arm goes down into mold, MY axis goes to the max. coordinate(+), this is P1's MY coordinate.
- (P2): When completing open mold, min. location of MY axis inside the mold : When completing open



mold , MZ goes down into mold, MY axis goes to the min. coordinate(-), this is P2's MY coordinate.

- (P3): Open mold middle position, max. location of MY axis inside the mold : this function only valid for open mold middle signal. If there is no this function, you will need to set up the same to MY(P1), When middle position signal was trigged, MZ axis can go down to mold, when MZ goes to mold, MY axis can move to the max. location(+), this is P3's MY coordinate.
- (P4): The height for MZ axis to close mold safely : when MZ axis moves up to setting pocition, the max. down position for mold to close mold.

*This function will only be valid when [go down in mold standby function], otherwise X axis can only move to P8 when there is no open mold complete signal.

- (P5): X axis in the mold's min pick safety location: When completing open mold, vertical axis to go down to mold, the max. location for X axis to move(-)direction.
- (P6): X axis in the mold's max pick safety location : When completing open mold, vertical axis to go into mold, the max. location for X axis to move(+)direction.
- (P7): X axis in (+) direction at safety location outside of mold : the area when vertical axis outside of mold, when vertical axis to go down, the max. location for X axis to move(-)direction.
- (P8): MZ axis to go out safety height : when X axis goes out or in, the max. location that MZ axis will not hit safety door, this value can not be smaller or equal to 0, recommend value to be 10mm~50mm.



5.6.2 No go area setting for 5 axes

NO	Safe area	Semi Ready	MY 0.00 MZ 0.00	SY 0.0 SZ 0.0		0.00 Alarm	- Reset
			_			WARNING	
		No-go Area	Safe A	леа	Icon		
SET	215.00	(P1): Mold-open, th	ne max. MY in-n	old			
SET	-10.00	(P2): Mold-open, th	ne max. SY in-m	bld			
SET	210.00	(P3): Mold mid-pla	ce,the max. MY	in-mold			
SET	50.00	(P4): The max. MZ	safe mold-close				
SET	88.00	(P4): The max. SZ :	safe mold-close				
<-	F2 Edit	IO IO status	F4 Stack	i5 Sample/Reject	F6 FileManage	F7 Safe area	>>
			DIGCIX	Print Lough			
	Safe area	Semi Ready	MY 0.00 MZ 0.00	SY 0.0 SZ 0.0) x	0.00 Alarm	Dent
	Safe area	Semi Read y	MY 0.00 MZ 0.00	SY 0.0 SZ 0.0		0.00 Alarm WARNING	Reset
	Safe area	Semi Ready No-go Area	MY 0.00 MZ 0.00 Safe 4	SY 0.0 SZ 0.0) X Icon	0.00 Alarm WARNING	Reset
SET	Safe area	Semi Ready No-go Area (P5): X in-mold mi	MY 0.00 MZ 0.00 Safe A	SY 0.0 SZ 0.0) X Icon	0.00 Alarm WARNING	Reset
SET SET	Safe area -10.00 100.00	Semi Ready No-go Area (P5): X in-mold mi (P6): X in-mold ma	MY 0.00 MZ 0.00 Safe <i>i</i> n. safe area x. safe area	SY 0.0 SZ 0.0) X Icon	0.00 Alarm WARNING	Reset
SET SET SET	-10.00 800.00	Semi Ready No-go Area (P5): X in-mold mi (P6): X in-mold ma (P7): X+ out-mold i	MY 0.00 MZ 0.00 Safe <i>i</i> n. safe area x. safe area min. safe area	SY 0.0 SZ 0.0) X Icon	0.00 Alarm WARNING	Reset
SET SET SET SET	-10.00 -10.00 100.00 800.00 10.00	Semi Ready No-go Area (P5): X in-mold min (P6): X in-mold ma (P7): X+ out-mold ma (P8): Max. MZ can	MY 0.00 MZ 0.00 Safe <i>i</i> n. safe area x. safe area min. safe area min. safe area	SY 0.0 SZ 0.0) X Icon	0.00 Alarm WARNING	Reset
SET SET SET SET SET	Safe area -10.00 100.00 800.00 10.00 10.00	Semi Ready No-go Area (P5): X in-mold mi (P6): X in-mold ma (P7): X+ out-mold i (P8): Max. MZ can (P8): Max. SZ can f	MY 0.00 MZ 0.00 Safe 1 n. safe area x. safe area min. safe area min. safe area	SY 0.0 SZ 0.0) X Icon	0.00 Alarm WARNING	Reset
SET SET SET SET SET	Safe area -10.00 100.00 800.00 10.00	Semi Ready No-go Area (P5): X in-mold mi (P6): X in-mold ma (P7): X+ out-mold i (P8): Max. MZ can (P8): Max. SZ can t	MY 0.00 MZ 0.00 Safe <i>i</i> n. safe area x. safe area min. safe area min. safe area traverse in/out	SY 0.0 SZ 0.0) X Icon	D.00 Alarm WARNING	Reset
SET SET SET SET SET	Safe area -10.00 100.00 800.00 10.00	Semi Ready No-go Area (P5): X in-mold min (P6): X in-mold ma (P7): X+ out-mold ma (P7): X+ out-mold ma (P8): Max. MZ can (P8): Max. SZ can t	MY 0.00 MZ 0.00 Safe <i>i</i> n. safe area x. safe area min. safe area traverse in/out	SY 0.0 SZ 0.0) X Icon	0.00 Alarm WARNING	Reset
SET SET SET SET SET	Safe area -10.00 100.00 800.00 10.00	Semi Ready No-go Area (P5): X in-mold mi (P6): X in-mold ma (P7): X+ out-mold i (P8): Max. MZ can (P8): Max. SZ can f	MY 0.00 MZ 0.00 Safe 4 n. safe area ux. safe area min. safe area min. safe area traverse in/out	SY 0.0 SZ 0.0) X Icon	0.00 Alarm WARNING	Reset





- (P1): When completing open mold, max. location of MY axis inside the mold : when completing open mold, main arm goes down into mold, MY axis goes to the max. coordinate(+), this is P1's MY coordinate.
- (P2): When completing open mold, max. location of SY axis inside the mold : when completing open mold , SZ goes down into mold, SY axis goes to the max. coordinate(-), this is P2's SY coordinate.
- (P3): Open mold middle position, max. location of MY axis inside the mold : this function only valid for open mold middle signal. If there is no this function, you will need to set up the same to MY(P1), When middle position signal was trigged, MZ axis can go down to mold, when MZ goes to mold, MY axis can move to the max. location(+), this is P3's MY coordinate.
- (P4): The height for MZ axis to close mold safely : when MZ axis moves up to setting pocition, the max. down position for mold to close mold.
 - This function will only be valid when [go down in mold standby function], otherwise X axis can only move to P8 when there is no open mold complete signal.
- (P4): The height for SZ axis to close mold safely : when SZ axis moves up to setting pocition, the max. down position for mold to close mold.

This function will only be valid when [go down in mold standby function], otherwise X axis can only move to P8 when there is no open mold complete signal.

- (P5): X axis in the mold's min pick safety location: When completing open mold, vertical axis to go down to mold, the max. location for X axis to move(-)direction.
- (P6): X axis in the mold's max pick safety location : When completing open mold, vertical axis to go into mold, the max. location for X axis to move(+)direction.
- (P7): X axis in (+) direction at safety location outside of mold : the area when vertical axis outside of mold, when vertical axis to go down, the max. location for X axis to move(-)direction.
- (P8): MZ axis to go out safety height : when X axis goes out or in, the max. location that MZ axis will not hit safety door, this value can not be smaller or equal to 0, recommend value to be 10mm~50mm.
- (P8): SZ axis to go out safety height: when X axis goes out or in, the max. location that SZ axis will not hit safety door, this value can not be smaller or equal to 0, recommend value to be 10mm~50mm.

5.7 @Variables

Show mutual variable for main program and sub program.

NG	6) Var	Sen Read	ui Iy	MY 0 MZ 0	.00 SY .00 SZ	0.00 0.00	x	0.00	Alarm	Reset
CIN	2									WARNING	
					0						
	0	1	2	3	4	5	6	7	8	9	_
0	0	0	0	0	0	0	0	0	0	0	
10	0	0	0	0	0	0	0	0	0	0	
20	0	0	0	0	0	0	0	0	0	0	
30	0	0	0	0	0	0	0	0	0	0	
40	0	0	0	0	0	0	0	0	0	0	
50	0	0	0	0	0	0	0	0	0	0	
60	0	0	0	0	0	0	0	0	0	0	₩ ¥
70	0	0	0	0	0	0	0	0	0	0	Y
80	0	0	0	0	0	0	0	0	0	0	
90	0	0	0	0	0 1	0	0	0	0	0	-
	Goto	0									_
<-	172	@ Var	F3 Mac	10	4 Sys Macro						>>



5.8 MACRO

Show MACRO as below.

	Масто	Semi Read y	MY 0.00 MZ 0.00	SY 0.00 SZ 0.00	x	0.00 Alam	1 Report
	Move to MZ=0.0	0				WARNI	NG
Маст	o 1			Command	: MST		
1	IF Rej-parts Signal	OFF GOTO Lab	el 1 📥 🛣	м1	10004		
2	Move to MZ=@52	23					
3	Move to MZ=0.00			M2			
4	Label 1			м3			
5	PROCEDURE RE	TURN	*				
6				s	2		
7				т			
8			• <u> </u>				
Del Line	Cut Copy	Paste 🗖	Single				
- 3	0 % Frank	In Hom Stop A	auto Single	Commar	nd	Add	Replace
<-	e Var	F3 Macro	F4 Sys Macro				>>

Notice

- 1. If you want to edit MACRO, you will need to switch to machine maker level (10~19).
- 2. System offers 100 groups of MACRO to edit.
- 3. MACRO file name can accept $0 \sim 99$, the MACRO here is for teach mode to call.

MACRO command editing description

MACRO editing is the same to teach program command, refer to chapter 5. Teach.



6 Parameter

6.1 General parameter

This is the paramter list for general end-user, you can click setting value column to see keypad to do setting. Detail general parameters, refer to chapter 10.

	Genera	1	Semi Read y	MY 0.00 MZ 0.00) SY) SZ	0.00 0.00	х	0.00	Alarm		Reset	
	Robot mod	e [0: P i	oduction; 1: Te	sting]					WARNING		React	
No.	Set Value	Desci	iption							•		
7999	0	Robo	t mode [0: Produ	action; 1: Testin	g]							
8000.2	0	Main	in-Arm Wrist Gesture to Enter Mold[0:Vertical;1:Horizontal]									
8000.10	0	Main	in-Arm Wrist Gesture at Waiting Positon[0:Vertical;1:Horizontal]									
8004	0	Chec	k drop[0:Check	All;1:Check Ins	ide Mold;	2:Uncheo	:k]				\	
8005	0	Presta	ge (robot waitin	g above mold)	0: Not all	lowed;1:	Allowed]				¥	
8010.1	0	Checl	king Main-Arm	Wrist Gesture 😽	hen it's A	crossing	Out[0:No;1:	Yes]			V	
8010.2	0	Main	Arm Wrist Gest	ure to Across O	ut[0:Verti	cal;1:Hor	izontal]					
8050.2	0	Open	& close safety g	gate to skip faile	d grip/va	cuum ver	ification sign	nals (O): Not allowe	•		
	Goto 0		Mold NO.									
۲-	F2 Gene	eral Language Advance Machine Maintain Network										



6.2 Language

Choose the language you want to use and press OK.

NA	Laguage	Semi Read y	MY 0.00 MZ 0.00	SY 0.0 SZ 0.0	$\begin{bmatrix} 0 \\ 0 \end{bmatrix} \mathbf{x} = 0$	0.00 Alarm	Popot
						WARNIN	G
Used La	nguage						
English(Built-in)						
Langaue	Selected						
Tradition	al Chinese(Built-in))					
Simplifie	d Chinese(Built-in)						
English(Built-in)						
	12						
<-	ОК	-17 -17					



6.3 Common parameter

This is the common parameter for machine makers, if you want to change this value, you will need to change to 10-19 level. You can click setting value column to see keypad to do setting. Detail general parameters, refer to chapter 10.

NA	Сотто	n	Semi Ready	MY 0.00 MZ 0.00) SY) SZ	0.00 0.00	Х	0.00	Alarm		Reset	
CIVE	Permit hon	ing to	origin when arm	ı is down inside	ІММ [0:	Not allow	ed; 1: Allow	red]	WARNING		incont	
No.	Set Value	Descr	iption							•		
8050.0	1	Регті	t homing to orig	in when arm is	down ins	ide IMM [0: Not allow	red; 1	: Allowed]		Ā	
8050.3	0	Cycle	cle start check IMM's auto single[0:check;1:Uncheck]									
8050.4	0	Регті	rmit robot to perform 'HOME' function outside IMM without confirming arm up sen									
8070	10000.00	Retur	n wait position s	peed(mm/Min)							V	
8071	0	Safety	y gate opens in a	uto mode [0:Cl	ose safety	y gate & cl	lick start key	y to co	ontinue auto :		¥	
8072	20	Buzze	er beeping timer	[0 ~ 9999; unit	in second	ds]					V	
8073	5	Warni	ing light on/off t	imer [0 ~ 99; ur	uit in 0.1	second]						
8074	5	Buzze	Buzzer beeping on/off timer [0∼99; unit in 0.1 second]									
	Goto 0	-	Mold NO.									
<-	F2 Comr	non MY Axis MZ Axis SY Axis SZ Axis X Axis										



6.4 Machine parameter

NA	h	lachine	Semi Ready	MY 0. MZ 0.	00 SY 00 SZ	0.00 0.00	X (0.00	Alarm	Reset
								W	ARNING	Readin
	1	MY Motor	Gear Ratio(N)							MY Param
	5	MY Motor	Gear Ratio(D)							MZ Param
5	50.00	MY Pitch(i	nm)						Î	SY Param
	0000	MY Pulse I	Per Revolution							SZ Param
	300	MY RPM o	of Motor 1V				ħ			X Param
									J	PageNo:1/1
<-	F2	General	13 Language	M Advance	F5 Ma	chine	Maintain	F7 Ne	twork	8 Reboot

This is to set up reducer gear ratio and motor parameters.

- 1. **Gear ratio** (**numerator**): Set up gear ratio-numerator, if there is no reducer design, numerator and denominator will be 1, EX : reducer=1 : 5, parameter=1.
- 2. **Gear ratio** (**Denominator**): Set up gear ratio- denominator, if there is no reducer design, numerator and denominator will be 1, EX : reducer=1 : 5, parameter=1.
- 3. Pitch(mm) : Most of the mechanical structure of the robot is through the motor and reducer to drive gear. And gear through the belt to move machine mechanical structure. Distance of gear per 1 revolution = gear diameter X circumference ratio. In order to make this calculation easier, system will time this circumference ratio automatically. Users only need to input gear diameter value.

%. If you use screw to move mechanical structure, not via gear and belt, you will need to input pitch devide circumference ratio.

- 4. **Motor 1 revolution pulse numbers :** Motor corresponding rotation per revolution. The setting should be relevant, then moving distance will be correct.
- 5. **Motor 1 vollabele to rotation speed :** motor's max. rpm is corresponding to 10V, so make this value to devide into 10, this is the value that we are going to set up.



6.5 Maintain

6.5.1 Maintain setting

		Setting	Semi Read y	MY 0.0 MZ 0.0	0 SY 0 SZ	0.00 0.00	х	0.00	Alarm	Reset
(II)									WARNING	
No.			Maintain it	ems			Style	Сус	le 📩	Ā
001	drainin	g water from the	e ari filiter/reguat	or assembly?			Time	0 D		
002	check t	o make sure fu	nctions of the grij	pper and vacuu	m suction	n headwo:	Time	0 D		
003	tighten	connecting scre	ews on the vacuu	m suction head	work(EC)AT)?	Time	0 D		
004	check i	if there is any pa	art on the ROBO	for loosen?			Тіте	0 D		Y
005	check i	if connections b	etween ROBOT a	and I.M.M., and	l betweer	n hand-ho	Тіте	0 D		
006	drainin	g water from the	e air compressor	?			Тіте	0 D		
007	clean a	nd resort appear	rance of the ROE	OT?			Тіте	0 D		
800	clean th	he surface of are	:h				Тіте	0 D		
009	re-lubri	icate bearings o	n the crosswise a	xis?			Time	0 D	•	
	<-	12 Setting	F3 Status	F4 History						

6.5.2 Maintain status

		Status	Semi Ready	MY 0.00 MZ 0.00	SY 0.00 SZ 0.00	x	0.00	Alarm	Reset
G	V						WA	RNING	
No.			Maintain it	ешз		Remaining	Next tin	ie	Ā
001	drai	ning water from the	e ari filiter/reguat	or assembly?		3D	2012/03/1	6	
002	che	ck to make sure fur	nctions of the grij	pper and vacuum	suction headwo	5D	2012/03/1	8	X
									Ĭ.▼
									Date
				k					Z01203/13
									991
									Complete
	<-	F2 Setting	ES Status	History					



6.5.3 Maintain history

	Histor y	Semi Read y	MY 0.00 MZ 0.00	SY 0.0 SZ 0.0	X0 _ : X0 _ :	x 0	.00	Alarm	Reset
								WARNING	
Date			1	ïme					<u> </u>
2012-03-13 20:25:21	No.002 che e normal?	ck to make sure	functions of the	gripper and vac	:uum :	suction hea	dwo	rk(EOAT) ar	
2012-03-13 20:25:21	No.002 che	ck to make sure	functions of the	gripper and vac	uum :	suction hea	dwo	rk(EOAT) ar	
2012-03-13 20:25:20	No.002 che	ck to make sure	functions of the	gripper and vac	uum :	suction hea	d₩o	rk(EOAT) ar	
2012-03-13 20:25:16	No.001 drai	ning water from	the ari filiter/reg	uator assembly	?				*
2012-03-13 20:25:16	No.001 drai	ning water from	the ari filiter/reg	uator assembly	?				V
2012-03-13 20:25:15	No.001 drai	ning water from	the ari filiter/reg	uator assembly	?				
2012-03-13 20:25:15	No.001 drai	ning water from	the ari filiter/reg	uator assembly	?				-
۲-	F2 Setting	F3 Status	14 History						



6.6 Network

How to set robot net address.

	Network	Semi Ready	MY MZ	0.00 0.00	SY SZ	0.00 0.00	X C	0.00	Alarm	Reset
	Address_1[0~	255]							WARNING	- Acada
Local IP Ad	idress									
IP Address		192	168 .	7		20				
Sub-mask		255 .	255 .	255].[0				
Gateway		192 .	168 .	7		254				
					I	+				
<-	F2 General	F3 Languag	e F4 Adv	ance	5 Ma	chine III	Maintain	F7 1	Jetwork	8 Reboot



7 System

7.1 About

Show robot relating information.

NA	About	Semi Read y	MY 0.00 MZ 0.00	SY 0.0 SZ 0.0	0 0 X	c 0.0	0 Alarm	Popot
							WARNING	Kesei
Mfr. Date		2011	EX:2008/01/01				Dote	
						Year	Month	Day
Model						2012	03	13
Mfr. No.						,	,	,
Version		02.01.45					Time	
version		05.01.45				Н	M	Sec
CBU Clock	2	577 A94 MU2				20	25	51
	2	JZ7.404 MIIZ				1	1	
RAM		249.137 MB	k					
CD Card	e Virtual II	DE Hard Drive						
<-	About	13 Info.	14 Ladder	rS — R Value —	F6 Pai	rameter	I/O Map	>>



7.2 System info

Show system relaing info page.

NA	Info.		Semi Ready	MY MZ	0.00 0.00	SY SZ	0.00 0.00	X 0	.00	Alarm	Repot
									w	ARNING	
Machine H	'os.										
MY	-200000	MZ 🛛	0	SY		0	sz		0 X		0
Servo lag(Pulse)										
му	0	MZ 🛛	0	SY		0	sz		0 X		0
Vcmd lag	(Pulse)										
мү	0	mz [0	SY		0	sz		0 X		0
Encoder(P	ulse)										
MY	-63662	mz [0	SY		0	sz		0 X		0
Zero Point	Grid Data(%))									
MY	0	mz [0	SY		0	sz		0 X		0
Interrupt		1									
	32021			k							
<-	P2 Abou	ıt	F3 Info.	14 Ladde	эт 	5 R Valu	e	6 Parameter	7 1/0	Мар	>>

- 1. Machine coordinate : Show current location machine coordinate, unit=um.
- 2. Servo lag(Pluse) : Sending out movement command and exact feedback difference.
- 3. Vcmd servo lag(Pluse) : Sending out movement command and exact feedback difference. When motor use vollabele command, servo lag should refer to this column.
- 4. Encoder value: Current position's corresponding encoder value. This value is encoder's feedback value. Machine zero's encoder value should be 0.(only has small difference) When robot moves, encoder's value will change together. If you want to verify the accuracy of the machine, you can move back and forth to check if the encoder value are the same.
- 5. Return home grid position(%) : The percentabele between the distance of Home dog signal trigger location to motor Z axis signal and the distance of 1 motor revolution.



7.3 Ladder





7.4 R bit

Show system register value.

NG	R	Register	Sen Read	ni Iy	MY (MZ (0.00 0.00	SY SZ	0.00 0.00	х	0.00	Alarm	Res	et
CIVC	1										WARNING	-105	
					R Regi	ster							
	0	1	2	3	4	5		6	7	8	9		
0	0	0	0	0	0	0		0	1	0	0		_
10	0	0	0	0	0	0		0	0	0	0		
20	0	0	0	0	0	0		0	0	0	0		
30	2	0	0	0	0	0		0	0	0	0		
40	0	0	0	0	0	0		0	0	0	0		
50	0	0	0	0	0	0		0	0	0	0		
60	0	0	0	0	0	0		0	0	0	0		7
70	0	0	0	0	0	0		0	0	0	0		7
80	0	0	0	0	0	0		0	0	0	0		
90	0	0	0	0	0	0		0	0	0	0	-	
Goto 0													
<-	12	About	F3 Info	э.	M Ladder		5 R V	alue) Parame	eter I	/O Map	>>	

7.5 System parameter

	Hardware	Semi Ready	MY 0.00 MZ 0.00	SY 0. SZ 0.	.00 X	0.00	Alarm	Reset			
						W	ARNING	Keser			
No.	Set Value	Description						-			
[©] 40054.5	0	5th EPCIO Motion	Card Local I/O	Гуре(21~24)(():I,1:O)						
[©] 40054.6	0	5th EPCIO Motion	ith EPCIO Motion Card Local I/O Type(25~28)(0:1,1:0)								
[©] 40055.0	0	6th EPCIO Motion	th EPCIO Motion Card Local I/O Type(1~4)(0:1,1:0)								
[©] 40055.1	0	6th EPCIO Motion	th EPCIO Motion Card Local I/O Type(5-8)(0:1,1:0)								
[©] 40055.2	0	6th EPCIO Motion	Card Local I/O	Гуре(9~12)(0:	I,1:0)						
	0		a-111 <i>1</i> 0	r - (12 16) <i>4</i>	1 10						
40055.3	U	OIL EPCIO MOUOL	Cald Local I/U	Type(15~10)(():1,1:0)			V			
[©] 40055.4	0	6th EPCIO Motion	Card Local I/O	Гуре(17~20)(():I,1:O)			Y			
[©] 40055.5	0	6th EPCIO Motion	6th EPCIO Motion Card Local I/O Type(21~2))(0:1,1:0)								
[©] 40055.6	0	6th EPCIO Motion	Card Local I/O	Гуре(25~28)(():I,1:O)		-	▼			
Goto 48080											
<-	F2 Hardwar	re Path	14 Axis	F5 HMI	F6 Defaul	t All	Def.				



7.6 I/O Map

7.6.1 DI Map

Set up exact input and software input corresponding relationship.

N	6	DIN	Map	Semi Ready		MY MZ	0.00 0.00	SY SZ	0.00 0.00	х	0.00	Alarm	Reset
GN	V	2										WARNING	
DI No.	,	CardType	CardNo.	CardSet	Offs	et	Reverse	Descript	ion				_
0	٥	0	0	0	16		False						
1	۲	-1	0	0	0		False						$\overline{\mathbf{A}}$
2	0	-1	0	0	0		False						
3	0	-1	0	0	18		False						
4	٥	-1	0	0	0		Тгие						
5	۲	-1	0	0	24		Тгие						*
6	0	0	0	0	5		Тпие	MY-Ha	ıdware Li	mit			V
7	0	0	0	0	6		Тпие	MY+Ha	ardware L	imit			
8	0	0	0	0	106		Тгие	MZ- Hai	ıdware Li	mit			
9	0	0	0	0	9		Тпие	MZ+Ha	ıdware Li	imit			
10	0	0	0	0	110		Тгие	SY-Han	dware Lir	nit			-
		F2		F3	1	F4				•	1	1	
<	<-	D	I Map	DO Ma	р	,	Apply						



7.6.2 DO Map

Ν	0	DOI	Map	Semi Ready		MY MZ	0.00 0.00	SY SZ	0. 0.	.00 x 0.00	Alarm	Reset
GN	V										WARNING	
DO No).	CardType	CardNo.	CardSet	Offse	t	Reverse	Force	State	Description		
0	•	0	0	0	0		False	False	False	M-arm Horizontal		
1	0	0	0	0	5		False	False	False	M-arm Vertical		$\overline{\mathbf{A}}$
2	0	-1	0	0	1		False	False	False	S-arm Horizontal		
3	0	-1	0	0	4		False	False	False	S-arm Vertical		
4	0	-1	0	0	4		False	False	False			
5	0	-1	0	0	5		False	False	False			*
6	0	-1	0	0	6		False	False	False			X
7	0	-1	0	0	7		False	False	False			
8	•	-1	0	0	2		False	False	False			
9	0	-1	0	0	3		False	False	False			
10	0	0	0	0	1		False	False	False	Gripper 1		
		12	ſ	F3	l IF	4						
<	<-	D	I Map	DO Ma	р	1	Apply					

Set up exact output and software output corresponding relationship

7.6.3 DI Map DO Map setting

If you want to modify DI Map and DO Map, you need to have machine maker level or even bigger than this. (10~19)

DI DO mutual columns :

CardType : Show motion card type, current setting is 0, if -1=not in use.

CardNo : Show EPCIO card number, current setting is 0.

CardSet : 1=Local IO ; 0=Remote IO, current robot did not use Local IO, therefore setting=0.

Offset : I/O to hardware location, connect EIO2000 to RIO1-15Pin HD-SUB female(robot project).Offset=0~191.

Reverse : True=make reverse of the signal or output. 0 : False ; 1 : True ${\scriptstyle \circ}$

DO description :

Force : Whether to enforce the O point output, 0 : False ; 1 : True ${\scriptstyle \circ}$

State : O point output status, 0 : False (OFF); 1 : True (ON) •

Offset description :

EIO2000 to RIO1 HD 15Pin D-SUB female, Offset is from 0. One set of EIO2000 can connect with 3 I/O card, 1

I/O has 20IN/16OUT, maximum is 3 cards, 60IN/48OUT. But here one EIO2000 need to be 64IN/64OUT, so the second EIO2000 IO card offset is from 64, third EIO2000 Offset is from 128.

One set of EIO2000 can connect with 3 I/O card, 1 I/O has 20IN/16OUT, maximum is 3 cards, 60IN/48OUT. But

here one EIO2000 need to be 64IN/64OUT, so the second EIO2000 IO offset is from 256, the third EIO2000 Offset is from 320.

Motion card EIO2000		REL to	Offset					
position	Switch setting	EIO2000	I	0				
		I/O P1	0~19	0~15				
	S1 ON	I/O P2	20~39	16~31				
		I/O P3	40~59	32~47				
		I/O P1	64~83	64~79				
RIO1	S2 ON	I/O P2	84~103	80~95				
		I/O P3	104~123	96~111				
		I/O P1	128~147	128~143				
	S3 ON	I/O P2	148~167	144~159				
		I/O P3	168~187	160~175				
		I/O P1	192~211	192~207				
	S1 ON	I/O P2	212~231	208~223				
		I/O P3	232~251	224~239				
		I/O P1	256~275	256~271				
RIO2	S2 ON	I/O P2	276~295	272~287				
		I/O P3	296~315	288~303				
		I/O P1	320~339	320~335				
	S3 ON	I/O P2	340~359	336~351				
		I/O P3	360~379	352~367				



7.7 Backup

Run this function to do backup or restore machine paramter.

7.7.1 Parameter backup

Notice :

- 1. We recommend you to backup parameter files before using the controller, in case you want to restore to the default status.
- 2. Currenly only support 4GB and below USB drive.
- 3. After backup, backup file will be saved at the backup directory.
- 4. There will have machine and ncfiles under this directory of backup, but sub program will be save outside of ncfiles, other files will all be saved under machine directory.
- 5. Backup directory tree as shown below.



Operation:

1. Go to [SYSTEM], press [BACKUP] to see below.

NA	Backup	Semi Ready	MY 0.00 MZ 0.00	SY SZ	0.00	x 0.0	00 Alarm	Reset
CINC							WARNING	1000
1. Sele	ect : Input or	Output						
L P	put from USB		Γ	Output to	USB			
Select			Item	l				$\overline{\mathbf{A}}$
			k					
								\
								0%
	17	13	14	F 5	FG		7	0.70
<-	Select	Unselect	All Sel.	All Unsel.		Trans.	Abort	>>

2. Insert USB to controller.

3. Click [output to USB], if controller can not read this USB, there will be a message to show the USB insert fail. That means controller did not accept this model's USB; If the loading is success, you will see details as below.



- 4. Select the file you want to backup, use F2~F5 or choose directly on the page, the file that you chose will be download. You can click again to cancel selection.
- After selection, press [F6 to start downloading]. If you want to cancel the downloading, you can press [F7 cancel downloading]. We recommand you not to do this while downloading in order to ensure the integrity of the backup data.
- 6. If there is previous backup file in this USB, system will ask if you want to rewrite current file, we recommend you to press [yes to all] to make the integrity of the backup data.



	Backup	Semi Ready	MY 0.0 MZ 0.0	0 SY 0 0 SZ 0	.00 X	0.00 Alarm	Repot
						WARNING	
1. Sel	ect : Input or	Output					
	nput from USB		1	Output to U	ISB		
2. Sel	ect : Output t	o USB					
Select				FIRM			<u>^</u>
N	Macro Program (n ro1041.str))1000.str~mac	
R	IO Map (aiomap.ii		Are you sure ?	(тасто000.тас	:)		
R	System Parameter aram_mot.dat;plc_		Old File:2012-()3-10 21:16:1(03 10 16:24:3)	aram_int.dat;p	
₹	Ladder (cnc.lcod; _1041.str)		NCW FIICZOIZ-	05-10 1024.5	2	0.str~cnc_plc	
R	Operator Layer (u	Yes Y	es(ALL)	No No(A	LL) CANCEL		
R	Machine Information	лителнизени) ис	IJ.				
							_
							0 %
<-	F2 Select	13 Unselect	14 — All Sel. —	ES All Unsel.	F6 Trans.	F7 Abort	>>

7.7.2 Parameter restore

Notice :

- 1. After the modification results in the machine parameter error, you can restore previous parameter backup to return to default setting.
- 2. Currenly only support 4GB and below USB drive.
- 3. Before running parameter restore, you should put backup file to backup directory of USB.
- 4. There will have machine and ncfiles under this directory of backup, but sub program will be save outside of ncfiles, other files will all be saved under machine directory
- 5. Backup directory tree as shown below.




Operation :

1. Go to [SYSTEM] , press [BACKUP] to see below

	Backup	Semi Read y	MY 0.0 MZ 0.0	0 SY (0 SZ (0.00 X	A 00.0	larm Reset
1. Sel	ect : Input or	Output	-			WA	RNING
	nput from USB			Output to	JSB		
Select			Iter	D			- -
Г	Macro Program (m ro1041.str)	асто000.mac~п	асто099.mac;ш	acro0000.str~i	nacro0002.str	;macro1000.st	г~пас
	IO Map (aiomap.in	i;iomap.ini)					
	System Parameter aram_mot.dat;plc_	(param_define.t save.dat;recon.d	xt;param_op.dat lat;coord.dat)	;param_hwif.d	at;param_hmi	.dat;param_in	t.dat;p
Г	Ladder (cnc.lcod;c _1041.str)	nc.lmlc;cnc.lpar	;cnc_plc_0000.	str~cnc_plc_0)02.str;cnc_pl	c_1000.str~cn	
	Operator Layer (us	er.bin)					
	Machine Informati	on (machine.inf	0)				
	1	1	4	1	1	1	0%
<-	F2 Select	F3 Unselect	F4 All Sel.	All Unsel.	Po Trans.	Abo	nt >>



- 2. Insert USB to controller.
- 3. Click [input from USB], if controller can not read this USB, there will be a message to show the USB insert fail. That means controller did not accept this model's USB; If the loading is success, you will see details as below.

	Backup	Semi Ready	MY MZ	0.00 0.00	SY SZ	0.00 0.00	х	0.00	Alarm	Reset
									WARNING	React
1	ool - Tupal or	8.tp								
	nput from USB		_		Outpu	it to USB				
2. Sel	ect : Input fr	om USB		* .						•
Select				ltem						
П	Macro Program (m ro1041.str)	асто000.mac~m	асто099.	шас;шао	ло0000).str~macro	00002.st	tr;macro10	00.str~mac	
П	IO Map (aiomap.ir	i;iomap.ini)								
Г	System Parameter aram_mot.dat;plc_	(param_define.tz save.dat;recon.d	rt;param_ at;coord.	op.dat;p dat)	aram_h	wif.dat;pa	ram_hn	ni.dat;parar	m_int.dat;p	V
Г	Ladder (cnc.lcod;c _1041.str)	nc.lmlc;cnc.lpar	;cnc_plc_	_0000.sti	~cnc_p	olc_0002.s	tr;cnc_p	lc_1000.st	tr~cnc_plc	
П	Operator Layer (us	er.bin)								
Г	Machine Informati	on (machine.inf	o)							- I
			•							_
										0%
<-	12	F3	F4		5	FC	T	17	41	>>



- 4. Select the file you want to upload, use F2~F5 or choose directly on the page, the file that you chose will be upload. You can click again to cancel selection. •
- After selection, press [F6 to start uploading]. If you want to cancel the uploading, you can press [F7 cancel uploading]. We recommand you not to do this while uploading in order to ensure the integrity of the backup data.
- 6. If there is previous backup file in this controller, system will ask if you want to rewrite old file, we recommend you to press [yes to all] to make the integrity of the backup data.

NA	Backup	Semi Read y	MY 0.00 MZ 0.00	0 SY 0 0 SZ 0	0.00 X	0.00	Alarm	Reset
							WARNING	
1. Sele	ect : Input or	Output						
₩ 1	nput from USB		1	Output to U	JSB			
2. Sele	ect : Input fro	on USB						
Select				FIRM				
R	Macro Program (n ro1041.str)			(000	、 、	>1()00.str~mac	
R	IO Map (aiomap.i		Ale you sule ?	(macrouulmae	c)			
₩	System Parameter aram_mot.dat;plc_		Old File:2012-(New File:2012-	03-10 16:24:3 03-10 21:16:1	9	ыа	m_int.dat;p	V
R.	Ladder (cnc.lcod; _1041.str)					0.s	tr~cnc_plc	V
R.	Operator Layer (u	Yes Y	'es(ALL)	No No(A	LL) CANCI	iL.		
R	Machine Information	лициасниения	<i>n</i>			1		▼ ▼
				•				0%
	F2	F3	F4	F5	F6	F7		
<-	Select	Unselect	All Sel.	All Unsel.	Trans.		Abort	>>



7.8 Upgrade

You may need to have upgrade when the current operating system has error or this system has new software functions.

Notice :

- 1. Currenly only support 4GB and below USB drive.
- 2. Save the new upgrade file from system provider into USB setup directory, such as below.





Operation :

1. Go to [SYSTEM] , press [UPGRADE] to see below.

	Upgrade	Semi Ready	MY 0. MZ 0.	00 SY 00 SZ	0.00 0.00 X	0.00	Alarm	Popot
						WA	RNING	KCOCI
1. Confir	m Device							
Pls Cli	ck OK after US	B is plugged-in.						
2. Confir	m Upgrade V	ersion						
3. Copy F	ile							
			I	t				0%
4. Restar	t							
<-	Р2 — ОК —	F3 Cancel						

- 2. Insert the USB with upgrade file into controller.
- 3. Press [F2 OK], if controller can not read this USB, there will be a message to show the USB insert fail. If the loading is ok, system will show upgrade file version number, you can check if the version number is correct before loading.



	Upgrade	Semi Ready	MY 0.00 MZ 0.00	SY 0.0 SZ 0.0	0 X	0.00	Alarm	Poset
							WARNING	KCoCI
1. Conf	irm Device							
Pls	Click OK after US	B is plugged-in.						
2. Conf	irm Upgrade V	ersion						
Std	_03.01.45							
3. Copy	File							
								0 %
4. Rest	art							
		,						
		k						
<-	T2 OK	13 Cancel						

4. After confirming, press [F2 OK], system will copy the upgrade file into controller data buffer area. After copy,

you will need to press EMG button first and reboot the system.

	Upgrade	Semi Read y	MY 0.00 MZ 0.00	SY SZ	0.00 X	0.00	Alarm	Peset
							WARNING	React
1. Confir	m Device							
Pls Cli	ick OK after USE	is plugged-in.						
2. Confir	n Upgrade Ve	ension						
Std_0	3.01.45							
3. Copy F	ile							
			h					100 %
4. Restar Click	rt OK to Restart &I	install New Versi	io					
<-	Г2 — ОК	73 Cancel						

- 5. You will need to reboot after upgrading, then the upgrade is complete.
- 6. While upgrading, you can press [F3 cancek] to cancel before rebooting.



7.9 Operator authority

Set up authority for different users with different operation functions. Level 13 users can see level 13~29 and 99 operation page, but can not see higher level 12 page.

NG		perator	Semi Ready	MY 0.00 MZ 0.00	SY 0.0 SZ 0.0	0 x 0	0.00 Alarm	Reset
CIVC	1						WARNING	
			C	urrent User 1				
NO.	Limit	Page Nam	e					
1	99	Ноте						
2	99	Action						Ā
3	99	Teach Mo	de					
4	99	Infomation	1					
5	99	Parameter						•
6	99	Upgrade						
7	99	FileManag	(e			•		
8	99	Transfer				•		
9	99	Stack						•
<-	12	Backup	F3 Upgrade	14 Operator	15 1/0	Password	77 TP Cali	>>



7.10 I/O

Show current system I ${\scriptstyle \cdot}$ O ${\scriptstyle \cdot}$ C ${\scriptstyle \cdot}$ S ${\scriptstyle \cdot}$ A status.

				ю			Sem Read	i y	M M	Y Z	0.00 0.00	SY SZ	, ,	0.0 0.0	0	X		0.00	Al	arm		Rese	
9	11	2																	WAR	NIN	G	11000	
					I	Bits											С	Bits					
	0	1	2	3	4	5	6	7	8	9	•		0	1	2	3	4	5	6	7	8	9	
0	0	0	0	0	0	0	1	1	1	1		0	0	0	0	0	0	0	0	0	0	0	
10	1	1	1	1	1	1	0	0	1	1		10	0	0	0	0	0	0	0	0	0	0	
20	0	0	0	0	1	0	0	0	0	0		20	0	0	0	0	0	0	0	0	0	0	
30	0	1	0	0	0	0	0	0	0	0		30	0	0	0	0	0	0	0	0	0	0	•
40	0	0	0	0	0	0	0	0	0	0							S	Bits					
50	0	0	0	0	0	0	0	0	0	0			0	1	2	3	4	5	6	7	8	9	
60	1	1	0	1	0	0	0	0	0	0		0	0	0	0	0	0	0	0	0	0	0	
-					0	Bits						10	0	0	0	0	0	0	0	0	0	0	
	0	1	2	3	4	5	6	7	8	9		20	0	0	0	0	0	0	0	0	0	0	
0	0	1	0	0	0	0	0	0	0	0		30	0	0	0	0	0	0	0	0	0	0	-
10	0	0	0	0	0	0	0	0	0	0							A	Bits					
20	0	0	0	0	0	0	0	0	0	0	R		0	1	2	3	4	5	6	7	8	9	
30	0	0	0	0	0	0	0	0	0	0		0	1	0	0	0	0	0	0	0	0	0	
40	0	0	1	1	1	1	1	0	0	0		10	0	0	0	0	0	0	0	0	0	0	
50	0	0	0	0	0	0	0	0	0	0		20	0	0	0	0	1	0	0	0	0	0	
60	1	1	1	1	٥	1	٥	Δ	Λ	٥	•	30	Λ	٥	۵	Δ	Δ	Λ	٥	Λ	۵	Δ	-
	<-		F2	Back	up	F3	Ирдта	de	F4	Орега	tor	F5	ı/O		F6 P	asswe	ord	17	TP Ca	li		>>	



7.11 Change password

Notice :

Here you can only change current user's password. If you want to change user user level, refer to user change chapter.

Description :

Go to [MAINTAIN], press [PASSWORD] to see below.

NA	Password	Semi Ready	MY 0.0 MZ 0.0	0 SY 0 SZ	0.00 0.00	х	0.0	0 Alarm	Reset
								WARNING	-
		C	Current User	1					_
		U	ser		1				
		Passwo	rd						
		New passwo	ord						
		Password confi	m						
		192		OK	k				
<-	Backup	Upgrade	Operator	V	0	Pass	word	TP Cali	>>

- 1. Here can only show current user level, you can not do any change here.
- Then input current password, new password and confirm again new passwordd. Password will be shown as
 *.





- 3. Password must be your current one.
- 4. New password and confirm password should be the same. If there are different, the setting will be fail.



7.12 Monitor tuning

When monitor touching is not precise, you can use this function to do tuning.

1. This function only support to system provider, press monitor tuning to continue.

NA	TP Cali	Semi Ready	MY 0.00 MZ 0.00	SY 0.0 SZ 0.0	0 x ().00 Alarm	Reset
						WARNING	5
			Calibrate Te	ouch panel			
						k	
<-	F2	F3	F4	F5	16	F7	>>
	Backup	Upgrade	Operator	I/O	Password	TP Cali	

2. Press Reset, and power off to reboot.



	rencal version 1.02		X
•			
		•	
Pleas	e touch the red point		
	p		
•			
•			
	Ś	• [<u>R</u> eset

3. After rebooting, if the touch is still not precise, you can go to tuning page to retune again. At this time, you can use tough pen to touch the little red point, after touch these 4 points in order, power off and reboot again.



8 Alarm record

8.1 Alarm

Show current alarm content.

	Alarm	Mar Rea	nual Id y	MY MZ	200.00 0.00	SY SZ	0.00 0.00	Х	0.00	Alarm	Reset
										WARNING	rtaci
No	Time		Comme	ent							
110001	2012-03-13 20:35:26	5	M-Arm	ι C+ ₩	ait Time O	venun					Ā
							Ņ	t			
											V
											V
											\mathbf{X}
<-	52 Alarm	13 War	ning	F4 Hi	stor y	5 OP Hi	story				



8.2 Warning

Show current warning content.





8.3 Alarm/warning history

Show record of alarm and warning.

	History	Manua Ready	MY 200.00 SY 0.00 X 0.00 Alarm	Reset
			WARNING	nooti
		Date	Comment	▲
WARNING	120000 PLC	2012-03-13 20:36:57	EMG Button is Triggered test	Ā
WARNING	120000 PLC	2012-03-13 20:36:55	EMG Button is Triggered test	
WARNING	120000 PLC	2012-03-13 20:36:51	EMG Button is Triggered test	
WARNING	120000 PLC	2012-03-13 20:36:17	EMG Button is Triggered test	*
Alarm	110001 PLC	2012-03-13 20:35:26	M-Arm C+ Wait Time Overrun	V
Alarm	110010 PLC	2012-03-13 20:33:55	Both main arm wrist vertical signal and main arm wrist horizontal sig	
Alarm	110010 PLC	2012-03-13 20:20:38	Both main arm wrist vertical signal and main arm wrist horizontal sig	-
<- R2 B - Alarm Warning			g History OP History	



8.4 Operation history

Show operator's total record.

OP History		Manual Read y	MY 200.00 MZ 0.00	SY 0.0 SZ 0.0	0 x (0.00 Alarm	Reset
						WARNING	
Date		Time					
2012-03-13 20:36:15	DI Map DI22:CardSet 18->108						
2012-03-13 20:36:10	Current Use	Current User 99->10					
2012-03-13 20:35:22	Mode Hom	Mode Home->Manual					
2012-03-13 20:33:52	Enter the system, Software Version:03.01.45						*
2012-03-13 20:33:52	Status Error->Ready						
2012-03-13 20:33:52	Mode Ready->Home						
2012-03-13 20:33:15	TP Cali Calibrate Touch panel End						•
<-	F2 Alarm	13 Warning	F4 History	r5 OP History			



9 Switch users

- 1. If end-user wants to edit program, he needs to change level to 20~29.
- 2. If machine maker wants to do maintenance, he needs to change to 10~19.
- 3. User 99 can only open file and do processing.
- 4. Default level is 99.
- Every users can have his own password, password setting method refer to MANTAIN>CHANGE PASSWORD chatper.

	User	Manual Read y	MY 200.00 MZ 0.00) SY 0.0) SZ 0.0	0 X	0.00	Alarm	Reset
							WARNING	- Aller
		C	urrent User	10				
		U	ser	10				
		Passwor	d					
				ОК				
FI Home	Manual	F3 Auto	F4 Teach	Parameter	F6 Maintain	F7 *	Alarm	8 User

Level should be as below

User 0~9 : System provider

User 10~19 : Machine maker, default password=1111.

User 20~29 : End-user, but can edit program file, default password=2222.

User 99 : can only open file and do processing, no need to use password here, only need to input user and press OK.



10 Parameter

10.1 General parameter

Parameter 7999 running mode[0:General;1:trial]

Range : 0~1 ·

0 ∶ under auto mode, open mold should have OFF→ON signal, then arm will go down to pick goods.

1 : under auto mode, open mold only have ON signal, then arm will go down to pick goods. This is for tuning mode.

Tuning mode as below :

- a. Open mold only have ON signal, robot can run, no need to have upper side trigger.
- b. Ignore I/Ostep delay time.
- c. When system reboot or return home, this parameter will return to 0.

Parameter 8000.2 the main arm posture when going into mold[0:vertical;1:horizontal]

Range : 0~1 $_{\circ}$

Check if the posture is not corresponding to setting when going into mold, trigger alarm.

- 0: The posture to go into mold should be vertical.
- 1 : The posture to go into mold should be horizontal.

Parameter 8000.10 main arm posture when standby[0:vertical;1:horizontal]

- a. The rotating posture when main arm return to standby point.
- b. If posture is not the same with parameter, stop processing.

Parameter 8004 parts drop check while moving [0:check for whole travel;1:check in mold 2:not check]

Range : $0 \sim 2 \circ$

Check timing for drop parts while picking goods with vacuumer/gripper.

- 0 (Check for whole travel) : continue checking when picking to placing.
- 1 (Check in mold): only chek while X axis in mold area.
- 2 (Not check): do no check if goods drop.

Parameter 8005 standby vertically[0:N/A;1:Yes]

If vertical stanby.

0 : N/A

Main arm : limit location is the max. distance to go down in mold $\[\[(P8): MZ axis to go in/out safety height]\]$ Sub arm : limit location is the max. distance to go down in mold $\[\[(P8): SZ axis to go in/out safety height]\]$

1 : Yes

Main arm : limit location is the max. distance to go down in mold $\[\[P4) \]$: the height of MZ axis to close mold safely $\[\]$ Sub arm : limit location is the max. distance to go down in mold $\[\[P4) \]$: the height of SZ axis to close mold safely $\[\]$

Parameter 8010.1 check main arm posture when going out [0:Not check;1:check]

Range ∶0~1 ∘

In order to check the program, you can set up parameter to check if moving posture correct or not while X axis in mold.

0: do not check •



1 : check if correct, refer to parameter 8010.2 to see posture setting(vertical, horizontal).

Parameter 8010.2 check main arm posture when going out [0:vertical;1:horizontal]

Range : 0~1 •

Check if moving posture correct or not while X axis in mold. This only valid when parameter 8010.1=1

- 0:vertical
- 1 : horizontal

Parameter 8050.2 safety door status when vacuumer/gripper takes fail[0:N/A;1:close door and continue]

When vacuumer/gripper takes fail, it will trigger warning and stop machine. Under general situation, users need to press [cycle start] to run again. In order to speed up processing, users can close safety door one time, this action is equivalent to pressing the[cycle start] button.

Parameter 8050.6 middle plate[0:Yes;1:N/A]

a. When machine do not use middle plate function, make parameter to be $\[\] 1 : N/A_{\]}$

b. When using middle plate function, check below info and run.

- If wiring correct.
- If DI Map setting correct.

Parameter 20001.2 not using robot[0:N;1:Y]

Range :0~1. If output not using robot signal. 0:N 1 :Y

Parameter 48401 monitor sleep time setting[unit:minute]

Range $: 0 \sim 999 \circ$ When monitor is not under operation, go to sleep mode. 0: N/A $1 \sim 999: delay time setting$

10.2 Common parameter → Mutual parameter

Parameter 8050.0 in mold, Z axis in mold to return to standby point[0:N/A;1:Yes]

Range : $0 \sim 1$

Return standby point function is easy, but when robot is going down in mold, it has risk to scratch mold, so default setting is that you can not return to standby. You need to move the robot arm to certain safe height and then return stanby point.

Below is the order to return standby point :

Arm location

- In mold : pull axis→vertical axis→turning→horizonal axis.
- No in mold : vertical axis → turning → pull axis → horizonal axis.

Parameter 8050.3 run and check injection molding machine auto signal [0:check;1:not check]

If you run auto mode, you will need to check injection molding machine auto signal.



Parameter 8050.3 run and check injection molding machine auto signal [0:check;1:not check]

Range : $0 \sim 1 \circ$

This function is to set up the check system for injection molding machine auto signal and then robot to run auto mode .

machine did not have auto signal, set up parameter= 1 : Not check.

- 0 : need to check
- 1 : no need to check

Parameter 8050.4 out of mold, if z axis did not go to up limit, can not return to standby[0:N/A; 1:Yes]

Range : $0 \sim 1 \circ$

Return standby point function is easy, but when robot is at safe area out of moldwhen robot goes down to pick goods, it has risk to collide with other parts, so default setting is that you can not return to standby. You need to move the robot arm to certain safe height and then return stanby point, set up parameter to be 1 : Yes Below is the order to return standby point :

Arm location

- In mold : pull axis → vertical axis → turning → horizonal axis
- Not in mold : vertical axis → turning→ pull axis → horizonal axis

Parameter 8070 return standby point speed [unit:mm/Min]

Range : 10~50000 •

Press [return standby], the speed for every axis to go to this point.

Parameter 8071 safe door status in auto mod[0:door close, press cycle start to continue;1:door close and continue working;2:stop immediately]

Range : $0 \sim 2$

Under auto mode, open safety door, robot will ...

0 : door close, press cycle start to continue \rightarrow when opening safe door, alarm will stop immediately, when close the door, you will need to press cyclestart to continue the next movement.

1 : door close and continue working → when opening safe door, alarm will stop immediately. But when closing safety door, robot will continue to move later movement.

2 : Stop immediately → when open safety door, alarm will stop immediately (the same to reset button), you will need to return robot to stanbypoint and repress cyclestart button to continue.

% If there is customers who want to cancel this safety door function, you will need to emphasize the risk, if the customer does not accept this, please recommend customer to short connect the safety door signal.

Parameter 8072 buzzer ring time[0~9999,unit:second]

Range : 0~9999

If you think the buzzer is too noisy, you can set up the time for buzzer to shut down.

0: buzzer continued to do output, do not have auto shut down function.

Not 0 : for how many seconds, buzzer to shut down, until next alarm to ring.

Parameter 8073 alarm light flash interval time [0~99, unit : 0.1second]

Range : $0 \sim 99$

The setting of alarm light flash interval time.

0 : always on, if the alarm light has flash function, set up parameter=0.

Not 0 : for how many seconds, light to shut down or turn on period.



Parameter 8074 buzzer flash interval time [0~99 , unit : 0.1second]

Range : $0 \sim 99$

The setting of buzzer to ring on and off interval time.

0: always on, if the buzzer has on and off funtion, set up parameter=0.

Not 0 : for how many seconds, buzzer to shut down or turn on period.

Parameter 9001.0 axis movement safety switch check setting [0:Not check;1:check]

Range : $0 \sim 1 \circ$

When moveing axis manually, if need to check right side safety switch on teach pandent.

0: Not check •

1 :Check ∘

Parameter 9001.1 general O point safety switch check setting[0:Not check;1:check]

Range : 0~1 •

When manual output or close robot air cylinder, if need to check right side safety switch on teach pandent. Air cylinder movement has vertical, horizontal, sub-arm.

0: Not check •

1 : Check \circ

Parameter 9001.2 vacuumer/gripper O point safety switch check setting[0:Not check;1:check]

Range : 0~1 °

When manual output or close vacuumer or gripper, if need to check right side safety switch on teach pandent.

0: Not check •

1 : Check \circ

Parameter 9001.3 peripheral devices O point safety switch check setting[0:Not check;1:check]

Range : $0 \sim 1 \circ$

When manual output or close peripheral devices, if need to check right side safety switch on teach pandent

0: Not check •

1 : Check ${\scriptstyle \circ}$

Parameter 9001.4 run/stop safety switch check setting [0:Not check;1:check]

Range : 0~1 ·

When teach or auto mode run or stop, if need to check right side safety switch on teach pandent

0: Not check •

1 : Check \circ

Parameter 9030 robot I/O alarm delay time[unnit:minute]

Range : 0~9.9 \circ

When output vertical/horizonal/robot air cylinder movement, the corresponding input arrive signal did not trigger, system will send alarm.

• Recommand is 3 second.

Parameter 9037 Movable max.positon & offset of limit position in manual mode[unit:mm]

Range : $0 \sim 100.00$

0 : when moving manually, you can move to soft limit or restricted location to trigger soft limit warning. Not cero value : when in manual movement, you can only move to soft limit or restricted location to minus



arameter setting value, then this is the max.movable location to prevent trigger soft limit warning. EX : the max movement positon of horizonal axis in mold is 100, min. is -20, offset is 5, then arm can move between -15~95 to prevent trigger soft limit warning.

Parameter 9039 open mold complete, delay for how long to do down[unit:ms]

Range : $0 \sim 10000 \text{ (max.10 second)}$

System may receive open mold complete signal, but the injection molding machine still not opens up completely, therefore you can set up ON delay time, then robot will go down in mold to prevent collision.

Parameter 48056 editable distance range under auto mode [unit:mm]

Range : 0~999999.999

If you want to do position fine tune under auto mode, but you are afraid that the tuning value is too big to have collision. You can set this parameter to define the range.

Parameter 48057 machine type[0:5 servo;1:3 servo]

Range $: 0 \sim 1$ Set up machine type.

Parameter 48091 interval between main arm and sub-arm pull out axis after returning home[unit:mm]

Range : 0~999999.999

- This parameter is only valid for 5 servo axis robot.
- The distance between main pull arm and sub pull arm after returning home and 2 pull out axis standby point is cero.

• If this parameter setting is too big may lead wrong range judgement to make main arm and sub-arm pull arm to collide.

Parameter 48402 delay time when monitor sleep to wake [unit:second]

Range : 0~999 $^{\circ}$

When monitor in sleep mode, you can touch monitor to wake it up, but there will be a delay time. You can set up this parameter to define the delay. This delay can prevent wrong operation while monitor is still black, recommend setting is 3 second.

Parameter 50012 arrive check range default[unit:mm]

Range : $0 \sim 999999.999 \circ$

When point to point, range is smaller than parameter setting, you can run next command. If this parameter setting is too small, the movement speed will be too slow, recommand setting is 30mm.

Parameter 60172 movement max. speed[unit:mm/Min]

Range : 0.001~999999.999 •

The max. movement speed program speed is 100% and run speed is 100%). But the exact speed will need to refer to exact stuation under auto mode (Parameter60214 \sim 60218).

10.3 Common parameter → Axis parameter

Parameter 48011 \ 48013 \ 48015 \ 48017 \ 48019 xx axis soft limit(+)[unit:mm]

Range : -999999.999~999999.999 •

After returning home, max. (+)distance that axis can move



Parameter 48012 \ 48014 \ 48016 \ 48018 \ 48020 xx axis soft limit(-) [unit:mm]

Range ∶-999999.999~999999.999 ∘ After returning home, max. (-)distance that axis can move

Parameter 48048~48052 xx axis max.speed manually[unit:mm/min]

Range : 1000~200000 ° When moving axis manually,100% speed.

Parameter 60214~60218 xx axis max.speed[unit:mm/Min]

Range $: 0.1 \sim 9999999.999$ $_{\odot}$ The max. speed to move under auto mode. Because the speed for every axis is not the same. You can use this parameter to set up max. speed to prevent motor overload.

Parameter 71200~71204 xx axis linear ACC/DEC time[unit:ms]

Range $: 0 \sim 2000 \circ$ Linear ACC/DEC under auto mode.

Parameter 71232~71236 xx axis S shape ACC/DEC time [unit:ms]

Range $: 0 \sim 2000$ \circ S shape ACC/DEC under auto mode.

Parameter 77064~77068 xx axis return home offset[unit:mm]

Range : $-999999.999 \sim 999999.999 \circ$ If the axis position is wrong after retuning home(may be (+) or (-)) to lead the movement insufficient, you can use this parameter to move axis home position.

Parameter 77097.0~77097.4 xx axis return home direction(0:+;1:-)

Range $: 0 \sim 1 \circ$ Choose axis to go (+) or (-) to return home.

Parameter 77132~77136 xx axis return home section 1 speed[unit:mm/Min]

Range : 1.000~999999.999 •

The moving speed to find home dog when returning home. When the speed is too slow, you can make this parameter bigger, but not to hit home dog.

Parameter77164~77168 xx axis return home section 2 speed [unit:mm/Min]

Range : 1.000~999999.999 .

The moving speed to find motor Z signal when leaving home dog after returning home. This value can not be too big, otherwise you may not find motor Z signal.



11 Troubleshooting

11.1 Alarm troubleshooting

Alarm 110000 notify main arm vertical over delay waiting time

- (1) Main arm vertical check signal did not trigger, check if switch signal is ok.
- (2) Check common parameter → mutual parameter 9030 setting.
- (3) Check if air is not enough to stop this movement.

Alarm 110001 notify main arm horizontal over delay waiting time

- (1) Main arm horizontal check signal did not trigger, check if switch signal is ok
- (2) Check common parameter → mutual parameter 9030 setting
- (3) Check if air is not enough to stop this movement.

Alarm 110002 Z axis is not in safety height, move to certain safe height then return to standby point

- (1) Z axis is not in safe height, move manually to safety position and return to standy point.
- (2) Inside mold, arm is not at safe height, but you still want to go home, set u parameter8050.0 to be 1. (inside mold, Z axis can return home when[0:N/A;1:Yes])
- (3) Outside of mold, arm is not at safe height, can not return home, set u parameter8050.4 to be 0. (outside of mold, if Z axis did not move to up limit, can not return home[0:N/A; 1:Yes])

Alarm 110004 I/O communication errors

I/O card communication error will make I/O stop.

- (1) Reboot to check if working.
- (2) If the trouble is the same, check I/O card or relating hardware.
- (3) Check cables.
- (4) Check if there is any strong interference.

Alarm 110005 the posture to go in mold is vertical, but vertical limit did not trigger

- (1) Check is the posture is vertical when going in mold.
- (2) Check main arm limit switch.
- (3) If you want to set up the posture to be horizontal, set up parameter 8000.2 (main arm posture[0:vertical;1:horizontal]) to be 1.

Alarm 110006 the posture to go in mold is horizontal, but horizontal limit did not trigger

- (1) Check is the posture is horizontal when going in mold \circ
- (2) Check main arm limit switch.
- (3) If you want to set up the posture to be horizontal, set up parameter 8000.2 (main arm posture[0:vertical;1:horizontal]) to be 0.

Alarm 110008 posture is not vertical, stop moving horizontally.

- (1) When arm is in mold, the moving posture need to be vertical.
- (2) If you want to cancel check function, set up general parameter8010.1 to be 0.
- (3) If you want to change the check posture to be horizonal, set up parameter8010.2 to be 1.

Alarm 110009 posture is not horizontal, stop moving horizontally.

(1) When arm is in mold, the moving posture need to be horizontal.



- (2) If you want to cancel check function, set up general parameter8010.1 to be 0.
- (3) If you want to change the check posture to be vertical, set up parameter8010.2 to be 0.

Alarm 110010 main arm posture is not vertical nor horizontal, output correct posture manually

After entering system, vertical and horizontal signal did not trigger, in order to prevent error, output arm posture manually

Alarm 110011 main arm vertical and horizonal signal trigger together, check if vertical and horizonal sensor error. Check if both limit sensors have errors.

Alarm 110012 sub-arm vertical and horizontal signal trigger together, check if sensor error

Check if limit sensor has error.

Alarm 110013 open mold complete and close mold complete signals trigger together, check if injection molding machine signal error.

Check open mold and close mold complete signal from injection molding machine.

Alarm 110014 vertical check signal flash, check if turning device or low air.

- (1) When arm is vertical, but there is no vertical signal. The reason may be low air or high vibration.
- (2) Turning device may have error or bad sensor.

Alarm 110015 horizonal check signal flash, check if turning device or low air.

- (1) When arm is horizonal, but there is no horizonal signal. The reason may be low air or high vibration. •
- (2) Turning device may have error or bad sensor.

Alarm 110016 open mold complete, but middle plate signal did not trigger

Under open mold complete, but milddle plate check signal did not trigger.

- (1) Check if middle plate check signal is general.
- (2) Check DI Map setting.
- (3) If you do not use middle plate check functio, set up parameter8050.6 to be1.

Alarm 110017 complete home return before returning standby point

After returning home, the movement will be correct. So before go to standby point, you will need to return home.

Alarm 110018 there is no Y axis safety confirm signal out of mold when going down ,check signal

When axis moves to safety area out of mold, the safe signal out of mold should be ON, then arm can go down. When there is no this signal, even the position is in the safe area, arm still can not go down. Therefore if you want to enlarge safe area out of the mold, you can enlarge safety area setting and extended the length of the iron sheet.

Alarm 110025 notify sub-arm horizontal over delay waiting time

- (1) Sub-arm horizonal check signal did not trigger, check switch signal is ok.
- (2) Check common parameter → mutual parameter 9030 setting.
- (3) Check if air low to stop movement.

Alarm 110027 notify sub-arm vertical over delay waiting time

- (1) Sub-arm vertical check signal did not trigger, check switch signal is ok.
- (2) Check common parameter → mutual parameter 9030 setting.
- (3) Check if air low to stop movement.



Alarm 110036 air low

- a. check if air pressure is not enough.
- b. After clearing, press [stop] to clear alarm.

Alarm 110037~110041

MY axis servo drive error

MZ axis servo drive error

SY axis servo drive error SZ axis servo drive error

X axis servo drive error

Servo drive has errors, check error codes of drives and refer to driver manual.

Alarm 110042~110051 MY axis over soft limit(+) MZ axis over soft limit(+) SY axis over soft limit(+) SZ axis over soft limit(+) X axis over soft limit(+) MY axis over soft limit(-) MZ axis over soft limit(-) SY axis over soft limit(-) Z axis over soft limit(-) X axis over soft limit(-)

- a. Trigger axis soft limit(+) under auto mode.
- b. When there is alarm, check if this movement command is over soft limit setting or not.
- c. Press [stop] to clear alarm.
- d. Switch to manual mode, move to (-) direction to clear warning.

Alarm 110052~110061

MY axis trigger hard limit(+)

MY axis trigger hard limit(-)

- MZ axis trigger hard limit(+)
- MZ axis trigger hard limit(-)
- SY axis trigger hard limit(+)
- SY axis trigger hard limit(-)
- SZ axis trigger hard limit(+)
- SZ axis trigger hard limit(-)

X axis trigger hard limit(+)

X axis trigger hard limit(-)

- a. Confirm alarm axis direction.
- b. Press [stop] to clear alarm.
- c. Switch to manaul mode, move to reverse direction to clear warning.
- d. Check if hardware limit sensor.

Alarm 410160 Tangent in position check timeout

a. Make note of [MAINTAIN] → [SYSTEM] pulse and votalge command servo lag value(Pluse).



b. Check [MANUAL] \rightarrow [Parameter] \rightarrow [machine parameter] \rightarrow [mutual parameter] arrive check range setting value, setting can not smaller than 3mm.

- c. Check program line movement setting range, setting can not smaller than 3mm.
- d. Press EMG, return home, run again.
- (target position current position) < arrive check range
- Under auto mode, every movement command will check the distance between exact position and target position is smaller than arrive range setting. If current position cannot meet check range, this alarm will be triggered.

Alarm 416400 axis 1 command and feedback over max. lag (Axis 1 Servo Lag Over Range)

b. Y1 axis servo lag is over than parameter71400 setting, trigger this alarm ^{[7} Axis 1 max. command and feedback lag(Pulse) ^[1]

- c. Make a record of [MAINTAIN] → [SYSTEM], Y1 axis servo lag value(Pulse) and Vcmd servo lag value.
- d. Press EMG to clear value, move Y1 manually, check if there is servo lag.
- e. If there is still have servo lag, check below items.
- Check if servo cable is lose or braking.
- Check if drive rigidity parameter setting too low.
- Change motor or drives, confirm if there is error or not.
- Change controller, confirm if there is error or not.

Alarm 416401 axis 2 command and feedback over max. lag (Axis 2 Servo Lag Over Range)

a. Z1 axis servo lag is over than parameter71401 setting, trigger this alarm [®] Axis 2 max. command and feedback lag(Pulse)

- b. Make a record of [MAINTAIN] → [SYSTEM], Z1 axis servo lag value(Pulse) and Vcmd servo lag value.
- c. Press EMG to clear value, move Z1 manually, check if there is servo lag.
- d. If there is still have servo lag, check below items.
- Check if servo cable is lose or braking.
- Check if drive rigidity parameter setting too low.
- Change motor or drives, confirm if there is error or not.
- Change controller, confirm if there is error or not.

Alarm 416402 axis 3 command and feedback over max. lag (Axis 3 Servo Lag Over Range)

a. Y2 axis servo lag is over than parameter71402 setting, trigger this alarm ^{[7} Axis 3 max. command and feedback lag(Pulse) ^{[7}

- b. Make a record of [MAINTAIN] → [SYSTEM], Y2 axis servo lag value(Pulse) and Vcmd servo lag value.
- c. Press EMG to clear value, move Y2 manually, check if there is servo lag.
- d. If there is still have servo lag, check below items.
- Check if servo cable is lose or braking.
- Check if drive rigidity parameter setting too low.
- Change motor or drives, confirm if there is error or not.
- Change controller, confirm if there is error or not.

Alarm 416403 axis 4 command and feedback over max. lag (Axis 4 Servo Lag Over Range)

a. Z2 axis servo lag is over than parameter71403 setting, trigger this alarm ^{[7} Axis 4 max. command and feedback lag(Pulse) ^{[1}



- b. Make a record of [MAINTAIN] → [SYSTEM], Z2 axis servo lag value(Pulse) and Vcmd servo lag value.
- c. Press EMG to clear value, move Z2 manually, check if there is servo lag.
- d. If there is still have servo lag, check below items.
- Check if servo cable is lose or braking.
- Check if drive rigidity parameter setting too low.
- Change motor or drives, confirm if there is error or not.
- Change controller, confirm if there is error or not.

Alarm 416404 axis 5 command and feedback over max. lag (Axis 5 Servo Lag Over Range)

a. X axis servo lag is over than parameter71404 setting, trigger this alarm ^r Axis 5 max. command and feedback lag(Pulse) ^a

- b. Make a record of [MAINTAIN] → [SYSTEM], X axis servo lag value(Pulse) and Vcmd servo lag value.
- c. Press EMG to clear value, move X manually, check if there is servo lag.
- d. If there is still have servo lag, check below items.
- Check if servo cable is lose or braking.
- Check if drive rigidity parameter setting too low.
- Change motor or drives, confirm if there is error or not.
- Change controller, confirm if there is error or not.

Alarm 416432 axis1 rest, command and feedback over max. lag (Axis 1 Servo Lag Over Range in Standstill Status)

a. Y1 axis servo lag is over than parameter71432 setting, trigger this alarm ^{[7} Axis 1 rest, command and feedback max.lag(Pulse)_.

- b. Make a record of [MAINTAIN] → [SYSTEM], Y1 axis servo lag value(Pulse) and Vcmd servo lag value.
- c. Press EMG to clear value, move Y1 manually, check if there is servo lag.
- d. If there is still have servo lag, check below items.
- Check if servo cable is lose or braking.
- Check if drive rigidity parameter setting too low.
- Change motor or drives, confirm if there is error or not.
- Change controller, confirm if there is error or not.

Alarm 416433 axis 2 rest, command and feedback over max. lag (Axis 2 Servo Lag Over Range in Standstill Status)

a. Z1 axis servo lag is over than parameter71433 setting, trigger this alarm ^{[7} Axis 2 rest, command and feedback max.lag(Pulse) [[]

- b. Make a record of [MAINTAIN] → [SYSTEM], Z1 axis servo lag value(Pulse) and Vcmd servo lag value.
- c. Press EMG to clear value, move Z1 manually, check if there is servo lag.
- d. If there is still have servo lag, check below items.
- Check if servo cable is lose or braking.
- Check if drive rigidity parameter setting too low.
- Change motor or drives, confirm if there is error or not.
- Change controller, confirm if there is error or not.

Alarm 416434 axis 3 rest, command and feedback over max. lag (Axis 3 Servo Lag Over Range in Standstill Status)

a. Y2 axis servo lag is over than parameter71434 setting, trigger this alarm ^[] Axis 3 rest, command and

LNC-R6000 Troubleshooting

feedback max.lag(Pulse) (Pulse) _

- b. Make a record of [MAINTAIN] → [SYSTEM], Y2 axis servo lag value(Pulse) and Vcmd servo lag value.
- c. Press EMG to clear value, move Y2 manually, check if there is servo lag.
- d. If there is still have servo lag, check below items.
- Check if servo cable is lose or braking.
- Check if drive rigidity parameter setting too low.
- Change motor or drives, confirm if there is error or not.
- Change controller, confirm if there is error or not.

Alarm 416435 axis 4 rest, command and feedback over max. lag (Axis 4 Servo Lag Over Range in Standstill Status)

a. Z2 axis servo lag is over than parameter71435 setting, trigger this alarm ^[7] Axis 4 rest, command and feedback max.lag(Pulse) (Pulse) ^[1]

- b. Make a record of [MAINTAIN] → [SYSTEM], Z2 axis servo lag value(Pulse) and Vcmd servo lag value.
- c. Press EMG to clear value, move Z2 manually, check if there is servo lag.
- d. If there is still have servo lag, check below items.
- Check if servo cable is lose or braking.
- Check if drive rigidity parameter setting too low.
- Change motor or drives, confirm if there is error or not.
- Change controller, confirm if there is error or not.

Alarm 416436 axis 5 rest, command and feedback over max. lag (Axis 5 Servo Lag Over Range in Standstill Status)

a. X axis servo lag is over than parameter71436 setting, trigger this alarm ^r Axis 5 rest, command and feedback max.lag(Pulse) (Pulse) ¹

- b. Make a record of [MAINTAIN] → [SYSTEM], X axis servo lag value(Pulse) and Vcmd servo lag value.
- c. Press EMG to clear value, move X manually, check if there is servo lag.
- d. If there is still have servo lag, check below items.
- Check if servo cable is lose or braking.
- Check if drive rigidity parameter setting too low.
- Change motor or drives, confirm if there is error or not.
- Change controller, confirm if there is error or not.



11.2 Warning troubleshooting

Warning 12000 EMG trigger

- a. Release EMG button on teach pendant.
- b. Release EMG button on injection molding machine.

Warning 12002 There is no open mold complete signal, arm can not move down inside mold.

- a. In mold, if arm did not have open mold complete signal, arm can not go down.
- b. When arm goes into to mold, open mold complete signal will be off and trigger this warning.

Warning 12003 Robot not in safe area, stop move down

- a. The position that arm goes down is not the position inside mold or ourside mold.
- b. Check if safe height too small, can not smaller than 10mm.

Warning 12004 Robot not in safe area, stop move out

- a. When robot move down to mold, stop move out.
- b. Move to certain safe height and move out.

Warning 12005 Processing parts meet cycle times

Go to auto cycle monitor page, make acceptable parts to be 0.

Warning 12007 Maintain time arrive, do machine maintenance

- a. Run hint maintain item.
- b. Go to [Parameter setting] → [periodical check] → [status], go to certian items and press [maintain] button.

Warning 120064~120083 When putting, vacuumer 1 limit interrupt

:

When putting, hold 12 limit interrupt.

Press [cyclestart] to clear warning and process.

Warning 120096~120105 wait conveyor OFF to over delay waiting time

:

Wait peripherals 8 OFF over delay waiting time. Press [cyclestart] to clear warning and process.

Warning 120128~120137 wait conveyor ON to over delay waiting time

:

Wait peripherals 8 ON over delay waiting time.

Press [cyclestart] to clear warning and process.



12 Q&A

12.1 How to write note of movement command of mold document

12.1.1 Add one line note for movement command

1. Go to TEACH>linear move command, set up value for axis, then press write note button.



2. Choose the note you want, then press [ADD] to complete this.

Command: Comment	Return	
Comment		
down position		[Note list] :
pull position		you to add.
pick position		
up position		

3. According above operation, there will be a new line of program command.

Move to MZ=800.00 // down position



12.1.2 Modify note

- Go to TEACH>linear movement command, choose the linear movement command that you want to change, EX :[move to MZ= 700.00 // drop location].
- 2. Press[write]button.

Comr Runni	nand: Axis- ng	Moving		С	omment
МҮ		шш	MY-	M	[write] :
MZ	0.00	mm	MZ-	Μ	note list.
x		шш	X -	X	+
R.					

3. Choose the note you want, then press [MODIFY] to complete this modificaiton.

Command: Comment Current Comment	Return	
down position		
Comment		Current note.
down wait point(standby)	Ā	
down position		
pull position		[Note list] :
pick position *	V	Show note list for
pull & backward		you to add.
up position		



12.1.3 Delete note

1. Go to TEACH>linear movement command, choose the linear movement command that you want to delete. EX:choose[move to MZ= 700.00 //drop location], then press[write].



2. Click on the blank note and press[MODIFY] to complete this delete.





12.1.4 Add note that you want to note

- 1. Go to $\lceil SYSTEM \rceil \rightarrow \lceil BACKUP \rceil \rightarrow \rceil$ Parameter backup \rceil , refer to chapter 7.1.1.
- 2. Under backup\ncfiles directory, there will be macro00xx.str, xx=number $00 \sim 42$, refer to language and change.

macro0000.str : Traditional Chinese macro0001.str : Simplified Chinese macro0002.str : English

- 3. Use word editor to open file, EX : Note or Word.
- 4. File example as below :

[HMIstring]

2300=MACRO 0 2301=MACRO 1

2302=MACRO 2

5801=drop location

5803=pick position

5805=Up position

5802=pullout location

5804=pullout backward

5807=feed head location

5808=production position 1 5809=production position 2 5810=production position 3 5811=production position 4

5806=cylinder turning location

5800=this is the first line of note. a. 5800=drop wait(standby point)

> b.

no keyword, it cannot show.

In order to offer delete function, [©] 5849 must be blank. C.

This line is file keyword, must have. If there is

d. Left string definition is system default setting.

```
5. Go to \lceil SYSTEM \rfloor \rightarrow \lceil BACKUP \rfloor \rightarrow \rceil Parameter restore \rfloor import function, refer to chapter 7.1.2.
```

6. Reboot controll to complete modification.

5812= 5813=

... ... 5846= 5847= 5848= 5849=