

LNC Milling series

Software Manual

2020/07 version : V01.00 (LN4408210139)

Enable intelligent machines

Menu


1	System Update	1
2	PLC Maintenance -- C , S BITS & Register	7
	2.1C BIT Definition	7
	2.2S Bits definition.....	11
	2.3Register definition.....	15
	2.4C Bits Description	18
	2.5S Bits description.....	30
	2.6Register description.....	41
	2.7PLC Window.....	48
	2.8PLC initialize sets (PLCIO.CFG)	52
3	Parameters	54
	3.1Parameters.....	55
	3.2Servo Parameter	78
	3.3Mechanical parameter	96
	3.4Spindle Parameter.....	98
	3.5MPG Parameter	118
	3.6Compensation Parameter	120
	3.7Home Parameter	127
	3.8Operation Parameter.....	143
4	SYSTEM ALARM (Alarm) and WARNING (Warning)	172
	4.1OP OPERATION ALARM	172
	4.2OP Operation related alarm	174
	4.3INT interpreter alarm	175
	4.4MOT MOTION RELATED ALARM	186
	4.5MOT Alarms	205
5	Machine Adjustment.....	206
	5.1Milling Rigid Tapping Commanding.....	206
	5.2Laser Compensation Procedure	210
	5.3Double Ball Bar Measure – Backlash or Circular Spike	213
	5.4Spindle Positioning Tuning	215
	5.5Digital communication adjust instruction	217
	APPENDIX A PARAMETER ADJUSTMENT EXAMPLE	221

A1 Parameter Adjustment of V Command Control Method	221
A2 Parameter Adjustment when Encoder is installed besides Ball Screw	223
A3 Parameter Adjustment when using Linear Scale Control Method	225
Appendix E Internet Setting Description	227
Appendix C Key Code switch	281
1 Summary	281
2 Applicable edition.....	281
3 Instruction	281
4 Add and edit the parameter	286
4.1 Parameter 0658.....	286
5 Add and Edit MLC Signal	286
5.1 S401~488.....	286
5.2 C401~488.....	286
6 Add and Edit the alarm and warning.....	287
7 Add and Edit the system information	287
8 Add and Edit the G code and M code	287
9 Add and Edit the system variable	287
10 Remark	287

1 System Update

1. Large-screen series (LNC-615i, LNC-600, LNC-520, LNC-516i...)


This function can only be executed under incomplete preparation, press EMG-STOP and press system update, below picture will be shown on the screen, users can choose each item to continue :




System Update Main Page

System update :


This function offers two ways for update: general disk/RS232 transmission. Please install LNC Technology Co., Ltd. latest version software if choosing this function. Pressing **【YES】**, the installation screen will occur. There is installation program instruction during installation so you only need to follow the instruction to upgrade the system.



At the system upgrade file , move cursor to the line and press **【OK】**



System will double confirm if you want to do upgrade, make sure if you really want to do upgrade and press **【OK】**



Then system will turn to DOS page as below to show current version and update version, press **【Y】** and system will process upgrade automatically.

```

=====
WELCOME TO INSTALL LNC-M600 SERIES
=====
Current Version:
  M600_VER_03.12.002

Installing Version:
  M600_VER_03.12.002

Are you sure to install?[Y,N]?

```

Please wait the upgrading process.

```

Installing...
Please wait,file preparing ...

```

System upgraded, press any key to restart.

```

Wonderful ! Fully install finish!!

Press any key to continue . . .

```

2. Small-screen Series (LNC-320i...)


This function can only be executed under incomplete preparation and EDIT mode, press EMG-STOP and press system update, below picture will be shown on the screen, users can choose each item to continue :



System Update Main Page


A. System update :

Press OK after Choosing SYSTEM UPGRADE, there are 2 ways to update: general disk/RS232



1. General disk/RS232

- a. After pressing confirm, system will pop up dialog box for users to choose update method. Please use up/down/left/right to move cursor to choose installation source, then press INPUT. It will show you the path at column A and all the folders under the path at column B.
- b. Move the cursor to column A after choosing the right path, please press OK



- c. Press OK to confirm it again after choosing the right path.



- d. It will show you the message if the path that you chose is wrong



- e. It will leave the system and enter into installation screen if the path is correct.

System install instruction :

The welcome page shows the information of the current version in use (Current Version) and the version to be installed (Installing Version), please verify the version first, and then click “Y” to start the installation of this software. The following page will appear after the installation is completed, please press any key to reboot the system to validate the configuration and then enter LNC system.

```
=====
WELCOME TO INSTALL LNC-M300 SERIES
=====
Current Version:
  Not install

Installing Version:
  M300i_VER_03.00.013U1

Are you sure to install?[Y,N]?
```

2 PLC Maintenance -- C , S BITS & Register

2.1 C BIT Definition

Some models offer 4~6 axis function. Please ignore the parameter if your system doesn't show that.

C BIT PLC→CNC

BIT #	SYMBOL	DESCRIPTION	PAGE
C000	ST	CYCLE START	18
C001	SP	FEED HOLD	18
C002	-	-	
C003	PPROT	PROGRAM PROTECTION	18
C004	MANRET	MANUAL RETURN	18
C005	-	-	
C006	+X	SELECT AXIS & DIRECTION: +X	18
C007	-X	SELECT AXIS & DIRECTION: -X	18
C008	+Y	SELECT AXIS & DIRECTION: +Y	18
C009	-Y	SELECT AXIS & DIRECTION: -Y	18
C010	+Z	SELECT AXIS & DIRECTION: +Z	18
C011	-Z	SELECT AXIS & DIRECTION: -Z	18
C012	+4	+4 Axis Direction	18
C013	-4	-4 Axis Direction	18
C014	-	-	
C015	-	-	
C016	HX	SELECT MPG AXIS: X AXIS	19
C017	HY	SELECT MPG AXIS: Y AXIS	19
C018	HZ	SELECT MPG AXIS: Z AXIS	19
C019	H4	Handle 4th Axis	19
C020	MPGDRN	MPG DRY RUN	19
C021	SCNSAV	QUIT SCREENSAVER	19
C023	RT	RAPID TRAVEL	19
C024~C030	-	-	
C031	HOMEX	HOME DOG: X AXIS	19
C032	HOMEY	HOME DOG: Y AXIS	19
C033	HOMEZ	HOME DOG: Z AXIS	19
C034	HOME4	4th Axis Home DOG Signal	19
C035	-	-	
C036	ESP	EMERGENCY STOP	19
C037	ERS	EXTERNAL RESET	19
C038	FIN	M, S, T CODE FINISH	20
C039	-	-	
C040	SBK	SINGLE BLOCK	20
C041	BDT	OPTIONAL BLOCK SKIP	20
C042	DRN	DRY RUN	20
C043	MLK	MACHINE LOCK	20
C044	OPS	M01 OPTIONAL STOP	20
C045	ZNG	IGNORE SERVO AXIS: Z AXIS	21
C046	AFL	AUXILIARY FUNCTION LOCK	21
C047~C048	-	-	
C049	4NG	SERVO AXIS IGNORE SERVO AXIS: THE 4TH AXIS	21
C050	+LX	AXIS OVER TRAVEL: +X	21
C051	-LX	AXIS OVER TRAVEL: -X	21
C052	+LY	AXIS OVER TRAVEL: +Y	21
C053	-LY	AXIS OVER TRAVEL: -Y	21

BIT #	SYMBOL	DESCRIPTION	PAGE
C054	+LZ	AXIS OVER TRAVEL: +Z	21
C055	-LZ	AXIS OVER TRAVEL: -Z	21
C056	+L4	+4th Axis OT	21
C057	-L4	-4th Axis OT	21
C058	-	-	
C059	INTLKX	AXIS INTERLOCK: X AXIS	22
C060	INTLKY	AXIS INTERLOCK: Y AXIS	22
C061	INTLKZ	AXIS INTERLOCK: Z AXIS	22
C062	INTLK4	4th Axis Interlock	22
C063	-	-	
C064	WINRW	PLC WINDOW READ/WRITE	22
C065	WINREQ	PLC WINDOW COMMAND	22
C066	HIX	HANDLE INTERRUPT: X AXIS	23
C067	HIY	HANDLE INTERRUPT: Y AXIS	23
C068	HIZ	HANDLE INTERRUPT: Z AXIS	23
C069	HI4	4th Axis: Select Axis Direction Signal of Handle INT	23
C070~C71	-	Reserve	
C072	S1JOG	1st Spindle JOG	23
C073	S2JOG	2rd Spindle JOG	23
C074	S3JOG	3rd Spindle JOG	23
C075	SVAX	SERVO ALARM: X AXIS	23
C076	SVAY	SERVO ALARM: Y AXIS	23
C077	SVAZ	SERVO ALARM: Z AXIS	23
C078	SVA4	4th Axis Servo Alarm	23
C079		PLC open file	23
C080	S3CW	3rd Spindle CW	24
C081	S3CCW	3rd Spindle CCW	24
C082	S1CW	1st Spindle CW	24
C083	S1CCW	1st Spindle CCW	24
C084	-	-	
C085	ORT	Spindle Orientation	24
C086		SP command switch to PULSE command, complete.	24
C087	S2CW	2nd Spindle CW	24
C088	S2CCW	2nd Spindle CCW	24
C089	MRX	ENABLE MIRROR: X AXIS	24
C090	MRY	ENABLE MIRROR: Y AXIS	24
C091	MRZ	ENABLE MIRROR: Z AXIS	24
C092	MR4	4th Axis Servo Alarm	24
C093~C094		reserve	
C095~C096	-	-	
C097	S1GR1	1st Spindle Gear #1	24
C098	S1GR2	1st Spindle Gear #2	24
C099	S1GR3	1st Spindle Gear #3	24
C100	UI0	MACRO Variable \$200	25
C101	UI1	MACRO Variable \$201	25
C102	UI2	MACRO Variable \$202	25
C103	UI3	MACRO Variable \$203	25
C104	UI4	MACRO Variable \$204	25
C105	UI5	MACRO Variable \$205	25
C106	UI6	MACRO Variable \$206	25
C107	UI7	MACRO Variable \$207	25
C108	UI8	MACRO Variable \$208	25
C109	UI9	MACRO Variable \$209	25
C110	UI10	MACRO Variable \$210	25
C111	UI11	MACRO Variable \$211	25

BIT #	SYMBOL	DESCRIPTION	PAGE
C112	UI12	MACRO Variable \$212	25
C113	UI13	MACRO Variable \$213	25
C114	UI14	MACRO Variable \$214	25
C115	UI15	MACRO Variable \$215	25
C116	S2GR1	2nd Spindle Gear #1	24
C117	S2GR2	2nd Spindle Gear #2	24
C118	S2GR3	2nd Spindle Gear #3	24
C119	ZP2ZDC	MOTION PROHIBITION FOR AREA BELOW THE 2ND ZERO POINT OF Z AXIS	25
C120	PMCGO	COMMAND SIGNAL OF PMC AXIS	25
C121	S3GR1	3rd Spindle Gear #1	24
C122	S3GR2	3rd Spindle Gear #2	24
C123	S3GR3	3rd Spindle Gear #3	24
C124	RTFIN	Disable Signal in Rigid Tapping	25
C125	RTST	Enable Signal in Rigid Tapping	25
C126	SWEN	Enable Signal of Spindle Motor Rotates in Gear-Shifting Speed	26
C127	SWFIN	Spindle Gear-Shifting Complete Signal	26
C128~C129	-	-	
C130	DTX	X Axis Detach	26
C131	DTY	Y Axis Detach	26
C132	DTZ	Z Axis Detach	26
C133	DT4	4th Axis Detach	26
C134	PRTCLR	CLEAR PART COUNT NUMBER	26
C135		PLC axis RESET signal	26
C136~C137	-	-	
C138		Activate 1st software non-go zone	26
C139		Activate 1st software non-go zone	26
C140	2NDSLX	THE 2ND SOFT-LIMIT: +X	26
C141	2NDSLX	THE 2ND SOFT-LIMIT: -X	26
C142	2NDSLY	THE 2ND SOFT-LIMIT: +Y	26
C143	2NDSLY	THE 2ND SOFT-LIMIT: -Y	2026
C144	2NDSLZ	THE 2ND SOFT-LIMIT: +Z	26
C145	2NDSLZ	THE 2ND SOFT-LIMIT: -Z	26
C146	2NDSL4	2nd +4th Axis Software Limit Choice	26
C147	2NDSL4	2nd -4th Axis Software Limit Choice	26
C148~C171		reserve	
C172~C180		-	
C181		Servo axis hide: X	27
C182		Servo axis hide: Y	27
C183		Servo axis hide: Z	27
C184		Servo axis hide:4th	27
C185~C186		reserve	
C187		Servo synchronize control: X	27
C188		Servo synchronize control: Y	27
C189		Servo synchronize control: Z	28
C190		Servo synchronize control: 4th	28
C191~C192		reserve	
C193~200	-	-	
C201	AERSTX	Absolute encoder Reset Ready Signal: X Axis	28
C202	AERSTY	Absolute encoder Reset Ready Signal: Y Axis	28
C203	AERSTZ	Absolute encoder Reset Ready Signal: Z Axis	28
C204	AERST4	Absolute encoder Reset Ready Signal:4th Axis	28
C207	AERDYX	Absolute Encoder Data Ready Signal: X Axis	28
C208	AERDYY	Absolute Encoder Data Ready Signal: Y Axis	28
C209	AERDYZ	Absolute Encoder Data Ready Signal: Z Axis	28

BIT #	SYMBOL	DESCRIPTION	PAGE
C210	AERDY4	Absolute Encoder Data Ready Signal:4th Axis	28
C211~C212		reserve	
C213	AEB0X	Absolute Encoder Data Bit 0Transmitting Signal : X Axis	28
C214	AEB0Y	Absolute Encoder Data Bit 0Transmitting Signal : Y Axis	28
C215	AEB0Z	Absolute Encoder Data Bit 0Transmitting Signal : Z Axis	28
C216	AEB04	Absolute Encoder Data Bit 0Transmitting Signal : 4th Axis	28
C217~C218		reserve	
C219	AEB1X	Absolute Encoder Bit 1 Transmit: X Axis	28
C220	AEB1Y	Absolute Encoder Bit 1 Transmit: Y Axis	28
C221	AEB1Z	Absolute Encoder Bit 1 Transmit: Z Axis	28
C222	AEB14	Absolute Encoder Bit 1 Transmit: 4th Axis	28
C223~C224		reserve	
C225~C230	-	-	
C231		Encoder value clean: X	28
C232		Encoder value clean: Y	28
C233		Encoder value clean: Z	28
C234		Encoder value clean: 4th	28
C235~C236		reserve	
C237		Clear encoder value: 1st SP	28
C238		Clear encoder value: 2nd SP	28
C239		Clear encoder value: 3rd SP	28
C240		Non	
C241		PMC/INT switch : X (0:INT,1:PMC)	29
C242		PMC/INT switch : Y (0:INT,1:PMC)	29
C243		PMC/INT switch : Z (0:INT,1:PMC)	29
C244		PMC/INT switch : 4th(0:INT,1:PMC)	29
C245~C246		Reserve	
C247		Servo axis name switch: X	29
C248		Servo axis name switch: Y	29
C249		Servo axis name switch: Z	29
C250		Servo axis name switch: 4 th	29
C251~C252		Reserve	
C253		Activate servo ABS coordinate update: X	29
C254		Activate servo ABS coordinate update: Y	29
C255		Activate servo ABS coordinate update: Z	29
C256		Activate servo ABS coordinate update: 4 th	29
C257~C258		Reserve	
C259		Activate servo ABS home update: X	29
C260		Activate servo ABS home update: Y	29
C261		Activate servo ABS home update: Z	29
C262		Activate servo ABS home update: 4 th	29
C263~C264		Reserve	
C265~C280		Non	29
C281		X M-II communication switch	
C282		Y M-II communication switch	29
C283		Z M-II communication switch	29
C284		4th M-II communication switch	29
C285~C286		Reserve	
C287		1st SP M-II communication switch	29
C288		2nd SP M-II communication switch	29
C289		3rd SP M-II communication switch	29
C290~C511		Non	

2.2 S Bits definition

S BIT CNC→PLC

BIT #	SYMBOL	DESCRIPTION	PAGE
S000	STL	CYCLE START	30
S001	SPL	FEED HOLD	30
S002	EDITL	MODE: EDIT	30
S003	MEML	MODE: MEM	30
S004	MDIL	MODE: MDI	30
S005	JOGL	MODE: JOG	30
S006	INCJOG	MODE: INC JOG	30
S007	MPGL	MODE: MPG	30
S008	HOMEL	MODE: HOME	30
S009	-	-	
S010	MREADY	MACHINE READY	30
S011	MDIPRS	MDI KEYS	30
S012		Manual Return status	
S013~S015	-	-	
S016	ZP1X	STATUS OF X AXIS AT THE 1ST ZERO POINT	30
S017	ZP1Y	STATUS OF Y AXIS AT THE 1ST ZERO POINT	30
S018	ZP1Z	STATUS OF Z AXIS AT THE 1ST ZERO POINT	30
S019	ZP14	4th 1st Axis Point Return End	30
S020	ZP2X	STATUS OF X AXIS AT THE 2ND ZERO POINT	30
S021	ZP2Y	STATUS OF Y AXIS AT THE 2ND ZERO POINT	30
S022	ZP2Z	STATUS OF Z AXIS AT THE 2ND ZERO POINT	30
S023	ZP24	4th 2nd Axis Point Return End	30
S024~S027		Reserve	
S028	WRN	SYSTEM ALARM	31
S029	MF	M CODE STROBE	31
S030	DEN	INTERPOLATION FINISH	31
S031	AL	SYSTEM ALARM	31
S032	RST	SYSTEM RESET	31
S033	NCRDY	SYSTEM READY	31
S034	-	-	
S035	X1000	STATUS OF MPG RATE: x1000	31
S036	X1	STATUS OF MPG RATE: x1	31
S037	X10	STATUS OF MPG RATE: x10	31
S038	X100	STATUS OF MPG RATE: x100	31
S039	PROGST	Program Restart	31
S040	SBKL	STATUS OF SINGLE BLOCK	31
S041	BDTL	STATUS OF OPTIONAL BLOCK SKIP	32
S042	DRNL	STATUS OF DRY RUN	32
S043	MLKL	STATUS OF MACHINE LOCK	32
S044	OPSL	STATUS OF OPTIONAL STOP	32
S045	RTL	STATUS OF RAPID TRAVERSE	32
S046	ZNGL	STATUS OF Z-AXIS NEGLECT	32
S047	AFLI	STATUS OF AUXILIARY FUNCTION LOCK	32
S048~S051	-	-	
S052	S2ZSA	2nd Spindle Zero Speed Arrival	36
S053	S2SA	2nd Spindle Speed Arrival	36
S054	S1STB	S CODE STROBE	32
S055	S2STB	2nd Spindle S Code	32
S056	S3STB	2nd Spindle S Code	32
S057	S3ZSA	3rd Spindle Zero Speed Arrival	36
S058	S3SA	3rd Spindle Speed Arrival	36
S059~S060	-	-	

BIT #	SYMBOL	DESCRIPTION	PAGE
S061	SK2	SOFT PANEL KEY: Z-AXIS NEGLECT	33
S062	SK3	SOFT KEY: MPG DRY RUN	33
S063	SK4	SOFT KEY: AUXILIARY FUNCTION LOCK OF M, S, T CODE	33
S064~S067	-	-	
S068	MPGDRN	MPG DRY RUN	34
S069	TSTB	T CODE STROBE	34
S070	-	-	
S071	SK6	SOFT KEY: MACHINE LOCK	34
S072	SK7	SOFT KEY: DRY RUN	34
S073	SK8	SOFT KEY: OPTIONAL BLOCK SKIP	35
S074	SK9	SOFT KEY: OPTIONAL STOP	35
S075~S078	-	-	
S079	PLCFN	PLC WINDOW COMPLETED	35
S080	M00	M00 STROBE	35
S081	M01	M01 STROBE	35
S082	M02	M02 STROBE	35
S083	M30	M30 STROBE	35
S084~S085	-	-	
S086	ORTFIN	FINISH SPINDLE ORIENTATION	35
S087	-	-	
S088	S1SA	THE 1ST SPINDLE REACHES ROTATION SPEED	36
S089~S090	-	-	
S091	G80	STATUS OF G080 IN CANNEL CYCLE	36
S092	S1ZSA	THE 1ST SPINDLE REACHES ZERO SPEED	36
S093	S1PLS	Spindle Command Format is Pulse signal	36
S094	GRCAR	Spindle Motor Speed when Gears are Switched	36
S095~S099	-	-	
S100	UO0	MACRO Variable \$600	36
S101	UO1	MACRO Variable \$601	36
S102	UO2	MACRO Variable \$602	36
S103	UO3	MACRO Variable \$603	36
S104	UO4	MACRO Variable \$604	36
S105	UO5	MACRO Variable \$605	36
S106	UO6	MACRO Variable \$606	36
S109	UO9	MACRO Variable \$609	36
S110	UO10	MACRO Variable \$610	
S111	UO11	MACRO Variable \$611	
S112	UO12	MACRO Variable \$612	36
S113	UO13	MACRO Variable \$613	36
S114	UO14	MACRO Variable \$614	36
S115	UO15	MACRO Variable \$615	36
S116~S119	-	-	
S120	PMCFIN	PMC AXIS	37
S121~S127	-	-	
S128	RTMODE	RIGID TAPPING	37
S129	-	-	
S130	MOVX	MOTION STATUS OF SERVO AXIS: X AXIS	37
S131	MOVY	MOTION STATUS OF SERVO AXIS: Y AXIS	37
S132	MOVZ	MOTION STATUS OF SERVO AXIS: Z AXIS	37
S133	MOV4	MOTION STATUS OF SERVO AXIS: THE 4TH AXIS	37
S134	WPARV	Max Working Piece Arrival	37
S135~S136		Reserve	
S137	-	-	
S138		Check mechanical coordinate if in 1st no-go zone(0:No,1:Yes)	37
S139		Check mechanical coordinate if in 2nd no-go zone(0:No,1:Yes)	37

BIT #	SYMBOL	DESCRIPTION	PAGE
S140	-	-	
S141		Fan 1 detection	37
S142		Fan 2 detection	37
S143~S149	-	-	
S150	SGRC1	Request Signal of Spindle Gear-Shifting: 1st Gear	38
S151	SGRC2	Request Signal of Spindle Gear-Shifting: 2nd Gear	38
S152	SGRC3	Request Signal of Spindle Gear-Shifting: 3rd Gear	38
S153	SGRC4	Request Signal of Spindle Gear-Shifting: 4th Gear	38
S154	MOVDX	MOTION DIRECTION OF SERVO AXIS: X AXIS	38
S155	MOVDX	MOTION DIRECTION OF SERVO AXIS: Y AXIS	38
S156	MOVDX	MOTION DIRECTION OF SERVO AXIS: Z AXIS	38
S157	MOVDX	MOTION DIRECTION OF SERVO AXIS: THE 4TH AXIS	38
S158~S159		reserve	38-38
S160		ENCODER wiring error: X	38
S161		ENCODER wiring error: Y	38
S162		ENCODER wiring error: Z	38
S163		ENCODER wiring error: 4 th	38
S164~S165		Reserve	
S166~S169	-	-	
S170		Status of back to 3rd home: X	38
S171		Status of back to 3rd home: Y	38
S172		Status of back to 3rd home: Z	38
S173		Status of back to 3rd home:4 th	38
S174~S175		Reserve	
S176		Status of back to 4th home: X	38
S177		Status of back to 4th home: Y	38
S178		Status of back to 3rd home: Z	38
S179		Status of back to 3rd home:4 th	38
S180~S181		Reserve	
S182		Servo ABS home ready: X (0:not yet,1: Done)	38
S183		Servo ABS home ready: Y (0:not yet,1: Done)	38
S184		Servo ABS home ready: Z (0:not yet,1: Done)	38
S185		Servo ABS home ready: 4 th (0:not yet,1: Done)	39
S186~S187		Reserve	
S188~S200	-	-	
S201	AETFX	Enter into Absolute Encoder Data Transmitting Mode: X Axis	39
S202	AETFY	Enter into Absolute Encoder Data Transmitting Mode: Y Axis	39
S203	AETFZ	Enter into Absolute Encoder Data Transmitting Mode: Z Axis	39
S204	AETF4	Enter into Absolute Encoder Data Transmitting Mode:4th Axis	39
S205~S206		Reserve	
S207	AETFRX	Absolute Encoder Data Transmitting: X Axis	39
S208	AETFRY	Absolute Encoder Data Transmitting: Y Axis	39
S209	AETFRZ	Absolute Encoder Data Transmitting: Z Axis	39
S210	AETFR4	Absolute Encoder Data Transmitting:4th Axis	39
S211~S212		Reserve	
S213	AERSTX	Absolute Encoder Reset: X Axis	39
S214	AERSTY	Absolute Encoder Reset:Y Axis	39
S215	AERSTZ	Absolute Encoder Reset:Z Axis	39
S216	AERST4	Absolute Encoder Reset:4th Axis	39
S217~S218		Reserve	
S219		Servo ABS coordinate update complete: X	39
S220		Servo ABS coordinate update complete: Y	39
S221		Servo ABS coordinate update complete: Z	39
S222		Servo ABS coordinate update complete: 4th	39
S223~S224		Reserve	

BIT #	SYMBOL	DESCRIPTION	PAGE
S225		Servo ABS home update complete: X	39
S226		Servo ABS home update complete: Y	39
S227		Servo ABS home update complete: Z	39
S228		Servo ABS home update complete: 4 th	39
S229~S230		Reserve	
S231		Encoder value cleared: X	39
S232		Encoder value cleared: Y	39
S233		Encoder value cleared: Z	39
S234		Encoder value cleared: 4th	39
S235~S236		reserve	
S237		Encoder value cleared: 1st SP	39
S238		Encoder value cleared: 2nd SP	39
S239		Encoder value cleared: 3rd SP	39
S240		Servo following lag value over parameter 2 value alarm: X	39
S241		Servo following lag value over parameter 3 value alarm: Y	39
S242		Servo following lag value over parameter 4 value alarm: Z	39
S243		Servo following lag value over parameter 5 value alarm: 4 th	39
S244~S245		Reserve	
S246		ERROR COUNTER over position alarm: X	40
S247		ERROR COUNTER over position alarm: Y	40
S248		ERROR COUNTER over position alarm: Z	40
S249		ERROR COUNTER over position alarm: 4th	40
S250~S251		reserve	
S252~S280		Non	
S281		X M-II servo activate status	40
S282		Y M-II servo activate status	40
S283		Z M-II servo activate status	40
S284		4 th M-II servo activate status	40
S285~S286		reserve	
S287		1st SPM-II servo activate status	40
S288		2nd SPM-II servo activate status	40
S289		3rd SPM-II servo activate status	40
S290		Non	
S291		X M-II Servo drive power status	40
S292		Y M-II Servo drive power status	40
S293		Z M-II Servo drive power status	40
S294		4 th M-II Servo drive power status	40
S295~S296		reserve	
S297		1st SP M-II Servo drive power status	40
S298		2nd SP M-II Servo drive power status	4040
S299		3rd SP M-II Servo drive power status	40
S300		Non	
S301		X M-II torque monitoring status	40
S302		Y M-II torque monitoring status	40
S303		Z M-II torque monitoring status	40
S304		4 th M-II torque monitoring status	40
S305~S306		reserve	
S307		1st SPM-II torque monitoring status	40
S308		2nd SPM-II torque monitoring status	40
S309		3rd SPM-II torque monitoring status	40
S310~S511		Non	

2.3 Register definition

REGISTER

BIT #	SYMBOL	DESCRIPTION	PAGE
R001	M_CODE	M CODE	41
R002	S_CODE	S CODE	41
R003	T_CODE	T CODE	41
R004	SPAS	ACTUAL ROTATION SPEED OF THE SPINDLE	41
R005	S2_CODE	2nd spindle rotational speed command	41
R006	S2AS	2nd Spindle Actual Speed	41
R007	S3_CODE	3rd spindle rotational speed command	41
R008	S3AS	3rd Spindle Actual Speed	41
R009~R012	-	-	
R013	OPMDOE	MODE SELECTION 1 : EDIT , 2 : MEM , 3 : MDI , 4 : JOG , 5 : INCJOG , 6 : MPG , 7 : HOME	41
R014	INCFED	MPG RATE 2: x10, 3: x100, OTHERS: x1 INCREMENTAL JOG OVERRIDE 2: x10, 3: x100, 4 : x1000, OTHERS: x1	42
R015	SPDOV	ROTATION SPEED OVERRIDE OF THE SPINDLE 0 ~ 12 REPRESENT 0% ~ 120%, RESPECTIVELY; OTHERS: SET VALUE x 0.01	42
R016	FEEDOV	CUTTING OVERRIDE 0 ~ 20 REPRESENT 0% ~ 200%, RESPECTIVELY; OTHERS: SET VALUE x 0.001	42
R017	JOGOV	JOG OVERRIDE 0 ~ 20 REPRESENT 0% ~ 200%, RESPECTIVELY; OTHERS: SET VALUE x 0.001	43
R018	RTOV	RAPID TRAVERSE OVERRIDE 0, 1: F0, 2: 25%, 3: 50% ~ 4: 100%; OTHERS: SET VALUE x 0.001	43
R019	S2OV	2nd Spindle Rotating Mode Override 0 ~ 12 REPRESENT 0% ~ 120%, RESPECTIVELY; OTHERS: SET VALUE x 0.01	42
R020	S3OV	3rd Spindle Rotating Mode Override 0 ~ 12 REPRESENT 0% ~ 120%, RESPECTIVELY; OTHERS: SET VALUE x 0.01	42
R021	PMCF	OVERRIDE OF PMC AXIS, UNIT: mm/min.	44
R022	PMCC	PMC AXIS CONTROL	44
R023	-	-	
R024	PMCXMM	MOTION COMMAND OF PMC AXIS: X AXIS, mm part	44
R025	PMCXUM	MOTION COMMAND OF PMC AXIS: X AXIS, μ m part	44
R026	PMCYMM	MOTION COMMAND OF PMC AXIS: Y AXIS, mm part	44
R027	PMCYUM	MOTION COMMAND OF PMC AXIS: Y AXIS, μ m part	44
R028	PM CZMM	MOTION COMMAND OF PMC AXIS: Z AXIS, mm part	44
R029	PM CZUM	MOTION COMMAND OF PMC AXIS: Z AXIS, μ m part	44
R030	PMC4MM	PMC Function of 4th-Axis Command Amount, Unit=mm	44
R031	PMC4UM	PMC Function of 4th-Axis Command Amount, Unit= μ m	44
R032~R035		reserve	
R036		PMC axis rapid locating % (OVERRIDE) value 0、1 : F0 , 2 : 25% , 3 : 50% , 4 : 100% , other: value * 0.01	44
R037		PMC axis cutting feed rate % (OVERRIDE) value 0 ~ 20 means 0% ~ 200%, others: value * 0.001	44
R038~R039	-	-	
R040	OPMES1	PLC ALARM	45
R041	OPMES2	PLC ALARM	45
R042	OPMES3	PLC ALARM	45
R043	OPMES4	PLC ALARM	

BIT #	SYMBOL	DESCRIPTION	PAGE
R044	OPMES5	PLC ALARM	45
R045	OPMES6	PLC ALARM	45
R046~R049	-	-	
R050		1st set analog voltage detection value	45
R051		2nd set analog voltage detection value	45
R052		3rd set analog voltage detection value	45
R053		4th set analog voltage detection value	45
R054		5th set analog voltage detection value	45
R055		6th set analog voltage detection value	45
R056		7th set analog voltage detection value	45
R057		8th set analog voltage detection value	45
R058		PLC Open file name	45
R059	-	-	
R060	PLCFN	PLC WINDOW FUNCTION	45
R061	PLCSF1	PLC WINDOW FUNCTION NO.1	45
R062	PLCSF2	PLC WINDOW FUNCTION NO.2	45
R063	PLCD1	PLC WINDOW READ/WRITE VALUE 1	45
R064	PLCD2	PLC WINDOW READ/WRITE VALUE 2	45
R065	PLCD3	PLC WINDOW READ/WRITE VALUE 3	45
R066	PLCD4	PLC WINDOW READ/WRITE VALUE 4	45
R067	PLCD5	PLC WINDOW READ/WRITE VALUE 5	45
R068	PLCD6	PLC WINDOW READ/WRITE VALUE 6	46
R069	PLCD7	PLC WINDOW READ/WRITE VALUE 7	46
R070	PLCD8	PLC WINDOW READ/WRITE VALUE 8	46
R071	PLCD9	PLC WINDOW READ/WRITE VALUE 9	46
R072	PLCD10	PLC WINDOW READ/WRITE VALUE 10	46
R073	PLCD11	PLC WINDOW READ/WRITE VALUE 11	46
R074	PLCD12	PLC WINDOW READ/WRITE VALUE 12	46
R075~R080		Non	
R081		MPG ratio select: Y 2 : x10 , 3 : x100, other values: x1 incremental jog value 2 : x10 , 3 : x100 , 4 : x1000, other values: x1	46
R082		MPG ratio select: Z 2 : x10 , 3 : x100, other values: x1 incremental jog value 2 : x10 , 3 : x100 , 4 : x1000, other values: x1	46
R083		MPG ratio select: 4th 2 : x10 , 3 : x100, other values: x1 incremental jog value 2 : x10 , 3 : x100 , 4 : x1000, other values: x1	46
R084~R085		reserve	
R085~R089		Non	
R090		Each axis jog feedrate (OVERRIDE) value: X 0 ~ 20 means 0% ~ 200%, other values: * 0.001	46
R091		Each axis jog feedrate (OVERRIDE) value: Y 0 ~ 20 means 0% ~ 200%, other values: * 0.001	46
R092		Each axis jog feedrate (OVERRIDE) value: Z 0 ~ 20 means 0% ~ 200%, other values: * 0.001	46
R093		Each axis jog feedrate (OVERRIDE) value: 4 th 0 ~ 20 means 0% ~ 200%, other values: * 0.001	46
R094~R095		reserve	
R096~R100		Non	
R101		X M-II torque %	47
R102		Y M-II torque %	47
R103		Z M-II torque %	47
R104		4 th M-II torque %	47
R105~R106		reserve	
R107		1st SP M-II torque %	47
R108		2nd SP M-II torque %	47
R109		3rd SP M-II torque %	47

BIT #	SYMBOL	DESCRIPTION	PAGE
R110		PLC axis compensation X absolute (Pulse)	47
R111		PLC axis compensation Y absolute (Pulse)	47
R112		PLC axis compensation Z absolute (Pulse)	47
R113		PLC axis compensation 4th absolute (Pulse)	47
R114~R115		reserve	
R116~R239		Non	
R240~R255		\$2000~\$2015 value	47-47

2.4 C Bits Description

C Bit 000	Cycle Start
Description :	<p>Assumed the system is under MEM or MDI mode. When the signal changes from OFF to On, the system will be ready to be 【Cycle Start】 condition. Meanwhile, the S BIT 000 signal will be set to ON in order to provide LADDER to enable work light ON function during machine running. On the other hand, assumed system is in 【F-HOLD】 or 【B-STOP】 condition, the S BIT 000 will be set to OFF in order to provide LADDER to enable work light OFF function during machine stop. However, this signal will not be accepted by the system under the below three conditions:</p> <ol style="list-style-type: none"> System is not under MEM or MDI mode. System is in 【NC NOT Ready】 or 【Cycle Start】 condition. System alarm occurs.

C Bit 001	Feed Hold
Description :	<p>Assumed the system is in MEM or MDI mode and also in 【NC Ready】 conditions. When this signal is ON, the system will be in 【F-HOLD】 condition. Meanwhile, the system will set S BIT 000 signal to OFF in order to provide LADDER to enable work light OFF function during machine running. And also, to set S BIT 001 signal to ON in order to provide LADDER to enable work light ON function during machine stop. But, please notice that this signal is disabled (ineffective) for PMC axis function under JOG or RAPID mode.</p>

C Bit 003	Prog Protect
Description :	When this signal is set to ON, part program editing is prohibited.

C Bit 004	Manual Return
Description :	<p>Assumed NC is under MEM or MDI mode. If switching to JOG or MPG mode during program executing and also manual moves the machine away from the original program interrupting position, user can have the following two selections to continue the unfinished command:</p> <ol style="list-style-type: none"> Manual Return: Moving the machine back to the original program interrupting position first and then to continue the unfinished commanding. Continue the unfinished commanding from the current position. But, there will be an OFFSET amount of coordinate.

C Bit 006	+X Axis Direction
C Bit 007	-X Axis Direction
C Bit 008	+Y Axis Direction
C Bit 009	-Y Axis Direction
C Bit 010	+Z Axis Direction
C Bit 011	-Z Axis Direction
C Bit 012	+4 Axis Direction
C Bit 013	-4 Axis Direction

Description :	<p>These signals are selection commanding of system relative axis direction. There are three corresponding motions under each mode:</p> <ol style="list-style-type: none"> JOG Mode: When axis direction signal is ON, the system will send out commanding signal to the designated axis direction in JOG speed until the signal is OFF. RAPID Mode:
----------------------	--

- When axis direction signal is ON, the system will send out commanding signal to the designated axis direction in RAPID speed until the signal is OFF.
- c. HOME:
When axis direction signal changes from OFF to ON, it starts moving back to HOME.

C Bit 016	Handle X Axis
C Bit 017	Handle Y Axis
C Bit 018	Handle Z Axis
C Bit 019	Handle 4th Axis

Description : These signals are used under MPG mode, which are to indicate the present select servo axis. For example, if C BIT 016 signal is ON, it indicates that the present MPG axis direction is X axis. So, turning the MPG rotary switch will moving the servo axis toward X axis.
HX : X Axis MPG Feed
HY : Y Axis MPG Feed
HZ : Z Axis MPG Feed
H4 : 4th Axis MPG Feed

C Bit 020	MPG Dry Run
------------------	--------------------

Description : Assumed the NC is in MEM or MDI mode. When this signal is ON, MPG is as feedrate control. So, when operator uses MPG, the axis is moving in original feedrate, otherwise, stop.

C Bit 021	Wake up the screen saver signal
------------------	--

Description : The signal which is used by PLC to notify system stopping screen saver and recount start-time.

C Bit 023	Rapid
------------------	--------------

Description : Assumed NC is in JOG mode. If RT signal is ON, feedrate becomes rapidly speed, which is equal to RAPID mode. So, operator can apply the same principle in HOME mode.

C Bit 031	X Axis Home DOG Signal
C Bit 032	Y Axis Home DOG Signal
C Bit 033	Z Axis Home DOG Signal
C Bit 034	4th Axis Home DOG Signal

Description : To notify NC the present HOME DOG signal.
Remark: When Parameter # 0175 is 1 and when HOME DOG uses REMOTE key-in point, this signal is enabled.

C Bit 036	Emergency Stop
------------------	-----------------------

Description : When this signal is ON, the system is in RESET condition and all motions stop, which means the system condition, is NOT READY.

C Bit 037	External Reset
------------------	-----------------------

Description : System outer RESET signal which is the same function as pressing RESET bottom.

C Bit 038

M, S, T Finish


Description :

Assumed NC is in the MEM or MDI mode. When the program executes M code interpretation, the content of M Code will be sent by REG 1. At the same time, it will send out M Code Read (MF) signal.

When LADDER finishes executing the related M Code and replies it back to M · S · T Finish (FIN) signal, the signal will inform the system that the executing of M code is completed.

Correct order is as following:

M CODE INTERPREATION



- When executing M77, 77 will be entered into REG 1.
- Assumed M Code and motion command are in the same BLOCK. If want M Code to execute its command after motion command is completed, then m code must coordinate with Distribution End (DEN) command under LADDER control.
- M00, M01, M02, M30, M98, M99 has no such simultaneous motion.

C Bit 040

Single Block

Description :

Assumed NC is in auto-executing condition of MEM mode. If this signal is ON, the system will stop after a BLOCK of program is finish executing. But, if STL signal in OFF and system condition is B_STOP, then NC will start executing the next BLOCK of program after Cycle Start (ST) signal is ON.

C Bit 041

Optional Block Skip

Description :

Assumed NC is in auto-executing of MEM mode. If there is a such symbol, “/”, in a program, any key-in after this symbol to EOB will be neglected.

C Bit 042

Dry Run

Description :

Assumed NC is in MEM or MDI mode. If this signal is ON, program will be executed under the below feedrate :

G00 : When RT is ON = RAPID feed.

When RT is OFF =JOG feed.

G01 : JOG feed.

C Bit 043

Machine Lock

Description :

Assumed NC is under manual and auto modes, all moving command will NOT send to position control servo system. But, software interpolation value is still executed which means that program coordinate will still be renewed.

C Bit 044

Optional Stop

Description :

Assumed this signal is ON. If program executing reaches M01, system will be paused and STL signal is OFF. This implies that the system will continue executing programs after pressing Cycle Start (ST) bottom.

C Bit 045

Z Axis Cancel

Description :

Assumed NC is in manual and auto modes. If this signal is ON, Z axis will be locked, which means that Z axis moving command will NOT be sent to loop control servo system. But, Z axis software interpolation value is still executing. So, program coordinate will be renewed.

C Bit 046

Auxiliary Function Lock

Description :

Assumed this signal is ON. When M, S and T codes are executing, content code and reading signal are not sending out which means not to execute M, S and T simultaneously.

C Bit 049

4th Axis Neglect

Description :

When this signal is ON, the corresponding axis commanding will NOT be executed. For example: Enable 4th axis neglect which means when executing part program G01 X10 Z10 C10, C10 commanding will be neglected.

C Bit 050

+X Axis OT

C Bit 051

-X Axis OT

C Bit 052

+Y Axis OT

C Bit 053

-Y Axis OT

C Bit 054

+Z Axis OT

C Bit 055

-Z Axis OT

C Bit 056

+4th Axis OT


C Bit 057

-4th Axis OT

Description :

Each axis sends out the machine hardware-traveling signal in order to inform the system to display it. These C Bits are PLC travel limit signals for each axis. When these C BIT signals are on, the system alarm will be enabled. So the servo axis can only move toward the opposite direction. The following list is the definition for each C BIT:

C BIT	Definition
50	X Axis +ive direction PLC Travel Limit
51	X Axis -ive direction PLC Travel Limit
52	Y Axis +ive direction PLC Travel Limit
53	Y Axis -ive direction PLC Travel Limit
54	Z Axis +ive direction PLC Travel Limit
55	Z Axis -ive direction PLC Travel Limit
56	4th Axis +ive direction PLC Travel Limit
57	4th Axis -ive direction PLC Travel Limit



The following list is the warning message of PLC travel limit:

WARNING ID	Warning Message
------------	-----------------

OP 6001	X AXIS OVER PLC TRAVEL LIMIT (+)
OP 6002	X AXIS OVER PLC TRAVEL LIMIT (-)
OP 6003	Y AXIS OVER PLC TRAVEL LIMIT (+)
OP 6004	Y AXIS OVER PLC TRAVEL LIMIT (-)
OP 6005	Z AXIS OVER PLC TRAVEL LIMIT (+)
OP 6006	Z AXIS OVER PLC TRAVEL LIMIT (-)
OP 6007	4TH AXIS OVER PLC TRAVEL LIMIT (+)
OP 6008	4TH AXIS OVER PLC TRAVEL LIMIT (-)

Warning/Alarm Cancel:

After the above system warning message is enabled, need to wait until the servo moves toward the opposite direction. And also, the corresponding C BIT changes from ON to OFF; the warning message will be removed automatically.

In JOG/RAPID or MPG mode, if the system warning message (OP 6001 ~ OP 6008) of PLC travel limit occurs, it is okay not to remove the warning message. Just moving directly to the reverse direction away from where the warning message occurs. After getting away from the software limitation range, the warning message will be removed.

Under mode of MEM, MDI or HOME, if the system warning message (OP 6001 ~ OP 6008) of PLC travel limit occurs, OP will send out the warning message. In this case, users must press "RESET" to reset the system.

ALARM ID	Warning Message
OP 1020	OVER PLC TRAVEL LIMIT

C Bit 059	X Axis Interlock
C Bit 060	Y Axis Interlock
C Bit 061	Z Axis Interlock
C Bit 062	4th Axis Interlock

Description : When the corresponding axis is ON, the axis will NOT move. But, the coordinate value will be renewed.

C Bit 064	PLC Window Read/Write Signal
C Bit 065	PLC Commanding Signal

Description : Please refer to 2.7 PLC Window structure for a detailed description.

C Bit 066	X Axis: Select Axis Direction Signal of Handle INT
C Bit 067	Y Axis: Select Axis Direction Signal of Handle INT
C Bit 068	Z Axis: Select Axis Direction Signal of Handle INT
C Bit 069	4th Axis: Select Axis Direction Signal of Handle INT

Description : Assumed NC is under MEM mode. User can use Manual Handle Interrupt function to increase/decrease tool shifting amount in order to modify path. However, before using this function, user must set Handle Interrupt axis selection signal and MPG ratio (R REGISTER 014). Then, user can use MPG to modify tool position. However, absolute coordinate will NOT be modified by Handle Interrupt; there will be an OFFSET amount of the initial program path and afterward tool path. This OFFSET amount will be cleared only by using manual reference point return.

C Bit 072	1st SP JOG
C Bit 073	2nd SP JOG
C Bit 074	3rd SP JOG

Description: When C bit ON, controller can release original SP RPM command, switch to the JOG speed which defined by parameter. SP will not control by Override during C bit ON, if C bit OFF, it comes to normal.

SP	Related parameter
1st SP	P 1121
2nd SP	P 1076
3rd SP	P 1077

C Bit 075	X Axis Servo Alarm
C Bit 076	Y Axis Servo Alarm
C Bit 077	Z Axis Servo Alarm
C Bit 078	4th Axis Servo Alarm

Description : This signal will notify system if motor driver of any axis has any extraordinary phenomenon.

C Bit 079	PLC Open file
------------------	----------------------

Description:

1. C079 = ON , Enter PLC Open file .
2. activate cycle start C000(under MEM) , NC get file name from R058(formula: O+4 number from R058= Oxxxx)
3. If C079 OFF during process, it will not affect the file selection. It will directly go to NC ready.

C Bit 082	1st Spindle CW
C Bit 083	1st Spindle CCW
C Bit 087	2ed Spindle CW
C Bit 088	2ed Spindle CCW
C Bit 080	3rd Spindle CW
C Bit 081	3rd Spindle CCW

Description : When C bit of clockwise is ON, spindle rotates in clockwise direction.
When C bit of counter-clockwise is ON, spindle rotates in counter-clockwise direction.
If the above two are both OFF, spindle stops rotating.
Note 1: The above C bits are enabled in normal spindle speed control mode, which is spindle clockwise, counter-clockwise and stop.
Note 2: If the spindle CW and CCW are controlled by inventor's CW and CCW connection point control, the above signals will only notify NC that the current spindle is in CW or CCW condition.

C Bit 082	1st SP CW signal
C Bit 083	1st SP CCW signal
C Bit 087	2nd SP CW signal
C Bit 088	2nd SP CCW signal
C Bit 080	3rd SP CW signal
C Bit 081	3rd SP CCW signal

Description:

When CW C bit= ON, Drive the SP CW

When CCW C bit= ON, Drive the SP CCW

Both are OFF, And then SP stops.

Note1: These C bit only valid under standard speed control mode, e.g. CW, CCW, and stop.

Note2: If the SP CW/CCW controlled by inverter's terminal, and then these signal only use for informing NC controller the SP command status.

C Bit 085	Spindle Orientation
------------------	----------------------------

Description :

This signal will be enabled when spindle orientation is decided by encoder and in JOG mode. Please notice that if Parameter # 0019, 1055, 1056 is not set for orientation position, spindle will be re-orientated again.

C Bit 086	Spindle Command Type Changes to Pulse Type Under Spindle Orientation and Rigid Tapping Modes
------------------	---

Description :

Signal of Spindle is in orientation mode and also finishes orientating.

C Bit 089	X Axis Mirror Image
C Bit 090	Y Axis Servo Alarm
C Bit 091	Z Axis Servo Alarm
C Bit 092	4th Axis Servo Alarm

Description :

When mirror image signal is ON under Auto mode, this axis will be in reverse moving direction.

C Bit 097	1st Spindle Gear #1
C Bit 098	1st Spindle Gear #2
C Bit 099	1st Spindle Gear #3
C Bit 116	2nd Spindle Gear #1
C Bit 117	2nd Spindle Gear #2
C Bit 118	2nd Spindle Gear #3
C Bit 121	3rd Spindle Gear #1
C Bit 122	3rd Spindle Gear #2
C Bit 123	3rd Spindle Gear #3

Description :

Setting the gear ratio between spindle motor and spindle. Every spindle provides 4sets of parameter # of gear ratio. The system default is to use the 4th set of gear ratio. If user wants to modify other sets of gear ratio, user can select the suitable gear ratio from each spindle's corresponding gear ratio C bit.

Spindle	Gear	C bit	# of Motor Tooth	# of Spindle Tooth
1 st Spindle	1	C97=ON	Parameter # 0049	Parameter # 0050
	2	C98=ON	Parameter # 0051	Parameter # 0052
	3	C99=ON	Parameter # 0178	Parameter # 0179
	4	C97,98,99=OFF	Parameter # 0181	Parameter # 0182
2 nd Spindle	1	C116=ON	Parameter # 0664	Parameter # 0665
	2	C117=ON	Parameter # 0666	Parameter # 0667
	3	C118=ON	Parameter # 0668	Parameter # 0669
	4	C116,117,118=OFF	Parameter # 0670	Parameter # 0671
3 rd Spindle	1	C121=ON	Parameter # 0672	Parameter # 0673
	2	C122=ON	Parameter # 0674	Parameter # 0675
	3	C123=ON	Parameter # 0676	Parameter # 0677
	4	C121,122,123=OFF	Parameter # 0678	Parameter # 0679

C Bit 100	MACRO Variable \$200
C Bit 101	MACRO Variable \$201
C Bit 102	MACRO Variable \$202
C Bit 103	MACRO Variable \$203
C Bit 104	MACRO Variable \$204
C Bit 105	MACRO Variable \$205
C Bit 106	MACRO Variable \$206
C Bit 107	MACRO Variable \$207
C Bit 108	MACRO Variable \$208
C Bit 109	MACRO Variable \$209
C Bit 110	MACRO Variable \$210
C Bit 111	MACRO Variable \$211
C Bit 112	MACRO Variable \$212
C Bit 113	MACRO Variable \$213
C Bit 114	MACRO Variable \$214
C Bit 115	MACRO Variable \$215

Description : These signals are the same as the MACRO system variables \$120~\$135. They provide input points of MACRO for LADDER. Example: If set UI0 to ON in LADDER, then \$120 will be 1 in MACRO. These MACRO input point signals will provide order determination for MACRO.

C Bit 119	ZP2Z Down Cancel
------------------	-------------------------

Description : When this signal is ON, the local Z axis motion will be inhibited after the 2nd reference point. This signal is to protect tool exchanging and to prevent tool collusion after tool magazine moves toward left.

C Bit 120	PMC Axis Go
------------------	--------------------

Description : Setting this signal to ON in order to enable PMC axis moving command under the condition of JOG mode and when all PMC axis moving data are ready.

C Bit 124	Disable Signal in Rigid Tapping
------------------	--


Description : Milling disables rigid tapping.

C Bit 125	Enable Signal in Rigid Tapping
------------------	---------------------------------------

Description : Rigid tapping (M29). When this signal is on, Z axis moving amount will follow the spindle encoder's pulse amount. So user must use M28 to delete the signal when rigid tapping is done in order to prevent any wrong motion from the system.

C Bit 126	Enable Signal of Spindle Motor Rotates in Gear-Shifting Speed
Description :	Milling spindle changes rotational speed.
C Bit 127	Spindle Gear-Shifting Complete Signal
Description :	Milling gear-shifting completed signal.
C Bit 130	Servo detach signal: X
C Bit 131	Servo detach signal : Y
C Bit 132	Servo detach signal : Z
C Bit 133	Servo detach signal : 4th
Description:	If the signal =ON, it means this axis was detached. This controlled by M code to enable and disable, the M code customize by user.
C Bit 134	Clear Working Piece Number
Description :	When NC reads M02, M30, the reading M code and parameter 89 are the same; NC will add the working piece by 1. If the working piece number is larger than or equal to that of the maximum working piece setting, NC will send out S134 to inform PLC to do the corresponding motion. When PLC sends out C 134, NC will clear the working piece number to zero.
C Bit 135	PLC axis RESET
Description:	If this signal =ON, press RESET, PLC axes will stop. If it is OFF, PLC axes will continue till program end when RESET pressed.
C Bit 138	Activate 1ST Software restricted area
C Bit 139	Activate 2ND Software restricted area
Description:	Activate Software restricted area
C Bit 140	2nd +X Axis Software Limit Choice
C Bit 141	2nd -X Axis Software Limit Choice
C Bit 142	2nd +Y Axis Software Limit Choice
C Bit 143	2nd -Y Axis Software Limit Choice
C Bit 144	2nd +Z Axis Software Limit Choice
C Bit 145	2nd -Y Axis Software Limit Choice
C Bit 146	2nd +4th Axis Software Limit Choice
C Bit 147	2nd -4th Axis Software Limit Choice
Description :	<p>1st software limit: Using parameter 1006 ~ 1013 to set the limit. After executing zero return procedure, the parameter setting value will be enabled. The booting default value of +ive direction is 99999.999mm and the booting default value of -ive direction is -99999.999mm.</p> <p>2nd software limit: Using parameter 1034 ~ 1041 to set the limit. After executing zero return procedure, the parameter setting value will be enabled. The booting default value of +ive direction is 99999.999mm and the booting default value of -ive direction is -99999.999mm.</p> <p>The corresponding C BIT of each axis can exchange any value between the 1st software limit and the 2nd software limit. This means that only one set/combination can be enabled at one time within the limit of the 1st software limitation and the 2nd software limitation.</p>

Software Limit	C BIT
X axis +ive direction software limit	C140 : When OFF, use 1 st software limit; When ON, using 2 nd software limit.
X axis -ive direction software limit	C141 : When OFF, use 1 st software limit; When ON, using 2 nd software limit.
Y axis +ive direction software limit	C142 : When OFF, use 1 st software limit; When ON, using 2 nd software limit.
Y axis -ive direction software limit	C143 : When OFF, use 1 st software limit; When ON, using 2 nd software limit.
Z axis +ive direction software limit	C144 : When OFF, use 1 st software limit; When ON, using 2 nd software limit.
Z axis -ive direction software limit	C145 : When OFF, use 1 st software limit; When ON, using 2 nd software limit.
4th axis +ive direction software limit	C146 : When OFF, use 1 st software limit; When ON, using 2 nd software limit.
4th axis -ive direction software limit	C147 : When OFF, use 1 st software limit; When ON, using 2 nd software limit.



G22 travel limit: Able to designated the embedded travel checking range. For Internal and external prohibit area, use parameter 0071 to set the prohibit area for both internal and external area. (0 means external prohibit area; 1 mean internal prohibit area).

C Bit 181	Servo axes hide : X
C Bit 182	Servo axes hide : Y
C Bit 183	Servo axes hide : Z
C Bit 184	Servo axes hide : 4 th

Hide the servo information from the user interface, but the axis still functional.

Description:

C Bit 187	Servo axis synchronize activate : X
C Bit 188	Servo axis synchronize activate : Y

C Bit 189	Servo axis synchronize activate : Z
C Bit 190	Servo axis synchronize activate : 4th

Description:

When C Bit= ON, it means the related servo axis in synchronal mode. C bit =OFF, cancel synchronize.

C Bit 201	Absolute encoder Reset Ready Signal: X Axis
C Bit 202	Absolute encoder Reset Ready Signal: Y Axis
C Bit 203	Absolute encoder Reset Ready Signal: Z Axis
C Bit 204	Absolute encoder Reset Ready Signal:4th Axis

Description :

When LADDER finishes absolute encoder zero return, this signal needs to be sent out to notify NC that.

C Bit 207	Absolute Encoder Data Ready Signal: X Axis
C Bit 208	Absolute Encoder Data Ready Signal: Y Axis
C Bit 209	Absolute Encoder Data Ready Signal: Z Axis
C Bit 210	Absolute Encoder Data Ready Signal:4th Axis

Description :

LADDER will notify NC when driver enters into ABS transmitting mode and driver data are ready.

C Bit 213	Absolute Encoder Data Bit 0Transmitting Signal : X Axis
C Bit 214	Absolute Encoder Data Bit 0Transmitting Signal : Y Axis
C Bit 215	Absolute Encoder Data Bit 0Transmitting Signal : Z Axis
C Bit 216	Absolute Encoder Data Bit 0Transmitting Signal : 4th Axis

Description :

Assumed absolute encoder data reading is sent by serial transmitting. Also, assumed 2 bits of Encoder will be transmitted every time. So, when this bit is ON, it indicates that the signal of transmitting 2 bits data from driver to NC is 1.

C Bit 219	Absolute Encoder Bit 1 Transmit: X Axis
C Bit 220	Absolute Encoder Bit 1 Transmit: Y Axis
C Bit 221	Absolute Encoder Bit 1 Transmit: Z Axis
C Bit 222	Absolute Encoder Bit 1 Transmit: 4th Axis

Description :

Assumed absolute encoder data reading is sent by serial transmitting. Also, assumed 2 bits of Encoder will be transmitted every time. So, when this bit is ON, it indicates that the signal of transmitting 2 bits data from driver to NC is 1.

C Bit 231	Clear encoder value: X
C Bit 232	Clear encoder value: Y
C Bit 233	Clear encoder value: Z
C Bit 234	Clear encoder value: 4th
C Bit 237	Clear encoder value: 1st SP
C Bit 238	Clear encoder value: 2nd SP
C Bit 239	Clear encoder value: 3rd SP

Description:

This C bit =ON= Clear related axis encoder value.

C Bit 241	PMC/INT switch : X-axis (0:INT,1:PMC)
C Bit 242	PMC/INT switch : X-axis (0:INT,1:PMC)
C Bit 243	PMC/INT switch : X-axis (0:INT,1:PMC)
C Bit 244	PMC/INT switch : X-axis (0:INT,1:PMC)

0 : from NC , 1 : from PMC ◦

Description:

C Bit 247	Servo axis name switch: X
C Bit 248	Servo axis name switch: Y
C Bit 249	Servo axis name switch: Z
C Bit 250	Servo axis name switch: 4 th

This C Bit= ON, it means the related axis turns into command name switch. If C bit =OFF, no name switch.

Description:

C Bit 253	Activate servo ABS coordinate update: X
C Bit 254	Activate servo ABS coordinate update: Y
C Bit 255	Activate servo ABS coordinate update: Z
C Bit 256	Activate servo ABS coordinate update: 4 th

These C Bit= ON, it will update the ABS coordinate to machine coordinate.

Description:

C Bit 259	Activate servo ABS home update: X
C Bit 260	Activate servo ABS home update: Y
C Bit 261	Activate servo ABS home update: Z
C Bit 262	Activate servo ABS home update: 4th

These C Bit=ON, it will set the current mechanical position to ABS home.

Description:

C Bit 281	X M-II communication switch
C Bit 282	Y M-II communication switch
C Bit 283	Z M-II communication switch
C Bit 284	4 th M-II communication switch
C Bit 287	1st SP M-II communication switch
C Bit 288	2nd SP M-II communication switch
C Bit 289	3rd SP M-II communication switch

When these C Bit=ON, it will activate the M- II Servo ON. When OFF, it will be M-II servo OFF.

Description:

2.5 S Bits description

S Bit 000	Cycle Start Light
------------------	--------------------------

Description : When the system accepts to enable "CYCLE START" key and enters into automatic executing condition, this signal is ON, which means the system is in the "Cycle Start" condition. This signal is OFF when the automatic executing completed or the system is in "FEED HOLD" condition.

S Bit 001	Feed Hold Light
------------------	------------------------

Description : When this signal is ON, it means the system is in "FEED HOLD" condition. So the system is in "Machine Stop" condition.

S Bit 002	Edit Mode Light
S Bit 003	MEM Mode Light
S Bit 004	MDI Mode Light
S Bit 005	JOG Mode Light
S Bit 006	INC JOG Mode Light
S Bit 007	MPG Mode Light
S Bit 008	Home Mode Light

Description : When these signals are ON, it means the system is in the relative operation mode condition.

S Bit 010	Preparation Completed
------------------	------------------------------

Description : When these signals are ON, the system is in "Preparation Complete" condition.

S Bit 011	MDI keyboard press signal
------------------	----------------------------------

Description :

1. The signal will be sent from system when pressing the bottom on MDI.
2. The signal notifies PLC to turn on LCD power and recount time to turn off LCD power.

S Bit 012	Manual Return status signal
------------------	------------------------------------

Description: When Manual Return enabled, C004=ON, this will be ON; When C004=OFF, this will be OFF.

S Bit 016	X 1st Axis Point Return End
S Bit 017	Y 1st Axis Point Return End
S Bit 018	Z 1st Axis Point Return End
S Bit 019	4th 1st Axis Point Return End

Description : When these signals are ON, it means the system relative axis completed the zero return procedure and stop at the zero point.

S Bit 020	X 2nd Axis Point Return End
S Bit 021	Y 2nd Axis Point Return End
S Bit 022	Z 2nd Axis Point Return End
S Bit 023	4th 2nd Axis Point Return End

Description : When these signals are ON, it means the system relative axis is completed the 2nd (or the 3rd, 4th) reference return procedure and stop at the 2nd (or 3rd, 4th) reference point.

S Bit 028	Warning																									
Description :	When system warning occurs, this signal will notify PLC. After cause is eliminated, system warning is off automatically and this signal is OFF.																									
S Bit 029	M Code Read																									
Description :	When executing to the M code, this signal is “ON” in order to provide LADDER to do M code executing until FIN signal replies back. Please refer to the description of M code end signal (C BIT 038).																									
S Bit 030	Distribution End Alarm																									
Description :	In MEM or MDI mode, when the moving command interpolation is completed, this signal will be sent out. So when M code and the moving G code are on the same BLOCK, please use this signal to control and to execute M code after moving G code. If do not use this signal, M code will be executed simultaneously with G code interpolation.																									
S Bit 031	Alarm																									
Description :	When the system alarm is on, this signal is ON.																									
S Bit 032	Reset																									
Description :	When the system receives the RESET command, this signal is ON. Remain one time scanning time in order for LADDER to reset.																									
S Bit 033	NC Ready																									
Description :	Assumed the controller’s power is on. After normally executing program, this signal will be ON.																									
S Bit 035	MPG x1000 Ratio Speeding																									
S Bit 036	MPG x1 Ratio Speeding																									
S Bit 037	MPG x10 Ratio Speeding																									
S Bit 038	MPG x100 Ratio Speeding																									
Description :	These four signals are used to indicate the current using MPG ratio. <table><tr><td>MPG Ratio</td><td>S035</td><td>S036</td><td>S037</td><td>S03</td></tr><tr><td>x1</td><td>0</td><td>1</td><td>0</td><td>0</td></tr><tr><td>x10</td><td>0</td><td>0</td><td>1</td><td>0</td></tr><tr><td>x100</td><td>0</td><td>0</td><td>0</td><td>1</td></tr><tr><td>x1000</td><td>1</td><td>0</td><td>0</td><td>0</td></tr></table>	MPG Ratio	S035	S036	S037	S03	x1	0	1	0	0	x10	0	0	1	0	x100	0	0	0	1	x1000	1	0	0	0
MPG Ratio	S035	S036	S037	S03																						
x1	0	1	0	0																						
x10	0	0	1	0																						
x100	0	0	0	1																						
x1000	1	0	0	0																						
S Bit 039	Program Restart																									
Description :	When system enters the Program Restart process, the state signal of Program Restart will be enable (S39=ON), and will be disable when the system is completed or leave the operational status of Program Restart.																									
S Bit 040	Single Block																									

Description : Conditional signal that is relative to single block (SBK).

S Bit 041

Optional Block Skip

Description : Conditional signal that is relative to Optional Block Skip (BDT) .

S Bit 042

Dry Run

Description : Conditional signal that is relative to Dry Run (DRN).

S Bit 043

Machine Lock

Description : Conditional signal that is relative to Machine Lock (MLK) .

S Bit 044

Optional Stop

Description : Conditional signal that is relative to Optional Stop (OPS) .

S Bit 045

Rapid Traverse

Description : Conditional signal that is relative to Rapid Traverse (RT) .

S Bit 046

Z-Axis Neglect

Description : Conditional signal that is relative to Z Axis Cancel (ZNG) .

S Bit 047

Auxiliary Function Lock

Description : Conditional signal that is relative to Auxiliary Function Lock (AFL) .

S Bit 054

S CODE STROBE

S Bit 055

2nd Spindle S Code

S Bit 056

2nd Spindle S Code


When NC executes some S code, S054 is ON to notify the ladder to process the S code until PLC responds with the signal FIN.

S Bit 061

Z-Axis Neglect

Description :

ON/OFF control on the communication style software Panel will communicate with LADDER through this signal. For Z-AXIS NEGLECT key on the software Panel, ON/OFF control will communicate with LADDER through this signal. The timing procedure is as following:




S Bit 062

MPG Dry Run

Description :

ON/OFF control on the communication style software Panel will communicate with LADDER through this signal. For MPG Dry Run key on the software Panel, ON/OFF control will communicate with LADDER through this signal. The timing procedure is as following:




S Bit 063

Auxiliary Function Lock

Description :

ON/OFF control on the communication style software Panel will communicate with LADDER through this signal. For AUXILIARY FUNCTION LOCK key on the software Panel, ON/OFF control will communicate with LADDER through this signal. The timing procedure is as following:



S Bit 068**MPG Dry Run**


Description : Conditional signal that is relative to MPG Dry Run (MPGDNRN) .

S Bit 069**T Code Read**


Description : When executing to T code, this signal is ON in order to provide LADDER to do T code executing until FIN signal is sending back.

S Bit 071**Machine Lock**

Description : ON/OFF control on the communication style software Panel will communicate with LADDER through this signal. For Machine Lock key on the software Panel, ON/OFF control will communicate with LADDER through this signal. The timing procedure is as following:

**S Bit 072****Dry Run**

Description : ON/OFF control on the communication style software Panel will communicate with LADDER through this signal. For Dry Run key on the software Panel, ON/OFF control will communicate with LADDER through this signal. The timing procedure is as following:




S Bit 073

Optional Block Skip

Description :

ON/OFF control on the communication style software Panel will communicate with LADDER through this signal. For Optional Block Skip key on the software Panel, ON/OFF control will communicate with LADDER through this signal. The timing procedure is as following:




S Bit 074

Optional Stop

Description :

ON/OFF control on the communication style software Panel will communicate with LADDER through this signal. For Optional Stop key on the software Panel, ON/OFF control will communicate with LADDER through this signal. The timing procedure is as following:



S Bit 079

PLC WINDOW COMPLETED

Please refer to 2.7 PLC Window structure for a detailed description.

S Bit 080

M00 Read

S Bit 081

M01 Read

S Bit 082

M02 Read

S Bit 083

M30 Read

Description :

M00 : after interpreting as M00, this signal is ON (remain one time scanning time)
 M01 : after interpreting as M01, this signal is ON (remain one time scanning time)
 M02 : after interpreting as M02, this signal is ON (remain one time scanning time)
 M30 : after interpreting as M03, this signal is ON (remain one time scanning time)

S Bit 086

Orientation Finish

Description :

When spindle orientation is completed, this signal is ON. When PLC cancels the spindle orientation command (C85), this signal will become OFF.

S Bit 053	2nd Spindle Speed Arrival
S Bit 058	3rd Spindle Speed Arrival
S Bit 088	THE 1ST SPINDLE REACHES ROTATION SPEED

When the spindle speed reaches the expected speed, these will ON.

Following parameter can set the tolerance rage

SP	Parameter
1 ST SP	1054
2 ND SP	0298
3 RD SP	0881

S Bit 091	Not in Canned Cycle Mode
------------------	---------------------------------

Description : Assumed the system is in Canned Cycle mode. If this signal is OFF, effective G code of Group G09 is not 80. On the other hand, if the system is not under Canned Cycle mode and this signal is ON, then the effective G code of Group G09 is 80.

S Bit 052	2nd Spindle Zero Speed Arrival
S Bit 057	3rd Spindle Zero Speed Arrival
S Bit 092	THE 1ST SPINDLE REACHES ZERO SPEED

When the rotation speed of each spindle is lower than the value set by the parameters below, the system will send this signal to notify PLC.

The 1st spindle: Pr. 1063.

The 2nd spindle: Pr. 0299.

The 3rd spindle: Pr. 0882.

S Bit 093	Spindle Command Type Changes to Pulse Command in Spindle and Rigid Tapping Mode
------------------	--

Description : NC notifies PLC spindle to get ready to switch to the position control mode. Meanwhile, driver does the corresponding switch.

S Bit 094	Spindle Motor Speed when Gears are Switched
------------------	--

Description : This signal will be sent out when spindle reaches gear-shifting speed.

S Bit 100	MACRO Variable \$600
S Bit 101	MACRO Variable \$601
S Bit 102	MACRO Variable \$602
S Bit 103	MACRO Variable \$603
S Bit 104	MACRO Variable \$604
S Bit 105	MACRO Variable \$605
S Bit 106	MACRO Variable \$606
S Bit 109	MACRO Variable \$609
S Bit 112	MACRO Variable \$612
S Bit 113	MACRO Variable \$613
S Bit 114	MACRO Variable \$614
S Bit 115	MACRO Variable \$615

Description : These signals are the MACRO system variables \$600~\$615, which are MACRO outputs to LADDER point. Example: set \$600 as 1 in MACRO, then U00 will be ON in LADDER, which means that MACRO output signals will be used as external control for LADDER.

S Bit 120	PMC Axis Finish
Description :	This signal is ON when PMC axis moving is completed.

S Bit 128	Riding Tapping Mode
Description :	NC notifies PLC that whether or not NC is in rigid tapping mode.

S Bit 130	X Axis Moving
S Bit 131	Y Axis Moving
S Bit 132	Z Axis Moving
S Bit 133	4th Axis Moving

Description : Moving condition of each axis :
 ON : Moving ;
 OFF : Stop.

S Bit 134	Max Working Piece Arrival
------------------	----------------------------------

Description : When the number of working piece is greater than or equal to that of the maximum setting-working piece, S134 will be sent out to inform PLC. If setting the maximum working piece to zero, then this signal will not be sent out. PLC will use C134 to inform NC to clear working piece.

Application Description:
 Enter into user parameter to do function select and set parameter No. 12 as 1. When the working piece number reaches the setting working piece number, it will enter into the Feed Hole condition and send out warning message (Wrokpiece is full).
 At this time, user can do any needed motion. If there is no need to do any other motion, please press "Cycle Start" key directly. Then the working piece number will be cleared to zero automatically. Furthermore, it will start working automatically and counting working piece number from zero. If no need this function at all, and then set parameter No.12 as 0. Circulating work of working piece will not be affected.

01	Program Editing	0	11	Power Off Delay Time	5
02	Home Point Search Priority	1	12	Work Piece Alarm	1
03	Return Home Axis Priority	1	13		
04	Rapidly Moving 50%	0	14		
05	Total Number of Turret	0	15		
06	Safety Door	0	16		
07	Enforce Track Lubrication	0	17		
08	Lubricate ON Time	5	18		
09	Lubricate OFF Time	30	19		
10	Auto Power Off Function	1	20		

S Bit 138	Machine coordinate at 1ST Software restricted area (0:No,1:Yes)
S Bit 139	Machine coordinate at 2ND Software restricted area (0:No,1:Yes)

Description: Indicator for the Software restricted area:
 ON : IN Software restricted area
 OFF : NOT IN Software restricted area

S Bit 141	Fan 1 detection
S Bit 142	Fan 2 detection

Description: ON: fan failed
 OFF: fan normal.

S Bit 150	Request Signal of Spindle Gear-Shifting: 1st Gear
S Bit 151	Request Signal of Spindle Gear-Shifting: 2nd Gear
S Bit 152	Request Signal of Spindle Gear-Shifting: 3rd Gear
S Bit 153	Request Signal of Spindle Gear-Shifting: 4th Gear

Description : When S code is not below into the current gear range, System will use S Bit to notify PLC to execute gear shifting:
S Bit 150 : 1st spindle gear shifting signal ;
S Bit 151 : 2nd spindle gear shifting signal ;
S Bit 152 : 3rd spindle gear shifting signal ;
S Bit 153 : 4th spindle gear shifting signal ;
At this time, spindle output voltage remains the same.

S Bit 154	X Axis Moving Direction
S Bit 155	Y Axis Moving Direction
S Bit 156	Z Axis Moving Direction
S Bit 157	4th Axis Moving Direction
S Bit 158	5th Axis Moving Direction
S Bit 159	6th Axis Moving Direction

Description : These S BITs express the moving direction of each axis, when axis is at moving state.
ON : positive direction
OFF : negative direction

S Bit 160	ENCODER wiring error: X
S Bit 161	ENCODER wiring error: Y
S Bit 162	ENCODER wiring error: Z
S Bit 163	ENCODER wiring error: 4th

When ENCODER send alarm, this will ON °

Description:

Servo	Alarm
X	MOT4026
Y	MOT4087
Z	MOT4096
4 th	MOT4097

S Bit 170	Status of back to 3rd home :X
S Bit 171	Status of back to 3rd home :Y
S Bit 172	Status of back to 3rd home :Z
S Bit 173	Status of back to 3rd home :4th

When these signal ON, it means the axes had zero to the 3rd home and on 3rd home.

Description:

S Bit 176	Status of back to 4th home :X
S Bit 177	Status of back to 4th home :Y
S Bit 178	Status of back to 4th home :Z
S Bit 179	Status of back to 4th home :4th

Description: When these signal ON, it means the axes had zero to the 4th home and on 4th home.

S Bit 182	Servo ABS home ready X(0:not yet,1: Done)
S Bit 183	Servo ABS home ready Y(0:not yet,1: Done)
S Bit 184	Servo ABS home ready Z(0:not yet,1: Done)

S Bit 185	Servo ABS home ready 4th(0:not yet,1: Done)
Description:	When these=ON, means servo went ABS home.

S Bit 201	Enter into Absolute Encoder Data Transmitting Mode: X Axis
S Bit 202	Enter into Absolute Encoder Data Transmitting Mode: Y Axis
S Bit 203	Enter into Absolute Encoder Data Transmitting Mode: Z Axis
S Bit 204	Enter into Absolute Encoder Data Transmitting Mode:4th Axis
Description :	To use this signal to notify servo driver to enter into ABS transmitting mode.

S Bit 207	Absolute Encoder Data Transmitting: X Axis
S Bit 208	Absolute Encoder Data Transmitting: Y Axis
S Bit 209	Absolute Encoder Data Transmitting: Z Axis
S Bit 210	Absolute Encoder Data Transmitting:4th Axis
Description :	To use this signal to request ABS transmitting from servo driver.

S Bit 213	Absolute Encoder Reset: X Axis
S Bit 214	Absolute Encoder Reset: Y Axis
S Bit 215	Absolute Encoder Reset:Z Axis
S Bit 216	Absolute Encoder Reset:4th Axis
Description :	To use this signal to notify servo driver to eliminate absolute Encoder zero return motion.

S Bit 219	Servo ABS coordinate update complete: X
S Bit 220	Servo ABS coordinate update complete: Y
S Bit 221	Servo ABS coordinate update complete: Z
S Bit 222	Servo ABS coordinate update complete: 4th
Description:	ON: Servo ABS coordinate updated OFF: Servo ABS coordinates not update yet.

S Bit 225	Servo ABS home update complete: X
S Bit 226	Servo ABS home update complete: Y
S Bit 227	Servo ABS home update complete: Z
S Bit 228	Servo ABS home update complete: 4th
Description:	ON: Servo ABS home updated OFF: Servo ABS home not update yet.

S Bit 231	Encoder value cleared: X
S Bit 232	Encoder value cleared: Y
S Bit 233	Encoder value cleared: Z
S Bit 234	Encoder value cleared: 4th
S Bit 237	Encoder value cleared: 1st SP
S Bit 238	Encoder value cleared: 2nd SP
S Bit 239	Encoder value cleared: 3rd SP
Description:	These signal=ON, it means these encoder value cleared.

S Bit 240	Servo following lag value over parameter 2 value alarm: X
S Bit 241	Servo following lag value over parameter 3 value alarm: Y
S Bit 242	Servo following lag value over parameter 4 value alarm: Z
S Bit 243	Servo following lag value over parameter 5 value alarm: 4th
Description:	When Servo following lag value over these parameter value, this signal will ON.

Servo	Alarm
X	MOT4006

Y	MOT4007
Z	MOT4008
4th	MOT4009

S Bit 246	HAS ERROR COUNTER over position alarm: X
S Bit 247	HAS ERROR COUNTER over position alarm: Y
S Bit 248	HAS ERROR COUNTER over position alarm: Z
S Bit 249	HAS ERROR COUNTER over position alarm: 4th

When it has ERROR COUNTER alarm, this will ON °

Description:

Servo	Alarm
X	MOT4006
Y	MOT400
Z	MOT4008
4 th	MOT4009

S Bit 281	X M-II servo activate status
S Bit 282	Y M-II servo activate status
S Bit 283	Z M-II servo activate status
S Bit 284	4 th M-II servo activate status
S Bit 287	1st SPM-II servo activate status
S Bit 288	2nd SPM-II servo activate status
S Bit 289	3rd SPM-II servo activate status

Means M- II servo ON/OFF status.

Description:

ON : SERVO ON ;
OFF : SERVO OFF °

S Bit 291	X M-II Servo drive power status
S Bit 292	Y M-II Servo drive power status
S Bit 293	Z M-II Servo drive power status
S Bit 294	4 th M-II Servo drive power status
S Bit 297	1st SPM-II Servo drive power status
S Bit 298	2nd SPM-II Servo drive power status
S Bit 299	3rd SPM-II Servo drive power status

Means M- II Servo drive power status :

Description:

ON : Powered ;
OFF : No power

S Bit 301	X M-II torque monitoring status
S Bit 302	Y M-II torque monitoring status
S Bit 303	Z M-II torque monitoring status
S Bit 304	4 th M-II torque monitoring status
S Bit 307	1st SPM-II torque monitoring status
S Bit 308	2nd SPM-II torque monitoring status
S Bit 309	3rd SPM-II torque monitoring status

Means M- II torque monitoring status :

Description:

ON: Monitoring;
OFF: No monitoring

2.6 Register description

R Bit 001	M CODE R001 sends out M code value when M code is being executed. Range: 00 ~ 99.
R Bit 002	S CODE R002 sends out S code value when S code is being executed. Range: 0000 ~ 9999.
R Bit 003	T CODE R001 sends out T code value when T code is being executed. Range: 0000 ~ 9999.
R Bit 004 R Bit 006 R Bit 008	ACTUAL ROTATION SPEED OF THE SPINDLE 2nd Spindle Actual Speed 3rd Spindle Actual Speed The actual rotation speed of the spindle.
R Bit 005 R Bit 007	2nd spindle rotational speed command 3rd spindle rotational speed command The command of the spindle's rotational speed.
R Bit 013	MODE SELECTION 1 : EDIT , 2 : MEM , 3 : MDI , 4 : JOG , 5 : INCJOG , 6 : MPG , 7 : HOME

The register value of each operation module is listed as the chart below:

Operation Mode	REG 013
EDIT	1
MEM	2
MDI	
JOG	4 (C23=OFF)
RAPID	4 (C23=ON)
NCJOG	5
MPG	6
HOME	7

R Bit 014
MPG RATE 2: x10, 3: x100, OTHERS: x1
INCREMENTAL JOG OVERRIDE 2: x10, 3: x100, 4 : x1000, OTHERS: x1

The register value of each MPG rate is listed as the chart below:

MPG Ratio	REG 014
X1	1 (Or Others)
x10	2
x 00	3

R Bit 015
ROTATION SPEED OVERRIDE OF THE SPINDLE
0 ~ 12 REPRESENT 0% ~ 120%, RESPECTIVELY; OTHERS: SET VALUE × 0.01
R Bit 019
2nd Spindle Rotating Mode Override
R Bit 020
3rd Spindle Rotating Mode Override

The register value of each spindle rotation speed's override is listed as the chart below:

%	REG 015
0%	0
10%	1
20%	2
30%	3
40%	4
50%	5
60%	6
70%	7
80%	8
90%	9
100%	10
110%	11
120%	12
1%	Others

R Bit 016
CUTTING OVERRIDE
0 ~ 20 REPRESENT 0% ~ 200%, RESPECTIVELY; OTHERS: SET VALUE × 0.001

The register value of each cutting override is listed as the chart below:

%	REG 016
0%	0
10%	1
20%	2
30%	3
40%	4
50%	5
60%	6
70%	7
80%	8
90%	9
100%	10
110%	11
120%	12
130%	13

140%	14
150%	15
160%	16
170%	17
180%	18
190%	19
200%	20
‰ (Thousandth)	Others

R Bit 017**JOG OVERRIDE****0 ~ 20 REPRESENT 0% ~ 200%, RESPECTIVELY; OTHERS: SET VALUE × 0.001**

The register value of each manual override is listed as the chart below:

%	REG 017
0%	0
10%	1
20%	2
30%	3
40%	4
50%	5
60%	6
70%	7
80%	8
90%	9
100%	10
110%	11
120%	12
130%	13
140%	14
150%	15
160%	16
170%	17
180%	18
190%	19
200%	20
‰ (Thousandth)	Others

R Bit 018**RAPID TRAVERSE OVERRIDE****0, 1: F0, 2: 25%, 3: 50% ~ 4: 100%: OTHERS: SET VALUE × 0.001**

The register value of each rapid feed override is listed as the chart below:

%	REG 18
F0%	0
F0%	1
25%	2
50%	3
100%	4
1%	Others

NOTE: The actual rapid override of F0% is set by Pr. 0040.

R Bit 021	VERRIDE OF PMC AXIS, UNIT: mm/min. R021 sets the override of PMC axis.
------------------	--

R Bit 022	PMC AXIS CONTROL R022 sets the axis to be controlled by PMC. Bit 1, Bit 0 : 00 for G00; 01 for G01; 10 for G53 Bit 2 : 1 spindle. Bit 3 : Reserved. Bit 4 : 1 X axis Bit 5 : 1 Y axis Bit 6 : 1 Z axis Bit 7 : 1 The 4 th axis
------------------	--

R Bit 024	MOTION COMMAND OF PMC AXIS: X AXIS, mm part
R Bit 025	MOTION COMMAND OF PMC AXIS: X AXIS, μm part
R Bit 026	MOTION COMMAND OF PMC AXIS: Y AXIS, mm part
R Bit 027	MOTION COMMAND OF PMC AXIS: Y AXIS, μm part
R Bit 028	MOTION COMMAND OF PMC AXIS: Z AXIS, mm part
R Bit 029	MOTION COMMAND OF PMC AXIS: Z AXIS, μm part
R Bit 030	PMC Function of 4th-Axis Command Amount, Unit=mm
R Bit 031	PMC Function of 4th-Axis Command Amount, Unit=μm

R024 ~ R029 set the assigned motion distance for each PMC axis when executing a motion command. Motion distances must be set by entering two parts, mm & um, respectively into each register.

R Bit 036	PMC axes fast locate feed rate (OVERRIDE) value 0、1 : F0、2 : 25%、3 : 50%、4 : 100%, other values: value * 0.01
------------------	--

Feed rate % definition as following :

Description:

%	REG 36
F0%	0
F0%	1
25%	2
50%	3
100%	4
1%	other

R Bit 037	PMC axis cutting feed rate(OVERRIDE) value 0 ~ 20 means 0% ~ 200%, other values: value * 0.001
------------------	---

Cutting feed rate definition as following chart:

Description:

%	REG 037
0	0
10%	1
20%	2
30%	3
40%	4
50%	5
60%	6
70%	7

80%	8
90%	9
100%	10
110%	11
20%	12
130%	13
140%	14
150%	15
160%	16
170%	17
80%	18
190%	19
200%	20
‰ (千分之一)	others

R Bit 040	PLC ALARM
R Bit 041	PLC ALARM
R Bit 042	PLC ALARM
R Bit 043	PLC ALARM
R Bit 044	PLC ALARM
R Bit 045	PLC ALARM

R040 ~ R045 enables alarms. There are 6 registers (word), and 96 messages in total for definition and actuation. For example, if the alarms #1 & #3 are to be enabled, LADDER must enter R40 into constant 5 (bit 1 & bit 3) with a MOV command. At the same time, messages must be pre-defined in the corresponding position in ENG_PLC.ERR. To clear the PLC alarm, simply set R40 to 0.

R Bit 050	1ST set analog voltage detection value
R Bit 051	2ND set analog voltage detection value
R Bit 052	3RD set analog voltage detection value
R Bit 053	4TH set analog voltage detection value
R Bit 054	5TH set analog voltage detection value
R Bit 055	6TH set analog voltage detection value
R Bit 056	7TH set analog voltage detection value
R Bit 057	8TH set analog voltage detection value

Description:

Use DAQ3718 analog voltage detect card, NC controller can detect external analog voltage signal and save in R register.

R Bit 058	PLC Open file Name
-----------	--------------------

Description:

Use the 4 digit number as file name, if it is negative then define as no action.
E.g.:
R058 = 123 , then Open O123
R058 = 12345 , then Open O2345
R058 = -678 , then Open file failed, use the original file which selected in UI.

R Bit 060	PLC WINDOW FUNCTION
R Bit 061	PLC WINDOW FUNCTION NO.1
R Bit 062	PLC WINDOW FUNCTION NO.2
R Bit 063	PLC WINDOW READ/WRITE VALUE 1
R Bit 064	PLC WINDOW READ/WRITE VALUE 2
R Bit 065	PLC WINDOW READ/WRITE VALUE 3
R Bit 066	PLC WINDOW READ/WRITE VALUE 4
R Bit 067	PLC WINDOW READ/WRITE VALUE 5

R Bit 068	PLC WINDOW READ/WRITE VALUE 6
R Bit 069	PLC WINDOW READ/WRITE VALUE 7
R Bit 070	PLC WINDOW READ/WRITE VALUE 8
R Bit 071	PLC WINDOW READ/WRITE VALUE 9
R Bit 072	PLC WINDOW READ/WRITE VALUE 10
R Bit 073	PLC WINDOW READ/WRITE VALUE 11
R Bit 074	PLC WINDOW READ/WRITE VALUE 12

Please refer to the description of 4.7 PLC Window mechanisms.

R Bit 081	MPG ratio select: Y 2 : x10 , 3 : x100, other values: x1 incremental jog value 2 : x10 , 3 : x100 , 4 : x1000, other values: x1
R Bit 082	MPG ratio select: Z 2 : x10 , 3 : x100, other values: x1 incremental jog value 2 : x10 , 3 : x100 , 4 : x1000, other values: x1
R Bit 083	MPG ratio select: 4TH 2 : x10 , 3 : x100, other values: x1 incremental jog value 2 : x10 , 3 : x100 , 4 : x1000, other values: x1

When P0014 MPG ratio setup=1, MPG ratio definition as following chart.

Description:

MPG ratio	REG
x1	1 (or others)
x10	2
x100	3

R Bit 090	Each axis jog feedrate (OVERRIDE) value: X 0 ~ 20 means 0% ~ 200%, other values: Value * 0.001
R Bit 091	Each axis jog feedrate (OVERRIDE) value: Y 0 ~ 20 means 0% ~ 200%, other values: Value * 0.001
R Bit 092	Each axis jog feedrate (OVERRIDE) value: Z 0 ~ 20 means 0% ~ 200%, other values: Value * 0.001
R Bit 093	Each axis jog feedrate (OVERRIDE) value: 4 th 0 ~ 20 means 0% ~ 200%, other values: Value * 0.001

When P0023(each feed rate0)R17 1)R90-R95 =1, manual feed rate register define as following:

Description:

%	REG
%	0
10%	1
20%	2
30%	3
40%	4
50%	5
60%	6
70%	7
80%	8
90%	9
100%	10
110%	11
120%	12
130%	13
140%	14
150%	15

160%	16
170%	17
180%	18
190%	19
200%	20
(1/1000)	others

R Bit 101	X M-II torque %
R Bit 102	Y M-II torque %
R Bit 103	Z M-II torque %
R Bit 104	4th M-II torque %
R Bit 107	1st SPM-II torque %
R Bit 108	2nd SPM-II torque %
R Bit 109	3rd SPM-II torque %

Monitoring M- II torque value which saved in R register

Description:

R Bit 110	PLC axis compensation X absolute (Pulse)
R Bit 111	PLC axis compensation Y absolute (Pulse)
R Bit 112	PLC axis compensation Z absolute (Pulse)
R Bit 113	PLC axis compensation 4th absolute (Pulse)

Description: Use PLC to set R value for control each axis comprehension

R Bit 240~255	\$2000~\$2015 value
--------------------------	----------------------------

Use R to read \$2000~\$2015

Description:

2.7 PLC Window

After Ladder key-in the desired item codes in R60 ~ R62, setting C640 (0: Read, 1 writes). When completed, using C65 to inform NC. NC will enter the desired item into the corresponding R register (C64 is 0) according to the setting of R60 ~ R62 and C64. Or read the setting value (C64 is 1) from the corresponding R register. When completed the task, using S79 to inform Ladder. This function is enabled (raising edge trigger) when C65 becomes 1 from 0; S79 will become OFF after C65 has become OFF.


R Register Definition :

R Register	Definition	Remarks
60	Item Code 1 : read absolute coordinate value ; 2 : read machine coordinate value ; 3 : read & write macro global variables ; 4 : read parameter value ;	1 : read only ; 2 : read only ; 3 : read & write . 4 : read only ;
61	Sub-Item Code 1 (different depends on R60) R60 : 3, means the starting numbers of macro global variables(1 ~ 500) that are read and wrote R60 : 4, the starting parameter #s that are read	
62	Sub-Item Code 2 (different depends on R60 and R61) R60 : 3 , means the desired read/write macro global variables numbers (starting from the number that is designated by R61) , maximum 8. R60 : 4 , means the desired read/write parameter variables numbers(starting from the number that is designated by R61) , maximum 8.	Use R61 and R62 to order read and write multiple macro global variables continuously (max 8 variables),or the designated parameter continuously
63	Read/Write Value (different depends on R60~R62) R60 : 1 , means X axis absolute coordinate mm part ; R60 : 2 , means X axis machine coordinate mm part ; R60 : 3 , means the present value of the 1 st macro global variable that is designated by R61 and R62. R60 : 4 , means the value of 1 st parameter that is designated by R61 and R62.	Please refer to Attention.
64	Read/Write Value (different depends on R60~R62) R60 : 1 , means X axis absolute coordinate um part ; R60 : 2 , means X axis machine coordinate um part ; R60 : 3 , means the present value of the 1 st macro global variable that is designated by R61 and R62. R60 : 4 , means the value of 1 st parameter that is designated by R61 and R62.	Please refer to Attention.
65	Read/Write Value (different depends on R60~R62) R60 : 1 , means Y axis absolute coordinate mm part ; R60 : 2 , means Y axis machine coordinate mm part ; R60 : 3 , means the present value of the 1 st macro global variable that is designated by R61 and R62. R60 : 4 , means the value of 1 st parameter that is designated by R61 and R62.	Please refer to Attention.

R Register	Definition	Remarks
66	Read/Write Value (different depends on R60~R62) R60 : 1 , means Y axis absolute coordinate um part ; R60 : 2 , means Y axis machine coordinate um part ; R60 : 3 , means the present value of the 1 st macro global variable that is designated by R61 and R62. R60 : 4 , means the value of 1 st parameter that is designated by R61 and R62.	Please refer to Attention.
67	Read/Write Value (different depends on R60~R62) R60 : 1 , means Z axis absolute coordinate mm part ; R60 : 2 , means Z axis machine coordinate mm part ; R60 : 3 , means the present value of the 1 st macro global variable that is designated by R61 and R62. R60 : 4 , means the value of 1 st parameter that is designated by R61 and R62.	Please refer to Attention.
68	Read/Write Value (different depends on R60~R62) R60 : 1 , means Z axis absolute coordinate um part ; R60 : 2 , means Z axis machine coordinate um part ; R60 : 3 , means the present value of the 1 st macro global variable that is designated by R61 and R62. R60 : 4 , means the value of 1 st parameter that is designated by R61 and R62.	Please refer to Attention.
69	Read/Write Value (different depends on R60~R62) R60 : 1 , means 4th axis absolute coordinate mm part ; R60 : 2 , means 4th axis machine coordinate mm part ; R60 : 3 , means the present value of the 1 st macro global variable that is designated by R61 and R62. R60 : 4 , means the value of 1 st parameter that is designated by R61 and R62.	Please refer to Attention.
70	Read/Write Value (different depends on R60~R62) R60 : 1 , means 4th axis absolute coordinate um part ; R60 : 2 , means 4th axis machine coordinate um part ; R60 : 3 , means the present value of the 1 st macro global variable that is designated by R61 and R62. R60 : 4 , means the value of 1 st parameter that is designated by R61 and R62.	Please refer to Attention.
71	Read/Write Value (different depends on R60~R62) R60 : 3 , means the present value of the 9th macro global variable that is designated by R61 and R62. R60 : 4 , means the value of 9 th parameter that is designated by R61 and R62.	Please refer to Attention.
72	Read/Write Value (different depends on R60~R62) R60 : 3 , means the present value of the 10th macro global variable that is designated by R61 and R62. R60 : 4 , means the value of 10 th parameter that is designated by R61 and R62.	Please refer to Attention.
73	Read/Write Value (different depends on R60~R62) R60 : 3 , means the present value of the 11th macro global variable that is designated by R61 and R62. R60 : 4 , means the value of 11 th parameter that is designated by R61 and R62.	Please refer to Attention.

R Register	Definition	Remarks
74	Read/Write Value (different depends on R60~R62) R60 : 3 , means the present value of the 12th macro global variable that is designated by R61 and R62. R60 : 4 , means the value of 12 th parameter that is designated by R61 and R62.	Please refer to Attention.

Timing Procedure Diagram :



Attention :

- For read only items, if Ladder sets C64 to 1, NC will ignore it. Using the same principle for the writing items, if Ladder sets C64 to 0, NC will ignore it.
- Macro variables belong to DOUBLE type. But the present Ladder can only take care of the value in INT type. So if Ladder reads macro global variables via MLC Window, NC will check whether or not the macro global variable value is between -32768 ~ 32767. If yes, the macro global variables will change to INT type and then enter into the corresponding R register. If no, then the alarm **【OP 1019 DESIRED MACRO VARIABLES OVER RANGE】** will occur.
- Using R61 and R62, Ladder can read/write multiple macro global variables (maximum 8 variables) continuously. Example: set R60 to 3, R61 to 200 and R62 to 5. When C64 is OFF, it means the total current value of the designated reading/writing @200 ~ @204, total 5 macro global variables. But, if $(R61 + R62 - 1) > 500$, then alarm message **【OP 1018 DESIRED MACRO GLOBAL VARIABLES NOT EXISTED】** will occur.
- Macro local variables not able to execute read and write via MLC Window.
- The reading parameter value must be an integrate number (INT) or long integrate number (LONG). But the present Ladder can only take care of the values in INT type. So if Ladder reads parameter value via MLC Window, NC will check whether or not that parameter value is between -32768 ~ 32767. If yes, the parameter will change to INT type, and then enter into the corresponding R register. If not, the alarm message **【OP 1022 DESIRED PARAMETER VARIABLES OVER RANGE】** will occur.

6. Using R61 and R62, Ladder can read/write multiple parameter variables (maximum 8 variables) continuously. Example: set R60 to 3, R61 to 200 and R62 to 5. When C64 is OFF, it means the total value of the reading parameter variables 0200 ~ 0204, total 5 parameter variables. If it is over the valid parameter range, the alarm message **【OP 1023 DESIRED PARAMETER VARIABLES NOT EXISTED】** will occur.
Valid parameter variable range : 0 ~ 220 , 300 ~ 899 , 1000 ~ 1200 °
7. Parameter is not able to execute setting via PLC Window.

2.8 PLC initialize sets (PLCIO.CFG)


In LNCMILL\MACHINE, file name is PLCIO.CFG, this file is to set PLC I/O configuration and definition, file content is as following :


```

InputSignalInverse=0    // I point is reverse turning, 0=No , 1=Yes
OutputSignalInverse=0  // O point is reverse turning, 0=No , 1=Yes
BaseAddress=0x200      // pcc1620 base address
Set1Slave1=1           // whether to use Set1's Slave1, 0=No, 1=Yes
Set1Slave2=0           // whether to use Set1's Slave2, 0=No, 1=Yes
Set2Slave1=1           // whether to use Set2's Slave1, 0=No, 1=Yes
Set2Slave2=0           // whether to use Set2's Slave2, 0=No, 1=Yes
I    0    1    0x200    // column [I or O][NUMBER][SET][ADDRESS][able to add footnote]
I    8    1    0x201    // no blank space in between
I   16    1    0x202    // I or i is okay
I   24    1    0x203    // O or o is okay
I   32    1    0x204    // SET=1means SET1, SET=2 means SET2
I   40    2    0x200    // must starts from I0
O    0    1    0x200    // O point must be set as even number.
O   16    1    0x202
O   32    2    0x200
O   48    2    0x202

```

(Note) I 0 1 0x200





Due to user option I/O board and different connection methods, need to define on different I/O address. For the above diagram, due to connect to RIO1, the I/O address must be defined to SET 1.

3 Parameters

Parameters separated into 7 types: servo parameter, machine parameter, spindle parameter, MPG parameter, compensation parameter, original parameter, and operation parameter.

Note:

1. Four effective times due to different parameter setting values.
 - a : Effective immediately
 - b : Effective after RESET (R)
 - c : Effective after rebooting (⏻)
 - d : Effective after re-power on (⏻)
2. Two types of authorization status according to each parameter's functions. However, under **【End-User】** status, some parameter will NOT occur :
 - a : End-user
 - b : Machine maker
3. Some parameters use Bit method to set whether or not to enable a certain function. Usually, Bit0 corresponds X axis, Bit1 corresponds Y axis, Bit2 corresponds Z axis. The setting method is as below:
 - Bit0 : 1 means 1 in 1, 2, 4, 8, 16, 32 and so on
 - Bit1 : 1 means 2 in 1, 2, 4, 8, 16, 32 and so on :
 - Bit2 : 1 means 4 in 1, 2, 4, 8, 16, 32 and so on :
 - Bit3 : 1 means 8 in 1, 2, 4, 8, 16, 32 and so on :
 - Bit4 : 1 means 12 in 1, 2, 4, 8, 16, 32 and so on :

So, if want to set a certain Bit to 1, only need to adding up the corresponding value into the parameter.

For example, if want to set both Bit1 and Bit3 to 1, the setting value of this parameter is 10 (2 + 8) .

3.1 Parameters

No	Group	Description	Effective	Level	Page
1	Servo	SYSTEM LOOP GAINS FOR V CMD	⊙	Machine Maker	78
2	Servo	MAX. SERVO LAG OF X AXIS, μm	R	Machine Maker	78
3	Servo	MAX. SERVO LAG OF Y AXIS, μm	R	Machine Maker	78
4	Servo	MAX. SERVO LAG OF Z AXIS, μm	R	Machine Maker	78
5	Servo	MAX. SERVO LAG OF THE 4TH AXIS, μm	R	Machine Maker	78
6	Servo	IN-POSITION CHECK WINDOW OF X AXIS, μm	R	Machine Maker	78
7	Servo	IN-POSITION CHECK WINDOW OF Y AXIS, μm	R	Machine Maker	78
8	Servo	IN-POSITION CHECK WINDOW OF Z AXIS, μm	R	Machine Maker	78
9	Servo	IN-POSITION CHECK WINDOW OF THE 4TH AXIS, μm	R	Machine Maker	78
10	Servo	G00'S ACCEL. /DECEL. TIME OF X AXIS, ms	⊙	Machine Maker	79
11	Servo	G00'S ACCEL. /DECEL. TIME OF Y AXIS, ms	⊙	Machine Maker	79
12	Servo	G00'S ACCEL. /DECEL. TIME OF Z AXIS, ms	⊙	Machine Maker	79
13	Servo	G00'S ACCEL. /DECEL. TIME OF THE 4TH AXIS, ms	⊙	Machine Maker	79
14	Servo	G01 ACCEL. /DECEL. TIME	⊙	Machine Maker	79
15	MPG	CORRESPONDING MECHANICAL AXIS OF MPG SIMULATED AXIS	⊙	Machine Maker	118
16	Spindle	ACC/DEC TIME OF 1ST SPINDLE	⊙	Machine Maker	98
17		reserve			
18	Servo	THREAD CUTTING ACC/DEC TIME	⊙	Machine Maker	118
19	Zero Point	SOLUTIONS WHEN HOME IS ON DOG	R	Machine Maker	127
20	Zero Point	DEFAULT SETTING OF HOME RETURN BIT	⊙	Machine Maker	127
21	Spindle	RPM OF THE 1ST SPINDLE'S ORIENTATION	R	Machine Maker	98
22		reserve			
23	Operation	Each axis JOG feed rate 0)R17 1)R90-R95	⊙	Machine Maker	143
24	Servo	CORRESPONDING SERVO AXIS NUMBER OF X AXIS	⊙	Machine Maker	79
25	Servo	CHANNEL NO FOR Y AXIS	⊙	Machine Maker	79
26	Servo	CORRESPONDING SERVO AXIS NUMBER OF Z AXIS	⊙	Machine Maker	79
27	Servo	CORRESPONDING SERVO AXIS NUMBER OF THE 4TH AXIS	⊙	Machine Maker	79

No	Group	Description	Effective	Level	Page
28	MPG	MPG CONNECTION PORT OF X AXIS	⊙	Machine Maker	119
29	Spindle	THE CORRESPONDING SERVO AXIS NUMBER OF THE 1ST SPINDLE	⊙	Machine Maker	98
30	Zero Point	OFFSET AMOUNT OF HOME RETURN: X AXIS μm	R	Machine Maker	127
31	Zero Point	OFFSET AMOUNT OF HOME RETURN: Y AXIS μm	R	Machine Maker	127
32	Zero Point	OFFSET AMOUNT OF HOME RETURN: Z AXIS μm	R	Machine Maker	127
33	Zero Point	OFFSET AMOUNT OF HOME RETURN: THE 4TH AXIS μm	R	Machine Maker	127
34	Zero Point	IDLE DURATION FOR X AXIS TO SEARCH FOR ZERO POINT 10ms	R	Machine Maker	128
35	Zero Point	IDLE DURATION FOR Y AXIS TO SEARCH FOR ZERO POINT 10ms	R	Machine Maker	128
36	Zero Point	IDLE DURATION FOR Z AXIS TO SEARCH FOR ZERO POINT 10ms	R	Machine Maker	128
37	Zero Point	IDLE DURATION FOR THE 4TH AXIS TO SEARCH FOR ZERO POINT 10ms	R	Machine Maker	128
38	Compensation	BACKLASH COMPENSATION UNIT 0)PULSE 16) μm	⊙	Machine Maker	120
39	Operation	G92 IS CANCELLED AT G54~G59	R	User	143
40	Servo	G00'S LOWEST OVERRIDE AT F0	R	User	79
41	Operation	SYNCHRONIC MOTION OF G00 COMMAND 0)NO 1)YES	R	User	143
42	Operation	COMMENT TYPE 0:/*...*/ 1:(...)	R	User	144
43	Operation	FLAG OF EXACT CHECK	R	User	144
44	Compensation	BACKLASH COMPENSATION AMOUNT OF X AXIS μm	R	Machine Maker	120
45	Compensation	BACKLASH COMPENSATION AMOUNT OF Y AXIS μm	R	Machine Maker	120
46	Compensation	BACKLASH COMPENSATION AMOUNT OF Z AXIS μm	R	Machine Maker	120
47	Compensation	BACKLASH COMPENSATION AMOUNT OF THE 4TH AXIS μm	R	Machine Maker	120
48	Zero Point	HOME SEARCH METHOD BIT	⊙	Machine Maker	128
49	Spindle	MOTOR'S TOOTH NUMBER OF THE 1ST SPINDLE IN 1ST GEAR	⊙	Machine Maker	99
50	Spindle	THE 1ST SPINDLE'S TEETH NUMBER IN 1ST GEAR	⊙	Machine Maker	99
51	Spindle	TOOTH NUMBER OF THE 1ST SPINDLE'S MOTOR IN 2ND GEAR	⊙	Machine Maker	100
52	Spindle	TOOTH NUMBER OF THE 1ST SPINDLE IN 2ND GEAR	⊙	Machine Maker	100
53	Servo	ENCODER FEEDBACK MULTIPLIER OF THE 4TH AXIS 1/2/4	⊙	Machine Maker	80
54	Servo	ENCODER FEEDBACK MULTIPLIER OF X AXIS 1/2/4	⊙	Machine Maker	80
55	Servo	ENCODER FEEDBACK MULTIPLIER OF Y AXIS 1/2/4	⊙	Machine Maker	80
56	Servo	ENCODER FEEDBACK MULTIPLIER OF Z AXIS 1/2/4	⊙	Machine Maker	80
57	Spindle	FEEDBACK RATE OF THE 1ST SPINDLE	⊙	Machine Maker	101

No	Group	Description	Effective	Level	Page
58~61		Non			
62	Machine	UNIT OF Pr.0104 ~ Pr.0107 0) METRIC 1) IMPERIAL	⊙	Machine Maker	96
63	Operation	SET RELATIVE COORDINATES ACCORDING TO ABSOLUTE COORDINATES 0)NO 1)YES	R	User	145
64	Zero Point	HOME DOG SENSOR IS 0)NC 1)NO	⊙	Machine Maker	128
65	Servo	ABSOLUTE ENCODER BIT 0-3	⊙	Machine Maker	80
66	Servo	SET THE 4TH AXIS AS A 0)ROTARY 1)LINEAR AXIS	⊙	Machine Maker	81
67		Non			
68	Machine	TOOTH NUMBER OF X AXIS MOTOR (DENOMINATOR IN GEAR RATIO)	⊙	Machine Maker	96
69	Machine	TOOTH NUMBER OF Y AXIS'S MOTOR (DENOMINATOR IN GEAR RATIO)	⊙	Machine Maker	96
70	Machine	TOOTH NUMBER OF Z AXIS'S MOTOR (DENOMINATOR IN GEAR RATIO)	⊙	Machine Maker	96
71	Operation	PATH CHECK G22 ADOPTS 0)OUTSIDE 1)INSIDE	R	User	145
72	Machine	TOOTH NUMBER OF THE 4TH AXIS'S MOTOR (DENOMINATOR IN GEAR RATIO)	⊙	Machine Maker	96
73	Operation	ACCELERATION/DECELERATION OF G31 0)NO 1)YES	⊙	Machine Maker	145
74	Operation	EXECUTE SINGLE BLOCK OF MACRO	R	User	146
75	MPG	MPG CONNECTION PORT OF THE 4TH AXIS	⊙	Machine Maker	119
76	Zero Point	SET ABSOLUTE COORD. AFTER HOME RETURN 0)NO 1)YES	R	Machine Maker	129
77	Zero Point	G00 1)DISABLED 0) 1)EFFECTIVE	R	User	129
78	Operation	ENABLE C AXIS TANGENT FOLLOW	⊙	User	
79	Zero Point	X AXIS'S ZERO POINT IS 0)AFTER 1)BEFORE DOG	R	Machine Maker	130
80	Zero Point	Y AXIS'S ZERO POINT IS 0)AFTER 1)BEFORE DOG	R	Machine Maker	130
81	Zero Point	Z AXIS'S ZERO POINT IS 0)AFTER 1)BEFORE DOG	R	Machine Maker	130
82	Zero Point	THE 4TH AXIS'S ZERO POINT IS 0)AFTER 1)BEFORE DOG	R	Machine Maker	130
83	Operation	G00 IS 0)DISABLED 1)EFFECTIVE IN DRY RUN	R	User	146
84	Spindle	THE 1ST SPINDLE ORIENTATION 0)SENSOR 1)ENCODER	R	Machine Maker	101
85~86		Non			
87	MPG	MPG CONNECTION PORT OF Y AXIS	⊙	Machine Maker	119
88	MPG	MPG CONNECTION PORT OF Z AXIS	⊙	Machine Maker	119
89	Operation	SET M CODE COMMAND OF PART COUNT BY USER	R	User	147
90	Spindle	THE 1ST SPINDLE DISPLAYS 0)COMMAND 1) SENSOR		Machine Maker	102
91~92		Non			
93		reserve			
94	Operation	EDIBILITY OF 09XXX 0)NO 1)YES		Machine Maker	147

No	Group	Description	Effective	Level	Page
95	Spindle	MIN. SPEED OF THE 1ST SPINDLE	R	Machine Maker	102
96~97		Non			
98	Spindle	VOLTAGE COMMAND'S OFFSET VALUE OF THE 1ST SPINDLE'S RPM	R	Machine Maker	103
99		Non			
100	Machine	BALL SCREW'S TOOTH NUMBER OF X AXIS (NUMERATOR IN GEAR RATIO)	⊙	Machine Maker	96
101	Machine	BALL SCREW'S TOOTH NUMBER OF Y AXIS (NUMERATOR IN GEAR RATIO)	⊙	Machine Maker	96
102	Machine	BALL SCREW'S TOOTH NUMBER OF Z AXIS (NUMERATOR IN GEAR RATIO)	⊙	Machine Maker	96
103	Machine	BALL SCREW'S TOOTH NUMBER OF THE 4TH AXIS (NUMERATOR IN GEAR RATIO)	⊙	Machine Maker	96
104	Machine	BALL SCREW PITCH. OF X AXIS	⊙	Machine Maker	97
105	Machine	BALL SCREW PITCH. OF Y AXIS	⊙	Machine Maker	97
106	Machine	BALL SCREW PITCH. OF Z AXIS	⊙	Machine Maker	97
107	Machine	BALL SCREW PITCH. OF THE 4TH AXIS	⊙	Machine Maker	97
108	Servo	RPM TO VOLTAGE RATIO FOR X AXIS RPM/1V	⊙	Machine Maker	81
109	Servo	RPM TO VOLTAGE RATIO FOR Y AXIS RPM/1V	⊙	Machine Maker	81
110	Servo	RPM TO VOLTAGE RATIO FOR Z AXIS RPM/1V	⊙	Machine Maker	81
111	Servo	RPM TO VOLTAGE RATIO FOR THE 4TH AXIS RPM/1V	⊙	Machine Maker	81
112	Compensation	TOTAL SESSION NUMBER OF PITCH ERROR COMPENSATION OF X AXIS	⊙	Machine Maker	120
113	Compensation	TOTAL SESSION NUMBER OF PITCH ERROR COMPENSATION OF Y AXIS	⊙	Machine Maker	120
114	Compensation	TOTAL SESSION NUMBER OF PITCH ERROR COMPENSATION OF Z AXIS	⊙	Machine Maker	120
115	Compensation	TOTAL SESSION NUMBER OF PITCH ERROR COMPENSATION OF THE 4TH AXIS	⊙	Machine Maker	120
116	Servo	MOVING DIR OF EACH AXIS	⊙	Machine Maker	81
117	Compensation	BACKLASH COMPENSATION FUNCTION BIT	R	Machine Maker	121
118	Compensation	DIRECTION OF PITCH ERROR COMPENSATION BIT	⊙	Machine Maker	121
119	Compensation	PITCH ERROR COMPENSATION FUNCTION BIT	⊙	Machine Maker	121
120	Zero Point	DIRECTION OF HOME RETURN FOR EACH AXIS BIT	⊙	Machine Maker	130
121	Operation	Tool fleeing direction when G76/G87 Cycle process	R	User	147
122	Operation	NAME THE 4TH AXIS (ABCUVW)	⊙	Machine Maker	148
123	Operation	UNIT SYSTEM 0)G21 METRIC 1)G20 IMPERIAL	⊙	User	148
124	Operation	INITIAL MOTION COMMAND 0)G00 1)G01	⊙	User	148
125~128		Non			

No	Group	Description	Effective	Level	Page
129	Operation	G02 G03 Curve tolerance range	R	User	148
130	Operation	UNIT OF INPUT VALUE	R	User	149
131	Operation	CUTTER COMPENSATION TYPE 0)A 1)B	R	Machine Maker	149
132~133		Non			
134	Operation	G83/G87 EXTRACT 0)ESCAPE 1)R	R	User	149
135	Operation	DEFAULT COORDINATES 0)ABSOLUTE G90 1)INCREMENTAL G91	⊙	User	149
136	Operation	X SCALING IS EFFECTIVE OR NOT	R	User	150
137	Operation	Y SCALING IS EFFECTIVE OR NOT	R	User	150
138	Operation	Z SCALING IS EFFECTIVE OR NOT	R	User	150
139	Operation	RADIUS COMP SYMBOL SET	R	User	150
140	Operation	GLOBAL VARIABLES AFTER RESET 0)DELETED 1)PRESERVED	R	User	150
141	Operation	LOCAL VARIABLES AFTER RESET 0)DELETED 1)PRESERVED	R	User	150
142	Operation	ABS/RLT ROTATION COMMAND	R	User	151
143	Operation	CODE FOR SCALING	R	User	151
144		Non			
145	Operation	DEFAULT PLANE 0)XY 1)ZX 2)YZ	⊙	Machine Maker	151
146	Operation	M CODE FOR MACRO O9001	R	Machine Maker	151
147	Operation	M CODE FOR MACRO O9002	R	Machine Maker	151
148	Operation	M CODE FOR MACRO O9003	R	Machine Maker	151
149	Operation	DEFAULT FEED RATE	⊙	User	152
150	Operation	TOOL ESCAPE AMOUNT IN DRILLING CYCLE	R	User	152
151		Non	R		
152	Operation	ROTARY PATH OF THE 4TH AXIS	R	User	153
153~154		Non	⊙		
155	Operation	UNIT OF INITIAL FEED RATE 0)MM/REV 1)MM/MIN	⊙	User	153
156	Servo	COMMAND TYPE OF X AXIS 0)AB 1)CW 2)PD 3)V	⊙	Machine Maker	81
157	Servo	COMMAND TYPE OF Y AXIS 0)AB 1)CW 2)PD 3)V	⊙	Machine Maker	81
158	Servo	COMMAND TYPE OF Z AXIS 0)AB 1)CW 2)PD 3)V	⊙	Machine Maker	81
159	Servo	COMMAND TYPE OF THE 4TH AXIS 0)AB 1)CW 2)PD 3)V	⊙	Machine Maker	82
160		Non			
161	Operation	M CODE FOR MACRO O9004	R	Machine Maker	153
162	Operation	M CODE FOR MACRO O9005	R	Machine Maker	153
163	Operation	M CODE FOR MACRO O9006	R	Machine Maker	153
164	Operation	M CODE FOR MACRO O9007	R	Machine Maker	153
165	Operation	M CODE FOR MACRO O9008	R	Machine Maker	153

No	Group	Description	Effective	Level	Page
166	Operation	G CODE FOR MACRO O9010	R	Machine Maker	153
167	Operation	G CODE FOR MACRO O9011	R	Machine Maker	153
168	Operation	G CODE FOR MACRO O9012	R	Machine Maker	153
169	Operation	T CODE CALLS O9020	R	Machine Maker	153
170	Operation	MODAL UPDATE AFTER MDI TO MEM	R	User	154
171	Spindle	FEEDBACK DIR. OF SPINDLES(BIT)	⊙	Machine Maker	103
172~174		Non	⊙		
175	Zero Point	HOME DOG I POINT 0)LOCAL 1)REMOTE	⊙	Machine Maker	131
176	Operation	LOCAL PORT NO FOR G31 P1	R	Machine Maker	154
177	Operation	G31 SIGNAL SOURCE TYPE 0)NC 1)NO	R	Machine Maker	154
178	Spindle	TOOTH NUMBER OF THE 1ST SPINDLE'S MOTOR IN 3RD GEAR	⊙	Machine Maker	104
179	Spindle	TOOTH NUMBER OF THE 1ST SPINDLE IN 3RD GEAR	⊙	Machine Maker	104
180	Operation	MANUAL RETURN	R	User	155
181	Spindle	TOOTH NUMBER OF THE 1ST SPINDLE'S MOTOR IN 4TH GEAR	⊙	Machine Maker	104
182	Spindle	TOOTH NUMBER OF THE 1ST SPINDLE IN 4TH GEAR	⊙	Machine Maker	105
183	Spindle	COMMAND TYPE OF THE 1ST SPINDLE'S SPEED	⊙	Machine Maker	105
184	Spindle	LOCAL INPUT OF THE 1ST SPINDLE'S ORIENTATION	R	Machine Maker	107
185	Servo	INV POS FEEDBACK OF EACH AXIS	⊙	Machine Maker	82
186	Servo	Enable or not, pulse rise automatically adjust		Machine Maker	83
187	Operation	AUTO ARC FEED RATE CLAMP 0)NO 1)YES	R	User	156
188	Servo	POSITION LOOP GAIN OF SERVO AXIS IN PULSE COMMAND 1/sec.	R	Machine Maker	83
189	Spindle	DEFAULT INITIAL SPEED OF THE 1ST SPINDLE	⊙	User	107
190	Spindle	POSITION COMMAND TYPE	⊙	Machine Maker	107
191	Servo	ENCORDER SIGNAL TYPE OF X AXIS	⊙	Machine Maker	83
192	Servo	ENCORDER SIGNAL TYPE OF Y AXIS	⊙	Machine Maker	83
193	Servo	ENCORDER SIGNAL TYPE OF Z AXIS	⊙	Machine Maker	83
194	Servo	ENCORDER SIGNAL TYPE OF THE 4TH AXIS	⊙	Machine Maker	83
195	Spindle	SIGNAL TYPE OF THE 1ST SPINDLE'S ENCODER	⊙	Machine Maker	108
196~199		Non			
200	Operation	FEEDRATE DISPLAY 0)COMMAND 1)ACTUAL FEEDBACK	R	User	157
201		Non			

No	Group	Description	Effective	Level	Page
202	Operation	OPERATION LANGUAGE 0)ENGLISH 1)TRADITIONAL CHINESE 2)SIMPLIFIED CHINESE	⊙	User	157
203		Non			
204	Zero Point	ZERO POINT RECORDED BY NC BIT	R	Machine Maker	132
205	Operation	TOOL COMPENSATION 0)ABSOLUTE 1) RELATIVE INPUT	R	User	157
206~207		Non			
208	Zero Return	REFERENCE MARKS OF LINEAR SCALE	⊙	Machine Maker	28
209	Zero Return	HOME RETURN FOR LINEAR SCALE	R	Machine Maker	28
210	Zero Return	HOME POINT FOR LINEAR SCALE	R	Machine Maker	28
211	Operation	STOP PRE-INTERPRETATION OF M CODE	R	User	157
212	Operation	STOP PRE-INTERPRETATION OF M CODE	R	User	157
213	Operation	STOP PRE-INTERPRETATION OF M CODE	R	User	157
214	Operation	STOP PRE-INTERPRETATION OF M CODE	R	User	157
215	Operation	STOP PRE-INTERPRETATION OF M CODE	R	User	157
216	Operation	STOP PRE-INTERPRETATION OF M CODE	R	User	157
217	Operation	STOP PRE-INTERPRETATION OF M CODE	R	User	157
218	Operation	STOP PRE-INTERPRETATION OF M CODE	R	User	157
219	Operation	STOP PRE-INTERPRETATION OF M CODE	R	User	157
220	Operation	STOP PRE-INTERPRETATION OF M CODE	R	User	157
221	Operation	DIGITAL FILTER FREQUENCY (KHZ)	⊙	Machine Maker	158
222		Non			
223	Operation	AXES MANUAL RETURN(BIT)	R	Machine Maker	158
224	Spindle	2ND SPD SPEED CHK 0)ACT 1)CMD	R	Machine Maker	110
225	Spindle	3RD SPD SPEED CHK 0)ACT 1)CMD	R	Machine Maker	110
226	Spindle	MOVING DIR. OF SPINDLES(BIT)	⊙	Machine Maker	108
227~230		Non			
231	Operation	HIDE INFORMATION OF X AXIS		Machine Maker	159
232	Operation	HIDE INFORMATION OF Y AXIS		Machine Maker	159
233	Operation	HIDE INFORMATION OF Z AXIS		Machine Maker	159
234	Operation	HIDE INFORMATION OF THE 4TH AXIS		Machine Maker	159
235~236		reserve			
237		Non			
238	Operation	Coordinate detection page(0:ON 1:OFF)	R	User	83
239		Non		User	
240	Spindle	CLOSE LOOP GAIN OF THE 1ST SPINDLE'S ORIENTATION	R	Machine Maker	109
241	Spindle	1ST SPD POS GAIN AT RIGID TAP	R	Machine Maker	109
242~247		Non			

No	Group	Description	Effective	Level	Page
248	Spindle	1ST SPD ORIENT OFFSET UNIT	R	Machine Maker	109
249	Operation	DISPLAY ABNORMALITY OF RAMDISK 0)OFF 1)ON	⊙	Machine Maker	159
250~251		reserve			
252~253		Non			
254~291		reserve			
292	Operation	ENABLE C AXIS PATH FOLLOWING	⊙	User	146
293	Zero Point	REFERENCE OF SERVO AXIS'S ZERO POINT	⊙	Machine Maker	133
294	Spindle	CORRESPONDING TO 2ND SPINDLE	⊙	Machine Maker	98
295	Spindle	CORRESPONDING TO 3RD SPINDLE	⊙	Machine Maker	98
296	Spindle	COMMAND TYPE OF THE 2ND SPINDLE'S SPEED	⊙	Machine Maker	105
297	Spindle	COMMAND TYPE OF THE 3RD SPINDLE'S SPEED	⊙	Machine Maker	105
298	Spindle	RPM REACHES SET RANGE OF THE 2ND SPINDLE	R	Machine Maker	110
299	Spindle	THE 2ND SPINDLE REACHES ZERO SPEED RPM	R	Machine Maker	112
300~349	Compensation	PITCH ERROR COMPENSATION OF 001~050 SESSION OF X AXIS μm	R	Machine Maker	122
351	Operation	UNIT OF CUTTING OVERRIDE FEED RATE	⊙	Machine Maker	160
352	Operation	UNIT OF JOG OVERRIDE	⊙	Machine Maker	160
353	Operation	UNIT OF RAPID TRAVERSDE OVERRIDE	⊙	Machine Maker	160
354	Spindle	OVERRIDE UNIT OF THE 1ST SPINDLE'S RPM	⊙	Machine Maker	109
355	Spindle	OVERRIDE UNIT OF THE 2ND SPINDLE'S RPM	⊙	Machine Maker	109
356	Spindle	OVERRIDE UNIT OF THE 3RD SPINDLE'S RPM	⊙	Machine Maker	109
357		reserve			
358	Compensation	ENABLE THERMO DEFORMED CMP	⊙	Machine Maker	122
359	Compensation	ALLOWANCE OF THERMO CMP INPUT		Machine Maker	122
360	Operation	SET OPERATION SCREEN COLOR (0~3)	⊙	User	160
361	Operation	SET THE NUMBER FOR BLACK (0~16)	⊙	User	161
362	Operation	SET THE NUMBER FOR BLUE (0~16)	⊙	User	161
363	Operation	SET THE NUMBER FOR GREEN (0~16)	⊙	User	161
364	Operation	SET THE NUMBER FOR CYAN (0~16)	⊙	User	161
365	Operation	SET THE NUMBER FOR RED (0~16)	⊙	User	161
366	Operation	SET THE NUMBER FOR PURPLE (0~16)	⊙	User	161
367	Operation	SET THE NUMBER FOR BROWN (0~16)	⊙	User	161
368	Operation	SET THE NUMBER FOR WHITE (0~16)	⊙	User	161
369	Operation	SET THE NUMBER FOR GRAY (0~16)	⊙	User	161
370	Operation	SET THE NUMBER FOR LIGHT BLUE (0~16)	⊙	User	161
371	Operation	SET THE NUMBER FOR LIGHT GREEN (0~16)	⊙	User	161

No	Group	Description	Effective	Level	Page
372	Operation	SET THE NUMBER FOR LIGHT CYAN (0~16)	⊙	User	161
373	Operation	SET THE NUMBER FOR LIGHT RED (0~16)	⊙	User	161
374	Operation	SET THE NUMBER FOR LIGHT PURPLE (0~16)	⊙	User	161
375	Operation	SET THE NUMBER FOR YELLOW COLOR (0~16)	⊙	User	161
376	Operation	SET THE NUMBER FOR BRIGHT WHITE COLOR (0~16)	⊙	User	161
377	Operation	SET THE NUMBER FOR CURSOR (0~16)	⊙	User	161
378	Operation	SET THE NUMBER FOR HIGHLIGHT (0~16)	⊙	User	161
379	Operation	SET THE NUMBER FOR UPPER FRAME (0~16)	⊙	User	161
380	Operation	SET THE NUMBER FOR LOWER FRAME (0~16)	⊙	User	161
381	Operation	Cutting speed lock on curve surface	R	User	161
382~392		Non			
393	Spindle	1st SP gear change 0)Auto 1)Manual	⊙	Machine Maker	109
394	Operation	SCREENSAVER WAIT TIME	⊙	User	161
395	Operation	Operation record ON 1)Y 0)N	⊙	Machine Maker	162
396	Operation	Set the work path using method.	⊙	Machine Maker	162
397	Operation	M98 calling file name format: (0)4 digit (1)7 digit	R	User	162
398	Servo	Set the PMC axis G00 acceleration time /ms	⊙	Machine Maker	84
399	Servo	Set the PMC axis G01 acceleration time /ms	⊙	Machine Maker	84
400	Servo	[R1]Cutting Linear acceleration time /ms	R	Machine Maker	84
401	Servo	[R1]Cutting bell shape acceleration time /ms	R	Machine Maker	84
402	Servo	[R1]Cutting smooth acceleration time /ms	R	Machine Maker	85
403	Servo	[R1]After cutting acceleration time /ms	R	Machine Maker	85
404	Servo	[R1]Round speed lock um/min	R	Machine Maker	85
405	Servo	[R1]Round minim speed lock um/min	R	Machine Maker	85
406	Servo	SHINING MODE	R	Machine Maker	85
407	Servo	Activate feed forward	R	Machine Maker	85
408	Servo	G05R_default value	R	User	85
409	Servo	Curve fitting tolerance (um)	R	Machine Maker	86
410	Servo	[R1]X Corner speed difference um/min	R	Machine Maker	86
411	Servo	[R1]Y Corner speed difference um/min	R	Machine Maker	86
412	Servo	[R1]Z Corner speed difference um/min	R	Machine Maker	86

No	Group	Description	Effective	Level	Page
413	Servo	[R1]4th Corner speed difference um/min	R	Machine Maker	86
414~415		reserve			
416	Servo	X stops Servo lag check um	R	Machine Maker	86
417	Servo	Y stops Servo lag check um	R	Machine Maker	86
418	Servo	Z stops Servo lag check um	R	Machine Maker	86
419	Servo	4th stops Servo lag check um	R	Machine Maker	86
420~421		reserve			
422	Servo	X position loop gain 1/s	R	Machine Maker	87
423	Servo	Y position loop gain 1/s	R	Machine Maker	87
424	Servo	Z position loop gain 1/s	R	Machine Maker	87
425	Servo	4th position loop gain 1/s	R	Machine Maker	87
426~427		reserve			
428		Non			
429	Servo	Corner method 0) Normal 1)Speed difference 2) referenced	R	Machine Maker	87
430	Servo	[R1] Corner reference speed um/min	R	Machine Maker	87
431	Servo	[R1]X speed feed forward (%%)	R	Machine Maker	87
432	Servo	[R1]Y speed feed forward (%%)	R	Machine Maker	87
433	Servo	[R1]Z speed feed forward (%%)	R	Machine Maker	87
434	Servo	[R1]4th speed feed forward (%%)	R	Machine Maker	87
435~436		reserve			
437	Servo	X feed forward acceleration time (ms)	R	Machine Maker	88
438	Servo	Y feed forward acceleration time (ms)	R	Machine Maker	88
439	Servo	Z feed forward acceleration time (ms)	R	Machine Maker	88
440	Servo	4th feed forward acceleration time (ms)	R	Machine Maker	88
441~442		reserve			
443~449		Non			
450~499	Compensation	PITCH ERROR COMPENSATION OF 001 ~050 SESSION OF Y AXIS μm	R	Machine Maker	122
500	Servo	In synchronization X follow target axis Name	⊙	Machine Maker	88
501	Servo	In synchronization Y follow target axis Name	⊙	Machine Maker	88
502	Servo	In synchronization Z follow target axis Name	⊙	Machine Maker	88
503	Servo	In synchronization 4 th follow target axis Name	⊙	Machine Maker	88
504~505		reserve			

No	Group	Description	Effective	Level	Page
506	Servo	In synchronization X direction setup as a follower.	⊙	Machine Maker	88
507	Servo	In synchronization Y direction setup as a follower.	⊙	Machine Maker	88
508	Servo	In synchronization Z direction setup as a follower.	⊙	Machine Maker	88
509	Servo	In synchronization 4th direction setup as a follower.	⊙	Machine Maker	88
510~511		Reserve			
512	Servo	Analog voltage detect card address	⊙	Machine Maker	162
513	Servo	Analog voltage detect	⊙	Machine Maker	162
514	Operation	1ST Analog voltage detect range	⊙	Machine Maker	162
515	Operation	2ND Analog voltage detect range	⊙	Machine Maker	162
516	Operation	3RD Analog voltage detect range	⊙	Machine Maker	162
517	Operation	4TH Analog voltage detect range	⊙	Machine Maker	162
518	Operation	5TH Analog voltage detect range	⊙	Machine Maker	162
519	Operation	6TH Analog voltage detect range	⊙	Machine Maker	163
520	Operation	7TH Analog voltage detect range	⊙	Machine Maker	163
521	Operation	8TH Analog voltage detect range	⊙	Machine Maker	163
522	Operation	1ST Analog voltage detects minim value.	⊙	Machine Maker	163
523	Operation	1ST Analog voltage detects max value.	⊙	Machine Maker	163
524	Operation	2ND Analog voltage detects minim value.	⊙	Machine Maker	163
525	Operation	2ND Analog voltage detects max value.	⊙	Machine Maker	163
526	Operation	3RD Analog voltage detects minim value.	⊙	Machine Maker	163
527	Operation	3RD Analog voltage detects max value.	⊙	Machine Maker	163
528	Operation	4TH Analog voltage detects minim value.	⊙	Machine Maker	163
529	Operation	4TH Analog voltage detects max value.	⊙	Machine Maker	163
530	Operation	5TH Analog voltage detects minim value.	⊙	Machine Maker	163
531	Operation	5TH Analog voltage detects max value.	⊙	Machine Maker	163
532	Operation	6TH Analog voltage detects minim value.	⊙	Machine Maker	163
533	Operation	6TH Analog voltage detects max value.	⊙	Machine Maker	163
534	Operation	7TH Analog voltage detects minim value.	⊙	Machine Maker	163

No	Group	Description	Effective	Level	Page
535	Operation	7TH Analog voltage detects max value.	⊙	Machine Maker	163
536	Operation	8TH Analog voltage detects minim value.	⊙	Machine Maker	163
537	Operation	8TH Analog voltage detects max value.	⊙	Machine Maker	163
538	Servo	Axis name which switch with X	⊙	Machine Maker	89
539	Servo	Axis name which switch with Y	⊙	Machine Maker	89
540	Servo	Axis name which switch with Z	⊙	Machine Maker	89
541	Servo	Axis name which switch with 4th	⊙	Machine Maker	89
542~543		reserve			
544	MPG	MPG X acceleration time (ms)	⊙	Machine Maker	119
545	MPG	MPG Y acceleration time (ms)	⊙	Machine Maker	119
546	MPG	MPG Z acceleration time (ms)	⊙	Machine Maker	119
547	MPG	MPG 4th acceleration time (ms)	⊙	Machine Maker	119
548~549		Reserve			
550	MPG	MPG X max speed (um/min)	R	Machine Maker	119
551	MPG	MPG Y max speed (um/min)	R	Machine Maker	119
552	MPG	MPG Z max speed (um/min)	R	Machine Maker	119
553	MPG	MPG 4th max speed (um/min)	R	Machine Maker	119
554~555		reserve			
556	Operation	LCD type (0~2)	⊙	Machine Maker	163
557		Non			
558	Operation	Process line No. record Time interval		Machine Maker	163
559		Non			
560	Operation	Floppy settings	⊙	Machine Maker	164
561	Operation	User interface group switch	⊙	Machine Maker	164
562	compensation	PLC axis compensation bit 0)OFF 1)ON	⊙	Machine Maker	123
563	compensation	PLC axis compensation X acceleration time ms	R	Machine Maker	123
564	compensation	PLC axis compensation Y acceleration time ms	R	Machine Maker	123
565	compensation	PLC axis compensation Z acceleration time ms	R	Machine Maker	123
566	compensation	PLC axis compensation 4 th acceleration time ms	R	Machine Maker	123
567~568		reserve			
569	compensation	X backlash compensation acceleration time ms	R	Machine Maker	123

No	Group	Description	Effective	Level	Page
570	compensation	Y backlash compensation acceleration time ms	R	Machine Maker	123
571	compensation	Z backlash compensation acceleration time ms	R	Machine Maker	123
572	compensation	4th backlash compensation acceleration time ms	R	Machine Maker	123
573~574		reserve			
575~599		Non			
600~649	Compensation	PITCH ERROR COMPENSATION OF 001~050 SESSION OF Z AXIS μm	R	Machine Maker	123
650	Operation	SET THE METHOD OF PROGRAM RESTART		User	164
651	Operation	Internet method 0)Net disk 1)ReCON	⊙	Machine Maker	164
652	Operation	Net monitor time out (sec)		Machine Maker	164
653	Operation	Activate Data Recorder	⊙	Machine Maker	164
654~662		Non			
663	Spindle	1ST SPD ORIENT ACC/DEC TIME	⊙	Machine Maker	110
664	Spindle	MOTOR'S TOOTH NUMBER OF THE 2ND SPINDLE IN 1ST GEAR	⊙	Machine Maker	99
665	Spindle	THE 2ND SPINDLE'S TEETH NUMBER IN 1ST GEAR	⊙	Machine Maker	99
666	Spindle	TOOTH NUMBER OF THE 2ND SPINDLE'S MOTOR IN 2ND GEAR	⊙	Machine Maker	100
667	Spindle	TOOTH NUMBER OF THE 2ND SPINDLE IN 2ND GEAR	⊙	Machine Maker	100
668	Spindle	TOOTH NUMBER OF THE 2ND SPINDLE'S MOTOR IN 3RD GEAR	⊙	Machine Maker	104
669	Spindle	TOOTH NUMBER OF THE 2ND SPINDLE IN 3RD GEAR	⊙	Machine Maker	104
670	Spindle	TOOTH NUMBER OF THE 2ND SPINDLE'S MOTOR IN 4TH GEAR	⊙	Machine Maker	104
671	Spindle	TOOTH NUMBER OF THE 2ND SPINDLE IN 4TH GEAR	⊙	Machine Maker	105
672	Spindle	MOTOR'S TOOTH NUMBER OF THE 3RD SPINDLE IN 1ST GEAR	⊙	Machine Maker	99
673	Spindle	THE 3RD SPINDLE'S TEETH NUMBER IN 1ST GEAR	⊙	Machine Maker	99
674	Spindle	TOOTH NUMBER OF THE 3RD SPINDLE'S MOTOR IN 2ND GEAR	⊙	Machine Maker	100
675	Spindle	TOOTH NUMBER OF THE 3RD SPINDLE IN 2ND GEAR	⊙	Machine Maker	100
676	Spindle	TOOTH NUMBER OF THE 3RD SPINDLE'S MOTOR IN 3RD GEAR	⊙	Machine Maker	104
677	Spindle	TOOTH NUMBER OF THE 3RD SPINDLE IN 3RD GEAR	⊙	Machine Maker	104
678	Spindle	TOOTH NUMBER OF THE 3RD SPINDLE'S MOTOR IN 4TH GEAR	⊙	Machine Maker	104
679	Spindle	TOOTH NUMBER OF THE 3RD SPINDLE IN 4TH GEAR	⊙	Machine Maker	105
680~699		Non			
700	Servo	[R10]Cutting Linear acceleration time ms	R	Machine Maker	89

No	Group	Description	Effective	Level	Page
701	Servo	[R10]Cutting bell shape acceleration time ms	R	Machine Maker	89
702	Servo	[R10]Smooth Cutting acceleration time ms	R	Machine Maker	89
703	Servo	[R10]After Cutting acceleration time ms	R	Machine Maker	89
704	Servo	[R10] round speed lock um/min	R	Machine Maker	90
705	Servo	[R10] round speed lock minimum/min	R	Machine Maker	90
706~709		Non			
710	Servo	[R10]X Corner speed difference um/min	R	Machine Maker	90
711	Servo	[R10]Y Corner speed difference um/min	R	Machine Maker	90
712	Servo	[R10]Z Corner speed difference um/min	R	Machine Maker	90
713	Servo	[R10]4TH Corner speed difference um/min	R	Machine Maker	90
714~715		Reserve			
716~729		Non			
730	Servo	[R10]Corner reference speed um/min	R	Machine Maker	90
731	Servo	[R10]X speed front feedback (%%)	R	Machine Maker	90
732	Servo	[R10]Y speed front feedback (%%)	R	Machine Maker	90
733	Servo	[R10]Z speed front feedback (%%)	R	Machine Maker	90
734	Servo	[R10]4th speed front feedback (%%)	R	Machine Maker	90
735~736		reserve			
737~749		Non			
750~799	Compensation	PITCH ERROR COMPENSATION OF 001~050SESSION OF THE 4TH AXIS μm	R	Machine Maker	123
800	Servo	G00'S IN-POSITION CHECK WINDOW OF X AXIS, μm	R	Machine Maker	91
801	Servo	G00'S IN-POSITION CHECK WINDOW OF Y AXIS, μm	R	Machine Maker	91
802	Servo	G00'S IN-POSITION CHECK WINDOW OF Z AXIS, μm	R	Machine Maker	91
803	Servo	G00'S IN-POSITION CHECK WINDOW OF THE 4TH AXIS, μm	R	Machine Maker	91
804	Operation	Screen saver		User	165
805~809		Non	R	User	
810	Operation	G101~G105 Rigid tapping setup	R	User	165
811	Compensation	BALL BAR COMPENSATION G CODE 0)G2 G3 1) ALL	R	Machine Maker	124
812	Compensation	REVERSAL SPIKE COMPENSATION: +X	R	Machine Maker	124
813	Compensation	DURATION OF REVERSAL SPIKE COMPENSATION: +X	R	Machine Maker	124
814	Compensation	REVERSAL SPIKE LAG COMPENSATION: +X	R	Machine Maker	125

No	Group	Description	Effective	Level	Page
815	Compensation	REVERSAL SPIKE COMPENSATION: -X	R	Machine Maker	125
816	Compensation	DURATION OF REVERSAL SPIKE COMPENSATION: -X	R	Machine Maker	126
817	Compensation	REVERSAL SPIKE LAG COMPENSATION: -X	R	Machine Maker	126
818	Compensation	REVERSAL SPIKE COMPENSATION: +Y	R	Machine Maker	124
819	Compensation	DURATION OF REVERSAL SPIKE COMPENSATION: +Y	R	Machine Maker	124
820	Compensation	REVERSAL SPIKE LAG COMPENSATION: +Y	R	Machine Maker	125
821~824		Non			
825	Compensation	REVERSAL SPIKE COMPENSATION: -Y	R	Machine Maker	125
826	Compensation	DURATION OF REVERSAL SPIKE COMPENSATION: -Y	R	Machine Maker	126
827	Compensation	REVERSAL SPIKE LAG COMPENSATION: -Y	R	Machine Maker	126
828	Compensation	REVERSAL SPIKE COMPENSATION: +Z	R	Machine Maker	124
829	Compensation	DURATION OF REVERSAL SPIKE COMPENSATION: +Z	R	Machine Maker	124
830	Compensation	REVERSAL SPIKE LAG COMPENSATION: +Z	R	Machine Maker	125
831	Compensation	REVERSAL SPIKE COMPENSATION: -Z	R	Machine Maker	125
832	Compensation	DURATION OF REVERSAL SPIKE COMPENSATION: -Z	R	Machine Maker	126
833	Compensation	REVERSAL SPIKE LAG COMPENSATION: -Z	R	Machine Maker	126
834	Zero Point	READING DURATION OF ABSOLUTE ENCODER	R	Machine Maker	134
835~838		Non	⊙		
839	Spindle	TOLERANCE OF THE 1ST SPINDLE DURING ORIENTATION	R	Machine Maker	110
840~844		Non			
845	Servo	X AXIS LINEAR/ROTARY TYPE	⊙	Machine Maker	91
846	Servo	Y AXIS LINEAR/ROTARY TYPE	⊙	Machine Maker	91
847	Servo	Z AXIS LINEAR/ROTARY TYPE	⊙	Machine Maker	91
848	Operation	X AXIS OPTIMAL	R	User	165
849	Operation	Y AXIS OPTIMAL	R	User	165
850	Operation	Z AXIS OPTIMAL	R	User	165
851~873		Non			
874	Spindle	1ST SPD SPEED CHK 0)ACT 1)CMD	R	Machine Maker	110
875	Spindle	DEFAULT INITIAL SPEED OF THE 2ND SPINDLE	⊙	User	107
876	Spindle	MAX SPEED OF 2ND SPINDLE	R	Machine Maker	102

No	Group	Description	Effective	Level	Page
877	Spindle	MIN. RPM OF THE 2nd SPINDLE	R	Machine Maker	102
878	Spindle	INITIAL RPM OF THE 3RD SPINDLE	⊙	User	102
879	Spindle	MAX. RPM OF THE 3RD SPINDLE	R	Machine Maker	102
880	Spindle	MIN. RPM OF THE 3RD SPINDLE	R	Machine Maker	102
881	Spindle	RPM REACHES SET RANGE OF THE 3RD SPINDLE	R	Machine Maker	110
882	Spindle	THE 3RD SPINDLE REACHES ZERO SPEED RPM	R	Machine Maker	112
883	Spindle	CORRESPONDING RPM OF THE 2ND SPINDLE MOTOR'S INPUT VOLTAGE 10V	R	Machine Maker	102
884	Spindle	VOLTAGE COMMAND'S OFFSET VALUE OF THE 2ND SPINDLE'S RPM	R	Machine Maker	103
885	Spindle	ACC/DEC TIME OF 2ND SPINDLE	⊙	Machine Maker	98
886	Spindle	CORRESPONDING RPM OF THE 3rd SPINDLE MOTOR'S INPUT VOLTAGE 10V	R	Machine Maker	102
887	Spindle	VOLTAGE COMMAND'S OFFSET VALUE OF THE 3RD SPINDLE'S RPM	R	Machine Maker	103
888	Spindle	ACCEL. /DECEL. TIME PER KILO-REV.OF THE 3RD SPINDLE	⊙	Machine Maker	98
889	Spindle	PPR OF THE 2ND SPINDLE'S ENCODER	⊙	Machine Maker	101
890	Spindle	FEEDBACK RATE OF THE 2ND SPINDLE	⊙	Machine Maker	101
891	Spindle	SIGNAL TYPE OF THE 2ND SPINDLE'S ENCODER	⊙	Machine Maker	108
892	Spindle	INSTALL THE 2ND SPINDLE'S ENCODER ONTO THE 0)SPINDLE 1)MOTOR	R	Machine Maker	103
893	Spindle	PPR OF THE 3RD SPINDLE'S ENCODER	⊙	Machine Maker	101
894	Spindle	FEEDBACK RATE OF THE 3RD SPINDLE	⊙	Machine Maker	101
895	Spindle	SIGNAL TYPE OF THE 3RD SPINDLE'S ENCODER	⊙	Machine Maker	108
896	Spindle	INSTALL THE 3RD SPINDLE'S ENCODER ONTO THE 0)SPINDLE 1)MOTOR	R	Machine Maker	103
897	Spindle	THE 2ND SPINDLE DISPLAYS 0)COMMAND 1) SENSOR	R	Machine Maker	102
898	Spindle	THE 3RD SPINDLE DISPLAYS 0)COMMAND 1) SENSOR	R	Machine Maker	102
899	Operation	APPLY CE REGULATIONS 0)NO 1)YES	R	Machine Maker	166
900~999		reserve			
1000	Servo	G00 MAX. SPEED OF X AXIS IN RAPID TRAVERSE, $\mu\text{m}/\text{min}$	R	Machine Maker	91
1001	Servo	G00 MAX. SPEED OF Y AXIS IN RAPID TRAVERSE, $\mu\text{m}/\text{min}$	R	Machine Maker	91
1002	Servo	G00 MAX. SPEED OF Z AXIS IN RAPID TRAVERSE, $\mu\text{m}/\text{min}$	R	Machine Maker	91
1003	Servo	G00 MAX. SPEED OF THE 4TH AXIS IN RAPID TRAVERSE, $\mu\text{m}/\text{min}$	R	Machine Maker	91
1004	Servo	G01 MAX. SPEED OF LINEAR CUTTING, $\mu\text{m}/\text{min}$	R	Machine Maker	91

No	Group	Description	Effective	Level	Page
1005		Non			
1006	Operation	SOFT PROTECTION OF THE 1ST TRAVEL LIMIT: +X μm	R	Machine Maker	166
1007	Operation	SOFT PROTECTION OF THE 1ST TRAVEL LIMIT: - X μm	R	Machine Maker	166
1008	Operation	SOFT PROTECTION OF THE 1ST TRAVEL LIMIT: +Y μm	R	Machine Maker	166
1009	Operation	SOFT PROTECTION OF THE 1ST TRAVEL LIMIT: - Y μm	R	Machine Maker	166
1010	Operation	SOFT PROTECTION OF THE 1ST TRAVEL LIMIT: +Z μm	R	Machine Maker	166
1011	Operation	SOFT PROTECTION OF THE 1ST TRAVEL LIMIT: - Z μm	R	Machine Maker	166
1012	Operation	SOFT PROTECTION OF THE 1ST TRAVEL LIMIT: +THE 4TH μm	R	Machine Maker	166
1013	Operation	SOFT PROTECTION OF THE 1ST TRAVEL LIMIT: - THE 4TH AXIS μm	R	Machine Maker	166
1014	Zero Point	ABSOLUTE COORDINATES OF X AXIS AFTER RETURNING TO HOME POINT μm	R	Machine Maker	134
1015	Zero Point	ABSOLUTE COORDINATES OF Y AXIS AFTER RETURNING TO HOME POINT μm	R	Machine Maker	134
1016	Zero Point	ABSOLUTE COORDINATES OF Z AXIS AFTER RETURNING TO HOME POINT μm	R	Machine Maker	134
1017	Zero Point	ABSOLUTE COORDINATES OF THE 4TH AXIS AFTER RETURNING TO HOME POINT μm	R	Machine Maker	134
1018	Compensation	SESSION INTERVAL OF PITCH ERROR COMPENSATION: X AXIS μm	⊙	Machine Maker	126
1019	Compensation	SESSION INTERVAL OF PITCH ERROR COMPENSATION: Y AXIS μm	⊙	Machine Maker	126
1020	Compensation	SESSION INTERVAL OF PITCH ERROR COMPENSATION: Z AXIS μm	⊙	Machine Maker	126
1021	Compensation	SESSION INTERVAL OF PITCH ERROR COMPENSATION: THE 4TH AXIS μm	⊙	Machine Maker	126
1022	Zero Point	THE CORRESPONDING OFFSET AMOUNT OF X AXIS'S 2ND ZERO POINT TO THE 1ST ZERO POINT μm	R	Machine Maker	134
1023	Zero Point	THE CORRESPONDING OFFSET AMOUNT OF Y AXIS'S 2ND ZERO POINT TO THE 1ST ZERO POINT μm	R	Machine Maker	134
1024	Zero Point	THE CORRESPONDING OFFSET AMOUNT OF Z AXIS'S 2ND ZERO POINT TO THE 1ST ZERO POINT μm	R	Machine Maker	134
1025	Zero Point	THE CORRESPONDING OFFSET AMOUNT OF THE 4TH AXIS'S 2ND ZERO POINT TO THE 1ST ZERO POINT μm	R	Machine Maker	134
1026	Zero Point	THE CORRESPONDING OFFSET AMOUNT OF X AXIS'S 3RD ZERO POINT TO THE 1ST ZERO POINT μm	R	Machine Maker	135
1027	Zero Point	THE CORRESPONDING OFFSET AMOUNT OF Y AXIS'S 3RD ZERO POINT TO THE 1ST ZERO POINT μm	R	Machine Maker	135
1028	Zero Point	THE CORRESPONDING OFFSET AMOUNT OF Z AXIS'S 3RD ZERO POINT TO THE 1ST ZERO POINT μm	R	Machine Maker	135

No	Group	Description	Effective	Level	Page
1029	Zero Point	THE CORRESPONDING OFFSET AMOUNT OF THE 4TH AXIS'S 3RD ZERO POINT TO THE 1ST ZERO POINT μm	R	Machine Maker	135
1030	Zero Point	THE CORRESPONDING OFFSET AMOUNT OF X AXIS'S 4TH ZERO POINT TO THE 1ST ZERO POINT μm	R	Machine Maker	135
1031	Zero Point	THE CORRESPONDING OFFSET AMOUNT OF Y AXIS'S 4TH ZERO POINT TO THE 1ST ZERO POINT μm	R	Machine Maker	135
1032	Zero Point	THE CORRESPONDING OFFSET AMOUNT OF Z AXIS'S 4TH ZERO POINT TO THE 1ST ZERO POINT μm	R	Machine Maker	135
1033	Zero Point	THE CORRESPONDING OFFSET AMOUNT OF THE 4TH AXIS'S 4TH ZERO POINT TO THE 1ST ZERO POINT μm	R	Machine Maker	135
1034	Operation	SOFT PROTECTION OF THE 2ND TRAVEL LIMIT: +X μm	R	Machine Maker	167
1035	Operation	SOFT PROTECTION OF THE 2ND TRAVEL LIMIT: -X μm	R	Machine Maker	167
1036	Operation	SOFT PROTECTION OF THE 2ND TRAVEL LIMIT: +Y μm	R	Machine Maker	167
1037	Operation	SOFT PROTECTION OF THE 2ND TRAVEL LIMIT: -Y μm	R	Machine Maker	167
1038	Operation	SOFT PROTECTION OF THE 2ND TRAVEL LIMIT: +Z μm	R	Machine Maker	167
1039	Operation	SOFT PROTECTION OF THE 2ND TRAVEL LIMIT: -Z μm	R	Machine Maker	167
1040	Operation	SOFT PROTECTION OF THE 2ND TRAVEL LIMIT: +4TH AXIS μm	R	Machine Maker	167
1041	Operation	SOFT PROTECTION OF THE 2ND TRAVEL LIMIT: -4TH AXIS μm	R	Machine Maker	167
1042	Servo	G31 PRESET FEED RATE	R	Machine Maker	92
1043~1045		Non		User	
1046	Compensation	START POSITION OF PITCH ERROR: X AXIS μm	⊙	Machine Maker	126
1047	Compensation	START POSITION OF PITCH ERROR: Y AXIS μm	⊙	Machine Maker	126
1048	Compensation	START POSITION OF PITCH ERROR: Z AXIS μm	⊙	Machine Maker	126
1049	Compensation	START POSITION OF PITCH ERROR: THE 4TH AXIS μm	⊙	Machine Maker	126
1050~1053		Non			
1054	Spindle	RPM REACHES SET RANGE OF THE 1ST SPINDLE	R	Machine Maker	110
1055		Non			
1056	Spindle	SPD ORIENTATION OFFSET ANGLE	R	Machine Maker	111
1057		Non			
1058	Spindle	1st SP Rigid tapping following max lag value μm	R	Machine Maker	
1059	Spindle	ACCEL. /DECEL. TIME PER KILO-REV. OF THE 1ST SPINDLE DURING RIGID TAPPING	R	Machine Maker	111
1060	Spindle	1ST SPD RIGTAP EXTRACTION RATE			
1061	Servo	MAX. SPEED OF LATHE TAPPING	R	Machine Maker	92

No	Group	Description	Effective	Level	Page
1062		Non	R	Machine Maker	
1063	Spindle	THE 1ST SPINDLE REACHES ZERO SPEED RPM	R	Machine Maker	112
1064	Spindle	COMMAND COMPENSATION AMOUNT OF THE 1ST SPINDLE'S RPM DURING RIGID TAPPING	R	Machine Maker	112
1065	Spindle	COMMAND COMPENSATION AMOUNT OF THE 1ST SPINDLE'S ACCELERATION DURING RIGID TAPPING	R	Machine Maker	112
1066	Spindle	COMPENSATIVE FILTER INTENSITY OF THE 1ST SPINDLE'S RPM DURING RIGID TAPPING	R	Machine Maker	113
1067~1069		Non			
1070	Spindle	COMPENSATIVE FILTER INTENSITY OF THE 1ST SPINDLE'S ACCELERATION SPEED DURING RIGID TAPPING	R	Machine Maker	113
1071	Spindle	1st SP revers rigid tap output 0)NO 1)YES	R	Machine Maker	113
1072	Servo	PULSE WIDTH μ s	☉	Machine Maker	92
1073~1074		Non			
1075	Spindle	TOLERANCE OF THE 1ST SPINDLE IN CONTROL MODE	R	Machine Maker	113
1076	Spindle	SPD1 RIGTAP DEC TIME/1000 RPM	R	Machine Maker	114
1077	Spindle	JOG SPEED OF 3RD SPINDLE	R	Machine Maker	114
1078~1090		Non			
1091	Operation	Default turning angle for coordinate system	R	User	167
1092	Operation	Ratio for X coordinate zoom	R	User	168
1093	Operation	Ratio for Y coordinate zoom	R	User	168
1094	Operation	Ratio for Z coordinate zoom	R	User	168
1095		Non			
1096	Spindle	MAX SPEED OF 1ST SPINDLE	R	Machine Maker	114
1097	Spindle	1ST SPINDLE D/A SCALE RPM/10V	R	Machine Maker	114
1098	Zero Return	ABS. ENCODER CHECK RANGE	R	Machine Maker	135
1099		Non			
1100	Servo	JOG SPEED FOR X AXIS μ m/min	R	Machine Maker	93
1101	Servo	JOG SPEED FOR Y AXIS μ m/min	R	Machine Maker	93
1102	Servo	JOG SPEED FOR Z AXIS μ m/min	R	Machine Maker	93
1103	Servo	JOG SPEED FOR THE 4TH AXIS μ m/min	R	Machine Maker	93
1104	Zero Point	HOME RETURN AT THE 1ST SPEED: X AXIS μ m/min	R	Machine Maker	136
1105	Zero Point	HOME RETURN AT THE 1ST SPEED: Y AXIS μ m/min	R	Machine Maker	136
1106	Zero Point	HOME RETURN AT THE 1ST SPEED: Z AXIS μ m/min	R	Machine Maker	136

No	Group	Description	Effective	Level	Page
1107	Zero Point	HOME RETURN AT THE 1ST SPEED: THE 4TH AXIS $\mu\text{m}/\text{min}$	R	Machine Maker	136
1108	Zero Point	HOME RETURN AT THE 2ND SPEED: X AXIS $\mu\text{m}/\text{min}$	R	Machine Maker	136
1109	Zero Point	HOME RETURN AT THE 2ND SPEED: Y AXIS $\mu\text{m}/\text{min}$	R	Machine Maker	136
1110	Zero Point	HOME RETURN AT THE 2ND SPEED: Z AXIS $\mu\text{m}/\text{min}$	R	Machine Maker	136
1111	Zero Point	HOME RETURN AT THE 2ND SPEED: THE 4TH AXIS $\mu\text{m}/\text{min}$	R	Machine Maker	136
1112	Servo	ENCODER.X PULSES/ROTATION	⊙	Machine Maker	80
1113	Servo	ENCODER.Y PULSES/ROTATION	⊙	Machine Maker	80
1114	Servo	ENCODER.Z PULSES/ROTATION	⊙	Machine Maker	80
1115	Servo	ENCODER.4TH PULSES/ROTATION	⊙	Machine Maker	80
1116	Spindle	1ST SPINDLE ENCODER PPR	⊙	Machine Maker	114
1117		Non			
1118	Zero Point	INDEX PROTECTION	R	User	136
1119~1120		reserve			
1121	Spindle	JOG RPM OF THE 1ST SPINDLE	R	Machine Maker	114
1122~1149		reserve			
1150	Spindle	1st SP 1ST Gear switch RPM	R	Machine Maker	114
1151	Spindle	1st SP 2ND Gear switch RPM	R	Machine Maker	115
1152	Spindle	1st SP 3RD Gear switch RPM	R	Machine Maker	115
1153	Spindle	1st SP Motor gear change RPM	R	Machine Maker	116
1154	Spindle	1st SP Motor gear change RPM check range	R	Machine Maker	116
1155	Spindle	1st SP Max RPM at 1ST gear	R	Machine Maker	116
1156	Spindle	1st SP Max RPM at 2ND gear	R	Machine Maker	116
1157	Spindle	1st SP Max RPM at 3RD gear	R	Machine Maker	117
1158	Operation	SHOW F2~F12 FOR FUN. KEY	⊙	User	168
1159	Operation	PROGRAM READING OVERTIME		User	168
1160~1170		Non			
1171	Home	X multiple Home Linear encoder Home space 1 μm	⊙	Machine Maker	137
1172	Home	X multiple Home Linear encoder Home space 2 μm	⊙	Machine Maker	137
1173	Home	Y multiple Home Linear encoder Home space 1 μm	⊙	Machine Maker	137
1174	Home	Y multiple Home Linear encoder Home space 2 μm	⊙	Machine Maker	137
1175	Home	Z multiple Home Linear encoder Home space 1 μm	⊙	Machine Maker	137

No	Group	Description	Effective	Level	Page
1176	Home	Z multiple Home Linear encoder Home space 2/ μ m	⊙	Machine Maker	137
1177	Home	4th multiple Home Linear encoder Home space 1/ μ m	⊙	Machine Maker	137
1178	Home	4th multiple Home Linear encoder Home space 2/ μ m	⊙	Machine Maker	137
1179~1182		reserve			
1183	Home	X home OFFSET relative to Linear encoder.	R	Machine Maker	137
1184	Home	Y home OFFSET relative to Linear encoder.	R	Machine Maker	137
1185	Home	Z home OFFSET relative to Linear encoder.	R	Machine Maker	137
1186	Home	4th home OFFSET relative to Linear encoder.	R	Machine Maker	137
1187~1188		Reserve			
1189~1199		Non			
1200~1299	compensation	X the 051~150 section gear error compensation / μ m	R	Machine Maker	122
1300~1399	compensation	Y the 051~150 section gear error compensation / μ m	R	Machine Maker	122
1400~1499	compensation	Z the 051 section gear error compensation / μ m	R	Machine Maker	123
1500~1599	compensation	4 th the 051 section gear error compensation / μ m	R	Machine Maker	123
1600~1799		Reserve			
1800~1805		Non			
1806	Operation	COM1 address (0:Disable 744~1016)	⊙	Machine Maker	169
1807	Operation	COM2 address (0:Disable 744~1016)	⊙	Machine Maker	169
1809	Operation	COM1 Interrupt number (3~7)	⊙	Machine Maker	169
1810	Operation	COM2 Interrupt number (3~7)	⊙	Machine Maker	169
1811	Operation	COM1 (0:Non 1:File 2:ABS 3:Spindle)	⊙	Machine Maker	169
1812	Operation	COM2 (0Non 1:file 2:ABS 3:Spindle)	⊙	Machine Maker	170
1813	Operation	File transfer Speed (bps)(0~4)		User	170
1814	Operation	File transfer Data Bit(0:7 1:8 bit)		User	170
1815	Operation	File transfer stop bit(0:1 1:2)		User	170
1816	Operation	File transfer odd, even check (0: N 1: E 2: O)		User	170
1817	Operation	File transfer mode (0:terminal 1:Host)		User	170
1818~1823		Non			
1824	Servo	Servo communication type(0:NO 1:M)	⊙	Machine Maker	93
1825	Servo	X Servo communication station number(0:Not use 1~15)	⊙	Machine Maker	93
1826	Servo	Y Servo communication station number(0:Not use 1~15)	⊙	Machine Maker	93
1827	Servo	Z Servo communication station number(0:Not use 1~15)	⊙	Machine Maker	93
1828	Servo	4 th Servo communication station number(0:Not use 1~15)	⊙	Machine Maker	93
1829~1830		Reserve			

No	Group	Description	Effective	Level	Page
1831		X-PMC G01 position check window range um	R	Machine Maker	94
1832		Y-PMC G01 position check window range um	R	Machine Maker	94
1833		Z-PMC G01 position check window range um	R	Machine Maker	94
1834		4TH-PMC G01 position check window range um	R	Machine Maker	94
1835~1836		Reserve			
1837		X-PMC G00 position check window range um	R	Machine Maker	94
1838		Y-PMC G00 position check window range um	R	Machine Maker	94
1839		Z-PMC G00 position check window range um	R	Machine Maker	94
1840		4TH-PMC G00 position check window range um	R	Machine Maker	94
1841~1842		Reserve			
1843~1882	Operation	User parameter 2, R value column 1~40		Machine Maker	171
1883	Servo	PMC Linear Cutting G01 的 max speed um/min	R	Machine Maker	94
1884	Servo	X-PMC G00 max speed um/min	R	Machine Maker	94
1885	Servo	Y-PMC G00 max speed um/min	R	Machine Maker	94
1886	Servo	Z-PMC G00 max speed um/min	R	Machine Maker	94
1887	Servo	4TH-PMC G00 max speed um/min	R	Machine Maker	94
1888~1889		Reserve			
1900	Operation	1 ST Software restricted area X positive axis travel value(um)	R	Machine Maker	171
1901	Operation	1 ST Software restricted area X negative axis travel value(um)	R	Machine Maker	171
1902	Operation	1 ST Software restricted area Y positive axis travel value(um)	R	Machine Maker	171
1903	Operation	1 ST Software restricted area Y negative axis travel value(um)	R	Machine Maker	171
1904	Operation	1 ST Software restricted area Z positive axis travel value(um)	R	Machine Maker	171
1905	Operation	1 ST Software restricted area Z negative axis travel value(um)	R	Machine Maker	171
1906	Operation	1 ST Software restricted area 4th positive axis travel value(um)	R	Machine Maker	171
1907	Operation	1 ST Software restricted area 4th negative axis travel value(um)	R	Machine Maker	171
1908~1911		reserve			
1912	Operation	2ND Software restricted area X positive axis travel value(um)	R	Machine Maker	171
1913	Operation	2ND Software restricted area X negative axis travel value(um)	R	Machine Maker	171
1914	Operation	2ND Software restricted area Y positive axis travel value(um)	R	Machine Maker	171
1915	Operation	2ND Software restricted area Y negative axis travel value(um)	R	Machine Maker	171

No	Group	Description	Effective	Level	Page
1916	Operation	2ND Software restricted area Z positive axis travel value(um)	R	Machine Maker	171
1917	Operation	2ND Software restricted area Z negative axis travel value(um)	R	Machine Maker	171
1918	Operation	2ND Software restricted area 4TH positive axis travel value(um)	R	Machine Maker	171
1919	Operation	2ND Software restricted area 4TH negative axis travel value(um)	R	Machine Maker	171
1920~1923		reserve			
1924~1928		Non			
1929	Servo	M-II 0)OFF 1)ON	⊙	Machine Maker	94
1930	Servo	M-II communicate time (us)	⊙	Machine Maker	94
1931	Servo	M-II use ABS encoder(Bit)	⊙	Machine Maker	95
1932	Servo	Artificial Intelligent Cutting Type (0:AIC 1:AIC-II)	R	Machine Maker	95
1933	Servo	M-II G31 signal source axis name(Bit)	R	Machine Maker	95
1934~1939		Non			
1940~1947		reserve			
1948~2999		reserve			
3000~3131		reserve			
3132~3799		Non			
3800~3810		reserve			

3.2 Servo Parameter

1	SYSTEM LOOP GAINS FOR V CMD
	Range : 1 ~ 20000
	Effective : Effective After Reboot
	Access level : Machine Maker
	Default : 30
	Unit : 1/sec
	This used with V command position loop gain.

2	MAX. SERVO LAG OF X AXIS, μm
3	MAX. SERVO LAG OF Y AXIS, μm
4	MAX. SERVO LAG OF Z AXIS, μm
5	MAX. SERVO LAG OF THE 4TH AXIS, μm

Range : 1 ~ 30000
 Effective : Effective After RESET
 Access level : Machine Maker
 Default : 30000
 Unit : μm

This parameter is to set maximum following error amount of X axis (SERVO LAG). When the following error amount of X axis is over this parameter setting value, System Alarm [MOT The Axis Servo LAG Over Para. Setting Value] will occur.

$\text{lag} = F/K_p$
 F is the feedrate; K_p is the position Loop incremental value.
 From the above formula, the bigger the feedrate, the bigger the following error amount. So, user only needs to key-in maximum speed into the above formula to get the maximum following error amount of the axis.
 Example:

gain is $100(\frac{1}{s})$, the speed of G00 is 20000mm/min, and the servo lag would be:

$$\text{lag} = \frac{20000000(\mu\text{m})}{60(\text{s}) \times 100(\frac{1}{s})} = 3333.3\mu\text{m}$$

When the machine functions normally, the servo lag amount of X axis should not exceed $3334\mu\text{m}$ at any time. Hence, the recommendation is to multiply this value by a safe coefficient (about 1.1) and enter the product into Pr. 0002.

6	IN-POSITION CHECK WINDOW OF X AXIS, μm
7	IN-POSITION CHECK WINDOW OF Y AXIS, μm
8	IN-POSITION CHECK WINDOW OF Z AXIS, μm
9	IN-POSITION CHECK WINDOW OF THE 4TH AXIS, μm

Range : 1 ~ 20000
 Effective : Effective After RESET
 Access level : Machine Maker
 Default : 50
 Unit : μm

This parameter sets the in-position check window of each axis in the Exact Stop mode. When some axis's
 $|\text{command position} - \text{actual position}| \leq \text{this parameter's set value}$,
 This means that this axis has completed cutting feed and stopped. Please also refer to the setting description of Pr. 0043.

10	G00'S ACCEL. /DECEL. TIME OF X AXIS, ms
11	G00'S ACCEL. /DECEL. TIME OF Y AXIS, ms
12	G00'S ACCEL. /DECEL. TIME OF Z AXIS, ms
13	G00'S ACCEL. /DECEL. TIME OF THE 4TH AXIS, ms

Range : 3 ~ 1500

Effective : Effective After Reboot

Access level : Machine Maker

Default : 230

Unit : ms

This parameter sets each axis's acceleration & deceleration time of rapid traverse. The smaller the parameter is, the faster each axis reaches the designated motion speed. However, this might also cause vibration of each axis.

For 486IPC version (IPO is 5ms), the maximum value of this parameter is 2000.

For 586IPC version (IPO is 3ms), the maximum value of this parameter is 1500.

If the set value is smaller than IPO cycle or exceeds the tolerance of the above values, the alarm "MOT4031 ~ 4034 SET PAR ERROR" will be triggered.

14	G01 ACCEL. /DECEL. TIME
----	--------------------------------

Range : 3 ~ 1500

Effective : Effective After Reboot

Access level : Machine Maker

Default : 100

Unit : ms

This parameter is to set the acceleration/deceleration time of G00 of all servo axes. The smaller this parameter is, the faster the servo axis reaches the specified speed; vibration, however, would be more indispensable. For 486IPC version (the IPO is 10ms), the max. Value is 2000; for 586IPC version (the IPO is 3ms), the max. Value is 1500.

If the set value exceeds the above limit, the alarm "MOT 4030 SET PAR 14 ERROR" will be triggered.

24	CORRESPONDING SERVO AXIS NUMBER OF X AXIS
25	CHANNEL NO FOR Y AXIS
26	CORRESPONDING SERVO AXIS NUMBER OF Z AXIS
27	CORRESPONDING SERVO AXIS NUMBER OF THE 4TH AXIS

Range : 0 ~ 6

Effective : Effective After Reboot

Access level : Machine Maker

Default : 0

Unit : Null

If the lead of X (Y, Z, the 4th) axis is connected to the Nth axis of the transit card, then set this parameter to N; if not connected to a motor, set to 0.

40	G00'S LOWEST OVERRIDE AT F0
----	------------------------------------

Range : 0 ~ 25

Effective : Effective After RESET

Access level : User

Default : 10

Unit : %

This parameter sets the actual override value in percentage when the override rotary switch of rapid traverse is turned to 0%. For example, if this parameter is set to 10, and the rotary switch of rapid traverse is turned to 0%, then the actual corresponding value is 10%.

53	ENCODER FEEDBACK MULTIPLIER OF THE 4TH AXIS 1/2/4
54	ENCODER FEEDBACK MULTIPLIER OF X AXIS 1/2/4
55	ENCODER FEEDBACK MULTIPLIER OF Y AXIS 1/2/4
56	ENCODER FEEDBACK MULTIPLIER OF Z AXIS 1/2/4

Range : 1 ~ 4

Effective : Effective After Reboot

Access level : Machine Maker

Default : 4

Unit : Nul

This parameter sets the encoder feedback multiplier of each axis. This parameter is valid only when the types of encoder feedback signals are A/B PHASE. If each axis's encoder feedback signals are the CW/CCW or PULSE/DIRECTION type (the set value is 1 or 2, respectively), then the encoder feedback multiplier would always be 1.

In Pulse Command mode, the product of this parameter multiplying the output pulse number for each motor encoder to make one revolution is equal to the pulse command amount that NC demands to enable each axial motor to make one revolution.

1112	ENCODER.X PULSES/ROTATION
1113	ENCODER.Y PULSES/ROTATION
1114	ENCODER.Z PULSES/ROTATION
1115	ENCODER.4TH PULSES/ROTATION

Range : 1 ~ 99999999

Effective : Effective After Reboot

Access level : Machine Maker

Default : 2500

Unit : pulse

If the motor ENCODER 1 turn = 2500 PULSE, then this set to be 2500. Please refer to the ratio factor of each axis of feedback setup instructions.

65	Absolute encoder BIT
-----------	-----------------------------

Range: 0 ~ 63

Effective time: Effective After Reboot

Access level: Machine Maker

Default: 0

Unit: Non

Description: BIT 0 : Set 0=X use Incremental encoder, set1= X use ABS encoder.

BIT 1 : Set 0=Y use Incremental encoder, set1= Y use ABS encoder.

BIT 2 : Set 0=Z use Incremental encoder, set1= Z use ABS encoder.

BIT 3 : Set 0=4TH use Incremental encoder, set1= 4TH use ABS encoder.

66	SET THE 4TH AXIS AS A 0)ROTARY 1)LINEAR AXIS Range : 0 ~ 1 Effective : Effective After Reboot Access level : Machine Maker Default : 0 Unit : Nul 0: Rotary axis; 1: Linear axis. If the axes are linear axes, the ball screw's pitch should be set according to its actual value; if the axes are rotary axes, the ball screw's pitch should be set to 360 (which indicate 360°).
108	RPM TO VOLTAGE RATIO FOR X AXIS RPM/1V
109	RPM TO VOLTAGE RATIO FOR Y AXIS RPM/1V
110	RPM TO VOLTAGE RATIO FOR Z AXIS RPM/1V
111	RPM TO VOLTAGE RATIO FOR THE 4TH AXIS RPM/1V Range : 1 ~ 20000 Effective : Effective After Reboot Access level : Machine Maker Default : 200 Unit : RPM/1V This parameter sets the RPM that corresponds to 1V of input voltage for each axis motor. For example, if the input voltage is 10V, and the rotation speed of each axis motor is 2000RPM, then this parameter's set value would be 200. This parameter is only effective when the control mode of each axis is V Command.
116	MOVING DIR OF EACH AXIS Range : 0 ~ 63 Effective : Effective After Reboot Access level : Machine Maker Default : 0 Unit : Nul BIT0 : When set as 1, the X-axis should move in reverse direction against previous movement. When set as 0, there is no reverse movement. BIT1 : When set as 1, the Y-axis should move in reverse direction against previous movement. When set as 0, there is no reverse movement. BIT2 : When set as 1, the Z-axis should move in reverse direction against previous movement. When set as 0, there is no reverse movement. BIT3 : When set as 1, the 4 TH -axis should move in reverse direction against previous movement. When set as 0, there is no reverse movement. BIT4 : When set as 1, the spindle-axis should rotate in reverse direction against previous. When set as 0, there is no reverse rotation. This only effects only when the spindle is under PULSE COMMAND, such as spindle orientation and rigid tapping. Description: Take the X-axis for example, under JOG mode, if you pressed the +x button on the OP panel, the machine X-axis moves in negative direction, it means motor's positive rotation is in reverse to +X axis direction. Please set BIT0 as 1. If you pressed the +x button on the OP panel, the machine X-axis moves in positive direction as well, please set BIT0 as 0. Such is the same with the entire rest axis.
156	COMMAND TYPE OF X AXIS 0)AB 1)CW 2)PD 3)V
157	COMMAND TYPE OF Y AXIS 0)AB 1)CW 2)PD 3)V
158	COMMAND TYPE OF Z AXIS 0)AB 1)CW 2)PD 3)V

159

COMMAND TYPE OF THE 4TH AXIS 0)AB 1)CW 2)PD 3)V

Range : 0 ~ 3

Effective : Effective After Reboot

Access level : Machine Maker

Default : 0

Unit : Nul

0 : A/B PHASE ;

1 : CW/CCW ;

2 : PULSE/DIRECTION °

3 : Voltage

When some pulse command type is set at NC side, the same pulse command type must be also set for the motor driver. If the set value is 1 or 2, users must either set the rising width of output pulse (Pr. 1072) or enable Pr. 0186 so the rising width of output pulse will be adjusted to 50% automatically. For A/B PHASE, NC axis card adjusts itself to 50% duration automatically and does not require additional settings.

185

INV POS FEEDBACK OF EACH AXIS

Range : 0 ~ 63

Effective : Effective After Reboot

Access level : Machine Maker

Default : 0

Unit : Nul

BIT0 : when set as 1, means negative X-axis ENCODER feedback signal

BIT1 : when set as 1, means negative Y-axis ENCODER feedback signal

BIT2 : when set as 1, means negative Z-axis ENCODER feedback signal

BIT3 : when set as 1, means negative 4TH-axis ENCODER feedback signal

BIT4 : when set as 1, means negative spindle ENCODER feedback signal

【Setting timing】

Take X-axis for example, if X-axis is set as PULSE TYPE, when you press the +X button of OP panel, the machine X-axis moves in positive direction, but the value of system data #000(X-axis following error) continuously increases, and this value doesn't decrease down to the range of ± 1 , it means that you have to reverse the X-axis ENCODER signal.

(Usually this is caused when the BIT0 of parameter # 0116 is set as 1.) In this case, please set the BIT0 of parameter # 0116 as 1. If the above didn't occur, please set the BIT0 of parameter # 0116 as 0. If X-axis is under V COMMAND mode, when you press the +X button of OP panel, the machine X-axis rushes, it means that you have to reverse the X-axis ENCODER signal. In this case, please set the BIT0 of this parameter as 1.

So is the same with the other entire axis.

186	Enable the pulse rise wide auto adjustment
Range:	0 ~ 1
Effective time:	Effective After Reboot
Access level:	Machine Maker
Default:	0
Unit:	Non
Description:	Set to 1, command type=Pulse Dir. or CW/CCW, output pulse wide will auto adjust to 50%/50%. Need certain hardware to support this function.

188	POSITION LOOP GAIN OF SERVO AXIS IN PULSE COMMAND 1/sec.
Range :	1 ~ 32767
Effective :	Effective After RESET
Access level :	Machine Maker
Default :	30
Unit :	1/sec
	<p>This parameter is to calculate the actual contour of ARCH error set by ARCH FEEDRATE AUTO CLAMP function (please refer to Pr. 0187 for further details of this function). In PULSE TYPE, because position control loop is processed by servo driver, NC is unable to obtain the set value of this parameter. In order to allow NC to obtain the set value of this parameter when ARCH FEEDRATE AUTO CLAMP function is enabled, a position loop gain must be set manually in advance. Please note that the position loop gain of each axis must be the same, otherwise the actual contour of ARCH command will become an ellipse.</p> <p>Please also refer to the descriptions of related parameters: Pr.0187 & Pr.0809.</p>

191	ENCORDER SIGNAL TYPE OF X AXIS
192	ENCORDER SIGNAL TYPE OF Y AXIS
193	ENCORDER SIGNAL TYPE OF Z AXIS
194	ENCORDER SIGNAL TYPE OF THE 4TH AXIS
Range :	0 ~ 3
Effective :	Effective After Reboot
Access level :	Machine Maker
Default :	0
Unit :	Nul
	<p>0 : A/B PHASE</p> <p>1 : CW/CCW</p> <p>2 : PULSE/DIRECTION</p> <p>3 : n/A</p> <p>This parameter sets the output signal type of X axis's motor encoder . Please refer to the setting of motor driver. If X axis does not have an encoder (ex. a stepping motor), please set this parameter to 3.</p>

238	Enable the pulse rise wide auto adjustment
Range:	0 ~ 1
Effective time:	Effective After Reboot
Access level:	Machine Maker
Default:	0
Unit:	Non
Description:	Set to 1, command type=Pulse Dir. or CW/CCW, output pulse wide will auto adjust to 50%/50%. Need certain hardware to support this function.

298	Set PMC axis G00 acceleration time ms Range: 3 ~ 1500 Effective time: Effective After Reboot Access level: Machine Maker Default: 230 Unit: ms Description: Set PMC axis G00 acceleration time °
299	Set PMC axis G01 acceleration time ms Range: 3 ~ 1500 Effective time: Effective After Reboot Access level: Machine Maker Default: 100 Unit: Ms Description: Set PMC axis G01 acceleration time °
398	Set PMC axis G00 的 acceleration time ms Range: 3 ~ 1500 Effective time: Effective After Reboot Access level: Machine Maker Default: 230 Unit: Ms Description: Set PMC axis G00 acceleration time °
399	Set PMC axis G01 acceleration time ms Range: 3 ~ 1500 Effective time: Effective After Reboot Access level: Machine Maker Default: 100 Unit: Ms Description: Set PMC axis G01 acceleration time °
400	[R1]Cutting Linear acceleration time ms Range: 0 ~ 1000 Effective time: Effective After RESET Access level: Machine Maker Default: 60 Unit: Ms Description: Set HSP[R1]Cutting Linear acceleration time °
401	[R1]Cutting Bell shape acceleration time ms Range: 0 ~ 1000 Effective time: Effective After RESET Access level: Machine Maker Default: 20 Unit: ms Description: Set HSP[R1]Cutting Bell shape acceleration time °

402	[R1]Smooth Cutting acceleration time ms Range: 0 ~ 1000 Effective time: Effective After RESET Access level: Machine Maker Default: 0 Unit: ms Description: Set HSP[R1]Cutting Smooth acceleration time °
403	[R1]After Cutting acceleration time ms Range: 0 ~ 1000 Effective time: Effective After RESET Access level: Machine Maker Default: 60 Unit: ms Description: Set HSP[R1] After Cutting acceleration time °
404	[R1] round speed lock um/min Range: 100 ~ 200000000 Effective time: Effective After RESET Access level: Machine Maker Default: 2000000 Unit: Um/min Description: Set HSP[R1] round speed lock °
405	[R1] round speed lock minimum/min Range: 100 ~ 200000000 Effective time: EFFECTIVE AFTER RESET Access level: Machine Maker Default: 500000 Unit: Um/min Description: Set HSP[R1] round speed lock minim °
406	SHINING MODE Range: 0 ~ 1 Effective time: EFFECTIVE AFTER RESET Access level: Machine Maker Default: 0 Unit: Non Description: 0 : OFF SHINING MODE 1 : ON SHINING MODE
407	Feed forward Range: 0 ~ 1 Effective time: EFFECTIVE AFTER RESET Access level: Machine Maker Default: 0 Unit: Non Description: 0 : OFF feed forward 1 : ON feed forward
408	G05R_Default level

Range: 0 ~ 10
 Effective time: EFFECTIVE AFTER RESET
 Access level: User
 Default: 1
 Unit: Non
 Description: G05 HSP default level set up

409**Curve fitting tolerance (um)**

Range: -1 ~ 10
 Effective time: EFFECTIVE AFTER RESET
 Access level: Machine Maker
 Default: -1
 Unit: um
 Description: -1 : OFF °

410**[R1]X Corner speed difference um/min****411****[R1]Y Corner speed difference um/min****412****[R1]Z Corner speed difference um/min****413****[R1]4TH Corner speed difference um/min**

Range: 0 ~ 200000000
 Effective time: EFFECTIVE AFTER RESET
 Access level: Machine Maker
 Default: 8000000
 Unit: Um/min
 Description: Set HSP[R1]各 Corner speed difference °

416**X stops Servo lag check um****417****Y stops Servo lag check um****418****Z stops Servo lag check um****419****4TH stops Servo lag check um**

Range: 0 ~ 50000
 Effective time: EFFECTIVE AFTER RESET
 Access level: Machine Maker
 Default: 50
 Unit: um
 Description: This parameter use for set Servo stop lag checking range, When the axis servo lag over this value, it will send alarm[MOT Servo lag over range, check servo wiring or parameter]

422	X position loop gain 1/s
423	Y position loop gain 1/s
424	Z position loop gain 1/s
425	4TH position loop gain 1/s

Range: 0 ~ 1000
 Effective time: EFFECTIVE AFTER RESET
 Access level: Machine Maker
 Default: 60
 Unit: 1/s
 Description: Use this parameter to set position loop gain value

429	Corner method 0)Normal 1)Speed deference 2)reference
-----	---

Range: 0 ~ 3
 Effective time: EFFECTIVE AFTER RESET
 Access level: Machine Maker
 Default: 2
 Unit: Non
 Description: Set Corner method °

430	[R1] Corner reference speed um/min
-----	---

Range: 0 ~ 200000000
 Effective time: EFFECTIVE AFTER RESET
 Access level: Machine Maker
 Default: 800000
 Unit: Um/min
 Description: Set HSP[R1] Corner reference speed °

431	[R1]X speed feed forward (%)
432	[R1]Y speed feed forward (%)
433	[R1]Z speed feed forward (%)
434	[R1]4TH speed feed forward (%)

Range: 0 ~ 200
 Effective time: EFFECTIVE AFTER RESET
 Access level: Machine Maker
 Default: 0
 Unit: %
 Description: Set HSP[R1] each axis speed feed forward °

437	X feed forward acceleration time (ms)
438	Y feed forward acceleration time (ms)
439	Z feed forward acceleration time (ms)
440	4TH feed forward acceleration time (ms)

Range: 0 ~ 100

Effective time: EFFECTIVE AFTER RESET

Access level: Machine Maker

Default: 10

Unit: ms

Description: Use this to set feed forward acceleration time °

500	In synchronization X follow target axis Name
501	In synchronization Y follow target axis Name
502	In synchronization Z follow target axis Name
503	In synchronization 4TH follow target axis Name

Range: 0 ~ 6

Effective time: Effective After Reboot

Access level: Machine Maker

Default: 0

Unit: Non

Description: 0 : Not use (default)

1 : System X

2 : System Y

3 : System Z

4 : System 4TH

5 : System 5TH

6 : System 6TH

506	In synchronization X direction setup as a follower.
507	In synchronization Y direction setup as a follower.
508	In synchronization Z direction setup as a follower.
509	In synchronization 4TH direction setup as a follower.

Range: 0 ~ 1

Effective time: Effective After Reboot

Access level: Machine Maker

Default: 0

Unit: Non

Description: 0 : Forward

1 : Reverse

538	Axis name which switch with X
539	Axis name which switch with Y
540	Axis name which switch with Z
541	Axis name which switch with 4TH

Range: 0 ~ 6
 Effective time: Effective After Reboot
 Access level: Machine Maker
 Default: 0
 Unit: Non
 Description: 0 : Not use (default)
 1 : System X
 2 : System Y
 3 : System Z
 4 : System 4TH
 5 : System 5TH
 6 : System 6TH

700	[R10]Cutting Linear acceleration time ms
------------	---

Range: 0 ~ 1000
 Effective time: EFFECTIVE AFTER RESET
 Access level: Machine Maker
 Default: 100
 Unit: ms
 Description: Set HSP[R10]Cutting Linear acceleration time °

701	[R10]Cutting bell shape acceleration time ms
------------	---

Range: 0 ~ 1000
 Effective time: EFFECTIVE AFTER RESET
 Access level: Machine Maker
 Default: 20
 Unit: ms
 Description: Set HSP[R10]Cutting Bell shape acceleration time °

702	[R10]Smooth Cutting acceleration time ms
------------	---

Range: 0 ~ 1000
 Effective time: EFFECTIVE AFTER RESET
 Access level: Machine Maker
 Default: 0
 Unit: ms
 Description: Set HSP[R10]Smooth Cutting acceleration time °

703	[R10] After Cutting acceleration time ms
------------	---

Range: 0 ~ 1000
 Effective time: EFFECTIVE AFTER RESET
 Access level: Machine Maker
 Default: 25
 Unit: ms
 Description: Set HSP[R10]after Cutting acceleration time °

704	[R10] round speed lock um/min
	Range: 100 ~ 200000000
	Effective time: EFFECTIVE AFTER RESET
	Access level: Machine Maker
	Default: 1200000
	Unit: Um/min
	Description: Set HSP[R10] round speed lock °
705	[R10] round speed lock minimum/min
	Range: 100 ~ 200000000
	Effective time: EFFECTIVE AFTER RESET
	Access level: Machine Maker
	Default: 200000
	Unit: Um/min
	Description: Set HSP[R10] round speed lock minim °
710	[R10]X Corner speed difference um/min
711	[R10]Y Corner speed difference um/min
712	[R10]Z Corner speed difference um/min
713	[R10]4TH Corner speed difference um/min
	Range: 0 ~ 200000000
	Effective time: EFFECTIVE AFTER RESET
	Access level: Machine Maker
	Default: 300000
	Unit: Um/min
	Description: Set HSP[R10]各 Corner speed difference °
730	[R10]Corner reference speed um/min
	Range: 0 ~ 200000000
	Effective time: EFFECTIVE AFTER RESET
	Access level: Machine Maker
	Default: 400000
	Unit: Um/min
	Description: Set HSP[R10]Corner reference speed °
731	[R10]X speed feed forward (%)
732	[R10]Y speed feed forward (%)
733	[R10]Z speed feed forward (%)
734	[R10]4TH speed feed forward (%)
	Range: 0 ~ 200
	Effective time: EFFECTIVE AFTER RESET
	Access level: Machine Maker
	Default: 95
	Unit: %
	Description: Set HSP[R10]each axis speed feed forward °

800	G00'S IN-POSITION CHECK WINDOW OF X AXIS, μm
801	G00'S IN-POSITION CHECK WINDOW OF Y AXIS, μm
802	G00'S IN-POSITION CHECK WINDOW OF Z AXIS, μm
803	G00'S IN-POSITION CHECK WINDOW OF THE 4TH AXIS, μm

Range : 1 ~ 20000

Effective : Effective After RESET

Access level : Machine Maker

Default : 500

Unit : μm

This parameter sets the in-position check window of each axis when the exact stop function of rapid positioning is enabled. When some axis's
 $| \text{command position} - \text{actual position} | \leq \text{this parameter's set value}$,
This means that this axis has already completed rapid positioning and stopped.

845	Set X as 0)Linear 1)Rotate
846	Set Y as 0)Linear 1)Rotate
847	Set Z as 0)Linear 1)Rotate

Range: 0 ~ 1

Effective time: Effective After Reboot

Access level: Machine Maker

Default: 0

Unit: Non

Description: 0 : Set as linear axis, screw section please set as your machine type.
1 : Set as Rotate axis, screw section please set as 360(means 360 degree)

1000	G00 MAX. SPEED OF X AXIS IN RAPID TRAVERSE, μm/min
1001	G00 MAX. SPEED OF Y AXIS IN RAPID TRAVERSE, μm/min
1002	G00 MAX. SPEED OF Z AXIS IN RAPID TRAVERSE, μm/min
1003	G00 MAX. SPEED OF THE 4TH AXIS IN RAPID TRAVERSE, μm/min

Range : 1 ~ 99999999

Effective : Effective After RESET

Access level : Machine Maker

Default : 5000000

Unit : μm/min

This parameter sets the max. Motion speed of each axis during rapid traverse.

1004	G01 MAX. SPEED OF LINEAR CUTTING, μm/min
-------------	---

Range : 1 ~ 99999999

Effective : Effective After RESET

Access level : Machine Maker

Default : 2000000

Unit : μm/min

This parameter sets the following values:

1. The max. feed rate of the linear cutting command G01;
2. The max. feed rate of the curve cutting command G02/03;
3. The feed rate of the cutting commands G01/02/03 in DRY RUN mode.

This parameter's set value is taken by NC as the maximum allowed feedrate even when the actual feedrate set on the operation panel might exceed this parameter's set value.

1042**G31 PRESET FEED RATE**

Range : 1 ~ 99999999

Effective : Effective After RESET

Access level : Machine Maker

Default : 2000

Unit : $\mu\text{m}/\text{min}$

If assigning a feed rate in the block of G31 command, the block would take the command value as its feed rate; if there is no feed rate assigned in the block of G31 command, the feed rate is set by this parameter.

1061**MAX. SPEED OF LATHE TAPPING**

Range : 1 ~ 99999999

Effective : Effective After RESET

Access level : Machine Maker

Default : 10000000

Unit : μm

The cutting feed rate is decided by the spindle's rotation speed and thread pitch during lathe tapping. If the feed rate produced by these two elements exceeds the set value of this parameter, the alarm "MOT 4061: LATHE TAPPING SPEED OVER SETTING VALUE" will be triggered to prevent any danger that might be caused by false programming.

1072**PULSE WIDTH μs**

Range : 1 ~ 50


Effective : Effective After Reboot

Access level : Machine Maker

Default : 20

Unit : μs

When the pulse command type is CW/CCW or PULSE/DIRECTON, this parameter sets the pulse width as shown in the figure below.



Below is the formula for pulse cycle (ex. a linear axis) :

$$\frac{1}{T} = \frac{\text{feedrate}}{\text{pitch}} \times GR \times \text{Pulse/rev} \times \frac{1}{60000}, \text{ unit : ms}$$

Example :

In this example, the thread pitch of X axis is 10mm, the gear ratio is 2 (Deceleration ratio: When the motor makes 2 rev., the ball screw makes 1 rev.), the pulse/rev. is 10000, and the feed rate is 2000mm/min., and the required output pulse/1ms would be:

$$Pulses = \frac{2000}{10} \times 2 \times 10000 \times \frac{1}{60000} \approx 67 \text{ pulses/ms}$$

And the pulse cycle would be :

$$T = \frac{1000}{67} \approx 15 \mu s$$

Under this condition, the pulse width should be set as 7us to keep the pulse command as 50% of DURATION. If the set value of this parameter is too large, the pulse width might exceed the pulse cycle during high-speed motion, and the motor driver could not read the overlapping pulse command lines to actuate the motor's rotation normally.

However, if the set value is too small, the motor driver might also be unable to identify the pulse command lines. Therefore, the max value of this parameter should be set according to the max width within which tolerance that pulse command lines do not overlap each other. And the min. value should be set according to the min. width within which tolerance the motor can identify pulse command lines.

1100	JOG SPEED FOR X AXIS μm/min
1101	JOG SPEED FOR Y AXIS μm/min
1102	JOG SPEED FOR Z AXIS μm/min
1103	JOG SPEED FOR THE 4TH AXIS μm/min

Range : 1 ~ 99999999
 Effective : Effective After RESET
 Access level : Machine Maker
 Default : 2000000
 Unit : μm/min
 This parameter sets the moving speed of each axis in JOG mode.

1824	Servo Communication type(0:Not use 1:M)
-------------	--

Range: 0 ~ 1
 Effective time: Effective After Reboot
 Access level: Machine Maker
 Default: 0
 Unit: Non
 Description: Set Servo communication Servo motor brand
 0:Not use
 1:M

1825	X Servo communication station number(0:Not use 1~15)
1826	Y Servo communication station number(0:Not use 1~15)
1827	Z Servo communication station number(0:Not use 1~15)
1828	4TH Servo communication station number(0:Not use 1~15)

Range: 0 ~ 15
 Effective time: Effective After Reboot
 Access level: Machine Maker
 Default: 0
 Unit: Non
 Description: Set Servo drive and motor's station number. This parameter must be same with servo motor station. If set to 0 = not use servo communication.

1831	X-PMC G01 position check window range um
1832	Y-PMC G01 position check window range um
1833	Z-PMC G01 position check window range um
1834	4TH-PMC G01 position check window range um

Range: 1 ~ 20000
 Effective time: EFFECTIVE AFTER RESET
 Access level: Machine Maker
 Default: 50
 Unit: Non
 Description: Set PMC axis G01 position check range.

1837	X-PMC G00 position check range um
1838	Y-PMC G00 position check range um
1839	Z-PMC G00 position check range um
1840	4TH-PMC G00 position check range um

Range: 1 ~ 20000
 Effective time: EFFECTIVE AFTER RESET
 Access level: Machine Maker
 Default: 500
 Unit: Non
 Description: Set PMC axis G00 position check range.

1883	PMC linear Cutting G01 max speed um/min
-------------	--

Range: 1 ~ 99999999
 Effective time: EFFECTIVE AFTER RESET
 Access level: Machine Maker
 Default: 2000000
 Unit: um/min
 Description: Set PMC axis G01 max speed °

1884	X-PMC G00 max speed um/min
1885	Y-PMC G00 max speed um/min
1886	Z-PMC G00 max speed um/min
1887	4TH -PMC G00 max speed um/min

Range: 1 ~ 20000
 Effective time: EFFECTIVE AFTER RESET
 Access level: Machine Maker
 Default: 5000000
 Unit: um/min
 Description: Set PMC axis G00 max speed °

1929	M-II ON/OFF 0)OFF 1)ON
-------------	-------------------------------

Range: 0 ~ 1
 Effective time: Effective After Reboot
 Access level: Machine Maker
 Default: 0
 Unit: Non
 Description: Enable M-II

1930	M-II communication time(us)
-------------	------------------------------------

Range: 1500 ~ 4000
 Effective time: Effective After Reboot
 Access level: Machine Maker
 Default: 0

Unit: Non
Description: Set M-II communication time, please use default 2500us.

1931	M-II use Absolute encoder(Bit)
-------------	---------------------------------------

Range: 0 ~ 63
Effective time: Effective After Reboot
Access level: Machine Maker
Default: 0
Unit: Non
Description: Set M-II axis use ABS encoder or not: +1 : X use , +2 : Y use , +4 : Z use , +8 : 4TH use °

1932	Artificial intelligent cutting type: (0:AIC 1:AIC-II)
-------------	--

Range: 0 ~ 1
Effective time: EFFECTIVE AFTER RESET
Access level: Machine Maker
Default: 0
Unit: Non
Description: Set AIC type, AIC: G05 R1~R10. AIC-II: customize AIC parameter.

1933	M-II G31 signal source axis name(Bit)
-------------	--

Range: 0 ~ 64
Effective time: EFFECTIVE AFTER RESET
Access level: Machine Maker
Default: 4
Unit: Non
Description: +1 : X , +2 : Y , +4 : Z , +8 : 4TH

3.3 Mechanical parameter

62	UNIT OF Pr.0104 ~ Pr.0107 0) METRIC 1) IMPERIAL
	Range : 0 ~ 1
	Effective : Effective After Reboot
	Access level : Machine Maker
	Default : 0
	Unit : Nul
	This parameters sets the unit system of Pr.0104 ~ Pr.0107 to be metric or imperial.

68	TOOTH NUMBER OF X AXIS MOTOR (DENOMINATOR IN GEAR RATIO)
69	TOOTH NUMBER OF Y AXIS'S MOTOR (DENOMINATOR IN GEAR RATIO)
70	TOOTH NUMBER OF Z AXIS'S MOTOR (DENOMINATOR IN GEAR RATIO)
72	TOOTH NUMBER OF THE 4TH AXIS'S MOTOR (DENOMINATOR IN GEAR RATIO)
	Range : 1 ~ 32767
	Effective : Effective After Reboot
	Access level : Machine Maker
	Default : 1
	Unit : Nul
	This parameter sets the tooth number of each axis motor, which equals to setting an axis's denominator in gear ratio.

$$\text{Gear ratio of some axis} = \frac{\text{Ball screw's tooth number}}{\text{Motor's tooth number (this parameter)}}$$

If the gear ratio of some axis is larger than 1, motor speed is decelerated by ball screw; if smaller than 1, motor speed is accelerated by ball screw. Please refer to the following formula for the setting method:

$$\text{Motor's tooth number} \times \text{Motor's rotation speed} = \text{Ball screw's tooth number} \times \text{Ball screw's rotation speed}$$

100	BALL SCREW'S TOOTH NUMBER OF X AXIS (NUMERATOR IN GEAR RATIO)
101	BALL SCREW'S TOOTH NUMBER OF Y AXIS (NUMERATOR IN GEAR RATIO)
102	BALL SCREW'S TOOTH NUMBER OF Z AXIS (NUMERATOR IN GEAR RATIO)
103	BALL SCREW'S TOOTH NUMBER OF THE 4TH AXIS (NUMERATOR IN GEAR RATIO)
	Range : 1 ~ 32767
	Effective : Effective After Reboot
	Access level : Machine Maker
	Default : 1
	Unit : Nul
	This parameter sets the ball screw's tooth number of each axis, which equals to setting the numerator in gear ratio of each axis.

$$\text{Gear ratio of some axis} = \frac{\text{Ball screw's tooth number (this parameter)}}{\text{Motor's tooth number}}$$

If the gear ratio of some axis is larger than 1, motor speed is decelerated by ball screw; if smaller than 1, motor speed is accelerated by ball screw. Please refer to the following formula for the setting method:

$$\text{Motor's tooth number} \times \text{motor's rotation speed} = \text{Ball screw's tooth number} \times \text{ball screw's rotation speed}$$

104	BALL SCREW PITCH. OF X AXIS
105	BALL SCREW PITCH. OF Y AXIS
106	BALL SCREW PITCH. OF Z AXIS
107	BALL SCREW PITCH. OF THE 4TH AXIS

Range : 1 ~ 32767

Effective : Effective After Reboot

Access level : Machine Maker

Default : 360

Unit : μm

This parameter sets the ball screw pitch of each axis.

3.4 Spindle Parameter

16	1st SP every 1000RPM acceleration time
885	2nd SP every 1000RPM acceleration time
888	3rd SP every 1000RPM acceleration time

Range: 0 ~ 32767

Effective time: EFFECTIVE AFTER RESET

Access level: Machine Maker

Default: 1000

Unit: MS/KRPM

Description: This parameter can set Spindle RPM corresponding voltage, Pulse command acceleration speed.
When Spindle RPM use voltage control, it must set the offset and 10V corresponds to RPM.

21	RPM OF THE 1ST SPINDLE'S ORIENTATION
----	--------------------------------------

Range : 1 ~ 20000

Effective : Effective After RESET

Access level : Machine Maker

Default : 100

Unit : RPM

This parameter sets the spindle's rotation speed during orientation. This parameter also decides the spindle's rotation speed when the spindle is being oriented. To prevent deviation caused by different rotation speeds, please do not change the set value of this parameter after finishing the orientation adjustment of the spindle.

29	THE CORRESPONDING SERVO AXIS NUMBER OF THE 1ST SPINDLE
294	CORRESPONDING TO 2ND SPINDLE
295	CORRESPONDING TO 3RD SPINDLE

Range : 0 ~ 16

Effective : Effective After Reboot

Access level : Machine Maker

Default : 0

Unit : Nul

If the spindle's wiring is connected to the Nth axis of the transit card, set this parameter to N; if there is no spindle, set to 0.

49	MOTOR'S TOOTH NUMBER OF THE 1ST SPINDLE IN 1ST GEAR
664	MOTOR'S TOOTH NUMBER OF THE 2ND SPINDLE IN 1ST GEAR
672	MOTOR'S TOOTH NUMBER OF THE 3RD SPINDLE IN 1ST GEAR

Range : 1 ~ 32767

Effective : Effective After Reboot

Access level : Machine Maker

Default : 1

Unit : Nul

This parameter sets the motor's tooth number of some spindle in 1st gear, which equals to setting the denominator in gear ratio of some spindle in 1st gear. When some spindle is in 1st gear (C097 is ON) :

$$\text{Gear ratio of the spindle} = \frac{\text{Tooth number of spindle (Pr.0050)}}{\text{Tooth number of motor (this parameter)}}$$

If the spindle's gear ratio is larger than 1, there is a deceleration relationship between motor and spindle; if the ratio is smaller than 1, there is an acceleration relationship between motor and spindle. Please refer to the following formula for the setting method :

$$\text{Motor's toothnumber} \times \text{Motor's rotationspeed} = \text{Spindle's toothnumber} \times \text{Spindle's rotationspeed}$$

50	THE 1ST SPINDLE'S TEETH NUMBER IN 1ST GEAR
665	THE 2ND SPINDLE'S TEETH NUMBER IN 1ST GEAR
673	THE 3RD SPINDLE'S TEETH NUMBER IN 1ST GEAR

Range : 1 ~ 32767

Effective : Effective After Reboot

Access level : Machine Maker

Default : 1

Unit : Nul

This parameter sets the motor's tooth number of some spindle in 1st gear, which equals to setting the numerator in gear ratio of some spindle in 1st gear. When some spindle is in 1st gear (C097 is ON) :

$$\text{Gear ratio of the spindle} = \frac{\text{Tooth number of spindle (this parameter)}}{\text{Tooth number of motor (Pr.0049)}}$$

If the spindle's gear ratio is larger than 1, there is a deceleration relationship between motor and spindle; if the ratio is smaller than 1, there is an acceleration relationship between motor and spindle. Please refer to the following formula for the setting method :

$$\text{Motor's tooth number} \times \text{Motor's rotation speed} = \text{Spindle's tooth number} \times \text{Spindle's rotation speed}$$

51	TOOTH NUMBER OF THE 1ST SPINDLE'S MOTOR IN 2ND GEAR
666	TOOTH NUMBER OF THE 2ND SPINDLE'S MOTOR IN 2ND GEAR
674	TOOTH NUMBER OF THE 3RD SPINDLE'S MOTOR IN 2ND GEAR

Range : 1 ~ 32767

Effective : Effective After Reboot

Access level : Machine Maker

Default : 1

Unit : Nul

This parameter sets the tooth number of some spindle's motor in 2nd gear, which equals to setting the denominator in gear ratio of some spindle in 2nd gear. When some spindle is in 2nd gear (C098 is ON) :

$$\text{Gear ratio of the spindle} = \frac{\text{Tooth number of spindle (Pr.0052)}}{\text{Tooth number of motor (this parameter)}}$$

If the spindle's gear ratio is larger than 1, there is a deceleration relationship between motor and spindle; if the ratio is smaller than 1, there is an acceleration relationship between motor and spindle. Please refer to the following formula for the setting method :

$$\text{Motor's tooth number} \times \text{Motor's rotation speed} = \text{Spindle's tooth number} \times \text{Spindle's rotation speed}$$

52	TOOTH NUMBER OF THE 1ST SPINDLE IN 2ND GEAR
667	TOOTH NUMBER OF THE 2ND SPINDLE IN 2ND GEAR
675	TOOTH NUMBER OF THE 3RD SPINDLE IN 2ND GEAR

Range : 1 ~ 32767

Effective : Effective After Reboot

Access level : Machine Maker

Default : 1

Unit : Nul

This parameter sets the tooth number of some spindle in 2nd gear, which equals to setting the numerator in gear ratio of some spindle in 2nd gear. When some spindle is in 2nd gear (C098 is ON) :

$$\text{Gear ratio of the spindle} = \frac{\text{Tooth number of spindle (this parameter)}}{\text{Tooth number of motor (Pr.0051)}}$$

If the spindle's gear ratio is larger than 1, there is a deceleration relationship between motor and spindle; if the ratio is smaller than 1, there is an acceleration relationship between motor and spindle. Please refer to the following formula for the setting method :

$$\text{Motor's tooth number} \times \text{Motor's rotation speed} = \text{Spindle's tooth number} \times \text{Spindle's rotation speed}$$

57	FEEDBACK RATE OF THE 1ST SPINDLE
890	FEEDBACK RATE OF THE 2ND SPINDLE
894	FEEDBACK RATE OF THE 3RD SPINDLE

Range : 1 ~ 4

Effective : Effective After Reboot

Access level : Machine Maker

Default : 1

Unit : Nul

This parameter sets the feedback rate multiplier of some spindle's encoder and is only effective when the feedback signal type is AB PHASE (Pr.0195 is set to 0). If the feedback signal type of the spindle's encoder is CW/CCW or PULSE/DIRECTION (Pr.0195 is 1 or 2, respectively), the feedback rate multiplier would always be 1.

When the spindle's control mode is PULSE COMMAND (in SPINDLE ORIENTATION or RIGID TAPPING modes), the product of this parameter's set value and Pr.1116's set value (pulse/rev of the spindle motor's encoder) is the pulse command amount of NC to make one revolution of the spindle motor. If the spindle's control mode is V Command, the product of this parameter's set value and Pr.1116's set value is used to calculate the spindle's actual rotation speed only.

889	PPR OF THE 2ND SPINDLE'S ENCODER
893	PPR OF THE 3RD SPINDLE'S ENCODER

Range : 1 ~ 32767

Effective : Effective After Reboot

Access level : Machine Maker

Default : 1024

Unit : pulse

Assuming pulse/rev. of some motor encoder is 2500 then set this parameter to 2500.

84	THE 1ST SPINDLE ORIENTATION 0)SENSOR 1)ENCODER
-----------	---

Range : 0 ~ 1

Effective : Effective After RESET

Access level : Machine Maker

Default : 0

Unit : Nul

0 : Use a positioning sensor as the reference for spindle orientation.

1 : Use an encoder index as the reference for spindle orientation.

90	THE 1ST SPINDLE DISPLAYS 0)COMMAND 1) SENSOR
897	THE 2ND SPINDLE DISPLAYS 0)COMMAND 1) SENSOR
898	THE 3RD SPINDLE DISPLAYS 0)COMMAND 1) SENSOR

Range : 0 ~ 1
 Effective : Effective After RESET
 Access level : Machine Maker
 Default : 1
 Unit : Nul
 0 : Display the command value
 1 : Display the actual value, meanwhile NC calculates the actual rotation speed according to the feedback signal of the spindle's motor ENCODER and displays the product on HMI

If some spindle motor does not have an encoder, please set this parameter to 0 in case RPM check cannot reach the assigned speed.

92	SPINDLE D/A SCALE RPM/10V
883	CORRESPONDING RPM OF THE 2ND SPINDLE MOTOR'S INPUT VOLTAGE 10V
886	CORRESPONDING RPM OF THE 3rd SPINDLE MOTOR'S INPUT VOLTAGE 10V

Range : 1 ~ 32767
 Effective : Effective After RESET
 Access level : Machine Maker
 Default : 6000
 Unit : RPM
 Assume 10V of the spindle is corresponding to 3000RPM, and then set this parameter to 3000. This parameter is effective only when the spindle's driver in Velocity Command mode.

95	MIN. SPEED OF THE 1ST SPINDLE
96	MAX SPEED OF 1ST SPINDLE
876	MAX SPEED OF 2ND SPINDLE
877	MIN. RPM OF THE 2nd SPINDLE
878	INITIAL RPM OF THE 3RD SPINDLE
879	MAX. RPM OF THE 3RD SPINDLE
880	MIN. RPM OF THE 3RD SPINDLE

Range : 0 ~ 20000
 Effective : Effective After RESET
 Access level : Machine Maker
 Default : 0
 Unit : RPM
 This parameter sets the RPM range to prevent any part's damage of the machine caused by executing a command at a RPM that exceeds the acceptable range.

98	VOLTAGE COMMAND'S OFFSET VALUE OF THE 1ST SPINDLE'S RPM
884	VOLTAGE COMMAND'S OFFSET VALUE OF THE 2ND SPINDLE'S RPM
887	VOLTAGE COMMAND'S OFFSET VALUE OF THE 3RD SPINDLE'S RPM

Range : -5000 ~ 5000

Effective : Effective After RESET

Access level : Machine Maker

Default : 0

Unit : 0.3mV

This parameter sets the offset value of the spindle's voltage command. After the required voltage command is deduced based on the spindle command RPM, minus this parameter's set value from the voltage command, then the user can obtain the actual voltage command that needs to be sent to the spindle's A/C. The present DAC of the system's motion card is 16 bits, which corresponds to $\pm 10V$, so the dpi is $10/32768 = 0.3mV$, which is the unit of this parameter.

892	INSTALL THE 2ND SPINDLE'S ENCODER ONTO THE 0)SPINDLE 1)MOTOR
896	INSTALL THE 3RD SPINDLE'S ENCODER ONTO THE 0)SPINDLE 1)MOTOR

Range : 0 ~ 1

Effective : Effective After RESET

Access level : Machine Maker

Default : 0

Unit : Nul

This parameter sets the installation position of the spindle's encoder.

0: Onto the spindle.

1. Onto the motor.

171	Spindle feedback reverse BIT
------------	-------------------------------------

Range: 0 ~ 7

Effective time: Effective After Reboot

Access level: Machine Maker

Default: 0

Unit: Non

Description: Set Spindle feedback reverse bit

BIT 0 (+1) : 1st SP

BIT 1 (+2) : 2nd SP

BIT 2 (+4) : 3rd SP

178	TOOTH NUMBER OF THE 1ST SPINDLE'S MOTOR IN 3RD GEAR
668	TOOTH NUMBER OF THE 2ND SPINDLE'S MOTOR IN 3RD GEAR
676	TOOTH NUMBER OF THE 3RD SPINDLE'S MOTOR IN 3RD GEAR

Range : 1 ~ 32767

Effective : Effective After Reboot

Access level : Machine Maker

Default : 1

Unit : Nul

This parameter sets the tooth number of some spindle's motor in 3rd gear, which equals to setting the denominator in gear ratio of some spindle in 3rd gear. When some spindle is in 3rd gear (C099 is ON) :

$$\text{Gear ratio of the spindle} = \frac{\text{Tooth number of spindle (Pr.0179)}}{\text{Tooth number of motor (this parameter)}}$$

If the spindle's gear ratio is larger than 1, there is a deceleration relationship between spindle and motor; if the ratio is smaller than 1, there is an acceleration relationship between spindle and motor. Please refer to the following formula for the setting method :

$$\text{Motor's tooth number} \times \text{Motor's rotation speed} = \text{Spindle's tooth number} \times \text{Spindle's rotation speed}$$

179	TOOTH NUMBER OF THE 1ST SPINDLE IN 3RD GEAR
669	TOOTH NUMBER OF THE 2ND SPINDLE IN 3RD GEAR
677	TOOTH NUMBER OF THE 3RD SPINDLE IN 3RD GEAR

Range : 1 ~ 32767

Effective : Effective After Reboot

Access level : Machine Maker

Default : 1

Unit : Nul

This parameter sets the tooth number of some spindle in 3rd gear, which equals to setting the numerator in gear ratio of some spindle in 3rd gear. When some spindle is in 3rd gear (C099 is OFF) :

$$\text{Gear ratio of the spindle} = \frac{\text{Tooth number of spindle (this parameter)}}{\text{Tooth number of motor (Pr.0178)}}$$

If the spindle's gear ratio is larger than 1, there is a deceleration relationship between spindle and motor; if the ratio is smaller than 1, there is an acceleration relationship between spindle and motor. Please refer to the following formula for the setting method :

$$\text{Motor's tooth number} \times \text{Motor's rotation speed} = \text{Spindle's tooth number} \times \text{Spindle's rotation speed}$$

181	TOOTH NUMBER OF THE 1ST SPINDLE'S MOTOR IN 4TH GEAR
670	TOOTH NUMBER OF THE 2ND SPINDLE'S MOTOR IN 4TH GEAR
678	TOOTH NUMBER OF THE 3RD SPINDLE'S MOTOR IN 4TH GEAR

Range : 1 ~ 32767

Effective : Effective After Reboot

Access level : Machine Maker

Default : 1

Unit : Nul

This parameter sets the tooth number of some spindle's motor in 4TH gear,

which equals to setting the denominator in gear ratio of some spindle in 4th gear. When some spindle is in 4th gear (C097 ~ C099 are all OFF) :

$$\text{Gear ratio of the spindle} = \frac{\text{Tooth number of spindle (Pr.0182)}}{\text{Tooth number of motor (this parameter)}}$$

If the spindle's gear ratio is larger than 1, there is a deceleration relationship between spindle and motor; if the ratio is smaller than 1, there is an acceleration relationship between spindle and motor. Please refer to the following formula for the setting method:

$$\text{Motor's tooth number} \times \text{Motor's rotation speed} = \text{Spindle's tooth number} \times \text{Spindle's rotation speed}$$

182	TOOTH NUMBER OF THE 1ST SPINDLE IN 4TH GEAR
671	TOOTH NUMBER OF THE 2ND SPINDLE IN 4TH GEAR
679	TOOTH NUMBER OF THE 3RD SPINDLE IN 4TH GEAR

Range : 1 ~ 32767

Effective : Effective After Reboot

Access level : Machine Maker

Default : 1

Unit : Nul

This parameter sets the tooth number of some spindle in 4th gear, which equals to setting the numerator in gear ratio of some spindle in 4th gear. When some spindle is in 4th gear (C097 ~ C099 are all OFF) :

$$\text{Gear ratio of the spindle} = \frac{\text{Tooth number of spindle (this parameter)}}{\text{Tooth number of motor (Pr.0181)}}$$

If the spindle's gear ratio is larger than 1, there is a deceleration relationship between spindle and motor; if the ratio is smaller than 1, there is an acceleration relationship between spindle and motor. Please refer to the following formula for the setting method :

$$\text{Motor's tooth number} \times \text{Motor's rotation speed} = \text{Spindle's tooth number} \times \text{Spindle's rotation speed}$$

183	COMMAND TYPE OF THE 1ST SPINDLE'S SPEED
296	COMMAND TYPE OF THE 2ND SPINDLE'S SPEED
297	COMMAND TYPE OF THE 3RD SPINDLE'S SPEED

Range : 0 ~ 4

Effective : Effective After Reboot

Access level : Machine Maker

Default : 0

Unit : Nul

This parameter sets the command type of some spindle's rotation speed. The system's preset command type is voltage output. If the motor driver of the spindle has a PG card or the spindle motor is a servo motor, the output command type of the spindle can be set in the pulse type that the motor driver accepts.

Value	Type	axis	Description
0	Voltage command (0~10V)	Defined by P.29	(1) Spindle CW/CCW switch by ladder switch inverter terminal. (2) P16=0, accelerate controlled by inverter. If P16 has any value, the acceleration control by controller.
1	Pulse Output (A/B Phase)	4	(1) Spindle direction define by C82 , C83 (2) Accelerate control by P16
2	Pulse Output (CW/CCW)	4	(3) Output axis not effect by P29 (Spindle's servo no.) It fixed to 4TH, used for TRF1720 P5 (SPD AXIS) sends pulse.
3	Pulse Output (Pulse/Dir.)	4	(4) Under speed control, NC won't check Servo lag.
	V-command (-10V~10V)	Defined by P.29	(1) Spindle direction define by C82 , C83 (2) Accelerate control by P16
5	Pulse Output A/B Phase	Defined by P.29	(1) Spindle direction define by C82 , C83 (2) Accelerate control by P16 (3) Output axis not effect by P29 (Spindle's servo no.) (4) Under speed control, NC won't check Servo lag.
6	Pulse Output CW/CCW	Defined by P.29	
7	Pulse Output Pulse/Dir.	Defined by P.29	
8	M-II	Defined by P.29	

Note:

C82,C83 control method

C82 = ON ,C83=OFF => Spindle CW

C82 = OFF ,C83=ON => Spindle CCW

Others => Spindle Stop

184**LOCAL INPUT OF THE 1ST SPINDLE'S ORIENTATION**

Range : 1 ~ 10
 Effective : Effective After RESET
 Access level : Machine Maker
 Default : 9
 Unit : Nul

Bit 2	Bit 1	Bit 0	Description
0	0	1	Connected to Local input 1 (HS1 on the transit card) (Default)
0	1	0	Connected to Local input 2 (HS2 on the transit card)

Bit 3	Description
0	Normally close
1	Normally open. (Default)

Bit 0 ~ Bit 2 : Set the input number of the spindle's orientation sensor signal.

Set to 1, the local input is connected to HS1 on the transit card;
 set to 2, the local input is connected to HS2 on the transit card.

Bit 3 : Set the signal type of the spindle's orientation sensor. Set to 0: Normally Close (NC); set to 1: Normally Open. (NO).

Set to 1 : The local input port of spindle positioning sensor signal is HS1, the signal type is Normally Close (NC);

Set to 9 : The local input port of spindle positioning sensor signal is HS1, the signal type is Normally Open (NO);

Set to 2 : The local input port of spindle positioning sensor signal is HS2, the signal type is Normally Close (NC);

Set to 10 : The local input port of spindle positioning sensor signal is HS2, signal type is Normally Open (NO).

189**DEFAULT INITIAL SPEED OF THE 1ST SPINDLE****875****DEFAULT INITIAL SPEED OF THE 2ND SPINDLE**

Range : 0 ~ 99999
 Effective : Effective After Reboot
 Access level : User
 Default : 0
 Unit : RPM

When the system is started, this parameter is the preset initial rotation speed of the spindle.

190**1st SP Position command type**

Range: 0 ~ 6
 Effective time: EFFECTIVE AFTER RESET
 Access level: Machine Maker
 Default: 0
 Unit: Non
 Description:

value	Signal type	axis	description
-------	-------------	------	-------------

0	Pulse Output (A/B Phase)	4	<ul style="list-style-type: none"> ● Usually Spindle drive have position card(PG card) ※ Use pulse form TRF1720 P5
1	Pulse Output (CW/CCW)	4	
2	Pulse Output , (Pulse /Dir.)	4	
3	V command (-10V~10V) Controller inner hardware do the close loop control	Defined by P.29	<ul style="list-style-type: none"> ● Use with Spindle drive have close loop vector control, and accept $\pm 10V$ control(+ for CW, - for CCW) ● Spindle output V-cmd by TRF1720 P5(SPD AXIS) , and read SP encoder through SPD ENC.
4	Pulse Output (A/B Phase)	Defined by P.29	<ul style="list-style-type: none"> ● Use with Spindle and position card(PG card)
5	Pulse Output (CW/ CCW)	Defined by P.29	
6	Pulse Output (Pulse/Dir.)	Defined by P.29	
7	M-II		

195	ENCODER TYPE OF 1ST SPINDLE
891	ENCODER TYPE OF 2ND SPINDLE
895	ENCODER TYPE OF 3RD SPINDLE

Range : 0 ~ 3
 Active : Active After Reboot
 Level : Machinery Builder
 Default value : 0
 Unit : Nul
 Description : This parameter is to set the spindle Encoder's output signal type.
 0 : A/B PHASE
 1 : CW/CCW
 2 : PULSE/DIRECTION
 3 : none

226	MOVING DIR. OF SPINDLES(BIT)
-----	-------------------------------------

Range : 0 ~ 7
 Active : Active After Reboot
 Level : Machinery Builder
 Default value : 0
 Unit : Nul
 Description : **BIT 0** : When set to 1, motion direction of the 1st spindle must be reversed;
BIT 1 : When set to 1, motion direction of the 2nd spindle must be reversed;
BIT 2 : When set to 1, motion direction of the 3rd spindle must be reversed;
 Only valid when output command format of the spindle is in pulse format.

240
1ST SPD POS GAIN AT ORIENTATION

Range : 0 ~ 20000
 Active : Active After RESET
 Level : Machinery Builder
 Default value : 30
 Unit : 1/S
 Description : When the spindle's command format in control mode is V command (parameter No. 0190 = 3), this parameter sets the spindle's proportional gain during positioning.

241
1ST SPD POS GAIN AT RIGID TAP

Range : 0 ~ 20000
 Active : Active After RESET
 Level : Machinery Builder
 Default value : 30
 Unit : 1/S
 Description : When the spindle's command format in control mode is V command (parameter No. 0190 = 3), this parameter sets the spindle's proportional gain during rigid tapping.

248
1ST SPD ORIENT OFFSET UNIT

Range : 0 ~ 1
 Active : Active After Reboot
 Level : Machinery Builder
 Default value : 0
 Unit : NUL
 Description : 0: Unit of OFFSET amount between Spindle Orientation point and center point (Parameter #1056 and System Data #10) is pulse.
 1: Unit of OFFSET amount between Spindle Orientation point and center point (Parameter #1056 and System Data #10) is 0.001 degree.

354
1ST SPD OVERRIDE UNIT
355
2ND SPD OVERRIDE UNIT
356
3RD SPD OVERRIDE UNIT

Range : 0 ~ 1
 Active : Active After Reboot
 Level : Machinery Builder
 Default value : 0
 Unit : Nul
 Description : 0 : The 1st (2nd & 3rd) spindle's rotation override speed = R015 (R019 · R020) register value * 10% ;
 1 : The 1st (2nd & 3rd) spindle's rotation override speed = R015 (R019 · R020) register value * 1% .

393
1ST SPIDEL GEARING METHOD

Range : 0 ~ 1
 Active : Active After Reboot
 Level : Machinery Builder
 Default value : 0

Unit : Nul
Description : Choose either "automatic" or "manual" gear change method to be the spindle's gear change method
0 : Automatic gear change
1 : Manual gear change

663
1ST SPD ORIENT ACC/DEC TIME

Range : 0 ~ 1500
Active : Active After Reboot
Level : Machinery Builder
Default value : 100
Unit : ms
Description : This parameter is to set the acceleration and deceleration time of Spindle orientation (including Spindle Adjustment).

839
1ST SPD ORIENT CHECK TOLERANCE

Range : 0 ~ 32767
Active : Active After RESET
Level : Machinery Builder
Default value : 1000
Unit : 0.001 degree
Description : This parameter is to see the allowable error amount of Spindle Orientation. If the difference between Spindle stopping position and the actual orientation position is smaller than this parameter setting value, Spindle orientation task can be meant as accomplish. However, if the difference amount is larger than this parameter setting value, System Alarm 【MOT 4049 Spindle Orientation Exceed Allowable Error】 will occur.

224
2ND SPD SPEED CHK 0)ACT 1)CMD
225
3RD SPD SPEED CHK 0)ACT 1)CMD
874
1ST SPD SPEED CHK 0)ACT 1)CMD

Range : 0 ~ 1
Active : Active After RESET
Level : Machinery Builder
Default value : 0
Unit : Nul
Description : 0 : Spindle rotational speed checking signal source is Spindle Loop Encoder.
1 : Spindle rotational speed checking signal source is Spindle rotational command.

298
2ND SPD.SPEED ARRIVAL RANGE
881
3RD SPD.SPEED ARRIVAL RANGE
1054
1ST SPD.SPEED ARRIVAL RANGE

Range : 1 ~ 20000
Active : Active After RESET
Level : Machinery Builder
Default value : 50
Unit : RPM
Description : Under the condition that parameter 0090 is 1 (Spindle rotational speed is the actually speed), the system will calculate the actual rotational speed according to the spindle ENCODER feedback signal.
When | Spindle actual rotational speed – spindle command rotational speed | is

less than or equal to this parameter setting value, the system will set S BIT 088 to ON. Also, it will inform PL that the spindle actual rotational speed to is arrived to the commanding value. If this parameter setting value is too small, it is possible to cause the system's checking spindle actual rotational speed not able to arrive within the error range, which will not set S BIT 088 to ON. This further causes S code or M3, and M4 commands not able to end.

1056**1ST SPD ORIENT OFFSET VALUE**

Range : -99999999 ~ 99999999

Active : Active After RESET

Level : Machinery Builder

Default value : 0

Unit : pulse

Description : During Spindle orientation, this parameter sets the OFFSET amount of positioning final point and basic point. Parameter # 0248 can assign pulse or 0.001 degree as OFFSET amount unit.

1058**1ST SPD RIGTAP MAX FOLLOW ERROR**

Range : 1 ~ 32767

Active : Active After RESET

Level : Machinery Builder

Default value : 3000

Unit : um

Description : During rigid tapping, if the following error limit of Z-axis is larger than this setting value, the system will stop rigid tapping. Also, the system warning message (MOT 0052 error in rigid tapping is over limit) will occur. After machine adjustment, please set this parameter to a smaller value in order to prevent wrong motion that may cause damage of machines. After the rigid tapping machine adjustment is completed, please set the value that is 5 ~ 10 times larger than the display value from system data #021 on DGNOS page.

1059**1ST SPD RIGTAP ACC/DEC TIME**

Range : 1 ~ 32767

Active : Active After RESET

Level : Machinery Builder

Default value : 500

Unit : ms

Description : Setting under the rigid tapping mode, spindle's acc/deceleration time. Since under the rigid tapping mode, the movement amount of Z-axis is calculated by the spindle movement so this parameter also set the acc/deceleration time for Z-axis.

1060	1ST SPD RIGTAP EXTRACTION RATE
	Range : 1 ~ 400 Active : Active After RESET Level : Machinery Builder Default value : 100 Unit : % Description : During rigid tapping returning, the needed cutting power is small, so can use this parameter to set the increasing return speed. Example, if setting value is 200, this means during returning procedure, the spindle turns by two times of the original commanding rotational speed, Z-axis moves by two times of the original commanding the feedrate. But, the faster the rotational speed, the larger the following error of Z-axis. So must be careful in order to prevent crash situation. Also, must be careful of the limitation of the highest turning speed of the spindle and the highest cutting speed of the Z-axis.
299	2RD SPINDLE ZERO SPEED RANGE
882	3RD SPINDLE ZERO SPEED RANGE
1063	1RD SPINDLE ZERO SPEED RANGE
	Range : 1 ~ 20000 Active : Active After RESET Level : Machinery Builder Default value : 10 Unit : RPM Description : Under the condition that parameter 0090 is 1 (actual value of spindle rotational speed), the system ENCODER feedback signal will calculate the actual rotational speed. When the spindle actual rotational speed is less than or equal to this parameter setting value, the system will set S BIT 092 to ON and also inform the PLC that the spindle actual rotational speed has reached zero speed already.
1064	1ST SPD RIGTAP VELOCITY COMP.
	Range : 0 ~ 100000 Active : Active After RESET Level : Machinery Builder Default value : 0 Unit : Nul Description : when the rigid tapping machine adjustment is completed, Please set the commanding compensation value as the display value from data system #023 at (Diagnostic) DGNOS page.
1065	1ST SPD RIGTAP ACCELERATED COMP
	Range : 0 ~ 100000 Active : Active After RESET Level : Machinery Builder Default value : 0 Unit : Nul Description : after rigid tapping is completed, please set the commanding compensation value as the display value of data system #022 at (Diagnostic) DGNOS page.

1066**1ST SPD RIGTAP VELOCITY FILTER**

Range : 0 ~ 20

Active : Active After RESET

Level : Machinery Builder

Default value : 0

Unit : Nul

Description : The bigger the value, the less vibration will occur. , but the bigger the rigid tapping following error will be. When enter 0, this means there is no filtering effect. When enter the maximum value (i.e., 20), this means there is a completely filtering effect, which means the signal is filtered completely. Please adjust this parameter setting value during the rigid tapping machine adjustment.

1070**1ST SPD RIGTAP ACC. FILTER**

Range : 0 ~ 20

Active : Active After RESET

Level : Machinery Builder

Default value : 0

Unit : Nul

Description : The bigger the value, the less vibration will occur and the smaller of the following error. But, it is NOT absolute, which means there is an optimal value under certain filter intensity. When enter 0, it means there is no filtering effect. When enter the maximum value (i.e., 20), it means there is a completely filtering effect, which means the signal is filtered completely. Please adjust this parameter setting value during the rigid tapping machine adjustment.

1071**1ST SPD RIGTAP OUTPUT INVERSE**

Range : 0 ~ 1

Active : Active After RESET

Level : Machinery Builder

Default value : 0

Unit : Nul

Description : When the spindle +ive rotating direction under rigid tapping is not the same as that under not rigid tapping mode, please set this parameter to 1. Please adjust this parameter setting value during rigid tapping machine adjustment.

1075**1ST SPD SERVOLA G LIMIT**

Range : 0 ~ 100000

Active : Active After RESET

Level : Machinery Builder

Default value : 4096

Unit : Pulse

Description : When rigid tapping machine adjustment is complete, please set the value or the allowable following error that is 5-10 times larger of the display value from data system #26 at DGNOS page. If this setting value is too small, it is possible to cause the system alarm (MOT 055 rigid tapping spindle servo error is over the allowable limit) to occur during rigid tapping.

1096	MAX SPEED OF 1ST SPINDLE
	Range : 0 ~ 99999
	Active : Active After RESET
	Level : Machinery Builder
	Default value : 6000
	Unit : RPM
	Description : This parameter is used to set the max rotational speed of spindle. When spindle command rotational speed, which is set by user, is larger than this Parameter setting value, the system will restrict the spindle rotational speed according to this parameter setting value.

1097	1ST SPINDLE D/A SCALE RPM/10V
	Range : 1 ~ 99999
	Active : Active After RESET
	Level : Machinery Builder
	Default value : 6000
	Unit : RPM
	Description : this parameter is to set the corresponding spindle rotational Speed when the spindle motor input voltage is 10V.

1116	1ST SPINDLE ENCODER PPR
	Range : 1 ~ 32767
	Active : Active After Reboot
	Level : Machinery Builder
	Default value : 1024
	Unit : pulse
	Description : Assumed total pulse per rotation of spindle motor ENCODER is 2500, this means this parameter is set to 2500. Please refer to parameter # 0057 for setting description.

1076	JOG SPEED OF 2ND SPINDLE
1077	JOG SPEED OF 3RD SPINDLE
1121	JOG SPEED OF 1ST SPINDLE
	Range : 0 ~ 99999
	Active : Active After RESET
	Level : Machinery Builder
	Default value : 200
	Unit : RPM
	Description : When C BIT 072 is ON, spindle will rotate in this parameter's setting rotational speed.

1150	SPEED OF 1ST SPINDLE GEAR
	Range : 0 ~ 99999
	Active : Active After RESET
	Level : Machinery Builder
	Default value : 0
	Unit : RPM
	Description : This parameter is to determine whether or not to do gear shifting motion according to the spindle S code command. 1. when the spindle is at 1 st gear and assuming that the user command of the

spindle S code command is larger than (not including equal to) this parameter setting value, the system will inform PLC to do the gear shifting motion (shifting to which gear depends on the spindle commanding rotational speed);

2. when the spindle is NOT at 1st gear and assuming that the user command of the spindle S code command is smaller than (including equal to) this parameter setting value, the system will inform PLC to shift the spindle to the 1st gear;
3. If no spindle gear shifting need, recommend to use the 4th gear (C BIT 097 – 099 are OFF) and set this parameter to 0.

Need to pay attention to the following: NC only follow S code command from the user command of to determine the desired gear and then to inform PCL to execute gear shifting motion. If due to the spindle rotational speed OVERRIDE, which causes the actual rotational speed, is over that gear range, then NC will NOT execute the above motion.

1151
SPEED OF 2ND SPINDLE GEAR

Range : 0 ~ 99999

Active : Active After RESET

Level : Machinery Builder

Default value : 0

Unit : RPM

Description : This parameter is to determine whether or not to execute the gear shifting motion according to the spindle S code command.

1. when the spindle is at 2nd gear and assuming that the spindle S code command from the user commanding of is larger than (not including equal to) this parameter setting value, or smaller than (including equal to) the setting value of parameter 1150 (gear shifting rotational speed of 1st spindle gear), the system will inform PLC to execute the gear shifting motion (shifting to which gear is determined by the spindle commanding rotational speed);
2. the spindle is NOT at 2nd gear and assuming that the spindle S code command from the user command of is smaller than (including equal to) this parameter setting value and larger than (not including equal to) the setting value of parameter 1150 (gear shifting rotational speed of 1st spindle gear), the system will inform PLC to shift the spindle to the 2nd gear;
3. If no spindle gear shifting need, recommend to use the 4th gear (C BIT 097 – 099 are OFF) and set this parameter to 0.

Need to pay attention to the following: NC only follows the S code command from user command to determine the gear and then to inform PCL to execute gear shifting motion. If due to the spindle rotational speed OVERRIDE, the actual rotational speed is over that gear range, and then NC will NOT execute the above motion.

1152
SPEED OF 3RD SPINDLE GEAR

Range : 0 ~ 99999

Active : Active After RESET

Level : Machinery Builder

Default value : 0

Unit : RPM

Description : this parameter is to determine whether or not to execute gear shifting motion according to spindle S code command:

1. when spindle is at 3rd gear and assuming that the spindle S code command from user command of is larger than (not including equal to) this parameter setting value, or smaller than (including equal to) the setting value of parameter 1151 (gear shifting rotational speed of the 2nd spindle

- gear), the system will inform PLC to execute gear shifting motion (shifting to which gear is determined by the spindle commanding rotational speed);
2. when spindle is NOT at 3rd gear and assuming the spindle S code command from user command is smaller than (including equal to) this parameter setting value and larger than (not including equal to) the setting value of parameter 1151 (gear shifting rotational speed of the 2nd spindle gear). System will inform PLC to shift spindle to the 3rd gear.
 3. If no spindle gear shifting need, recommend to use the 4th gear (C BIT 097 – 099 are OFF) and set this parameter to 0.
- Need to pay attention to the following: NC only follows the S code command from user command to determine the gear and then to inform PCL to execute gear shifting motion. If due to the spindle rotational speed OVERRIDE, the actual rotational speed is over that gear range, then NC will NOT execute the above motion.

1153
1ST SPD MOTOR RPM OF GEARING

Range : 0 ~ 99999
Active : Active After RESET
Level : Machinery Builder
Default value : 100
Unit : RPM
Description : During spindle is shifting gears, when C BIT 126 is ON, the system will use this parameter to set the rotating speed to driver spindle motor. At this time, spindle rotational speed OVERRIDE does not work.

1154
1ST SPD MOTOR RPM RANGE OF GEAR

Range : 0 ~ 99999
Active : Active After RESET
Level : Machinery Builder
Default value : 50
Unit : RPM
Description : Assumed during spindle gear shifting procedure. Assumed C BIT 126 is ON, if the spindle motor actual rotational speed - parameter 1113 setting value is less than and equal to this parameter setting value, the system will set S BIT 094 to ON.

1155
MAX SPEED OF 1ST SPINDLE GEAR

Range : 0 ~ 99999
Active : Active After RESET
Level : Machinery Builder
Default value : 1000
Unit : RPM
Description : Assumed the spindle is at the 1st gear, when the spindle rotational speed (spindle S Code command * rotational speed OVERRIDE) is over this parameter setting value, the system will be restricted this parameter setting value.

1156
MAX SPEED OF 1ND SPINDLE GEAR

Range : 0 ~ 99999
Active : Active After RESET
Level : Machinery Builder
Default value : 2000
Unit : RPM
Description : Assumed the spindle is at the 2nd gear, when the spindle rotational speed (spindle S Code command * rotational speed OVERRIDE) is over this parameter setting value, the system will be restricted this parameter setting

value.

1157

MAX SPEED OF 1RD SPINDLE GEAR

Range : 0 ~ 99999

Active : Active After RESET

Level : Machinery Builder

Default value : 3000

Unit : RPM

Description : Assumed the spindle is at the 3rd gear, when the spindle rotational speed (spindle S Code command * rotational speed OVERRIDE) is over this parameter setting value, the system will be restricted this parameter setting value.

3.5 MPG Parameter

15

AXIS.HANDLE FOR MPG DRY RUN

Range : 1 ~ 19

Active : Active After Reboot

Level : Machinery Builder

Default value : 6

Unit : Nul

Description : This is used to set connection port number of the hand wheel under MPG dry run mode (works only in MEM or MDI modes).

18

MPG MULTIPLIER MODE

Range : 0 ~ 1

Active : Active After RESET

Level : Machinery Builder

Default value : 0

Unit : Nul

Description : When P18=0, all Servo MPG ration are defined by register 14, ratio value defined as following chart.

Servo	register	value	MPG ratio
X Y Z 4th	14	1	X1
		2	X10
		3	X100
		other	X1

When 18=1, different Servo MPG ratio defined by different register, please refer to following chart.

Servo	register	value	MPG ration
X	14	1	X1
		2	X10
		3	X100
		other	X1
Y	81	1	X1
		2	X10
		3	X100
		other	X1
Z	82	1	X1
		2	X10
		3	X100
		other	X1
4th	83	1	X1
		2	X10
		3	X100
		other	X1

28	MPG X PORT
75	MPG 4TH PORT
87	MPG Y PORT
88	MPG Z PORT

Range : 1 ~ 19
 Active : Active After Reboot
 Level : Machinery Builder
 Default value : 6
 Unit : Nul
 Description : Under MPG mode, connection port number of X-axis MPG.

544	MPGX acceleration time (ms)
545	MPGY acceleration time (ms)
546	MPGZ acceleration time (ms)
547	MPG4TH acceleration time (ms)

Range: 0 ~ 300
 Effective time: Effective After Reboot
 Access level: Machine Maker
 Default: 0
 Unit: ms
 Description: Under MPG mode, each axis MPG acceleration time °

550	MPGX max speed (um/min)
551	MPGY max speed (um/min)
552	MPGZ max speed (um/min)
553	MPG4TH max speed (um/min)

Range: 1 ~ 99999999
 Effective time: EFFECTIVE AFTER RESET
 Access level: Machine Maker
 Default: 2000000
 Unit: Um/min
 Description: Under MPG mode, each axis MPG max speed °

3.6 Compensation Parameter

Compensation can setup about backlash, gear tolerance and ball bar. Also can refer to 5.2 Laser Compensation Procedure 5.3 5.3 Double Ball Bar Measure – Backlash or Circular Spike Backlash

38	BACKLASH/PITCH COMP UNITS
	Range : 0 ~ 16
	Active : Active After Reboot
	Level : Machinery Builder
	Default value : 16
	Unit : Nul
	Description : to set units for backlash compensation parameters (parameters 0044~ 0047) and pitch compensation parameters (parameters 0300 ~ 0349 、 0450 ~0499 、 0600 ~ 0649 、 0750 ~ 0799).
44	X BACKLASH
45	Y BACKLASH
46	Z BACKLASH
47	4TH BACKLASH
	Range : 0 ~ 32767
	Active : Active After RESET
	Level : Machinery Builder
	Default value : 0
	Unit : um
	Description : To set backlash compensation of X-axis.
112	NUM.SECs OF X.PICTH COMP
113	NUM.SECs OF Y.PICTH COMP
114	NUM.SECs OF Z.PICTH COMP
115	NUM.SECs OF 4TH.PICTH COMP
	Range : 1 ~ 150
	Active : Active After Reboot
	Level : Machinery Builder
	Default value : 20
	Unit : Nul
	Description : To set total section of X-axis pitch error compensation. The multiple product of this parameter setting value and parameter 1018(1019, 1020, 1021) setting value should be the total length of X-axis ball screw pitch error compensation. Now the max compensation section is 50 sections for each axis.

117**ENABLE OF BACKLASH COMP(BIT)**

Range : 0 ~ 63

Active : Active After RESET

Level : Machinery Builder

Default value : 0

Unit : Nul

Description : BIT0: for X axis, 1 means to enable X-axis backlash compensation function; 0 means not to enable.
 BIT1 : For Y axis, 1 means to enable Y axis backlash compensation function; 0 means not to enable.
 BIT2 : For Z axis, 1 means to enable Z axis backlash compensation function; 0 means not to enable.
 BIT3 : For 4th axis, 1 means to enable 4th axis backlash compensation function; 0 means not to enable.

118**FLAG OF BACKLASH DIRECTION**

Range : 0 ~ 63

Active : Active After Reboot

Level : Machinery Builder

Default value : 0

Unit : Nul

Description : BIT0 : for setting X axis, 1 means pitch error compensation starts from –ive direction X axis returns to the reference point; 0 means pitch error compensation starts toward +ive direction.
 BIT1 : for setting Y axis, 1 means pitch error compensation starts from –ive direction Y axis returns to the reference point; 0 means pitch error compensation starts toward +ive direction.
 BIT2 : for setting Z axis, 1 means pitch error compensation starts from –ive direction Z axis returns to the reference point; 0 means pitch error compensation starts toward +ive direction.
 BIT3 : for setting 4th axis, 1 means pitch error compensation starts from –ive direction 4th axis returns to the reference point; 0 means pitch error compensation starts toward +ive direction.

119**ENABLE FLAG OF PITCH COMP**

Range : 0 ~ 63

Active : Active After Reboot

Level : Machinery Builder

Default value : 0

Unit : Nul

Description : BIT0 : For X axis, 1 means to enable X axis pitch error compensation function; 0 means not to enable.
 BIT1 : For Y axis, 1 means to enable Y axis pitch error compensation function; 0 means not to enable.
 BIT2 : For Z axis, 1 means to enable Z-axis pitch error compensation function; 0 means not to enable.
 BIT3 : For 4th axis, 1 means to enable 4th axis pitch error compensation function; 0 means not to enable.

300	PITCH X COMP.001
349	PITCH X COMP.050
1200	PITCH X COMP.051
1299	PITCH X COMP.150

Range : -20000 ~ 20000

Active : Active After RESET

Level : Machinery Builder

Default value : 0

Unit : um

Description : Assumed pitch error on the nth section of X axis is M (um), the parameter # (300+N – 1) is set as M, and parameter 0038 is set as 16.

358	ENABLE THERMO DEFORMED CMP
------------	-----------------------------------

Range : 0 ~ 1

Active : Active After Reboot

Level : Machinery Builder

Default value : 0

Unit : Nul

Description : 0 : Turn off the thermal compensation function
1 : Turn on the thermal compensation function

359	ALLOWANCE OF THERMO CMP INPUT
------------	--------------------------------------

Range : 1 ~ 1000

Active : Instant Activity

Level : Machinery Builder

Default value : 1000

Unit : um

Description : The maximum thermal compensation input amount allowed.

450	PITCH Y COMP.001
499	PITCH Y COMP.050
1300	PITCH Y COMP.051
1399	PITCH Y COMP.150

Range : -20000 ~ 20000

Active : Active After RESET

Level : Machinery Builder

Default value : 0

Unit : um

Description : Assumed pitch error on the nth section of Y axis is M (um), the Parameter # (450+N – 1) is set as M, and parameter 0038 is set as 16.

600	PITCH Z COMP.001
649	PITCH Z COMP.050
1400	PITCH Z COMP.051
1499	PITCH Z COMP.150

Range : -20000 ~ 20000
 Active : Active After RESET
 Level : Machinery Builder
 Default value : 0
 Unit : um
 Description : Assumed pitch error on the nth section of Z axis is M (um), the Parameter # (600+N – 1) is set as M, and parameter 0038 is set as 16.

750	PITCH A COMP.001
799	PITCH A COMP.050
1500	PITCH A COMP.051
1599	PITCH A COMP.150

Range : -20000 ~ 20000
 Active : Active After RESET
 Level : Machinery Builder
 Default value : 0
 Unit : um
 Description : Assumed pitch error on the nth section of Z axis is M (um), the parameter # (750+N – 1) is set as M, and parameter 0038 is set as 16.

562	PLC axis compensation bit 0)OFF 1)ON
------------	---

Range: 0 ~ 1
 Effective time: Effective After Reboot
 Access level: Machine Maker
 Default: 0
 Unit: Non
 Description: 0:OFF,1:ON

563	PLC axis compensation X acceleration time ms
564	PLC axis compensation Y acceleration time ms
565	PLC axis compensation Z acceleration time ms
566	PLC axis compensation 4TH acceleration time ms

Range: 100 ~ 1000
 Effective time: EFFECTIVE AFTER RESET
 Access level: Machine Maker
 Default: 1000
 Unit: ms
 Description: Set PLC axis compensation acceleration time

569	X backlash compensation acceleration time ms
570	Y backlash compensation acceleration time ms
571	Z backlash compensation acceleration time ms
572	4TH backlash compensation acceleration time ms

Range: 0 ~ 1000
 Effective time: EFFECTIVE AFTER RESET

Access level: Machine Maker
 Default: 0
 Unit: ms
 Description: Set each axis backlash compensation acceleration time

811	SPIKE CMP G CODE 0)G2 G3 1)ALL
	Range : 0 ~ 1
	Active : Active After RESET
	Level : Machinery Builder
	Default value : 0
	Unit : um
	Description : When parameter setting is 0, this means the spike compensation value, set by using circular testing, can only be applied on G02/03 arch interpolation command. When it is 1, the spike compensation value can be applied on all moving G codes, which means as long as servo axis is doing reverse direction motion; the setting spike compensation value will be added.

812	SPIKE +X CMP VALUE
818	SPIKE +Y CMP VALUE
828	SPIKE +Z CMP VALUE
	Range : 0 ~ 200
	Active : Active After RESET
	Level : Machinery Builder
	Default value : 0
	Unit : um
	Description : Assumed doing the circular testing. When the spike value of +ive X axis direction is 0, this means NOT to enable the spike compensation function of +ive X-axis direction.

813	SPIKE +X CMP TIME
819	SPIKE +Y CMP TIME
829	SPIKE +Z CMP TIME
	Range : 0 ~ 200
	Active : Active After RESET
	Level : Machinery Builder
	Default value : 0
	Unit : um
	Description : Please check the controller's actual disconnecting time interval first and then set the desired value. Assumed doing circular testing. When set the spike time interval to 0, it means NOT to enable the spike compensation function of +ive X-axis direction.

814	SPIKE +X CMP DELAY
820	SPIKE +Y CMP DELAY
830	SPIKE +Z CMP DELAY

Range : 0 ~ 200

Active : Active After RESET

Level : Machinery Builder

Default value : 0

Unit : um

Description : Please check the controller's actual disconnecting time interval first and then set the value. Assumed doing circular testing. Delay time interval between the spike point of +ive X-axis direction and the direction changing point.

815	SPIKE -X CMP VALUE
825	SPIKE -Y CMP VALUE
831	SPIKE -Z CMP VALUE

Range : 0 ~ 200

Active : Active After RESET

Level : Machinery Builder

Default value : 0

Unit : um

Description : Assumed doing the circular testing. When the spike value of -ive X axis direction is 0, this means NOT to enable the spike compensation function of -ive X-axis direction.

816	SPIKE -X CMP TIME
826	SPIKE -Y CMP TIME
832	SPIKE -Z CMP TIME

Range : 0 ~ 200
 Active : Active After RESET
 Level : Machinery Builder
 Default value : 0
 Unit : um
 Description : Please check the controller's actual disconnecting time interval first and then set the value. Assumed doing canned cycle testing. When set the spike time interval to 0, it means NOT to enable the spike compensation function of -ive X-axis direction.

817	SPIKE -X CMP DELAY
827	SPIKE -Y CMP DELAY
833	SPIKE -Z CMP DELAY

Range : 0 ~ 200
 Active : Active After RESET
 Level : Machinery Builder
 Default value : 0
 Unit : um
 Description : Please check the controller's actual disconnecting time interval first and then set the value. Assumed doing canned cycle testing. Delay time interval between the spike point of X axis -ive direction and the direction changing point.

1018	COMP DIST OF EACH SECTION.X
1019	COMP DIST OF EACH SECTION.Y
1020	COMP DIST OF EACH SECTION.Z
1021	COMP DIST OF EACH SECTION.A

Range : 0 ~ 99999999
 Active : Active After Reboot
 Level : Machinery Builder
 Default value : 30000
 Unit : um
 Description : Assumed pitch error compensation interval is 10000μm of every X axis section, so please set this parameter to 1000.

1046	START.X COMP POS
1047	START.Y COMP POS
1048	START.Z COMP POS
1049	START.4 COMP POS

Range : -99999999 ~ 99999999
 Active : Active After Reboot
 Level : Machinery Builder
 Default value : 0
 Unit : um
 Description : When the starting position of X axis pitch error compensation is 0μm (machine coordinate) , please set this parameter to 0.

3.7 Home Parameter

19	WAY TO DEAL HOMING ON DOG
	Range : 0 ~ 1 Active : Active After RESET Level : Machinery Builder Default value : 0 Unit : Nul Description : 0: Warning from the system in order to inform user to move away the servo axis. Then the system will execute the zero return procedure. Each axis warning message is as following: X Axis : 【MOT 0014 X axis is on HOME DOG】 Y Axis : 【MOT 0015 Y axis is on HOME DOG】 Z Axis : 【MOT 0016 Z axis is on HOME DOG】 4 th Axis : 【MOT 0017 4 th axis is on HOME DOG】 1 : NC moves away the servo axis automatically (moves toward the reverse direction from the reference point). After getting away from DOG, it will execute home/zero return procedure.
20	DEFAULT OF RETURN HOME FN.(BIT)
	Range : 0 ~ 63 Active : Active After Reboot Level : Machinery Builder Default value : 0 Unit : Nul Description : After turning on the machine, check if each axis is preset to having returned to reference point. Bit 0 : X axis Bit 1 : Y axis Bit 2 : Z axis Bit 3 : The 4 th axis
30	OFFSET LENGTH OF X.ORG
31	OFFSET LENGTH OF Y.ORG
32	OFFSET LENGTH OF Z.ORG
33	OFFSET LENGTH OF 4.ORG
	Range : -99999999 ~ 99999999 Active : Active After RESET Level : Machinery Builder Default value : 0 Unit : um Description : Assumed each axis moves N distance toward machine reference point. Setting this parameter to N if want to get the offset amount of N distance (um). Different setting value will change the reference point due to different offset amount. But, this setting value will NOT change the display coordinate after returning home. When the setting value is positive, it makes the machine home point of this axis moves away from DOG direction. When the setting value is negative, it makes the machine home point of this axis moves close to DOG direction.

34	PAUSE TIME.X HOME SERACHING
35	PAUSE TIME.Y HOME SERACHING
36	PAUSE TIME.Z HOME SERACHING
37	PAUSE TIME.4 HOME SERACHING

Range : 100 ~ 2000
Active : Active After RESET
Level : Machinery Builder
Default value : 100
Unit : 10 ms
Description : the required dwell time that is set by this parameter can be used in the following three places:

- Dwell time of decelerating stop when X axis moves toward the reference point in 1st speed and reaches DOG.
- dwell time of decelerating stop when X axis gets away from DOG in 2nd speed and finds motor INDEX.
- Dwell time of decelerating stop when X axis returns back the desired motor INDEX position.

48	DIRECT SET HOME POSITION
----	---------------------------------

Range : 0 ~ 63
Active : Active After Reboot
Level : Machinery Builder
Default value : 0
Unit : Nul
Description : BIT 0 : Setting 0 to indicate X axis re-searching HOME point method is re-searching DOG+ Index. 1 to indicate X axis re-searching HOME point method is force setting.
BIT 1 : Setting 0 to indicate Y axis re-searching HOME point method is re-searching DOG+ Index. 1 to indicate Y axis re-searching HOME point method is force setting.
BIT 2 : Setting 0 to indicate Z axis re-searching HOME point method is re-searching DOG+ Index. 1 to indicate Z axis re-searching HOME point method is force setting.
BIT 3 : Setting 0 to indicate the 4th axis re-searching HOME point method is re-searching DOG+ Index. 1 to indicate the 4th axis re-searching HOME point method is force setting.

64	HOME DOG 0)NC 1)NO
----	---------------------------

Range : 0 ~ 1
Active : Active After Reboot
Level : Machinery Builder
Default value : 0
Unit : Nul
Description : this parameter works only when the home DOG sensor signal is connected to LOCAL INPUTS (Transit Board HS1 ~ HS4 connect points). (Parameter 0175 setting value is 0). If the home dog sensor signal is connected REMOTE INPUTS, then PLC ladder diagram program needs to change each axis home DOG signal state to C BIT 0031 ~ 0035 in order to inform NC.

76

ENABLE ABS SET AFTER HOMING

Range : 0 ~ 1
 Active : Active After RESET
 Level : Machinery Builder
 Default value : 1
 Unit : Nul
 Description : please refer to 1014 ~ 1017 for absolute coordinate setting Value. After each servo axis returns home, display value of absolute coordinate is determined by following three points:
 a. setting value of parameters 1014 ~ 1017;
 b. 00 coordinated system, setting value of G54 ~ G59 coordinate system ;
 c. Setting value in G52 area coordinate system.

$$Para\#1014 \sim 1017 \text{ value} - \begin{pmatrix} 00 \text{ coordinate value} \\ + G54 \sim G59 \text{ coordinate value} \\ + G52 \text{ regional coordinate value} \end{pmatrix}$$

- In addition,
- a. setting value of parameters 1014 ~ 1017: use this parameter to decide whether or not they are effective ;
 - b. 00 coordinate system, G54 ~ G59 coordinate system setting values: effective permanently ;
 - c. Setting value in G52 area coordinate system: use parameter 0133 to decide whether or not it is effective.

77

ENABLE NONE HOMING G00 OPR

Range : 0 ~ 1
 Active : Active After RESET
 Level : User
 Default value : 1
 Unit : Nul
 Description :

	Parameter 77 setting value is 1, G00 is effective before zero return	Parameter 77 setting value is 0, G00 is NOT effective before Return Home
MEM, MDI Automatic mode	G00 motion normally, each axis feedrate is decided by the setting value of parameters 1000 ~ 1003.	Automatically change G00 motion to G01 motion, feedrate is the present F code designated value (use parameter 149 to set the default value).
JOG, RAPID Manual mode	Under JOG, each axis feedrate is decided by the Setting value of parameter 1100 ~ 1103; under RAPID, each axis feedrate is decided by the setting value of parameters 1000 ~ 1003.	Motion of RAPID and motion of JOG, each axis feedrate is decided by the setting value of parameter 1100 ~ 1103.

79	ORG.X AHEAD/BEHIND OF DOG
80	ORG.Y AHEAD/BEHIND OF DOG
81	ORG.Z AHEAD/BEHIND OF DOG
82	ORG.4 AHEAD/BEHIND OF DOG

Range : 0 ~ 1

Active : Active After RESET

Level : Machinery Builder

Default value : 1

Unit : Nul

Description : 0 : when reference point is behind DOG, after each axis reaches DOG, each axis will continue moving toward the same direction and look for the reference point ;
1 : Home position is ahead of DOG, after each axis reaches DOG; each axis will continue moving toward the reverse direction and look for the reference point.

120 HOME DIRECTION OF AXIS

Range : 0 ~ 63

Active : Active After Reboot

Level : Machinery Builder


Default value : 0

Unit : Nul


Description : About home return direction, other than this parameter setting, PLC also needs to do the corresponding modification according to this setting. Home return procedure that is written by PLC of the controller machine version uses the home point is at +ive direction as the standard.

Also, in the safety concern to prevent mistakenly touching, the <+> direction signal will be sent out (using X axis as an example, which is C6) no matter which servo axis key (<+> <->) that the user presses. So, under the condition that the home point is at the -ive servo axis direction, not only needs to set the corresponding BIT of this parameter to 1 but also needs to modify the corresponding returning home program in PLC.

Use X axis as an example, the diagram of PLC return home procedure from +ive direction is as following:



If X axis returns home at the -ive direction, other than setting this parameter BIT0 to 1, PLC modification is as following:



175

HOME DOG FROM 0)LOCAL 1)REMOTE

Range : 0 ~ 1

Active : Active After Reboot

Level : Machinery Builder

Default value : 0

Unit : Nul

Description : 0 : means the HOME DOG signal is connected LOCAL INPUTS (transit board HS1 ~ HS4), must setting the type of DOG signal to (parameter 0064);
1 : means the HOME DOG signal is connected REMOTE INPUTS, PLC must change each axis reference point DOG signal to the corresponding C BIT 0031 ~ 0034 (please refer to C BIT 0031 ~ 0034 for description).

204
HOME POSITION RECORD BIT

Range : 0 ~ 63
 Active : Active After RESET
 Level : Machinery Builder
 Default value : 0
 Unit : Nul
 Description : BIT 0 : 0 means when X axis is in Home point mode, the system must research Home point when executing return Home process.
 1 means when X axis is in Home point mode, the system uses NC record's Home point when executing return Home process.
 BIT 1 : 0 means when Y axis is in Home point mode, the system must research Home point when executing return Home process.
 1 means when Y axis is in Home point mode, the system uses NC record's Home point when executing return Home process.
 BIT 2 : 0 means when Y axis is in Home point mode, the system must research Home point when executing return Home process.
 1 means when Y axis is in Home point mode, the system uses NC record's Home point when executing return Home process.
 BIT 3 : 0 means when 4th axis is in Home point mode, the system must research Home point when executing return Home process.
 1 means when 4th axis is in Home point mode, the system uses NC record's Home point when executing return Home process.

208
REFERENCE MARKS OF LINEAR SCALE

Range : 0 ~ 63
 Active : Active After Reboot
 Level : Machinery Builder
 Default value : 0
 Unit : Nul
 Description : For a servo axis that uses a linear scale with multiple reference marks, zero point return can be done manually by measuring the signal intervals between any 2 or 3 reference positions. (Please use parameter No. 0209 & 0210 to set other relevant actions).
 BIT0 : 1 Heidenhain's linear scale with multiple reference marks is used for position feedback of X axis; 0 means not used.
 BIT1 : 1 Heidenhain's linear scale with multiple reference marks is used for position feedback of Y axis; 0 means not used.
 BIT2 : 1 Heidenhain's linear scale with multiple reference marks is used for position feedback of Z axis; 0 means not used.
 BIT3 : 1 Heidenhain's linear scale with multiple reference marks is used for position feedback of the 4th axis; 0 means not used.
 (Below is for 6-axis version)
 BIT4 : 1 Heidenhain's linear scale with multiple reference marks is used for position feedback of the 5th axis; 0 means not used.
 BIT5 : 1 Heidenhain's linear scale with multiple reference marks is used for position feedback of the 6th axis; 0 means not used.

209
HOME RETURN FOR LINEAR SCALE

Range : 0 ~ 63
 Active : Active After RESET
 Level : Machinery Builder
 Default value : 0
 Unit : Nul
 Description : This parameter is only applicable to Heidenhain's linear scale with multiple reference marks. When executing zero return manually, please use BIT defined as follows to set the numbers of reference mark signals that need to be checked for each axis.
 0 : In manual mode, 3 reference marks must be checked to complete the zero return.
 1 : In manual mode, only 2 reference marks have to be checked to complete the zero return. If this option is adopted, parameter No. 0210 must be set additionally.

210
HOME POINT FOR LINEAR SCALE

Range : 0 ~ 63
 Active : Active After RESET
 Level : Machinery Builder
 Default value : 0
 Unit : Nul
 Description : This parameter is only applicable to Heidenhain's linear scale with multiple reference marks. Please use BIT to set the relative position of each axis's machine zero point and the linear scale's zero point (Only valid when the relevant BIT value to parameter No. 0209 is set to 1).
 0 : Machine zero point is at the *positive* side of the linear scale's reference mark ;
 1 : Machine zero point is at the *negative* side of the linear scale's reference mark.

293
ZRN BY DOG OR INDEX

Range : 0 ~ 63
 Active : Active After Reboot
 Level : Machinery Builder
 Default value : 0
 Unit : Nul
 Description : BIT0 : 0 means X axis uses DOG for machine reference point reference and 1 means X uses motor INDEX signal for reference.
 BIT1 : 0 means Y axis uses DOG for machine reference point reference and 1 means Y uses motor INDEX signal for reference.
 BIT2 : 0 means Z axis uses DOG for machine reference point reference and 1 means Z uses motor INDEX signal for reference.

834	ABS. ENCODER READ TIME
Range :	0 ~ 10
Active :	Active After RESET
Level :	Machinery Builder
Default value :	5
Unit :	s
Description :	To set time restriction of NC executes Encoder reading movement.

1014	ABS COORD.X AFTER HOMING
1015	ABS COORD.Y AFTER HOMING
1016	ABS COORD.Z AFTER HOMING
1017	ABS COORD.4 AFTER HOMING
Range :	-99999999 ~ 99999999
Active :	Active After RESET
Level :	Machinery Builder
Default value :	0
Unit :	um
Description :	Assumed the desired X axis absolute coordinate is 300 um after home return, so the setting value must be 300. This parameter setting value only changes the coordinate display value after X-axis returns home. This will NOT change the actual machine position when X-axis returns home. So must set the parameter 0076 setting value to 1 for this setting to be effective.

1022	X.OFF FOR ORG.2 REF TO ORG.1
1023	Y.OFF FOR ORG.2 REF TO ORG.1
1024	Z.OFF FOR ORG.2 REF TO ORG.1
1025	4.OFF FOR ORG.2 REF TO ORG.1
Range :	-99999999 ~ 99999999
Active :	Active After RESET
Level :	Machinery Builder
Default value :	0
Unit :	um
Description :	This parameter is to set the offset amount of the 1 st reference point corresponding to the 2 nd reference point of X axis. Assumed the desired corresponding offset amount of the 1 st reference point is 2000 um, so set the offset amount to 2000.

1026	X.OFF FOR ORG.3 REF TO ORG.1
1027	Y.OFF FOR ORG.3 REF TO ORG.1
1028	Z.OFF FOR ORG.3 REF TO ORG.1
1029	4.OFF FOR ORG.3 REF TO ORG.1

Range : -99999999 ~ 99999999

Active : Active After RESET

Level : Machinery Builder

Default value : 0

Unit : um

Description : This parameter is to set the offset amount of the 1st reference point corresponding to the 3rd reference point of X axis. Assumed the desired corresponding offset amount of the 1st reference point is 2000um, so set the offset amount to 2000.

1030	X.OFF FOR ORG.4 REF TO ORG.1
1031	Y.OFF FOR ORG.4 REF TO ORG.1
1032	Z.OFF FOR ORG.4 REF TO ORG.1
1033	4.OFF FOR ORG.4 REF TO ORG.1

Range : -99999999 ~ 99999999

Active : Active After RESET

Level : Machinery Builder

Default value : 0

Unit : um

Description : This parameter is to set the offset amount of the 1st reference point corresponding to the 4th reference point of X axis. Assumed the desired corresponding offset amount of the 1st reference point is 2000um, so set the offset amount to 2000.

1098	ABS. ENCODER CHECK RANGE
-------------	---------------------------------

Range : 0 ~ 1000

Active : Active After RESET

Level : Machinery Builder

Default value : 30

Unit : pulse

Description : To set the max difference value that is between NC internal Encoder value and Driver Absolute Encoder value. Difference value that is between setting value of X axis Absolute Encoder (System Data #41) and NC internal value (System Data #32). Difference value that is between setting value of Y axis Absolute Encoder (System Data #42) and NC internal value (System Data #33). Difference value that is between setting value of Z axis Absolute Encoder (System Data #43) and NC internal value (System Data #34). Difference value that is between setting value of the 4th axis Absolute Encoder (System Data #44) and NC internal value (System Data #35).

1104	1ST SPEED OF X HOMING
1105	1ST SPEED OF Y HOMING
1106	1ST SPEED OF Z HOMING
1107	1ST SPEED OF C HOMING

Range : 1 ~ 99999999

Active : Active After RESET

Level : Machinery Builder

Default value : 2000000

Unit : um/min

Description : during each axis zero return procedure, moves toward this axis
Reference point in this parameter setting speed (set by parameter 0120).
After reaching the home DOG, please use the 2nd gear speed, which is set
By parameter 1108 ~ 1111, to move and to search for motor reference point.

1108	2ST SPEED OF X HOMING
1109	2ST SPEED OF Y HOMING
1110	2ST SPEED OF Z HOMING
1111	2ST SPEED OF C HOMING

Range : 1 ~ 99999999

Active : Active After RESET

Level : Machinery Builder

Default value : 200000

Unit : um/min

Description : during each axis zero return procedure, moves toward this axis
Reference point in Parameter #1104 ~ #1107's setting speed. (Set by parameter
0120). After touching the home DOG, please use the 2nd gear speed, which is
set by this parameter, to move and to search for motor reference point.

1118	ENABLE INDEX PROTECTED FUNCTION
------	---------------------------------

Range : 0 ~ 1

Active : Active After RESET

Level : User

Default value : 0

Unit : Nul

Description : When the distance between the 1st index and limit switch is less than 1/5 or
more than 4/5 revolution of the encoder, grid protection function will activate so
the next index mark will be used to make the distance between the 1st index and
limit switch over 1/2 revolution of the encoder if the distance in-between is less
than 1/2 revolution. This function ensures that the zero point is always the
original one.

1171	SPACE1 LINEAR SCALE OF X AXIS
1172	SPACE2 LINEAR SCALE OF X AXIS
1173	SPACE1 LINEAR SCALE OF Y AXIS
1174	SPACE2 LINEAR SCALE OF Y AXIS
1175	SPACE1 LINEAR SCALE OF Z AXIS
1176	SPACE2 LINEAR SCALE OF Z AXIS
1177	SPACE1 LINEAR SCALE OF 4TH AXIS
1178	SPACE2 LINEAR SCALE OF 4TH AXIS

Range : 0 ~ 99999999


Active : Active After Reboot

Level : Machinery Builder

Default value : 20020

Unit : um

Description : This parameter is only applicable to Heidenhain's linear scale with multiple reference marks. For the setting method, please go to the figure below for reference.



1183	OFFSET LINEAR SCALE OF X AXIS
1184	OFFSET LINEAR SCALE OF Y AXIS
1185	OFFSET LINEAR SCALE OF Z AXIS
1186	OFFSET LINEAR SCALE OF 4TH AXIS

Range : 0 ~ 99999999

Active : Active After RESET

Level : Machinery Builder


Default value : 0

Unit : um

Description : This parameter is only applicable to Heidenhain's linear scale with multiple reference marks. To change the set value of this parameter, please press RESET first and executes zero return manually again. By measuring 2 or 3 signal intervals of the linear scale, NC can detect instantly the relative position between each axis's current position and the linear scale's zero point. If the two positions do not match each other, the shift between them must be defined by setting this parameter.

Zero Return Procedure Description

■ When Reference Point is Behind DOG



D1 is the distance between two Z phase signals that are close together of servo motor ECNODER.

D2 is the distance between the HOME DOG input points to the servo axis by using the 1st gear speed decelerating stop. The calculating formula is as following:

$$D2 \doteq \text{servo lag} + \text{deceleration distance} \doteq \frac{F_{H1}}{K_p} + \frac{F_{H1} \cdot T_a}{2}$$

K_p is the servo position loop gain (sec^{-1}), T_a is the servo axis G00 acc/decelerating time.

If the length between the Home DOG input point and the disappear point is smaller than D2, then warning message (MOT 0027 Home DOG length is too short) will occur.

D3 is the traveling distance at the time when servo motor starts from complete stop and accelerates to 2nd gear speed to when Home DOG signal disappears. In order to catch the Z phase signal under the condition of the same speed, the distance of D3 must be long enough in order for the servo motor to be able to reach the 2nd gear speed. Calculating formula is as following:

$$D3 \geq \frac{F_{H2} \cdot T_a}{2}, \quad T_a \text{ is servo axis G00 acc/deceleration time.}$$

So, the length of the Home DOG must be at least (D2 + D3) long.

D4 is the time interval from the disappear point of Home DOG to the next Z phase signal of servo motor ECNODER. In order to prevent any confusion that is caused by the electric and the machine delay, D4 must be approximately one-half of D1, which means the disappear point of Home DOG must be approximately at the mid-point of the two Z phase signals that are close to the servo motor. If the motor rotates one time but not able to find the Z phase signal after the Home Dog signal is disappear, then the alarm message (MOT0045 not able to find the ZI light of motor) will occur. Please check whether there is motor connection error.

D5 is the traveling distance from the 1st Z phase signal of servo motor ENCODER after getting away DOG to servo axis in 2nd gear decelerating stop. The calculating formula is as following:

$$D5 \triangleq \text{servo lag} + \text{deceleration distance} \triangleq \frac{F_{H2}}{K_p} + \frac{F_{H2} \cdot T_a}{2}$$

K_p is the servo position loop gain (sec^{-1}), T_a is the servo axis G00 acc/decelerating time.

The distance between the machine reference point of servo axis and the traveling limit must be at least greater than D5. Or it will mistakenly cause travel limitation during zero return.

Recommending to set the offset amount of the servo axis reference point (parameters 0030 ~ 0033) greater than D5 in order to prevent any reverse direction moving of servo axis.

【Example】Assumed a servo axis home return in 1st gear speed is 10m/min, the 2nd gear speed is 200mm/min, G00 acc/decelerating time is 150ms, position loop gain is 100sec⁻¹. Under the condition that the reference point is behind DOG, the calculating formula of the shortest needed length of DOG is as following:

$$D2 \doteq \frac{10000/60}{100} + \frac{10000/60 \cdot 0.15}{2} \doteq 14.17\text{mm}$$

$$D3 \doteq \frac{200/60 \cdot 0.15}{2} \doteq 0.25\text{mm}$$


So, the shortest needed length of DOG is (D2 + D3) \doteq 14.42mm

Also,

$$D5 \doteq \frac{200/60}{100} + \frac{200/60 \cdot 0.15}{2} \doteq 0.28\text{mm}$$

If the setting vaule for the offset amount of this axis reference point is larger than 0.28mm, it will be able to prevent this axis to do the reverse direction moving at the last step of the home return procedure.

■ When Reference Point is Ahead DOG



D1 is the distance between two Z phase signals that are close together of servo motor ECNODER.

D2 is the distance between the HOME DOG input points to the servo axis by using the 1st gear speed decelerating stop. The calculating formula is as following:

$$D2 \doteq \text{servo lag} + \text{deceleration distance} \doteq \frac{F_{H1}}{K_p} + \frac{F_{H1} \cdot T_a}{2}$$

K_p is the servo position loop gain (sec^{-1}), T_a is the servo axis G00 acc/decelerating time.

If the length between the Home DOG input point and the disappear point is smaller than D2, then warning message (MOT 0027 Home DOG length is too short) will occur.

D2 is the traveling distance at the time when servo motor starts from complete stop and accelerates to 2nd gear speed to when Home DOG signal disappears. General speaking, the 2nd gear speed is smaller than the 1st gear speed, so the length of D2 must be long enough for the servo motor to accelerate to the 2nd gear speed, which means catching the servo motor Z phase signals in the same speed.

D3 is the time interval from the disappear point of Home DOG to the next Z phase signal of servo motor ECNODER. In order to prevent any confusion that is caused by the electric and the machine delay, D4 must be approximately one-half of D1, which means the disappear point of Home DOG must be approximately at the mid-point of the two Z phase signals that are close to the servo motor. If the motor rotates one time but not able to find the Z phase signal after the Home Dog signal is disappear, then the alarm message (MOT0045 not able to find the ZI light of motor) will occur. Please check whether there is motor connection error.

D4 is the traveling distance from the 1st Z phase signal of servo motor ENCODER after getting away DOG to servo axis in 2nd gear decelerating stop. The calculating formula is as following:

$$D5 \doteq \text{servo lag} + \text{deceleration distance} \doteq \frac{F_{H2}}{K_p} + \frac{F_{H2} \cdot T_a}{2}$$

K_p is the servo position loop gain (sec^{-1}), T_a is the servo axis G00 acc/decelerating time.

Recommending to set the setting value for the offset amount of the servo axis reference point that is greater than D4 in order to prevent the servo axis to do the reverse direction moving.

3.8 Operation Parameter

23

Each axis JOG feed rate 0)R17 1)R90-R95

Range: 0 ~ 1
 Effective time: Effective After Reboot
 Access level: Machine Maker
 Default: 0
 Unit: Non
 Description: Set to be 0, each axis feed rate will refer to R17, If set to be 1, each axis will refer to related R value for feed rate.

39


G92 IS CANCELLED AT G54~G59

Range : 0 ~ 1
 Active : Active After RESET
 Level : User
 Default value : 0
 Unit : Nul
 Description : 0 : When program executes G54 ~ G59 coordinate selecting command, not to cancel previous coordinate OFFSET amount which is caused by G92 command. Not to cancel neither the designated command of absolute command (G90) nor OFFSET amount G54 ~ G59.
 1 : When program executes G54 ~ G59 coordinates selecting command, cancel previous coordinate OFFSET amount which is caused by G92 command and also designated coordinate of absolute command (G90), which is for G54 ~ G59 coordinates ONLY.


41

G00 LINEAR INTERPOLATION

Range : 0 ~ 1
 Active : Active After RESET
 Level : User
 Default value : 1
 Unit : Nul
 Description : 0 : For G00 command, each servo axis will move by its setting G00 speed, NOT to do compensation motion simultaneously.
 1 : for G00 command, each servo does compensation motion simultaneously, the valid range is as following:
 a. G00 commands in MEM and/or MDI modes
 b. Same G00 motion commands under MEM and/or MDI modes, such as G27 ~ G30、G53;
 c. G00 and G53 commands of PMC axis function



Parameter 0041 setting value is 0



Parameter 0041 setting value is 1

42

COMMENT TYPE 0:/*...*/ 1:(...)

Range : 0 ~ 1

Active : Active After RESET

Level : User

Default value : 0

Unit : Nul

Description : Parameter No. 42 sets the annotation format for part programs. When parameter No. 42 is set to 0, the annotation format is /*.....*/, and the functional format can either be (...) or [...]. When parameter No. 42 is set to 1, the annotation format can be either /*.....*/ or (.....), but the functional format must be [...].

43

FLAG OF EXACT CHECK

Range : 0 ~ 127

Active : Active After RESET

Level : User

Default value : 16

Unit : Nul

Description : Bit0 : 1 means X axis straight-line cutting (G01) of exact stop checking function is canceled.
 Bit1 : 1 means Y axis straight-line cutting (G01) of exact stop checking function is canceled.
 Bit2 : 1 means Z axis straight-line cutting (G01) of exact stop checking function is canceled.
 Bit3 : 1 means 4th axis straight-line cutting (G01) of exact stop checking function is canceled.
 Bit4 : 1 means starting rapid traverse (G00) of exact stop checking function is canceled.

For straight-line cutting command (G01), if want to enable the exact stop checking function, not only needs to set this parameter corresponding bit but also needs to order G09 command (exact stop command, works for a single block), or G61 command (exact stop mode, permanently effective, so must use G64 command to cancel.)

Once activating the exact stop checking function of G01 command, NC system will wait until each enabled servo axis enters into the checking windows range

(parameters 0006 ~ 0009) after completed interpolation of any one of G01 command, then it will execute the next single block.
For the RAPID TRAVERSE command, G00, only need to set BIT 4 of this parameter to 1 in order to active the exact stop checking function. Under the condition that the exact stop function can be enable, NC system will wait until the actual position of each servo axis already enters into the checking windows range (parameters 0800 ~ 0803) after the interpolation is completed, then it will execute the next signal block. But if the former single block and the latter single block of a certain rapidly orientation command are both rapid traverse commands, then this rapid traverse command will NOT execute the exact stop checking.

63
COORD.RLT SET WITH COORD.ABS

Range : 0 ~ 1
Active : Active After RESET
Level : User
Default value : 1
Unit : Nul
Description : the valid range of this parameter setting value is as following:
1. Reboot coordinate display value ;
2. After zero return procedure is completed, coordinate display value ;
3. G54 ~ G59 commands (work coordinate system selection) ;
4. G92 command (coordinate value setting) .

71
INNER/OUTTER CHECK OF G22

Range : 0 ~ 1
Active : Active After RESET
Level : User
Default value : 0
Unit : Nul
Description : 0 : The embedded travel checking function that is set by G22 is the external prohibit area. When there is command that will move the tool to outside of the setting range, the system alarm will be enabled.
1 : The embedded travel checking function that is set by G22 is the external prohibit area. When there is command that will move the tool to outside of the setting range, the system alarm will be enabled.
About system alarm, please refer to the description of MOT 4058、9009 ~ 9014.

73
ENABLE G31 ACCELERATION

Range : 0 ~ 1
Active : Active After Reboot
Level : Machinery Builder
Default value : 1
Unit : Nul
Description : 0 : after G31 SKIP SIGNAL enters, immediately stop without decelerating;
1 : After G31 SKIP SIGNAL enters, use parameter 0041 to set the acc/decelerating time in order to precede stop in decelerating speed.

74

ENABLE MACRO TRACE UNDER SBK

Range : 0 ~ 1
 Active : Active After RESET
 Level : User
 Default value : 0
 Unit : Nul
 Description : 0 : Macro command (not NC command) Not execute single block;
 1 : Macro command (not NC command) execute single block.

78

ENABLE C AXIS TANGENT FOLLOW

292

ENABLE C AXIS PATH FOLLOWING

Range : 0 ~ 1
 Active : Active After Reboot
 Level : User
 Default value : 0
 Unit : Nul
 Description : When this function is enabled, C axis moving angle will move by following XY cutting line direction.

83

ENABLE G00 UNDER DRY RUN

Range : 0 ~ 1
 Active : Active After RESET
 Level : User
 Default value : 1
 Unit : Nul
 Description :

Under Dry Run, Motion of RAPID TRAVERSE Command

	Para #0083			
	0		1	
	Para #0041		Para #0041	
	0	1	0	1
RAPID mode	(1)			
In MEM and MDI modes, G00 command and/or motion with G00 command	(2)	(3)	(1)	(4)
G00 and G53 commands of PMC axis function	C23 OFF : (1)	C23 OFF : (3)	(1)	(4)
	C23 ON : (1)	C23 ON : (4)		

Each axis moves according to its G00 speed.
 Each axis moves according to its JOG speed
 Each axis moving speed will NOT excess its setting JOG speed.
 Each axis moving speed will NOT excess its setting G00 speed.

89
M CODE ID OF PART COUNTER

Range : 1 ~ 99
 Active : Active After RESET
 Level : User
 Default value : 99
 Unit : Nul
 Description : Other than M02 and M03, users can use this parameter to set another working piece counter control of M code command. But, must avoid using normal M code commands, such as M00 (program stop), M01 (optional stop), M3 (Spindle Positive Rotating) and est. Please refer to the program manual for a full detailed description of M code commands. When the program executes this M code, working piece will be added up at the POS page. At the same time, machine working time will return to zero automatically. If the adding-up sum of working piece is larger than the max sum of working piece which is set by users, the system will send out S BIT 134 signal to inform PLC.

94
EDIT FILE 09XXX 0)N 1)Y

Range : 0 ~ 1
 Active : Instant Activity
 Level : Machinery Builder
 Default value : 0
 Unit : Nul
 Description : Set the edibility of files No. 09000~09999, etc.

121
ESCAPE DIRECTION OF G76/G87

Range : 0 ~ 3
 Active : Active After RESET
 Level : User
 Default value : 0
 Unit : Nul
 Description :

Tool Escape Direction of Canned Cycle Commands (G76/G87)

	G17	G18	G19
0	+X	+Z	+Y
1	-X	-Z	-Y
2	+Y	+X	+Z
3	-Y	-X	-Z

122**NAME OF AXIS.4**

Range : 0 ~ 5
 Active : Active After Reboot
 Level : Machinery Builder
 Default value : 2
 Unit : Nul
 Description : Setting Value is 0, name of the 4th Axis is A;
 Setting Value is 1, name of the 4th Axis is B;
 Setting Value is 2, name of the 4th Axis is C;
 Setting Value is 3, name of the 4th Axis is U;
 Setting Value is 4, name of the 4th Axis is V;
 Setting Value is 5, name of the 4th Axis is W.

123**POWER ON METRIC/INCH SYSTEM**

Range : 0 ~ 1
 Active : Active After Reboot
 Level : User
 Default value : 0
 Unit : Nul
 Description : This parameter is to set the system starting unit after rebooting the system.
 Please use G20 (inch command)/G21 (metric command) to exchange the system starting unit.

124**POWER ON G00/G01 DEFAULT**

Range : 0 ~ 1
 Active : Active After Reboot
 Level : User
 Default value : 1
 Unit : Nul
 Description : This parameter is used to set the moving command after NC starts. After entering into NC system, user needs to execute the following command under MEM or MDI mode:
 G91 X100. Y100. Z100.
 When parameter setting value is 0, the above command equals to:
 G91 G00 X100. Y100. Z100.
 When parameter setting value is 1, the above command equals to:
 G91 G01 X100. Y100. Z100.

129**G02 G03 ARC ERROR RANGE**

Range : 0 ~ 32767
 Active : Active After RESET
 Level : User
 Default value : 5
 Unit : um
 Description : When part programs execute G02 or G03, the system will check if the terminal position of an arc is on the circle described by starting point coordinates and center point coordinates. If the deviation between the arc's terminal position and the circle exceeds the range set by parameter No. 129, the system will send a warning signal as [Illegal Radius].
 When parameter is set to 0, the range to be checked is preset as 5um.

130
AUTO CONTROL OF NUM PRECISION

Range : 0 ~ 1

Active : Active After RESET

Level : User

Default value : 1

Unit : Nul

Description : **【Example】** Under the metric unit system, if set this parameter to 0, user will order the following commands in MDI mode :

G90G00X100F1000

X axis moves 0.1mm position in 1mm/min speed

G90G00X100.F1000.

X axis moves to 100mm position in 1000mm/min speed

If set this parameter to 1 :

G90G00X100F1000

X axis moves to 100mm position in 1000mm/min speed

G90G00X100.F1000.

X axis moves to 100mm position in 1000mm/min speed

131
COMPENSATION STARTING TYPE

Range : 0 ~ 1

Active : Active After RESET

Level : Machinery Builder

Default value : 0

Unit : Nul

Description : 0 : path compensation by using Type A ;

1 : Path compensation by using Type B.

Please refer to program manual for the full detailed description of path compensation type.

134
G83/G87 EXTRACT 0)ESCAPE 1)R

Range : 0 ~ 1

Active : Active After RESET

Level : User

Default value : 1

Unit : Nul

Description : 0 : Start point

1 : R point

135
DEFAULTS OF G90/G91

Range : 0 ~ 1

Active : Active After Reboot

Level : User

Default value : 0

Unit : Nul

Description : 0:setting absolute coordinate(G90)as the coordinate type when starting system

1 : setting incremental coordinate (G91) as the coordinate type when starting system.

136	X SCALING IS EFFECTIVE OR NOT
137	Y SCALING IS EFFECTIVE OR NOT
138	Z SCALING IS EFFECTIVE OR NOT

Range : 0 ~ 1
 Active : Active After RESET
 Level : User
 Default value : 0
 Unit : Nul
 Description : 0 : invalid
 1 : valid

139	RADIUS COMP SYMBOL SET
------------	-------------------------------

Range : 0 ~ 1
 Active : Active After RESET
 Level : User
 Default value : 1
 Unit : Nul
 Description : 0 : H code
 1 : D code
 This parameter is to set the path compensation code is either H code or D code.
 0 means the path compensation command is G41H1
 1 means the path compensation command is G41D1

140	DISABLE RESET COMMON VAR CLR
------------	-------------------------------------

Range : 0 ~ 1
 Active : Active After RESET
 Level : User
 Default value : 1
 Unit : Nul
 Description : There are 500 command variables and all level programs share these common variables. The default value is VACANT for common variables @1 ~ @400 when rebooting. But, whether or not clear means VACANT is decided by this parameter when press RESET. For common variables @401 ~ @500, remaining as the original value after pressing RESET key and also remaining power-discontinue memory. @0 means VACANT permanently.

141	DISABLE RESET GLOBAL VAR CLR
------------	-------------------------------------

Range : 0 ~ 1
 Active : Active After RESET
 Level : User
 Default value : 0
 Unit : Nul
 Description : There are 33 local variables and program in each level program has its own 33 local variables. Only need to end that level program to clear local variables of that level. Since pressing RESET key will return back to the main program level, the content of local variables in the main program level will use this parameter to set whether or not to clear when pressing RESET. If rebooting, local variables will be cleared no matter in which local level. #0 means VANCANT permanently.

142**ABS/RLT ROTATION COMMAND**

Range : 0 ~ 1
 Active : Active After RESET
 Level : User
 Default value : 0
 Unit : Nul
 Description : 0 : absolute value
 1 : incremental value
 Please refer to program manual for a full detailed description.

143**CODE FOR SCALING**

Range : 0 ~ 1
 Active : Active After RESET
 Level : User
 Default value : 0
 Unit : Nul
 Description : 0 : X, Y, and Z axis zoom in/out scale is set by P code command
 1 : I, J, K code will set X, Y, and Z axis zoom in/out scale. In this case, each axis zoom in/out scale is set by parameters 1092 ~ 1094.
 Please refer to program manual for a full detailed description.

145**DEFAULTS OF PLANE XY/ZX/YZ**

Range : 0 ~ 2
 Active : Active After Reboot
 Level : Machinery Builder
 Default value : 0
 Unit : Nul
 Description : 0 : after entering into the system, default setting is XY panel (G17)
 1 : after entering into the system, default setting is ZX panel (G18)
 2 : after entering into the system, default setting is YZ panel (G19)

146**M CODE CALLING MACRO O9001****147****M CODE CALLING MACRO O9002****148****M CODE CALLING MACRO O9003**

Range : 0 ~ 99
 Active : Active After RESET
 Level : Machinery Builder
 Default value : 0
 Unit : Nul
 Description : O9001 is the automatic tool changing of MACRO program of the system. When the system executes to this parameter's setting M code, it will call and execute MACRO program O9001, which is to change tool automatically. The setting value of this parameter must avoid all normal M code commands. Please refer to program manual for a full detailed M code command list.

149**DEFAULTS VAL OF FEEDRATE**

Range : 0 ~ 32767

Active : Active After Reboot

Level : User

Default value : 1000

Unit : mm/min

Description : This parameter is to set the default feedrate of the system under MEM or MDI mode.

150**CLEANCE VALUE OF DEEP DRILLING**

Range : 0 ~ 32767


Active : Active After RESET

Level : User

Default value : 200

Unit : um

Description : This parameter is to set the shrinking amount that every time X-axis feed into a constant value in G73 peak drilling command. The following shows the separate motion of a peak drilling command. Please refer to program manual for a full detailed description.



152**4TH AXIS OPTIMAL**

Range : 0 ~ 3


Active : Active After RESET

Level : User

Default value : 0

Unit : Nul

Description : The following diagram shows when C axis moves from 300.000° position to -150.000° position, whether or not C axis takes into account the difference if take the shortest path: the path in ① means using the linear-type axis method of the rotatory axis. After completed, C axis coordinate display value is -150.000. The path in ② means to take the shortest path. When completed, C axis coordinate display value is 210.0000.

**155****FEEDRATE IS MM/REV OR MM/MIN**

Range : 0 ~ 1

Active : Active After Reboot

Level : User

Default value : 1

Unit : Nul

Description : This parameter is to set the default unit of the cutting federate under MEM or MDI mode, but this is not valid for the rapid traverse command (G00).
 0 : Using G95, under metric: unit is mm/rev; under inch: unit is inch/rev. In this situation, must match with the spindle rotating for the cutting command (G01/G02/G03) to be effective;
 1 : using G94 , under metric: Unit is mm/min; under inch: unit is inch/min.

161**M CODE CALLING MACRO O9004****162****M CODE CALLING MACRO O9005****163****M CODE CALLING MACRO O9006****164****M CODE CALLING MACRO O9007****165****M CODE CALLING MACRO O9008****166****G CODE CALLING MACRO O9010****167****G CODE CALLING MACRO O9011****168****G CODE CALLING MACRO O9012****169****MACRO O9020 CALLED BY T CODES**

Range : 0 ~ 1
 Active : Active After RESET
 Level : Machinery Builder
 Default value : 0
 Unit : Nul
 Description : when NC executes this parameter's setting M code, it will call and execute MACRO program O9004(O9005 ~ O9008 · O9010 ~ O9012 · O9020). Users can write the content of this MACRO themselves and then copy this file to the desired MACRO program menu (default: C:\[system path]\MACRO) in the system. The setting value of this parameter must avoid all normal M code commands. Please see program manual for the full detailed M code commands.

170
MODAL UPDATE AFTER MDI TO MEM

Range : 0 ~ 1
 Active : Active After RESET
 Level : User
 Default value : 0
 Unit : Nul
 Description : 0 : Yes, the changing modal of MDI mode does NOT work, all modals return back to the default condition
 1 : NO, the changing modal of MDI mode will continue to MEM mode.

【Example】 Assumed the setting value of parameter 0135 is 0 (the default system coordinate modal is G90 modal). After entering and executing the G91 command under the MDI mode, MDI mode will change to MEM mode. If the parameter setting value of this parameter is 0:
 Executing
 G01X100.F1000.
 Will move X axis to 100mm position in 1000mm/mm speed.
 If the parameter setting value is 1:
 Executing
 G01X100.F1000.
 Will move X axis direct to 100mm position in 1000mm/mm speed.

176
LOCAL PORT NO FOR G31

Range : 1 ~ 2
 Active : Active After RESET
 Level : Machinery Builder
 Default value : 1
 Unit : Nul
 Description : 1 : G31 SKIP signal to 1st LOCAL INPUT point (HS1 on Transit Board)
 2 : G31 SKIP signal to 2nd LOCAL INPUT point (HS2 on Transit Board)
 G31 SKIP signal must be connected to LOCAL INPUT on Transit board. This parameter is to set connector point number. Since G31 signal must use LOCAL INPUT to latch absolute position record value of each axis, must use the 1st and the 2nd point of LOCAL INPUT.

177
CONTACT TYPE OF G31

Range : 0 ~ 1
 Active : Active After RESET
 Level : Machinery Builder

Default value : 1

Unit : Nul

Description : 0 : G31 SKIP signal is NC. When SKIP signal changes from 1 to 0, this G31 signal blocks stops immediately and executes the next signal block.
1 : G31 SKIP signal is NO. When SKIP signal changes from 0 to 1, this G31 signal block stops immediately and executes the next signal block.

180

ENABLE MANUAL RETURN

Range : 0 ~ 1

Active : Active After RESET


Level : User


Default value : 0

Unit : Nul

Description : 0 : No
1 : Yes

Assumed the system is in MEM or MDI mode. If switching to JOG, MPG and/or RAPID modes during program executing, system will enter into 【Free Hold】. If user uses this manual function to move the machine from the initial program interrupting position and then continue executing the unfinished command in MEM or MDI mode, user has two choices. One is to move the machine back to the initial program interrupting position and continue the unfinished commanding, which is called MANUAL RETURN. The other one is to continue the unfinished commanding from the present position. But, there will be an OFFFET amount between the program path and afterward working path. Please refer the below diagrams for the difference between the above two methods.





Other than using this parameter to set MANUAL RETURN function, C BIT 0004 can also be used:

If C BIT 004 is ON, it means enable MANUAL RETURN function.

If C BIT 004 is OFF, it means disable MANUAL RETURN function.


Moreover, if the Parameter #0180 is 1, MANUAL RETURN function will be enabled no matter C BIT 004 is enable or not. On the other hand, if Parameter #0180 is 0, C BIT 004 does matter whether or not to enable this function.

187

FEED RATE CLAMPING

Range : 0 ~ 1
 Active : Active After RESET
 Level : User
 Default value : 0
 Unit : Nul
 Description : 0 : No
 1 : Yes

There will be an error amount ΔR between arch commanding and actual path.



Calculating formula is : $\Delta R = \left(\frac{1}{2K_p^2 R} + \frac{T^2}{24R} \right) V^2$. K_p Is position loop

incremental? T is acceleration and deceleration time integer number. R is arch

radius and V is the assigned feedrate. This formula is used only when the corresponding speed of speed loop is 3 ~ 10 times faster than position loop. Please also refer to description of Parameter 0188 and 0809 for detailed description.

200	FEEDRAT SHOW 0)CMD 1)ACTUAL
	Range : 0 ~ 1
	Active : Active After RESET
	Level : User
	Default value : 0
	Unit : Nul
	Description : 0 : HMI panel displays feedrate commanding value 1 : System will calculate the actual feedrate according to each axis motor ENCODER (or linear scale) and then will display it on HMI panel.
202	ENG/CHI/SIM LANG SETTING
	Range : 0 ~ 2
	Active : Active After Reboot
	Level : User
	Default value : 1
	Unit : Nul
	Description : 0 : English 1 : Traditional Chinese 2 : Simplify Chinese
205	REL/ABS COMP VALUE
	Range : 0 ~ 1
	Active : Active After RESET
	Level : User
	Default value : 0
	Unit : Nul
	Description : Using this parameter to set the entering tool compensation value at OFFSET page, either absolute value or relative value.
211	M CODE TO STOP INTERPRETER
212	M CODE TO STOP INTERPRETER
213	M CODE TO STOP INTERPRETER
214	M CODE TO STOP INTERPRETER
215	M CODE TO STOP INTERPRETER
216	M CODE TO STOP INTERPRETER
217	M CODE TO STOP INTERPRETER
218	M CODE TO STOP INTERPRETER
219	M CODE TO STOP INTERPRETER
220	M CODE TO STOP INTERPRETER
	Range : 0 ~ 299
	Active : Active After RESET
	Level : User
	Default value : 209

Unit : Nul

Description : If some M code must wait for outside signals, it must be registered here to prevent any false action caused by pre-interpretation of part programs.

221**DIGITAL FILTER FREQUENCY**

Range : 0 ~ 6666

Active : Active After Reboot

Level : Machinery Builder

Default value : 0

Unit : Nul

Description : Please go to the reference chart below for the valid ranges of digital filter frequency. If the frequency is set between two ranges, NC will use the closest value as the filter frequency. For example, parameter No. 221 is set as 250 KHz while the actual filter frequency is 256 KHz.

Filter Freq. (KHz)	Filter Freq. (KHz)	Filter Freq. (KHz)	Filter Freq. (KHz)	Filter Freq. (KHz)	Filter Freq. (KHz)
6667	256	131	81	53	28
3333	247	128	80	52	27
2222	238	126	79	51	26
1667	230	123	78	50	
1333	222	121	77	49	
1111	215	119	76	48	
952	208	117	75	47	
833	202	115	74	46	
741	196	113	73	45	
667	190	111	72	44	
606	185	109	71	43	
556	180	108	67	42	
513	175	106	66	41	
476	171	104	63	40	
444	167	101	65	39	
417	163	100	64	38	
392	159	98	63	37	
370	155	95	62	36	
351	152	94	61	35	
333	148	93	60	34	
317	145	90	59	33	
303	142	88	58	32	
290	139	85	57	31	
278	136	83	56	30	
267	133	82	54	29	

223**AXES MANUAL RETURN(BIT)**

Range : 0 ~ 63

Active : Active After RESET

Level : Machinery Builder

Default value : 0

Unit : Nul

Description : Bit 0: Enable manual return function of X axis.
 Bit 1: Enable manual return function of Y axis.
 Bit 2: Enable manual return function of Z axis.
 Bit 3: Enable manual return function of the 4th axis.

Bit 4: Enable manual return function of the 5th axis.
 Bit 5: Enable manual return function of the 6th axis.
 Preset as 0: Enable manual return function of all axes.

231	AXIS X INFORMATION HIDE
232	AXIS Y INFORMATION HIDE
233	AXIS Z INFORMATION HIDE
234	AXIS 4TH INFORMATION HIDE

Range : 0 ~ 3
 Active : Instant Activity
 Level : Machinery Builder
 Default value : 0
 Unit : Nul
 Description : 0 : Show relative HMI information of X (Y, Z, the 4th, the 5th, the 6th) axis.
 1 : Hide relative HMI information of X (Y, Z, the 4th, the 5th, the 6th) axis.
 2 : Set by C Bit 0181(0182、0183、0184、0185、0186). OFF: Show ; ON: Hide.

238	Coordinate measuring page (0:ON 1:OFF)
------------	---

Range: 0 ~ 1
 Effective time: Effective After Reboot
 Access level: Machine Maker
 Default: 0
 Unit: Non
 Description: 0: Display coordinate measuring page
 1: Hide coordinate measuring page

249	RAMDISK ERR MSG 0)OFF 1)ON
------------	-----------------------------------

Range : 0 ~ 1
 Active : Active After Reboot
 Level : Machinery Builder
 Default value : 0
 Unit : Nul
 Description : 0 : When RAMDISK error, did not show alarm message.
 1 : When RAMDISK error, show alarm message.

350	JOG FRATE REF TO MDI F COMMAND
------------	---------------------------------------

Range : 0 ~ 1
 Active : Active After RESET
 Level : User
 Default value : 0
 Unit : Nul
 Description : 0 : In JOG mode, the speed of each axis is *always* defined by parameters.
 1 : In JOG mode, the speed of each axis is *preset* by parameters. If executing F code in MDI mode, F code replaces JOG speed to set the speed of each axis until RESET is pressed. However, in JOG mode, the highest speed of each axis is still set by parameters.

351**FEEDRATE OVERRIDE UNIT**

Range : 0 ~ 1
 Active : Active After Reboot
 Level : Machinery Builder
 Default value : 0
 Unit : Nul
 Description : 0 : Cutting override feed rate = R016 register value* 10% ;
 1 : Cutting override feed rate = R016 register value* 1% ◦

352**JOG OVERRIDE UNIT**

Range : 0 ~ 1
 Active : Active After Reboot
 Level : Machinery Builder
 Default value : 0
 Unit : Nul
 Description : 0 : Jog override unit feed rate = R017 register value* 10% ;
 1 : Jog override unit feed rate = R017 register value* 1% ◦

353**RAPID TRAVERSE OVERRIDE UNIT**

Range : 0 ~ 1
 Active : Active After Reboot
 Level : Machinery Builder
 Default value : 0
 Unit : Nul
 Description : 0 : Rapid traverse override are F0, 25%, 50%, & 100%, respectively ;
 1 : Rapid traverse override = R018 register value* 1% ◦

360**OPTION COLOR SET(0~3)**

Range : 0 ~ 3
 Active : Active After Reboot
 Level : User
 Default value : 0
 Unit : Nul
 Description : 0 : Screen color setting is not applied.
 1 : Screen color setting is white words over a black background
 2 : Screen color setting is black words over a white background
 3 : Screen color setting is customized by users.

361	BLACK COLOR SET(0~16)
362	BLUE COLOR SET(0~16)
363	GREEN COLOR SET(0~16)
364	CYAN COLOR SET(0~16)
365	RED COLOR SET(0~16)
366	MAGENTA COLOR SET(0~16)
367	BROWN COLOR SET(0~16)
368	WHITE COLOR SET(0~16)
369	GRAY COLOR SET(0~16)
370	LIGHTBLUE COLOR SET(0~16)
371	LIGHTGREEN COLOR SET(0~16)
372	LIGHTCYAN COLOR SET(0~16)
373	LIGHTRED COLOR SET(0~16)
374	LIGHTMAGENTA COLOR SET(0~16)
375	YELLOW COLOR SET(0~16)
376	LIGHTWHITE COLOR SET(0~16)
377	CURSOR COLOR SET(0~16)
378	MARK COLOR SET(0~16)
379	UP EDGE COLOR SET(0~16)
380	DOWN EDGE COLOR SET(0~16)

Range : 0 ~ 16

Active : Active After Reboot

Level : User

Default value : 0

Unit : Nul

Description : Only valid when parameter No. 0360 is set to 3.

0 : Not applied.

1~16 : Applied and change to the selected color.

381	Curve surface Cutting feedrate speed fix
-----	---

Range: 0 ~ 1

Effective time: EFFECTIVE AFTER RESET

Access level: User

Default: 0

Unit: Non

Description: 0: Disable the speed fix function,

1: Enable the curve surface speed fix.

394	SCREENSAVER WAIT TIME
-----	------------------------------

Range : 0 ~ 9999

Effective : Effective After Reboot

Access level : User

Default : 0

Unit : Nul

1. When this parameter is set to 0, the screensaver is not applied.
2. When this parameter is not 0, the screensaver activates automatically after the system is not operated for a specified amount of time (time length set by the parameter). If screensaver has not activated and some key is pressed, wait time will be counted from the last keystroke. If screensaver already activates, pressing any key will immediately terminate it, and wait time will be counted from zero.

395	Operation history record 1)ON 0)OFF Range: 0 ~ 1 Effective time: Effective After Reboot Access level: Machine Maker Default: 0 Unit: Non Description: 0 : OFF Operation history record 1 : ON Operation history record
396	Set the work path using method Range: 0 ~ 2 Effective time: Effective After Reboot Access level: Machine Maker Default: 0 Unit: Non Description:
397	M98 Calling file type (0)4digit (1)7 digit Range: 0 ~ 1 Effective time: EFFECTIVE AFTER RESET Access level: User Default: 0 Unit: Non Description:
512	Analog voltage detect card address Range: 0 ~ 992 Effective time: Effective After Reboot Access level: Machine Maker Default: 0 Unit: Non Description: Set the analog voltage detect card base address
513	Analog voltage detect Range: 0 ~ 8 Effective time: Effective After Reboot Access level: Machine Maker Default: 0 Unit: Non Description: 0 : Not use 1 : active 1 ST Analog voltage detect 2 : active 1~2 ND Analog voltage detect 3 : active 1~3 RD Analog voltage detect 4 : active 1~4 TH Analog voltage detect 5 : active 1~5 TH Analog voltage detect 6 : active 1~6 TH Analog voltage detect 7 : active 1~7 TH Analog voltage detect 8 : active 1~8 TH Analog voltage detect
514	1ST Analog voltage detect range
515	2ND Analog voltage detect range
516	2RD Analog voltage detect range
517	4TH Analog voltage detect range
518	5TH Analog voltage detect range

519	6TH Analog voltage detect range
520	7TH Analog voltage detect range
521	8TH Analog voltage detect range

Range: 0 ~ 8
 Effective time: Effective After Reboot
 Access level: Machine Maker
 Default: 0
 Unit: Non
 Description: 0 : -5V ~ +5V
 1 : -2.5V ~ +2.5V
 2 : -1.25V ~ +1.25V
 3 : -0.625V ~ +0.625V
 4 : 0V ~ +10V
 5 : 0V ~ +5V
 6 : 0V ~ +2.5V
 7 : 0V ~ +1.25V
 8 : -10V ~ +10V

522	1ST Analog voltage detects minim value.
523	1ST Analog voltage detects max value.
524	2ND Analog voltage detects minim value.
525	2ND Analog voltage detects max value.
526	2RD Analog voltage detects minim value.
527	2RD Analog voltage detects max value.
528	4TH Analog voltage detects minim value.
529	4TH Analog voltage detects max value.
530	5TH Analog voltage detects minim value.
531	5TH Analog voltage detects max value.
532	6TH Analog voltage detects minim value.
533	6TH Analog voltage detects max value.
534	7TH Analog voltage detects minim value.
535	7TH Analog voltage detects max value.
536	8TH Analog voltage detects minim value.
537	8TH Analog voltage detects max value.

Range: -4096 ~ 4096
 Effective time: Effective After Reboot
 Access level: Machine Maker
 Default: 0
 Unit: Non
 Description: The max and min value after analog voltage measurement.

556	LCD type(0~2)
-----	---------------

Range: 0 ~ 2
 Effective time: Effective After Reboot
 Access level: Machine Maker
 Default: 0
 Unit: Non
 Description: 0:Auto set 320x234 or 320x240 frame mode.
 1:Set to 320x234 frame mode.
 2:Set to 320x240 frame mode.

558	Process line number record time interval
-----	--

Range: 0 ~ 3600

Effective time: Effective right away
Access level: Machine Maker
Default: 0
Unit: Sec
Description:

560
Floppy setting

Range: 0 ~ 1
Effective time: Effective After Reboot
Access level: Machine Maker
Default: 0
Unit: Non
Description: 0 : Not use , 1 : Use

561
UI group key switch

Range: 0 ~ 2
Effective time: Effective After Reboot
Access level: Machine Maker
Default: 0
Unit: Non
Description: Suitable to M60
To be 0= Num0~Num7 use for switch UI groups
To be 1= SHIFT+F1~F8 use for switch UI groups.
To be 2= CTRL+F1~F8 use for switch UI groups

650
SET THE METHOD OF PROGRAM RESTART

Range : 0 ~ 1
Active : Instant Activity
Level : User
Default value : 0
Unit : Nul
Description : 0 : Program restart definition 1st .
1 : Program restarts definition 2nd . (Call O9888)

651
Internet connection method 0)Net share 1)Recon

Range: 0 ~ 1
Effective time: Effective After Reboot
Access level: Machine Maker
Default: 0
Unit: Non
Description: 0 : Netshare
1 : ReCON

652
Net monitoring overtime (sec)

Range: 0 ~ 32767
Effective time: Active right away.
Access level: Machine Maker
Default: 0
Unit: Sec
Description:

653
Active Data Recorder

Range: 0 ~ 3

Effective time: Effective After Reboot
 Access level: Machine Maker
 Default: 0
 Unit: Non
 Description:

804**Screen saver**

Range: 0 ~ 2
 Effective time: right away
 Access level: User
 Default: 0
 Unit: Non
 Description:

810**SET RIGID TAP IN G101~G105**

Range : 0 ~ 1
 Active : Active After RESET
 Level : User
 Default value : 0
 Unit : Nul
 Description : When applying multi-hole drilling compound G code (G101 ~105), use this parameter to set the tapping function. Set to 1: rigid tapping is activated; set to 0, tapping is activated. The preset mode is tapping.

848**X AXIS OPTIMAL****849****Y AXIS OPTIMAL****850****Z AXIS OPTIMAL**

Range : 0 ~ 3
 Active : Active After RESET
 Level : User
 Default value : 0
 Unit : Nul
 Description : This parameter is effective only for rotary axis.

bit 0: Coordinate display method selection
 0: Display as Linear method.
 1: Display as one rotates 0.000~360.000 cycle method.

bit 1: Coordinate display method is 0~360 cycle (bit 0 setting is 1) , user is able to select whether or not the absolute command is handled as the shortest path.
 0: Calculate the shortest moving distance.
 1: Move according to commanding value.

(Note) Incremental commanding is NOT handled as the shortest path at all.

899	USE CE RULE 0)NO 1)YES
Range :	0 ~ 1
Active :	Active After RESET
Level :	Machinery Builder
Default value :	0
Unit :	Nul
Description :	0 : CE regulations are not applied. 1 : CE regulations are applied.

1006	1ST X+ SOFT LIMIT
1008	1ST Y+ SOFT LIMIT
1010	1ST Z+ SOFT LIMIT
1012	1ST 4+ SOFT LIMIT
Range :	-99999999 ~ 99999999
Active :	Active After RESET
Level :	Machinery Builder
Default value :	99999999
Unit :	um
Description :	<p>This parameter is to set the limitation value of the +ive X-axis software travel limit. It works only after X axis is completed zero return procedure, or using the rebooting default value 99999.999 um. If this parameter setting value is smaller than parameter # 1007 (-ive X-axis software travel limit), it will enable the alarm system (MOT 4005, 1st software traveling limit setting error). The +ive X axis 1st and 2nd software</p> <p>Traveling limit is able to execute exchanging through C BIT 140. Please refer to the description of C BIT. Under the condition that the +ive X axis 1st software traveling limit is enabled, when X-axis will excess the restricted range, it will enable the alarm system (MOT 9001 X-axis over the +ive software travel limit) or (MOT 4058 over the software travel limit). Please refer to the description of this warning message.</p>

1007	1ST X- SOFT LIMIT
1009	1ST Y- SOFT LIMIT
1011	1ST Z- SOFT LIMIT
1013	1ST 4- SOFT LIMIT
Range :	-99999999 ~ 99999999
Active :	Active After RESET
Level :	Machinery Builder
Default value :	-99999999
Unit :	um
Description :	<p>This parameter is to set the limitation value of the -ive X axis software travel limit. It works only after X axis is completed zero return procedure, or using the rebooting default value 99999.999 um. If this parameter setting value is larger than parameter # 1006 (+ive X-axis</p> <p>Software travel limit), it will enable the alarm system (MOT 4005, 1st software traveling limit setting error). The -ive X axis 1st and 2nd software traveling limit is able to execute exchanging through C BIT 141. Please refer to the description of C BIT. Under the condition that the -ive X axis 1st software traveling limit is enabled, when X axis will excess the restricted range, it will enable the alarm system (MOT 9002 X axis over the -ive software travel limit) or (MOT 4058 over the software travel limit). Please refer to the description of this warning message.</p>

1034	2ND X+ SOFT LIMIT
1036	2ND Y+ SOFT LIMIT
1038	2ND Z+ SOFT LIMIT
1040	2ND 4+ SOFT LIMIT

Range : -99999999 ~ 99999999

Active : Active After RESET

Level : Machinery Builder

Default value : 99999999

Unit : um

Description : This parameter is to set the limitation value of the +ive X axis software travel limit. It works only after X axis is completed zero return procedure, or using the rebooting default value 99999.999 um. If this parameter setting value is smaller than parameter # 1035 (-ive X axis Software travel limit), it will enable the alarm system (MOT 4023, 2nd software traveling limit setting error). The +ive X axis 1st and 2nd software traveling limit is able to execute exchanging through C BIT 140. Please refer to the description of C BIT. Under the condition that the +ive X axis 2nd software traveling limit is enabled, when X axis will excess the restricted range, it will enable the alarm system (MOT 9001 X axis over the +ive software travel limit) or (MOT 4058 over the software travel limit). Please refer to the description of this warning message.

1035	2ND X- SOFT LIMIT
1037	2ND Y- SOFT LIMIT
1039	2ND Z- SOFT LIMIT
1041	2ND 4- SOFT LIMIT

Range : -99999999 ~ 99999999

Active : Active After RESET

Level : Machinery Builder

Default value : -99999999

Unit : um

Description : This parameter is to set the limitation value of the -ive X axis software travel limit. It works only after X axis is completed zero return procedure, or using the rebooting default value 99999.999 um. If this parameter setting value is larger than parameter # 1034 (+ive X axis software travel limit), it will enable the alarm system (MOT 4023, 2nd software traveling limit setting error). The -ive X axis 1st and 2nd software traveling limit is able to execute exchanging through C BIT 141. Please refer to the description of C BIT. Under the condition that the -ive X axis 1st software traveling limit is enabled, when X axis will excess the restricted range, it will enable the alarm system (MOT 9002 X axis over the -ive software travel limit) or (MOT 4058 over the software travel limit). Please refer to the description of this warning message.

1091	PROTAG
-------------	---------------

Range : -360000 ~ 360000

Active : Active After RESET

Level : User

Default value : 0

Unit : um

Description : This parameter is to set the default angle for G68 coordinate rotating command.

1092	PSCRT Range : 1 ~ 99999999 Active : Active After RESET Level : User Default value : 1 Unit : Nul Description : When the setting value of parameter# 0143 is 1 (X, Y and Z axes zoom in/out scale is determined by I, J and K of G51 zoom in/out scale command), this parameter is to set the default zoom in/out scale of X-axis.
1093	PSCRT2 Range : 1 ~ 99999999 Active : Active After RESET Level : User Default value : 1 Unit : Nul Description : When the setting value of parameter# 0143 is 1 (X, Y and Z axes zoom in/out scale is determined by I, J and K of G51 zoom in/out scale command), this parameter is to set the default zoom in/out scale of Y-axis.
1094	PSCRT3 Range : 1 ~ 99999999 Active : Active After RESET Level : User Default value : 1 Unit : Nul Description : When the setting value of parameter# 0143 is 1 (X, Y and Z axes zoom in/out scale is determined by I, J and K of G51 zoom in/out scale command), this parameter is to set the default zoom in/out scale of Z axis.
1158	SHOW F2~F12 FOR FUN. KEY Range : 0 ~ 1 Active : Active After Reboot Level : User Default value : 0 Unit : Nul Description : Because inconvenience could occur when operators use commercial PC keyboard to operate controller, F2~F12 characters are shown on the function keys on the screen for users' convenience during operation.
1159	SET READ TIMEOUT TIMES Range : 0 ~ 30000 Active : Instant Activity Level : User Default value : 30 Unit : sec Description : If the time is too long when abnormal file reading of the controller happens during machining, a new dialog box with warning messages will appear to notify users about the abnormal situation and also remind users to reset the system to ensure efficiency of the controller and the machine.

1806	COM1 address (0:Disable 744~1016) Range: 744 ~ 1016 Effective time: Effective After Reboot Access level: Machine Maker Default: 1016 Unit: Non Description: COM1 address 。
1807	COM2 address (0:Disable 744~1016) Range: 744 ~ 1016 Effective time: Effective After Reboot Access level: Machine Maker Default: 760 Unit: Non Description: COM2 address 。
1808	COM1 base address (0:Disable 744~1016) Range: 0 ~ 1016 Effective time: Effective After Reboot Access level: Machine Maker Default: 1016 Unit: Non Description: Set COM1 base address 0 : Not use 。
1809	COM2 address (0:Disable 744~1016) Range: 0 ~ 1016 Effective time: Effective After Reboot Access level: Machine Maker Default: 760 Unit: Non Description: 設定 COM2 的基底 address 。 0 : Not use 。
1810	COM1 function (0Non 1:file 2:ABS 3:Spindle) Range: 0 ~ 3 Effective time: Effective After Reboot Access level: Machine Maker Default: 0 Unit: Non Description: Set COM1 IRQ Number
1811	COM2 function (0Non 1:file 2:ABS 3Spindle) Range: 0 ~ 3 Effective time: Effective After Reboot Access level: Machine Maker Default: 0 Unit: Non Description: Set COM2 IRQ number.

1812	File transfer speed (bps)(0~4) Range: 0 ~ 4 Effective time: Right away Access level: User Default: 0 Unit: bps Description:
1813	File transfer 資料位元(0:7 1:8 bit) Range: 0 ~ 1 Effective time: Right away Access level: User Default: 0 Unit: Bit Description:
1814	File transfer Stop bit(0:1 1:2) Range: 0 ~ 1 Effective time: Right away Access level: User Default: 0 Unit: Non Description:
1815	File transfer Odd even check (0: N 1: E 2: O) Range: 0 ~ 2 Effective time: Right away Access level: User Default: 0 Unit: Non Description:
1816	File transfer mode (0:terminal 1:Host) Range: 0 ~ 1 Effective time: Right away Access level: User Default: 0 Unit: Non Description:
1817	File transfer Coding type (0ASCII 1EIA 2ISO) Range: 0 ~ 2 Effective time: Right away Access level: User Default: 0 Unit: Non Description:

1843~1842

User parameter 2: 1~40 column R value

Range: 0 ~ 1023
 Effective time: Right away
 Access level: User
 Default: 0
 Unit: Non
 Description:

1890	1ST Software restricted area X positive axis travel value(um)
1891	1ST Software restricted area X negative axis travel value(um)
1892	1ST Software restricted area Y positive axis travel value(um)
1893	1ST Software restricted area Y negative axis travel value(um)
1894	1ST Software restricted area Z positive axis travel value(um)
1895	1ST Software restricted area Z negative axis travel value(um)
1896	1ST Software restricted area 4TH positive axis travel value(um)
1897	1ST Software restricted area 4TH negative axis travel value(um)

Range: -99999999 ~ 99999999
 Effective time: EFFECTIVE AFTER RESET
 Access level: Machine Maker
 Default: 0
 Unit: Um
 Description: Set each axis, 1ST Software restricted area value

1900	1ST Software restricted area X positive axis travel value(um)
1901	1ST Software restricted area X negative axis travel value(um)
1902	1ST Software restricted area Y positive axis travel value(um)
1903	1ST Software restricted area Y negative axis travel value(um)
1904	1ST Software restricted area Z positive axis travel value(um)
1905	1ST Software restricted area Z negative axis travel value(um)
1906	1ST Software restricted area 4TH positive axis travel value(um)
1907	1ST Software restricted area 4TH negative axis travel value(um)

Range: -99999999 ~ 99999999
 Effective time: EFFECTIVE AFTER RESET
 Access level: Machine Maker
 Default: 0
 Unit: Um
 Description: Set each axis, 1ST Software restricted area value °

1912	2ND Software restricted area X positive axis travel value(um)
1913	2ND Software restricted area X negative axis travel value(um)
1914	2ND Software restricted area Y positive axis travel value(um)
1915	2ND Software restricted area Y negative axis travel value(um)
1916	2ND Software restricted area Z positive axis travel value(um)
1917	2ND Software restricted area Z negative axis travel value(um)
1918	2ND Software restricted area 4TH positive axis travel value(um)
1919	2ND Software restricted area 4TH negative axis travel value(um)

Range: -99999999 ~ 99999999
 Effective time: EFFECTIVE AFTER RESET
 Access level: Machine Maker
 Default: 0
 Unit: Um
 Description: Set each axis, 2ND Software restricted area value °

4 SYSTEM ALARM (Alarm) and WARNING (Warning)

When the system alarm message (ALARM) occurs, operation will stop. User must check the whole machine according to the alarm message. If able to solve problems, then only need to click RESET again to clear the condition. (However, if need to change parameter, then must exit the system software and then re-enter for the system to work.)

Three types of alarm message which are MOT (MOTION) ALARM, OP (OPERATION) ALARM or INT (INTERPRETATION) ALARM. Definitions of the above alarm message are as following :

4.1 OP OPERATION ALARM

OP 1001 : X SERVO ALARM

OP 1002 : Y SERVO ALARM

OP 1003 : Z SERVO ALARM

OP 1004 : 4TH SERVO ALARM

- (1) Alarm message from SERVO driver.
- (2) Please check ERROR message from the SERVO driver to know the cause.
- (3) Please re-booting.

OP 1013: SWITCH TO CONTROL/MONITOR WHILE X MOVING

Trigger C bit 130 while X moving.

Press RESET to clear move command and C 130

OP 1014: SWITCH TO CONTROL/MONITOR WHILE Y MOVING

Trigger C bit 131 while Y moving.

Press RESET to clear move command and C 131

OP 1015: SWITCH TO CONTROL/MONITOR WHILE Z MOVING

Trigger C bit 132 while Z moving

Press RESET to clear move command and C 132

OP 1016: SWITCH TO CONTROL/MONITOR WHILE 4 MOVING

Trigger C bit 133 while 4 moving

Press RESET to clear move command and C 133

OP 1017 : LNC SYSTEM EXPIRED

- (1) Please contact with distributor or machine makers.

OP 1018 : DESIRED MACRO VARIABLES NOT EXIST.

- (1) Check Macro variables.

OP 1019 : DESIRED MACRO VARIABLES OVER RANGE

- (1) Check Macro variable value.

OP 1020 : OVER MLC TRAVEL LIMIT

- (1) Check each axis hardware travel limit.

OP 1021 : GEAR SIGNAL ERROR

- (1) Check if gear is correct.

OP 1024: SWITCH TO CONTROL/MONITOR WHILE 5 MOVING

- (1) Trigger C bit 168 while 5 moving
- (2) Press RESET to clear move command and C 168

OP 1025: SWITCH TO CONTROL/MONITOR WHILE 6 MOVING

- (1) Trigger C bit 169 while 6 moving
- (2) Press RESET to clear move command and C 169

OP 1027 : HSP LONG, NEED TO CONTACT WITH SYSTEM PROVIDER.

Please contact with distributor or machine makers

OP 1029 : X AXIS OVER MLC TRAVEL LIMIT (+)

OP 1030 : X AXIS OVER MLC TRAVEL LIMIT (-)

OP 1031 : Y AXIS OVER MLC TRAVEL LIMIT (+)

OP 1032 : Y AXIS OVER MLC TRAVEL LIMIT (-)

OP 1033 : Z AXIS OVER MLC TRAVEL LIMIT (+)

OP 1034 : Z AXIS OVER MLC TRAVEL LIMIT (-)

OP 1035 : 4TH AXIS OVER MLC TRAVEL LIMIT (+)

OP 1036 : 4TH AXIS OVER MLC TRAVEL LIMIT (-)

OP 1037 : 5TH AXIS OVER MLC TRAVEL LIMIT (+)

OP 1038 : 5TH AXIS OVER MLC TRAVEL LIMIT (-)

OP 1039 : 6TH AXIS OVER MLC TRAVEL LIMIT (+)

OP 1040 : 6TH AXIS OVER MLC TRAVEL LIMIT (-)

OP1029~OP1040:

- (1) Press rest to reboot system
- (2) Move to the opposite side out of limit manually

OP 1100: 5TH axis Servo drive error

- (1) 5TH axis Servo drive send ALARM

- (2) Please check Servo drive ERROR log to know the reason
- (3) Restart

OP 1101: 6TH axis Servo drive error

- (1) 6TH axis Servo drive send ALARM
- (2) Please check Servo drive ERROR log to know the reason
- (3) Restart

4.2 OP Operation related alarm

OP 6001 : X AXIS OVER MLC TRAVEL LIMIT (+)

OP 6002 : X AXIS OVER MLC TRAVEL LIMIT (-)

OP 6003 : Y AXIS OVER MLC TRAVEL LIMIT (+)

OP 6004 : Y AXIS OVER MLC TRAVEL LIMIT (-)

OP 6005 : Z AXIS OVER MLC TRAVEL LIMIT (+)

OP 6006 : Z AXIS OVER MLC TRAVEL LIMIT (-)

OP 6007 : 4TH AXIS OVER MLC TRAVEL LIMIT (+)

OP 6008 : 4TH AXIS OVER MLC TRAVEL LIMIT (-)

OP 6009 : 5TH AXIS OVER MLC TRAVEL LIMIT (+)

OP 6010 : 5TH AXIS OVER MLC TRAVEL LIMIT (-)

OP 6011 : 6TH AXIS OVER MLC TRAVEL LIMIT (+)

OP 6012 : 6TH AXIS OVER MLC TRAVEL LIMIT (-)

OP6001~OP6012: Check each axis hardware travel limit.

4.3 INT interpreter alarm

INT 3001 : NO SUCH TOKEN

- (1) Part program enter data has invalid symbols or characters.
- (2) Modify program error.
- (3) Press RESET to clear the wrong warning message.

INT 3002 : GRAMMAR ERROR

- (1) Part program enter data has invalid symbols or characters.
- (2) Modify program error.
- (3) Press RESET to clear the wrong warning message.

INT 3003 : OUT OF NODE MEMORY

- (1) MACRO grammar has too complicate showing program such as too many brackets.
- (2) Simplify complexity degree or make it to be 2 blocks.
- (3) Press RESET to clear the wrong warning message.

INT 3004 : EXECUTE NODE ERROR

- (1) System executes mathematics calculation that is not allow to execute
- (2) Press RESET to clear the wrong warning message.

INT 3005 : FUNCTION ERROR

- (1) System executes invalid function that is not allow to execute. (Won't happen under normal system condition.)
- (2) System error, please contact the supplier.

INT 3006 : DIVIDED BY 0

- (1) MACRO is divided by 0.
- (2) Modify numerator of the division. Must NOT be 0.
- (3) Press RESET to clear the wrong warning message.

INT 3007 : VARIABLE OVER RANGE

- (1) One/some of local variables, common variables and global variables are out of range.
- (2) Modify variable numbers that are out of their number range.
- (3) Press RESET to clear the wrong warning message.

INT 3008 : MACRO DOMAIN ERROR

- (1) MACRO function domain error. If square (SQRT) argument is negative or ATAN arguments are two zeros.
- (2) Modify domain.
- (3) Press RESET to clear the wrong warning message.

INT 3010 : NOT ALLOWABLE DECIMAL POINT

- (1) NC address has not allowable decimal point.
- (2) Modify decimal point in NC address.

INT 3011 : WORD DATA OVER RANGE

- (1) NC address word data is out of range.
- (2) Modify word data in NC address.
- (3) Press RESET to clear wrong warning message.

INT 3012 : MACRO ILLEGAL MACRO PARAMETER INPUT (G , L , N , O , P)

- (1) Illegal arguments (G , L , N , O , P) in MACRO program.
- (2) Correcting these illegal arguments.
- (3) Press RESET to clear wrong warning message.

INT 3013 : PART PROGRAM HAS GRAMMER ERROR.

- (1) Input data has grammar error.
- (2) Part program error.
- (3) Press RESET to clear wrong warning message.

INT 3050 : TOOL DIAMETER IS 0

- (1) Modify tool diameter setting.

INT 3051 : ILLEGAL RPM GIVEN

- (1) Part program command has rotation speed command over maximum setting.
- (2) Modify error in part program.

INT 3052 : ILLEGAL FEEDRATE GIVEN

- (1) Part program command has feed rate command over maximum setting.
- (2) Modify error in part program.

INT 3053 : (D) EACH CUT DOWN DEPTH IS 0

- (1) When using G101~G133, check if setting cutting depth, if setting is equal to 0 or smaller than 0, Alarm.
- (2) Check program, if has this situation.
- (3) Revise program to prevent cutting depth is equal to 0 or smaller than 0.

INT 3054 : (H) TOTAL DEPTH IS 0

- (1) When using G101~G133, check if setting total cutting depth, if setting is equal to 0 or smaller than 0, Alarm
- (2) Check program, if has this situation .
- (3) Revise program to prevent total cutting depth is equal to 0 or smaller than 0.

INT 3055 : ESCAPE LOWER START POINT.Z

- (1) G100 can set up return amount, when using G101~G133, check if the setting of cycle return R point is higher than setting, Alarm.
- (2) Check program, if has this situation.
- (3) Revise program to make cycle return R lower than return amount.

INT 3056 : (W) EACH CUT WIDTH IS 0

- (1) When using G101~G133, check if setting cutting width, if setting is equal to 0 or smaller than 0, Alarm
- (2) Check program, if has this situation.
- (3) Revise program to prevent cutting width is equal to 0 or smaller than 0.

INT 3060 : HOLES TOO DENSITY

- (1) When using G101~G133, check if hole distance too small, Alarm.
- (2) Check program, if has this situation.
- (3) Revise program to prevent too small hole.

INT 3061 : HOLES COUNT MUST>=2

- (1) When using G101~G133, check if hole numbers are small or equal to 1, Alarm.
- (2) Check program, if has this situation.
- (3) Revise program to prevent hole numbers are small or equal to 1.

INT 3062 : R MUST > Z

- (1) When using G101~G133, check if this Z axis hold bottom coordinate setting is higher than cycle return R point, Alarm.
- (2) Check program, if has this situation.
- (3) Revise program, make this Z axis hold bottom coordinate lower then cycle return R.

INT 3070 : WRONG DATA : $R=0$

- (1) When using G101~G133, the R radius value=0, Alarm.
- (2) Check program, if has this situation.
- (3) Revise program, make R radius is not 0.

INT 3071 : WRONG DATA : $2R \leq PHI$

- (1) When using G101~G133, check if 2 times of R radius is smaller than tool diameter, Alarm.
- (2) Check program, if has this situation.
- (3) Revise program, make R radius to be reasonable value.

INT 3072 : WRONG DATA : $V > PHI$

- (1) When using G101~G133, check if finish amount is over tool diameter, Alarm.
- (2) Check program, if has this situation.
- (3) Revise program, make finish amount to be reasonable value.

INT 3073 : WRONG DATA : $Q=0$

- (1) When using G101~G133, check if setting total move value, and setting=0, Alarm.
- (2) Check program, if has this situation.
- (3) Revise program to prevent total setting= 0.

INT 3074 : WRONG DATA : $V \geq Q$

- (1) When using G101~G133, check if finish amount is over total cutting alarm, Alarm.
- (2) Check program, if has this situation.
- (3) Revise program, make finish amount to be reasonable value.

INT 3075 : WRONG DATA : $(PHI+2Q) \geq 2R$

- (1) When using G101~G133, check if setting diameter+2 time' total cutting amount is over 2 times' R radius, Alarm.
- (2) Check program, if has this situation.
- (3) Revise program, make above setting to be reasonable value.

INT 3076 : WRONG DATA : $I (J) = 0$

- (1) When using G101~G133, check if complete work size I or J=0, Alarm.
- (2) Check program, if has this situation.
- (3) Revise program, make above setting to be reasonable value.

INT 3077 : WRONG DATA : $I (J) - 2R \leq 0$

- (1) When using G101~G133, check if complete work sizes I or J is smaller than 2 times' R radius, Alarm.
- (2) Check program, if has this situation.
- (3) Revise program, make above setting to be reasonable value.

INT 3078 : WRONG DATA : $2Q+PHI \geq I (J)$

- (1) When using G101~G133, check if setting diameter+2 times' total cutting amount is over complete work piece I or J, Alarm.
- (2) Check program, if has this situation.
- (3) Revise program, make above setting to be reasonable value.

INT 3079 : WRONG DATA : 2V+PHI>I (J)

- (1) When using G101~G133, check if setting diameter+2 times' finish amount is over complete work piece I or J, Alarm.
- (2) Check program, if has this situation.
- (3) Revise program, make above setting to be reasonable value.

INT 3080 : DISTANCE OF TWO CENTER IS 0

- (1) When using G123~G133, check the runway-shaped command's center distance is less than or equal to 0, Alarm.
- (2) Check program, if has this situation.
- (3) Revise program, make above setting to be reasonable value.

INT 3081 : WRONG DATA : 2 (R-V) <PHI

- (1) When using G123~G133, check the runway-shaped command's R radius and finish amount difference is smaller than tool radius, Alarm.
- (2) Check program, if has this situation.
- (3) Revise program, make above setting to be reasonable value.

INT 3082 : WRONG DATA : 2 (R-V) <=PHI

- (1) When using G131~G133, check the runway-shaped command's R radius and finish amount difference is smaller than tool radius, Alarm.
- (2) Check program, if has this situation.
- (3) Revise program, make above setting to be reasonable value.

INT 3083 : WRONG DATA : 2V+PHI>=I (J)

- (1) When using G132, check this command's tool radius +2 times finish amount are over complete work piece I or J, Alarm.
- (2) Check program, if has this situation.
- (3) Revise program, make above setting to be reasonable value.

INT 3090 : T COMMAND ERROR

- (1) Check if T code has errors.
- (2) Check program, if has this situation.
- (3) Revise program, make change tool command tool number correct.

INT 3100 : ILLEGAL G CODE

- (1) Illegal G code in part program.

- (2) Delete illegal G code.
- (3) Press RESET to clear wrong warning message.

INT 3101 : PFM INITIAL ERROR

INT 3102 : TRANS INITIAL ERROR

INT 3103 : TABLE INITIAL ERROR

INT 3104 : POST INITIAL ERROR

INT 3105 : PFM ERROR

INT 3106 : NC Program Block Interpretation Fail

INT3101~INT3106

- (1) System normal will not happen
- (2) System error contact supplier

INT 3110 : FETCH ERROR

- (1) System normal will not happen
- (2) System error contact supplier

INT 3111 : LACK OF FILENAME (P address is not entered)

- (1) Lock of filenames in part program. (P address is not entered.)
- (2) Increase number of filenames.
- (3) Press RESET to clear wrong warning message.

INT 3112 : ILLEGAL FILENAME

- (1) Illegal filename in part program.
- (2) Modify filename.
- (3) Press RESET to clear wrong warning message.

INT 3113 : FILE NOT FOUND

- (1) File not found in the system.
- (2) Making/modifying the executing file.
- (3) Press RESET to clear wrong warning message.

INT 3114 : END OF FILE

INT 3120 : POST ERROR

INT 3121 : LACK OF SUB RETURN (M99)

- (1) No returning to the part program command in the sub-program.
- (2) Add returning back to the part program command in the sub-program.
- (3) Press RESET to clear wrong warning message.

INT 3122 : PROGRAM OVERFLOW (8)

- (1) Total numbers of calling Sub-program or MACRO is over the total level limit. (i.e., 8)
- (2) Decrease numbers of calling program level.
- (3) Press RESET to clear the wrong warning message.

INT 3123 : MACRO OVERFLOW (4)

- (1) Total numbers of calling MACRO is over the total level limit. (i.e., 4).
- (2) Decrease numbers of calling program level.
- (3) Press RESET to clear the wrong warning message.

INT 3124 : MACRO UNDERFLOW (G67)

- (1) Under G67, but give G67 command again.
- (2) Delete G67.
- (3) Press RESET to clear warning.

INT 3125 : WITHOUT LABEL

- (1) NO such LABEL .
- (2) Please check LABEL name.
- (3) Press RESET to clear wrong message error.

INT 3126 : BLOCK NOT FOUND

- (1) The designated BLOCK is not found.
- (2) Check whether or not the designated BLOCK is exist in part program.
- (3) Press RESET to clear wrong message error.

INT 3127 : ILLEGAL LABEL**INT 3128 : FEEDRATE OUT OF RANGE , Check G94/G95**

- (1) Check G94 and G95 are used correctly.
- (2) Check whether or not the FEEDRAT F value is too big.
- (3) Press RESET to clear the error and adjust G94, G95 and F value.

INT 3130 : COORDINATE ERROR**INT 3131 : UNKNOWN PLANE****INT 3132 : ILLEGAL RADIUS**

- (1) Using G02, G03 arch cutting command, the final coordinate is NOT on the arch
- (2) Check the position of center point, direction and final point's coordinate value
- (3) Press RESET to clear error.

INT 3135 : Tool Number Assigned Over Range

- (1) T code range is 0~99.
- (2) Modify T code.

INT 3136 : Tool Length Comp Number Assigned Over Range

- (1) Tool length compensation number or tool diameter compensation number over range.
- (2) Tool length or tool diameter range is 0~99.

INT 3137 : System Program Overflow

- (1) System sub-program +system MACRO are over call layer.
- (2) Decrease calling layers.

INT 3138 : System Macro Overflow

- (1) Call layer of system MACRO over limit (8)
- (2) Decrease calling layers.

INT 3139 : Does Not Permit Set Model Macro Call

- (1) This is in the model MACRO call, cannot be call again.
- (2) Check model MACRO call,

INT 3140 : SEND TABLE ERROR

- (1) System is not normal right now.
- (2) System error, contact LNC.

INT 3141 : NO FREE VARIABLES

- (1) System is not normal right now.
- (2) System error, contact LNC.

INT 3142 : Address Duplication Error

- (1) There is duplication in program single block, EX : G01 X10 Y20 X30 .
- (2) Modify program.

INT 3150 : INSUFFICIENT DATA

- (1) Not enough executing G code data. (Lack of G10's P , R , Z)
- (2) Supply the needed data.
- (3) Press RESET to clear wrong warning message.

INT 3152 : CC R RETURN

- (1) Executing G27 , G28 , G29 , G30 in the CANNED CYCLE.
- (2) Cancel the above G codes in CANNED CYCLE before executing.
- (3) Press RESET to clear wrong warning message.

INT 3153 : NO SUCH R POINT

- (1) Wrong reference point number in G30.
- (2) Modify the entered reference point number.
- (3) Press RESET to clear wrong warning message.

INT 3156 : ILLEGAL G31 IN COMPENSATION

- (1) G31 Skip signal stop SBK cannot be used under G41/G42, adjust program to prevent G31 in G41/G42.

INT 3157 : G10 P CODE OUT OF RANGE

- (1) P argument is over command legal usage range.
- (2) Modify P argument

INT 3158 : G10 L/E CODE OUT OF RANGE

- (1) L argument is over command legal usage range or E argument is over command legal usage range.
- (2) Modify P argument or E argument. °

INT 3160 : DNC : INCORRECT READ SEQUENCE

- (1) Check whether or not there is incorrect sub-program or jump sequence from the part program.
- (2) Press RESET to clear wrong warning message, and modify part program.

INT 3161 : DNC : LOSS DATA PACKET

- (1) DNC RS232 info lost when transmission.
- (2) Transmission cable loose or brake.
- (3) Lower Transmission speed parameter
- (4) Press RESET to clear warning or reboot.

INT 3162 : DNC : PROGRAM BUFFER OVERFLOW

- (1) Program buffer overflow while DNC RS232 is transmitting program.
- (2) Check whether or not the connecting line is disconnect or fall.
- (3) Press RESET to clear wrong warning message or reboot.

INT 3163 : G05 R CODE RANGE BETWEEN 1 TO 10

- (1) G05 R argument range 1-10.
- (2) Revise program to make G05 R argument in legal range.
- (3) Press RESET to clear warning or reboot.

INT 3165 : Illegal data in G54 P address

- (1) G05 extension coordinates P argument range 1-300
- (2) Revise program to make G05 extension coordinates P argument in legal range.
- (3) Press RESET to clear warning or reboot.

INT 3166 : Illegal data in G10

- (1) G10 gives L argument, L20 must set up extension coordinate.
- (2) Use G10 to set up extension coordinate, P range=1-300
- (3) Revise program to make G10 at reasonable range.
- (4) Press RESET to clear warning or reboot.

INT 3167 : G05 P/L CODE MUST APPEAR SIMULTANEOUSLY

- (1) G05, if set up for individual items, P and L must show together.
- (2) Revise program to make G05 at reasonable range.
- (3) Press RESET to clear warning or reboot.

INT 3168 : NO RETURN HOME

- (1) Before run HOME, make sure if return home manually.

INT 3169 : RETURN HOME FAILURE

- (1) Current position is not at home.
- (2) Check program.

INT 3177 : Address Q Not Found

- (1) G73/G83 did not give cutting feedrate argument, check program to make Q has value, and cannot be 0.

INT 3200 : THE SEQUENCE NO OF GOTO COMMAND ERROR

- (1) Skip line number is at the current line number, infinitive loop.
- (2) Modify skip serial.

INT 3201 : COMP UNIT VECTOR 0

- (1) Compensation unit vector is 0.
- (2) System error, please contact supplier.
- (3) Press RESET to clear wrong warning message

INT 3202**Mill V3: Comp Operation Does Not Permit Change Plane**

- (1) Under G41/G42, cannot change surface.
- (2) Revise program and cancel G17/G18/G19.

Mill V6: COMP START UP ARC

- (1) Compensating start-up is arch.
- (2) Please start compensating according to G00/G01.
- (3) Press RESET to clear wrong warning message.

INT 3203**Mill V3: Arc Line Not Found INTERsect At Comp Start Up Arc**

- (1) Compensation starting is arc.
- (2) Use linear as compensation starting.
- (3) Press RESET to clear warning.

Mill V6: COMP CANCEL ARC

- (1) Compensating cancel is arch.
- (2) Please cancel compensation according to G00/G01.
- (3) Press RESET to clear wrong warning message.

INT 3204 : Arc Line Not Found INTERsect At Comp Cancel Arc

- (1) Compensation cancel is arc.
- (2) Use linear to cancel compensation.
- (3) Press RESET to clear warning.

INT 3205 : COMP VECTOR LENGTH 0

- (1) When compensation calculating, there is no moving SBK.

- (2) Check program.

INT 3206 : Arc Line INTERsect Vector Over Comp Range

- (1) Not able to find the intersect points while calculating compensation value.
- (2) Decrease compensation radius or modify part program pathway.
- (3) Press RESET to clear wrong warning message.

INT 3207 : Arc Line INTERsect Vector Length Over Arc Move Vector

- (1) Not able to find the intersect points while calculating compensation value.
- (2) Decrease compensation radius or modify part program pathway.
- (3) Press RESET to clear wrong warning message.

INT 3223 : COMP OPERATION DOES NOT PERMIT CHANGE TOOL RADIUS OFFSET NO.

- (1) Under G41/G42, cannot change tool diameter compensation number at arc command SBK.
- (2) Revise program to cancel tool diameter compensation number at radius compensation mode.

INT 3301 : THIS AXIS IS SLAVE AXIS IN SYNCHRONOUS CONTROL

- (1) You cannot give command to slave axis, because the control is from master axis.
- (2) Revise program to delete slave axis program command.
- (3) Press RESET to clear warning.

INT 3303 : THIS REPLACED AXIS MOVE REPEAT IN AXIS NAME CHANGE MODE

- (1) You cannot give command to replace axis, because the control is from this SBK axis.
- (2) Revise program to cancel this SBK.
- (3) Press RESET to clear warning.

4.4 MOT MOTION RELATED ALARM

MOT 4001 : X-AXIS ERROR COUNTER OVERFLOW

- (1) Motion board X- Axis ERROR COUNTER overflow (16-BIT) .
- (2) Check or not the commanding speed is too fast.
- (3) Check whether or not servo motor is working normally.
- (4) Check whether or not the machine is running normally.
- (5) Check whether or not the board is normal.

MOT 4002 : Y-AXIS ERROR COUNTER OVERFLOW

- (1) Motion board Y-AXIS ERROR COUNTER overflow (16-BIT)
- (2) Check or not the commanding speed is too fast.
- (3) Check whether or not servo motor is working normally.
- (4) Check whether or not the machine is running normally.
- (5) Check whether or not the board is normal.

MOT 4003 : Z-AXIS ERROR COUNTER OVERFLOW

- (1) Motion board Z-AXIS ERROR COUNTER overflow (16-BIT)
- (2) Check or not the commanding speed is too fast.
- (3) Check whether or not servo motor is working normally.
- (4) Check whether or not the machine is running normally.
- (5) Check whether or not the board is normal.

MOT 4004 : 4TH-AXIS ERROR COUNTER OVERFLOW

- (1) Motion board 4th-AXIS ERROR COUNTER overflow (16-BIT)
- (2) Check or not the commanding speed is too fast.
- (3) Check whether or not servo motor is working normally.
- (4) Check whether or not the machine is running normally.
- (5) Check whether or not the board is normal.

MOT 4005 : SET FIRST SOFT LIMIT ERROR

- (1) Error setting of 1st soft limit parameter (i.e., +ive soft limit is smaller than -ive soft limit) Please check parameter numbers 1006~1013.
- (2) Clicking RESET to set new parameter.
- (3) After changing the parameter, please reboot.

MOT 4006 : X AXIS SERVO LAG OVERFLOW

- (1) X Axis servo lag over parameter 0002 setting value.
- (2) Check whether the setting speed is too fast or the parameter 0002 setting value is too small.
- (3) Clicking RESET to continue operating.
- (4) If reset parameter, must reboot.

MOT 4007 : Y AXIS SERVO LAG OVERFLOW

- (1) Y Axis servo lag over parameter 0003 setting value.
- (2) Check whether the setting speed is too fast or the parameter 0003 setting value is too small.
- (3) Clicking RESET to continue operating.
- (4) If reset parameter, must reboot.

MOT 4008 : Z AXIS SERVO LAG OVERFLOW

- (1) Z Axis servo lag over parameter 0004 setting value.
- (2) Check whether the setting speed is too fast or the parameter 0004 setting value is too small.
- (3) Clicking RESET to continue operating.
- (4) If reset parameter, must reboot.

MOT 4009 : 4TH AXIS SERVO LAG OVERFLOW

- (1) 4th Axis servo lag over parameter 0005 setting value.
- (2) Check whether the setting speed is too fast or the parameter 0005 setting value is too small.
- (3) Clicking RESET to continue operating.
- (4) If reset parameter, must reboot.

MOT 4012: SBK COMMAND ERROR

- (1) Check program.

MOT 4014 : X AXIS ON HOME DOG

- (1) X Axis on HOME DOG.
- (2) Clicking RESET, use JOG to take the machine away from HOME DOG then will be able to return to the reference point.

MOT 4015 : Y AXIS ON HOME DOG

- (1) Y Axis on HOME DOG.
- (2) Clicking RESET, use JOG to take the machine away from HOME DOG then will be able to return to the reference point.

MOT 4016 : Z AXIS ON HOME DOG

- (1) Z Axis on HOME DOG.

- (2) Clicking RESET, use JOG to take the machine away from HOME DOG then will be able to return to the reference point.

MOT 4017 : 4TH AXIS ON HOME DOG

- (1) 4th Axis on HOME DOG.
- (2) Clicking RESET, use JOG to take the machine away from HOME DOG then will be able to return to the reference point.

MOT 4018 : NO RETURN HOME

- (1) Not return to the reference point after rebooting.
- (2) Clicking RESET and return to the reference point first.

MOT 4023 : SET SECOND SOFT LIMIT ERROR

- (1) Maximum parameter value of the 2nd soft limit is smaller than the smallest value.
- (2) Checking parameters 1034~1041.
- (3) Reset parameter and then reboot.

MOT 4025 : G10 P RANGE ERROR

- (1) P value is over range.
- (2) Please checking the part program.

MOT 4026 : ENCODER A , B PHASE ERROR

- (1) ENCODER disconnect or 5V power problem
- (2) Checking whether or not the ENCODER or power port is connected.

MOT 4027 : HOME DOG TOO SHORT

- (1) Check whether or not HOME DOG is too short or the speed is too fast.
- (2) Extend DOG or slow down the zero return speed.

MOT 4035 : SET CMR ERROR

- (1) Setting CMR error
- (2) Checking Para. # 0053 ~ 0056 , 0067 ~ 0070 , 0072 , 0100 ~ 0107 , 1112 ~ 1115.
- (3) Re-setting parameter and re-booting.

MOT 4037 : SET DMR ERROR

- (1) DMR setting error.
- (2) Checking whether or not the setting value is over setting parameter 53~57 range.
- (3) Re-setting parameter and re-booting.

MOT 4039 : HOME LOW SPEED ERROR

- (1) 2nd home speed setting error.
- (2) Checking whether or not the setting value is over setting parameter 1108-1111 range.
- (3) Re-setting parameter and re-booting.

MOT 4040 : X CMP NO. ERROR

- (1) Pitch compensation section setting error.
- (2) Checking Parameter # 0112 range.
- (3) Re-setting parameter and re-booting.

MOT 4041 : Y CMP NO. ERROR

- (1) Pitch compensation section setting error.
- (2) Checking Parameter # 0113 range.
- (3) Re-setting parameter and re-booting.

MOT 4042 : Z CMP NO. ERROR

- (1) Pitch compensation section setting error.
- (2) Checking Parameter # 0114 range.
- (3) Re-set parameter and re-boot.

MOT 4043 : 4TH CMP NO. ERROR

- (1) Pitch compensation section setting error.
- (2) Checking Parameter # 0115 range.
- (3) Re-setting parameter and re-booting.

MOT 4044 : CMP INTERVAL ERROR

- (1) Pitch compensation section setting error.
- (2) Checking Parameter # 0114 range.
- (3) Re-setting parameter and re-booting.

MOT 4045 : NO INDEX INTERRUPT

- (1) Reference point index disconnect signal error or HOME DOG too short.
- (2) Checking connection for motor to servo.

MOT 4046 : RETURN HOME FAILURE

- (1) Checking whether nor not machine lock or other machine problems.
- (2) Press RESET to clear the condition.

MOT 4047 : I/O COMMUNICATION ERROR

- (1) Checking I/O board.
- (2) Checking all connectors on I/O board.

MOT 4048 : SPINDLE ORIENTATION SIGNAL NOT RELEASE

Assumed executing machine adjustment and orientation. If initially, the spindle is positioned on the sensor, the spindle will move away automatically. After the orientation signal is off, user will be able to execute machine adjustment or orientation. However, if the spindle already rotates one cycle but the orientation signal has not been released, then this alarm message will occur.

- (1) Checking whether or not there is connection problem on the spindle orientation sensor.
- (2) Checking whether or not the spindle orientation sensor signal and type setting is correct (Parameter # 184).
- (3) Checking whether or not the spindle orientation sensor is broken.

MOT 4049 : SPINDLE ORIENTATION FLAUT

When executing spindle orientation, the spindle is NOT able to reach the correct orientation point.

- (1) Please go to DGNOS page. If the data system NO. 10 are changing, but the spindle is not rotating. Then, it means the spindle motor ENCDER signal has external distribution that makes the system misunderstood.
- (2) Please check whether or not the setting orientation rate is too high by parameter NO. 21 that make spindle motor have missing step in the Pulse Mode.

MOT 4050 : SPINDLE ORIENTATION SIGNAL NOT FOUND

Assumed the spindle has rotated one time already but it hasn't found the orientation position sensor while executing machine adjustment or while orientation program is running. The following alarm messages will occur.

- (1) Checking whether or not there is connection problem on the spindle orientation sensor
- (2) Checking whether or not the spindle orientation sensor signal and type setting is correct (Parameter # 184).
- (3) Checking whether or not the spindle orientation sensor is broken.

MOT 4051 : NO SPINDLE SPEED DEFINE

No spindle speed definition. So please define rotary command in rigid tapping. Please key-in rotational speed command S before tapping command.

MOT 4052 : MOVE ERR OVER LIMIT IN RIGTAP

- (1) Please check whether or not the procedure of rigid machine adjustment is completed.
- (2) Please check whether not the setting value of Parameter 1058 is too small.

MOT 4053 : SPD SPEED WILL OVER LIMIT

- (1) Please check whether or not the setting spindle rotational speed is over the maximum speed that this gear spindle can handle.
- (2) Please check whether or not the setting of Parameter NO. 1060 for the spindle return accelerating speed is too big under rigid tapping. Unless necessary, recommend setting to 100.

MOT 4054 : Z AXIS FEEDRATE WILL OVER LIMIT

Z axis cutting feedrate speed of rigid tapping is larger than the maximum cutting speed that is set by Parameter 1004.

- (1) Checking whether or not Parameter NO. 1060 has set the spindle returning accelerating speed too large under rigid tapping. If speed starts to accelerate while returning (i.e., P1060 > 1000), then speed of cutting spindle will accelerate too. Unless necessary, recommend to set 100.

MOT 4055 : SPD SERROLAG OVER LIMIT IN RT

- (1) Please check whether or not ladder has error.
- (2) Please check whether or to the spindle is rotating in rigid tapping procedure. If not, please check (3) whether or not there is problem for the spindle driver setting.
- (3) Please check whether or not the spindle Encoder line is discount or fall.
- (4) Please check whether or not the setting of Parameter 1075 is too small.

MOT 4057: Z TRAVEL IS OVER 2 HOME LIMIT

When Z is at second home, stop move down.

MOT 4058 : OVER SOFTLIMIT

- (1) RESET system.
- (2) Move axis out of limit manually.

MOT 4059 : Spindle ERROR COUNTER

- (1) SP ERROR COUNTER overflow.
- (2) Check if command speed too big.
- (3) Check if driver is ok.
- (4) Check if machine is ok.
- (5) Check if board is ok.

MOT 4062 : X-AXIS ABSOLUTE ENCODER VALUE OUT OF TOLERANCE

After X axis re-finds home, NC will ask 4th absolute encoder to do returning zero. After complete, NC re-read encoder data to make sure it has return zero. But if the data is over the Pr.1098 setting, Alarm. (MITSUBISHI servo motor-when you want to re-read absolute encoder, you need to servo off, wait around 20ms and servo on, during the time, NC will follow 4th encoder to update coordinate. Later's comparison also use update coordinate.)

- (1) Check if Pr.1098 is correct or not.
- (2) Check if X axis absolute encoder completes the action of returning zero.

MOT 4063 : X AXIS ABSOLUTE ENCODER TRANSMISSION OVER TIME

When NC is doing X axis absolute encoder reading, if it didn't finish the reading action under Pr. 0834 setting time, Alarm

- (1) Check if servo drives set to be absolute encoder.
- (2) Check hardware cable connections.
- (3) Check if X axis Ladder correct (MITSUBISHI servo motor-when you want to re-read absolute encoder, you need to servo off, wait around 20ms and servo on. Check if CS bit is correct.)
- (4) Check if Pr.0834 setting time is enough to complete absolute encoder reading action.

MOT 4064 : X AXIS ABSOLUTE ENCODER CHECK SMM ERROR

X axis reading-absolute encoder has CHECK SMM error.

Check hardware cable connections.

Please check whether or not X Axis ladder has error

MOT 4065 : Y-AXIS ABSOLUTE ENCODER VALUE OUT OF TOLERANCE

After Y axis re-finds home, NC will ask 4th absolute encoder to do returning zero. After complete, NC re-read encoder data to make sure it has return zero. But if the data is over the Pr.1098 setting, Alarm. (MITSUBISHI servo motor-when you want to re-read absolute encoder, you need to servo off, wait around 20ms and servo on, during the time, NC will follow 4th encoder to update coordinate. Later's comparison also use update coordinate.)

- (1) Check if Pr.1098 is correct or not.
- (2) Check if Y axis absolute encoder completes the action of returning zero.

MOT 4066 : Y AXIS ABSOLUTE ENCODER TRANSMISSION OVER TIME

When NC is doing Y axis absolute encoder reading, if it didn't finish the reading action under Pr. 0834 setting time, Alarm.

- (1) Check if servo drives set to be absolute encoder.
- (2) Check hardware cable connections.
- (3) Check if Y axis Ladder correct (MITSUBISHI servo motor-when you want to re-read absolute encoder, you need to servo off, wait around 20ms and servo on. Check if CS bit is correct.)
- (4) Check if Pr.0834 setting time is enough to complete absolute encoder reading action.

MOT 4067 : Y AXIS ABSOLUTE ENCODER CHECK SMM ERROR

Y axis reading-absolute encoder has CHECK SMM error.

- (1) Check hardware cable connections.
- (2) Please check whether or not Y Axis ladder has error

MOT 4068 : Z-AXIS ABSOLUTE ENCODER VALUE OUT OF TOLERANCE

After Z axis re-finds home, NC will ask 4th absolute encoder to do returning zero. After complete, NC re-read encoder data to make sure it has return zero. But if the data is over the Pr.1098 setting, Alarm. (MITSUBISHI servo motor-when you want to re-read absolute encoder, you need to servo off, wait around 20ms and servo on, during the time, NC will follow 4th encoder to update coordinate. Later's comparison also use update coordinate.)

- (1) Check if Pr.1098 is correct or not.
- (2) Check if Z axis absolute encoder completes the action of returning zero.

MOT 4069 : Z AXIS ABSOLUTE ENCODER TRANSMISSION OVER TIME

When NC is doing Z axis absolute encoder reading, if it didn't finish the reading action under Pr. 0834 setting time, Alarm.

- (1) Check if servo drives set to be absolute encoder.
- (2) Check hardware cable connections.
- (3) Check if Z axis Ladder correct (MITSUBISHI servo motor-when you want to re-read absolute encoder, you need to servo off, wait around 20ms and servo on. Check if CS bit is correct.)
- (4) Check if Pr.0834 setting time is enough to complete absolute encoder reading action.

MOT 4070 : Z AXIS ABSOLUTE ENCODER CHECK SMM ERROR

Z axis reading-absolute encoder has CHECK SMM error.

- (1) Check hardware cable connections.
- (2) Please check whether or not Z Axis ladder has error

MOT 4071 : 4TH-AXIS ABSOLUTE ENCODER VALUE OUT OF TOLERANCE

After 4th axis re-finds home, NC will ask 4th absolute encoder to do returning zero. After complete, NC re-read encoder data to make sure it has return zero. But if the data is over the Pr.1098 setting, Alarm. (MITSUBISHI servo motor-when you want to re-read absolute encoder, you need to servo off, wait around 20ms and servo on, during the time, NC will follow 4th encoder to update coordinate. Later's comparison also use update coordinate.)

- (1) Check if Pr.1098 is correct or not.
- (2) Check if 4th axis absolute encoder completes the action of returning zero.

MOT 4072 : 4TH AXIS ABSOLUTE ENCODER TRANSMISSION OVER TIME

When NC is doing 4th axis absolute encoder reading, if it didn't finish the reading action under Pr. 0834 setting time, Alarm

- (1) Check if servo drives set to be absolute encoder.
- (2) Check hardware cable connections.
- (3) Check if 4th axis Ladder correct (MITSUBISHI servo motor-when you want to re-read absolute encoder, you need to servo off, wait around 20ms and servo on. Check if CS bit is correct.)
- (4) Check if Pr.0834 setting time is enough to complete absolute encoder reading action.

MOT 4073 : 4TH AXIS ABSOLUTE ENCODER CHECK SMM ERROR

4th axis reading-absolute encoder has CHECK SMM error.

- (1) Check hardware cable connection.
- (2) Please check whether or not 4th Axis ladder has error.

MOT 4079 : 5TH AXIS ABSOLUTE ENCODER TRANSMISSION OVER TIME

- (1) When NC reads 5 axes ABS encoder, if not finish at P.0834 setting time, Alarm.
- (2) Check servo drive is ABS setting.
- (3) Check hardware wiring see if there is any problem.
- (4) Check 4 axis Ladder(If you want to read MITSUBISHI ABS encoder, you will need to make servo motor servo off, wait 20ms and above time and servo on, check if corresponding CS bit is correct.)
- (5) Check if P.0834 setting too fast.

MOT 4080 : 5th AXIS ABSOLUTE ENCODER CHECK SMM ERROR

- (1) 5 read ABS encoder has CHECK SUM error.
- (2) Check hardware wiring see if there is any problem.
- (3) Check if 5 Ladder is correct.

MOT 4081: 6TH Absolute encoder big difference error

- (1) When 6 axis research home, NC will ask 6 axis ABS encoder to do zero : After completing, NC will read again ABS encoder to make sure this value is zero. If reading value and NC inner value is over P.1098 setting, Alarm. (If you want to read MITSUBISHI ABS encoder, you will need to make servo motor servo off, wait 20ms and above time and servo on. During this time, NC will update coordinate by 6 axis encoder, later will use new coordinate.)
- (2) Check P.1098 setting.
- (3) Check 6 axis ABS encoder if complete zero.

MOT 4082 : 6TH AXIS ABSOLUTE ENCODER TRANSMISSION OVER TIME

When NC is doing servo axis absolute encoder reading, if it didn't finish the reading action under Pr. 0834 setting time, Alarm.

- (1) Check if servo drives set to be absolute encoder.
- (2) Check hardware cable connections.
- (3) Check if servo axis Ladder correct (MITSUBISHI servo motor-when you want to re-read absolute encoder, you need to servo off, wait around 20ms and servo on. Check if CS bit is correct.)
- (4) Check if Pr.0834 setting time is enough to complete absolute encoder reading action.

MOT 4083 : 6th AXIS ABSOLUTE ENCODER CHECK SMM ERROR

Servo axis reading-absolute encoder has CHECK SMM error.

- (1) Check hardware cable connections.
- (2) Please check whether or not servo axis ladder has error.

MOT 4084: 5TH ABSOLUTE ENCODER BIG DIFFERENCE ERROR

- (1) When 5 axis research home, NC will ask 6 axis ABS encoder to do zero ; after completing, NC will read again ABS encoder to make sure this value is zero. If reading value and NC inner value is over P.1098 setting, Alarm. (If you want to read MITSUBISHI ABS encoder, you will need to make servo motor servo off, wait 20ms and above time and servo on. During this time, NC will update coordinate by 6 axis encoder, later will use new coordinate.)
- (2) Check P.1098 setting.
- (3) Check 5 axis ABS encoder if complete zero.

MOT 4087: Y motor ENCODER wiring error

- (1) ENCODER break or 5V power error
- (2) Stop machine and check wiring and connector.

MOT 4090 : X AXIS SERVO LAG TOO BIG, CHECK WIRING OR PR. 416
X Servo lag over range when stop, please check wire or P416 set too small.

MOT 4091 : Y AXIS SERVO LAG TOO BIG, CHECK WIRING OR PR. 417

Y Servo lag over range when stop, please check wire or P417 set too small.

MOT 4092 : Z AXIS SERVO LAG TOO BIG, CHECK WIRING OR PR. 418

Z Servo lag over range when stop, please check wire or P418 set too small.

MOT 4093 : 4TH AXIS SERVO LAG TOO BIG, CHECK WIRING OR PR. 419

4TH Servo lag over range when stop, please check wire or P419 set too small.

MOT 4094 : 5TH AXIS SERVO LAG TOO BIG, CHECK WIRING OR PR. 420

5TH Servo lag over range when stop, please check wire or P420 set too small.

MOT 4095 : 6TH AXIS SERVO LAG TOO BIG, CHECK WIRING OR PR. 421

6TH Servo lag over range when stop, please check wire or P421 set too small.

MOT 4096: Z motor ENCODER wiring error

- (1) ENCODER BRAKE OR 5V POWER ERROR.
- (2) Stop machine and check wiring or connector.

MOT 4097: 4TH motor ENCODER wiring error

- (1) ENCODER BRAKE OR 5V POWER ERROR.
- (2) Stop machine and check wiring or connector.

MOT 4098: 5TH motor ENCODER wiring error

- (1) ENCODER BRAKE OR 5V POWER ERROR.
- (2) Stop machine and check wiring or connector.

MOT 4099: 6TH motor ENCODER wiring error

- (1) ENCODER BRAKE OR 5V POWER ERROR.
- (2) Stop machine and check wiring or connector.

MOT 4100 : COM REPEAT CHECK PR.1810 AND 1811

- (1) Check if P.1810 & 1811 is the same.
- (2) Press RESET to clear alarm.

MOT 4104: X PMC/INT output error**MOT 4105: Y PMC/INT output error****MOT 4106: Z PMC/INT output error****MOT 4107: 4TH PMC/INT output error****MOT 4108: 5TH PMC/INT output error****MOT 4109: 6TH PMC/INT output error**

MOT4104~MOT4109: modify command to make it ok for PMC axis.

MOT 4121 : X AXIS COMMANDED UNDER DETACHED

- (1) RESET system to clear alarm
- (2) Check if PLC sends C bit 130 and clear it.

MOT 4122 : Y AXIS COMMANDED UNDER DETACHED

- (1) Check if PLC sends C bit 131 and clear it.

MOT 4123 : Z AXIS COMMANDED UNDER DETACHED

- (1) RESET system to clear alarm
- (2) Check if PLC sends C bit 132 and clear it.

MOT 4124 : 4th AXIS COMMANDED UNDER DETACHED

- (1) RESET system to clear alarm
- (2) Check if PLC sends C bit 133 and clear it.

MOT 4126: MOVE COMMAND NOT RESTART

Under MDI, you can not give move command at program restart.

MOT 4127 : 5th AXIS COMMANDED UNDER DETACHED

- (1) RESET SYSTEM TO CLEAR ALARM.
- (2) Check if PLC gives axis C bit 168 and release.

MOT 4128 : 6th AXIS COMMANDED UNDER DETACHED

- (1) RESET SYSTEM TO CLEAR ALARM.
- (2) Check if PLC gives axis C bit 169 and release.

MOT 4129 : LIMIT AND INDEX HAS CERTAIN SAFE DISTANCE, USE GRID TO PROTECT

- (1) This distance from index to limit sensor is smaller than encoder 1/5 or bigger than 4/5 revolution, then open grid protection function, if no, and then close grid protection function.
- (2) If confirming that the distance is smaller than 1/5 or bigger than 4/5 revolution, but this alarm still exist, check if home limit sensor position error.

MOT 4130 : X AXIS MULTI-HOME LINEAR SCALE HOME PITCH ERROR

- (1) X multi-home linear scale home interval setting error. (P.1171 、 1172 small or equal to 0.
- (2) Refer to linear scale manual and system P.1171 、 1172, reset.

MOT 4131 : Y AXIS MULTI-HOME LINEAR SCALE HOME PITCH ERROR

- (1) Y multi-home linear scale home interval setting error. (P.1173 、 1174 small or equal to 0).
- (2) Refer to linear scale manual and system P.1173 、 1174, reset.

MOT 4132 : Z AXIS MULTI-HOME LINEAR SCALE HOME PITCH ERROR

- (1) Z multi-home linear scale home interval setting error. (P.1175 、 1176 small or equal to 0).
- (2) Refer to linear scale manual and system P.1175 、 1176, reset.

MOT 4133 : 4TH AXIS MULTI-HOME LINEAR SCALE HOME PITCH ERROR

- (1) 4TH multi-home linear scale home interval setting error. (P.1177 、 1178 small or equal to 0)。
- (2) Refer to linear scale manual and system P.1177 、 1178, reset.

MOT 4134 : 5TH AXIS MULTI-HOME LINEAR SCALE HOME PITCH ERROR

- (1) 5TH multi-home linear scale home interval setting error. (P.1179 、 1180 small or equal to 0)。
- (2) Refer to linear scale manual and system P.1179 、 1180, reset.

MOT 4135 : 6TH AXIS MULTI-HOME LINEAR SCALE HOME PITCH ERROR

- (1) 6TH multi-home linear scale home interval setting error. (P.1181 、 1182 small or equal to 0)。
- (2) Refer to linear scale manual and system P.1181 、 1182, reset.

MOT 4136: 5TH PITCH COMPENSATION SEGMENT ERROR

- (1) Pitch compensation segment errors.
- (2) Check P.0280
- (3) Reset parameter and reboot.

MOT 4137: 6TH PITCH COMPENSATION SEGMENT ERROR

- (1) Pitch compensation segment errors.
- (2) Check P.0281
- (3) Reset parameter and reboot.

MOT 4138 : FOLLOW SP NAME ERROR

Fallow master axis number setting error, check if P. 500~505 setting error.

MOT 4139 : ANALOG VOLTAGE CHECKING CARD DO NOT EXIST

This controller did not have DAQ3718 analog voltage check card, make this to be 0, no use.

MOT 4140 : ANALOG VOLTAGE CHECKING MAX AND MIN SETTING ERROR

Maximum setting cannot smaller than minimum setting.

MOT 4141 : EXECUTE RETURN HOME WHEN AT PREPARE COMPLETE

Under NC-ready can return home.

MOT 4142 : STOP INT M CODE, M CODE REPEAT, CHECK PR.211~220

Check P.211~220 if using system M code (EX: M0, M1, M2, M30, M98, M99)

MOT 4143 : X AXIS ABS ENCODER COMMUNICATION ERROR**MOT 4144 : Y AXIS ABS ENCODER COMMUNICATION ERROR****MOT 4145 : Z AXIS ABS ENCODER COMMUNICATION ERROR****MOT 4146 : 4TH AXIS ABS ENCODER COMMUNICATION ERROR****MOT 4147 : 5TH AXIS ABS ENCODER COMMUNICATION ERROR****MOT 4148 : 6TH AXIS ABS ENCODER COMMUNICATION ERROR****MOT4143~MOT4148:**

- (1) Read this axis ABS encoder fail.
- (2) Check serial communication wiring.
- (3) Check if servo motor serial communication setting correct.
- (4) If PLC editing correct.
- (5) Press RESET to clear alarm.

MOT 4149 : X AXIS ABS ENCODER CAN NOT USE ROTATION AXIS, CHECK PR.845

RS-422ABS encoder cannot use at rotating axis, check P.845 if set up X to be rotating axis.

MOT 4150 : Y AXIS ABS ENCODER CAN NOT USE ROTATION AXIS, CHECK PR.846

RS-422ABS encoder cannot use at rotating axis, check P.846 if set up Y to be rotating axis.

MOT 4151 : Z AXIS ABS ENCODER CAN NOT USE ROTATION AXIS, CHECK PR.847

RS-422ABS encoder cannot use at rotating axis, check P.847 if set up Z to be rotating axis.

MOT 4152 : 4TH AXIS ABS ENCODER CAN NOT USE ROTATION AXIS, CHECK PR.66

RS-422ABS encoder cannot use at rotating axis, check P.66 if set up 4 axis to be rotating axis.

MOT 4153 : 5TH AXIS ABS ENCODER CAN NOT USE ROTATION AXIS, CHECK PR.260

RS-422ABS encoder cannot use at rotating axis, check P.260 if set up 5 axis to be rotating axis.

MOT 4154 : 6TH AXIS ABS ENCODER CAN NOT USE ROTATION AXIS, CHECK PR.261

RS-422ABS encoder cannot use at rotating axis, check P.261 if set up 6 axis to be rotating axis.

MOT 4155 : PMC G00 ACC/DEC (PR.398) ERROR

Check P.398 setting error.

MOT 4156 : PMC G01 ACC/DEC (PR.399) ERROR

Check P.399 setting error.

MOT 4157 : PMC G00 POSITION CHECK RANGE (PR.1831~1836) ERROR

Check P.1831~1836 setting error.

MOT 4158 : PMC G01 POSITION CHECK RANGE (PR.1837~1842) ERROR

Check P.1837~1842 setting error.

MOT 4159 : 1 SOFTWARE PROHIBIT ERROR

- (1) P.1900~1911 1ST Software restricted area (-) value Do not large then (+) value.
- (2) Modify this parameter, press RESET.

MOT 4160 : 2 SOFTWARE PROHIBIT ERROR

- (1) P.1912~1923 1ST Software restricted area (-) value Do not large then (+) value.
- (2) Modify this parameter, press RESET.

MOT 4161 : I/O CARD COMMUNICATION ERROR (RIO2)

- (1) Check I/O board.
- (2) Check I/O all wiring.
- (3) Check PLCIO.CFG setting error.

MOT 4162**Mill V3: OUT OF X AXIS HOME DOG, CHECK PR.1890 OR DOG SIGNAL**

Check P. 1890, see if it set too small or Check X Home dog see if it failed

Mill V6: Communication IO lost

RS232 communicate lost, please Check wiring and reboot.

MOT 4163**Mill V3: OUT OF Y AXIS HOME DOG, CHECK PR.1891 OR DOG SIGNAL**

Check P. 1891, see if it set too small or Check Y Home dog see if it failed

Mill V6: OUT OF X AXIS HOME DOG, CHECK PR.1890 OR DOG SIGNAL

Check P. 1890, see if it set too small or Check X Home dog see if it failed

MOT 4164**Mill V3: OUT OF Z AXIS HOME DOG, CHECK PR.1892 OR DOG SIGNAL**

Check P. 1892, see if it set too small or Check Z Home dog see if it failed

Mill V6: OUT OF Y AXIS HOME DOG, CHECK PR.1891 OR DOG SIGNAL

Check P. 1891, see if it set too small or Check Y Home dog see if it failed

MOT 4165**Mill V3: OUT OF C AXIS HOME DOG, CHECK PR.1893 OR DOG SIGNAL**

Check P. 1893, see if it set too small or Check 4TH Home dog see if it failed

Mill V6: OUT OF Z AXIS HOME DOG, CHECK PR.1892 OR DOG SIGNAL

Check P. 1892, see if it set too small or Check Z Home dog see if it failed

MOT 4166**Mill V3: OUT OF 5TH AXIS HOME DOG, CHECK PR.1894 OR DOG SIGNAL**

Check P. 1894, see if it set too small or Check 5TH Home dog see if it failed

Mill V6: OUT OF C AXIS HOME DOG, CHECK PR.1893 OR DOG SIGNAL

Check P. 1893, see if it set too small or Check 4TH Home dog see if it failed

MOT 4167**Mill V3: OUT OF 6TH AXIS HOME DOG, CHECK PR.1895 OR DOG SIGNAL**

Check P. 1895, see if it set too small or Check 6TH Home dog see if it failed

Mill V6: OUT OF 5TH AXIS HOME DOG, CHECK PR.1894 OR DOG SIGNAL

Check P. 1894, see if it set too small or Check 5TH Home dog see if it failed

MOT 4168**Mill V3: TWO SETS OF INNER M CODER CAN NOT EXIT TOGETHER**

Check there are 2 or more CNC inner M code in program, include : M00 、 M01 、 M02 、 M30 、 M98 、 M99.

Mill V6: OUT OF 6TH AXIS HOME DOG, CHECK PR.1895 OR DOG SIGNAL

Check P. 1895, see if it set too small or Check 6TH Home dog see if it failed

MOT 4169: X AXIS 2ND FEEDBACK EXAM WRONG, CHECK IF MACHINE INTERFERENCE OR PR. 1980 TOO SMALL

MOT 4170: Y AXIS 2ND FEEDBACK EXAM WRONG, CHECK IF MACHINE INTERFERENCE OR PR.1981 TOO SMALL

MOT 4171: Z AXIS 2ND FEEDBACK EXAM WRONG, CHECK IF MACHINE INTERFERENCE OR PR. 1982 TOO SMALL

MOT 4172: 4TH AXIS 2ND FEEDBACK EXAM WRONG, CHECK IF MACHINE INTERFERENCE OR PR.1983 TOO SMALL

MOT 4173: 5TH AXIS 2ND FEEDBACK EXAM WRONG, CHECK IF MACHINE INTERFERENCE OR PR.1984 TOO SMALL

MOT 4174: 6TH AXIS 2ND FEEDBACK EXAM WRONG, CHECK IF MACHINE INTERFERENCE OR PR.1985 TOO SMALL

MOT 4169~MOT4174

- (1) Check if feedback signal was interfered.
- (2) Check if have machine interference
- (3) Reset corresponding 2nd encoder feedback exam tolerance Pr.1980~1985 value, and press reset to continue.
- (4) Enlarge Pr. .1980~1985, press reset, clear alarm, press ZRN to make value to be 0.
- (5) Press reboots to make value to be 0.

MOT 4175: X AXIS AND MAIN AXIS LAG, CHECK IF MACHINE INTERFERENCE OR PR.1986 TOO SMALL

MOT 4176: Y AXIS AND MAIN AXIS LAG, CHECK IF MACHINE INTERFERENCE OR PR.1987 TOO SMALL

MOT 4177: Z AXIS AND MAIN AXIS LAG, CHECK IF MACHINE INTERFERENCE OR PR.1988 TOO SMALL

MOT 4178: 4TH AXIS AND MAIN AXIS LAG, CHECK IF MACHINE INTERFERENCE OR PR.1989 TOO SMALL

MOT 4179: 5TH AXIS AND MAIN AXIS LAG, CHECK IF MACHINE INTERFERENCE OR PR.1990 TOO SMALL

MOT 4180: 6TH AXIS AND MAIN AXIS LAG, CHECK IF MACHINE INTERFERENCE OR PR.1991 TOO SMALL

MOT 4175~MOT 4180

- (1) Reboot system.
- (2) Make Pr.1960~1965 bigger, press reset
- (3) Check if have machine interference.

MOT 4181: IO COMMUNICATION BRAKE

RS232 communication brake, check wiring and reboot.

MOT 4182: SP POSITIONING ERROR, CHECK P.184 OR WIRING

- (1) Check P.184 setting.
- (2) Check SP positioning signal wiring.

MOT 4190: Program restart but end by meets M02.M30/M99

Program restart, but there is M02/M30, check if confirming lines too much.

MOT 4191: DO NOT SUPPORT RIGID TAPPING

Mill V6 did not support rigid tapping, check if there is M29.

MOT 4202: 5TH ERROR COUNTER OVERFLOW

- (1) 5 axis ERROR COUNTER overflow (16-BIT)
- (2) Check if command speed is too big.
- (3) Check if servo driver is ok.
- (4) Check if machine is moving ok.
- (5) Check if board is ok.

MOT 4203: 6TH ERROR COUNTER OVERFLOW

- (1) 6 axis ERROR COUNTER overflow (16-BIT)
- (2) Check if command speed is too big.
- (3) Check if servo driver is ok.
- (4) Check if machine is moving ok.
- (5) Check if board is ok.

MOT 4204: 5TH SERVO LAG OVER P.250

- (1) 5 axis servo lag is over P.0250.
- (2) Check if speed too big or P.0250 too small.
- (3) Press RESET to continue operation.
- (4) If reset parameter, need to reboot.

MOT 4205: 6TH SERVO LAG OVER P.251

- (1) 5 axis servo lag is over P.0251.
- (2) Check if speed too big or P.0251 too small.
- (3) Press RESET to continue operation.
- (4) If reset parameter, need to reboot.

MOT 4206: 5TH AXIS IS ON HOME DOG

- (1) 5 axis is on HOME DOG.
- (2) Press RESET and use JOG to move axis out of HOME DOG.

MOT 4207: 6TH AXIS IS ON HOME DOG

- (1) 6 axis is on HOME DOG.
- (2) Press RESET and use JOG to move axis out of HOME DOG.

MOT 4208 : SERVO AXIS NO. REPEAT

Check P.24~27, 256~257 is double setting, revise and reboot to clear alarm. If only using reset to clear this alarm, then input port is invalid.

MOT 4209 : 2ND FEEDBACK EXAM INPUT PORT REPEAT, CHECK PR.1950~1955

- (1) Check if Pr.1950~1955 setting repeats. If so, modify and reboot to clear alarm. If only using reset to clear this alarm, this input port will be invalid.

MOT 4210: M-II INITIAL FAIL

Check MII axis setting or controller MII hardware error.

MOT 4211: M-II INTERRUPT FAIL

Check MII axis setting or controller MII hardware error.

MOT 4212: M-II X Servo On/Off COMMAND & STATUS NOT THE SAME.

- (1) Re-ON C281 OFF to trigger X motor.
- (2) Press RESET to clear alarm

MOT 4213: M-II Y Servo On/Off COMMAND & STATUS NOT THE SAME

- (1) Re-ON C282 OFF to trigger Y motor.
- (2) Press RESET to clear alarm.

MOT 4214: M-II Z Servo On/Off COMMAND & STATUS NOT THE SAME

- (1) Re-ON C283 OFF to trigger Z motor.
- (2) Press RESET to clear alarm.

MOT 4215: M-II C Servo On/Off COMMAND & STATUS NOT THE SAME

- (1) Re-ON C284 OFF to trigger C motor.
- (2) Press RESET to clear alarm.

MOT 4216: M-II 5TH Servo On/Off COMMAND & STATUS NOT THE SAME

- (1) Re-ON C285 OFF to trigger 5th motor.
- (2) Press RESET to clear alarm.

MOT 4217: M-II 6TH Servo On/Off COMMAND & STATUS NOT THE SAME

- (1) Re-ON C283 OFF to trigger 6th motor.
- (2) Press RESET to clear alarm.

MOT 4218: M-II 1st SP Servo On/Off COMMAND & STATUS NOT THE SAME.

- (1) Re-ON C287 OFF to trigger 1 SP.
- (2) Press RESET to clear alarm.

MOT 4219: M-II 2nd SP Servo On/Off COMMAND & STATUS NOT THE SAME.

- (1) Re-ON C288 OFF to trigger 2 SP.
- (2) Press RESET to clear alarm.

MOT 4220: M-II 3rd SP Servo On/Off COMMAND & STATUS NOT THE SAME.

- (1) Re-ON C289 OFF to trigger 3 SP.
- (2) Press RESET to clear alarm

MOT 4221: M-II COMMUNICATION READ INFO FAIL

- (1) M-II communication cable brake or disturbed, Re-ON communication cable.
- (2) Press RESET to clear alarm.

MOT 4222: M-II COMMUNICATION WRITE INFO FAIL

- (1) M-II communication cable brake or disturbed, Re-ON communication cable.
- (2) Press RESET to clear alarm.

MOT 4300: 1st SP COMMUNICATION ERROR

Check hardware wiring, BIOS parameter, and controller and inverter parameter, press RESET to make it reconnect and clear alarm.

MOT 4301 ~ MOT 4340: ALARM

- (1) This is inverter alarm, refer to inverter manual.
- (2) Press RESET to clear.

MOT 4341: 1st SP POLES SETTING CONFLICT, CHECK SYSTEM P.681& INVERTER P.4-04

- (1) Check controller P.681 & inverter P.4-04, check if both setting are the same.
- (2) After setting, press RESET to make parameter valid and clear alarm.

MOT 4342: 1st SP FREQUENCY GAIN SETTING CONFLICT, CHECK SYSTEM P.685& INVERTER P.0-23

- (1) Check controller P.685 & inverter P.0-23, check if both setting are reasonable.
- (2) After setting, press RESET to make parameter valid and clear alarm.

MOT 4343: 1st SP MAX. FREQUENCY SETTING CONFLICT, CHECK SYSTEM P.682& INVERTER P.1-00

- (1) Check controller P.682 & inverter P.1-00, check if both setting are reasonable.
- (2) After setting, press RESET to make parameter valid and clear alarm.

MOT 4344: 1st SP UP LIMIT OUTPUT FREQUENCY SETTING CONFLICT, CHECK SYSTEM P.683& INVERTER P.1-21

- (1) Check controller P.683 & inverter P.1-21, check if both setting are reasonable.
- (2) After setting, press RESET to make parameter valid and clear alarm.

MOT 4345: 1st SP DOWN LIMIT OUTPUT FREQUENCY SETTING CONFLICT, CHECK SYSTEM P.684& INVERTER P.1-22

- (3) Check controller P.684 & inverter P.1-22, check if both setting are reasonable.
- (4) After setting, press RESET to make parameter valid and clear alarm.

MOT 4950 : SYSTEM ALARM

Contact system maker, LNC.

MOT 4999: Spindle POSITION DIFFERENCE ANGLE OVER SETTING

- (1) Make P.1999 bigger.
- (2) Reboot system.
- (3) Contact LNC

4.5 MOT Alarms

MOT 9001 : X AXIS OVER SOFTLIMIT (+)

MOT 9002 : X AXIS OVER SOFTLIMIT (-)

MOT 9003 : Y AXIS OVER SOFTLIMIT (+)

MOT 9004 : Y AXIS OVER SOFTLIMIT (-)

MOT 9005 : Z AXIS OVER SOFTLIMIT (+)

MOT 9006 : Z AXIS OVER SOFTLIMIT (-)

MOT 9007 : 4TH AXIS OVER SOFTLIMIT (+)

MOT 9008 : 4TH AXIS OVER SOFTLIMIT (-)

MOT9001~MOT9008: Move this warning servo axis back to safe area, it can clear warning.

MOT 9009 : X AXIS OVER G22 SOFTLIMIT (+)

MOT 9010 : X AXIS OVER G22 SOFTLIMIT (-)

MOT 9011 : Y AXIS OVER G22 SOFTLIMIT (+)

MOT 9012 : Y AXIS OVER G22 SOFTLIMIT (-)

MOT 9013 : Z AXIS OVER G22 SOFTLIMIT (+)

MOT 9014 : Z AXIS OVER G22 SOFTLIMIT (-)

MOT9009~MOT9014: Move this warning servo axis back to safe area as G22 has set up, it can clear warning.

Check G22 each axis travel limit and see if need to be adjusted, or modify program command location.

MOT 9016: 5TH OVER (-) SOFTWARE LIMIT

MOT 9017: 6TH OVER (+) SOFTWARE LIMIT

MOT 9018: 6TH OVER (-) SOFTWARE LIMIT

MOT 9019: 5TH OVER (+) SOFTWARE LIMIT

MOT9016~MOT9019: Move this warning servo axis back to safe area, it can clear warning

MOT 4801~MOT 4876: AS ALARM SHOW

MOT 9033~MOT 9051: AS ALARM SHOW

- (1) This is M-II drive alarm and warning
- (2) Refer to M-II drive manual to clear this alarm/warning.
- (3) Reboot.

5 Machine Adjustment

5.1 Milling Rigid Tapping Commanding

Description :

G94 (G95)

Mode	Thread Pitch Calculation	F_ Unit
G94	F_ / S_	mm/min
G95	F_	mm/rev

G98 、 G99

G98 : Returning back to the initial height.

G99 : Returning back to R point

G84 (G74) X_Y_Z_R_P_F_K_ :

G84 : Right helical.

G74 : Left helical.

X_Y_ : Tapping position.

Z_ : Tapping's lowest point (hole bottom).

R_ : Tapping's starting point.

P_ : Tapping's stop time.

F_ : Tapping's Z axis feed speed (G94) or pitch (G95) .

K_ : Repeating tapping numbers.

Example :

G94 (G95) ; // To set Feedrate unit.

M29 S_ ; // To enable rigid tapping mode and to command spindle to the desired rotational speed.

G98 (G99) G84 (G74) X_Y_Z_R_P_F_K_ ;


G80 ; // or Group 0 commands (G00 、 G01 、 G02 、 G03) , disable rigid mode.

Returning acceleration function

Setting parameter 1060, which will be able to accelerate the Z axis returning speed under rigid tapping and to decrease working time °

Override

Under rigid tapping, Feed Override and Spindle Speed Override will be disabled



PLC Rigid Tapping C BIT

C BIT	SYMBOL	Description
C125	RT START	When C125 is ON, it will inform NC to start rigid tapping mode. PLC needs to wait until NC S128 = ON and then to disable C125.
C124	RT STOP	Disable rigid tapping mode. Under normal situation, rigid tapping mode will be disabled automatically after reading G80 or Group 1's G code. If there is special need, please set bit to ON and then rigid tapping will be disabled automatically.
S128	RT STATE	Rigid Tapping Mode Status When NC enters into the rigid tapping mode, S128 remains ON until it exits rigid tapping mode. If user press RESET under rigid tapping, NC will set S128 OFF.

Notice : When user press RESET, please disable rigid tapping mode in order to prevent any unpredicted situation.

Rigid Tapping System Information

Rigid Tapping System Information #	Description
#21	Max error in rigid tapping travel
#22	Estimate value of rigid tapping 1 st speed compensation value
#23	Estimate value of rigid tapping 1 st acceleration speed compensation value
#24	Estimate value of rigid tapping 2 nd speed compensation value
#25	Estimate value of rigid tapping 2 nd acceleration compensation value
#26	Rigid tapping spindle following error

Rigid Tapping Machine Adjustment Procedure

- (1). Please increase the maximum allowable following error of Z axis direction (Para. # 1058 is approximately set to 3000). Also increase the maximum servo error of the spindle (Para. # 1075 is approximately set to encoder size per rotation of the spindle*10) in order to prevent warning when doing machine adjustment.

- (2). Confirm Spindle Rotational Direction (Para. # 1071)

Executing the following program :

M29S500

G91G84R-10Z-50F500

M28

M30

Check whether or not the spindle rotational direction is the same direction as M3 direction under non-rigid tapping mode. If not the same, please set Para. # 1071 to 1.

- (3). Acc/Deceleration Time Adjustment

To adjust acc/deceleration time (parameter 1059) and execute the following program:

M29S2500; rotational speed setting is the maximum rigid tapping speed.

G91G84R-10Z-50F2500

M28

M30

during executing must make the spindle drive devices current lower than the saturation value, and make the spindle to turn smoothly.

Please pay attention to whether or not the needed maximum rotational speed can be reached at

the upper enter frequency limit of the spindle. Using Toshiba as an example, adjust Para. # 373, 425, 426, 427, and 428.

If the spindle rotational speed is not smooth in high rotational speed, please refer to Para. # 371.

(4). Speed Compensation

a. Please set parameters 1064 、 1065 、 1073 、 1074 to zero and reboot the system after modifying.

b. Executing the following program in dry run one time (no need to put on any material)

M29S2500

G91G84R-10Z-50 F2500 P1000

M28

M30

To observe system data #22, and to enter this value into speed compensation parameter 1064. This value should be between 100~8000. After entering system data #24 into parameter 1073 (S22 → P1064 · S24→P1073) , reboot the system.

c. Executing the above part program again. If there is any shaking, please adding parameter 1066 from 0 to 20 in order to decrease shaking. This value shouldn't be as too big as possible, or the following error will increase. Recommending value is between 3~5.

(5). Acceleration Speed Compensation

a. Executing Step 4 program one more time, enter system data # 23 and #25 separately into acceleration speed compensation parameter 1065 and 1074 and then reboot the system. This value should be between 100~8000.

b. If shaking occurs, please adding parameter 1070 from 0 to 20 in order to decrease shaking. Recommending value is 10~15.


c. After completed, please observe system data #21. This is the biggest error of Z axis direction during tapping.

(6). Servo Error Amount Checking

a. Reset Para. # 1058 as the allowable error amount and it must be larger than system data #21. Recommend setting this value as 5 – 10 times larger than system parameter 21. During rigid tapping, when the error is over this setting value, tapping will stop.

b. Using the same principle to set Para. # 1075 as the allowable error amount for the spindle servo. Recommend to set this value as 5-10 times larger than the system parameter #26. During rigid tapping, when the error is over this setting value, tapping will stop.

5.2 Laser Compensation Procedure




Program Argument Description

1. A : Axis direction, 1 means X axis, 2 means Y axis and 3 means Z axis.
2. E : Delete backlash moving distance. If it is a positive value, at beginning of measuring, the program should move ABS (E) distance toward this axis positive direction. Then moving ABS (E) distance toward negative direction (Step 2 and Step 3 from the above Diagram). After measuring forward direction, first moving ABS (E) distance toward negative direction and then moving ABS (E) distance toward positive direction (Steps K+4 and K+5 from the above diagram). If it is a negative value, then using the opposite method. So, if this axis pitch error compensation direction is positive, then this argument must be set as negative value. If it is a negative direction compensation, then this argument must be set as positive.
 To delete backlash motion is to execute G01 and the feedrate is constant to 800mm/min. In order to catch the first point of Backward direction (which equals to the last point of the Forward direction, final point of Step K+3 or the starting point of Step K+6), so the setting value of this argument should be bigger than the setting value of Laser measuring software (such as RENISHAW, HP and etc.). If not, Step K+4 and Step K+5 should stop for a while.
3. K : Measure section, this argument value must be the same as the total section setting value of the pitch error compensation (Parameters 0112 – 0115) for the corresponding axis direction in NC system.

4. Q : Each section's measuring length. If it is positive direction compensation, please set setting value as positive value. If it is negative direction, please set setting value as negative value. This argument value must be the same as each pitch error compensation distance's setting value for the corresponding axis in NC system. (Parameters 1018 – 1021, NC system parameter values are positive permanently. Parameter 0118 will set the compensation direction.)
5. R : Measure starting coordinate (machine coordinate), this argument value must be the same as the starting position's setting value of pitch error compensation (Parameters 1046 – 1049) for the corresponding axis direction in NC system.
6. T : For each section's pause time, unit is sec.
7. U : When the setting is 1, after executing $[K+4]$ Step, pause argument T will continue moving toward the reverse direction at the desired time. When the setting is 0, pause argument T will continue moving toward the reverse direction immediately after executing $[K+4]$ Step. Please refer to Argument E for a description.


Executing Steps

1. Check NC parameter 0038 (Backlash and pitch error compensation unit) setting value is correct or not.
2. Correct O0000 content and modify each argument's (E, K, Q, R) corresponding NC parameter setting value.
3. Disable backlash or pitch error compensation function (Parameters 0117 and 0119); reboot system.
4. Executing reference point procedure.
5. After resetting laser measure software (such as RENISHAW 、HP and est.), executing O0000 program and measuring the error amount of each section's compensation length. The measure result is as below:



Putting the measured backlash (From the upper diagram, the vertical difference between two lines) into NC parameter (Parameters 0044 ~ 0047), and enable the backlash function (Parameter 0117); reboot the system.


After looking for the reference point, re-executing Step 5 and the measure result should be as following :



Setting pitch error compensation values (NC Parameters 0300 ~ 0349、0450 ~ 0499、0600 ~ 0649 and 0750 ~ 0799) . Assumed the LNC system pitch error compensation value uses the relative value setting. If the laser measure software (such as RENISHAW, HP, and est.) able to execute exchanging, there will be no problem. But, if can only use the absolute value to indicate, the exchanging method is as following: :

The N^{th} section relative error = the N^{th} section absolute error – the $(N-1)^{\text{th}}$ section absolute error ; The N^{th} section compensation setting value = -ive N^{th} section relative error.

Ideal Time Interval, ex:




table

range.

5.3 Double Ball Bar Measure – Backlash or Circular Spike


Backlash

Using DOUBLE BALL BAR to measure backlash, the result analyzing diagram is as following (only the Y axis part, which is called Positive Backlash). Able to see the Y axis backlash is 14um from the diagram. So please set this value (i.e., 14um) into Para. # 0045 and set BIT1 of Para. # 0117 to 1 in order to enable Y axis backlash compensation functions.



Reversal Spikes

Using DOUBLE BALL BAR to executing canned cycle testing, the result analyzing diagram is as below. In the diagram, the sticking out path in the direction changing area of each axis is called the circular spikes phenomenon.



Using +ive X axis direction as an example, each related parameter setting for circular spikes compensation value is as following :

Parameter 0812 : + X Axis Direction of Reversal Spikes Value

Unit : um

Description: This parameter is to set the circular compensation value of +ive X axis direction. Using the above diagram as an example. The +ive X axis direction circular spike is 11. So based on the principle, the parameter setting value is 11. However, since the present LNC series controller is using PULSE COMMAND control mode (spike compensation is added to CURRENT LOOP value), there will be some delay between the actual corresponding of servo motor and the commanding value. Based on past experience, the circular compensation value should be set as 8-9 times of the actual value. So according to the result from the above diagram, the recommend setting value for this parameter is 90. If this parameter setting value is 0, it means not to enable the + X axis spike compensation function.

(7). Parameter 0813: Reversal Spikes Time Interval of +ive X Axis Direction

Unit: disconnecting time interval

486IPC is 10.6ms

586IPC is 3.6ms

Description: To use this parameter to set the maintaining time of +ive X axis direction spike compensation. The corresponding +ive X axis spike maintaining time (spindle width) is displayed on the result analyzing diagram. The measure software will provide each measured Sampling Rate. Using RENISHAW as an example, 【Sample: 7.81 per sec information will be displayed on the left side of analysis diagram. This means the time interval for two closing points is $\frac{1}{7.81} = 128ms$. Need at least 3 points (during time $2 \times 128 = 256ms$) if want the analysis diagram to display multiple-angle sharp. Under this requirement, the parameter setting value is $\frac{256}{3.6} = 71$ (586IPC) . If this parameter setting value is zero, this means not to enable the +ive X axis spike compensation function.

(8). Parameter 0814: Reversal Spikes Delay Time of +ive X axis

Unit: discounting time interval

486IPC is 10.6ms

586IPC is 3.6ms

Description: Assumed the circular spike occurring point of +ive X axis is not in the direction changing center (on the X axis), but it occurs after direction changing. Then, need to set this parameter.

Please refer to the description of parameter 0813 for the calculating method of this setting value

5.4 Spindle Positioning Tuning

Design Purpose

This tuning is the preparation for M19 spindle positioning preparation. Its purpose is finding the correct position for spindle positioning. After setting, NC will adjust to this new setting position automatically.

Tuning Steps

After booting, make sure the system is in preparation complete mode.

(1). Confirm relating parameters are all correct.

Pr.0021 : Spindle positioning speed(rpm)

We recommend that at first spindle positioning tuning, you can slow down speed to about 100 ~ 200rpm. When the movement turns to be normal, you can enlarge the parameter and re-do tuning again. In order to avoid the difference caused by different speed, please do not change this parameter setting after tuning.

Pr. 0663 : Spindle positioning acc/dec time(ms)

Pr. 0084 : Spindle tuning benchmark

0 : Spindle tuning benchmark use external positioning sensor, this sensor signal should connect to transit board's HS1 or HS2. Usually, between spindle and motor side will have gear ratio design.

1 : Spindle tuning benchmark use motor encoder Z phase signal, no need to do external connection.

Usually, between spindle and motor side will be 1:1 transmission design.

Pr. 0184 : Pr. 0184 : Spindle external positioning sensor connects and type. This parameter will be only effective when Pr.0084 is 0.

Pr. 0190 : Spindle position control command format.

If you use KEB, Delta inverter with position card (or so called PG card), the command format is AB phase, if use TOSHIBA inverter with positioning card, command format is CW/CCW, others, please define as its exact situation.

Pr. 0057 : Spindle encoder feedback magnification factor.

Pr. 0195 : Spindle encoder feedback signal format.

This two parameters can be judged by executing M3S1000. If use TOSHIBA inverter, usually set Pr.0057 to be 1, Pr.0195 to be 1024.


Pr. 0049 ~ 0052、0178 ~ 0179、0181 ~ 0182 : Spindle 1-4 gear ratio, confirm using section (C097 ~ C099) and corresponding gear ratio is correct.

Pr. 0248 : Offset unit of spindle positioning point and benchmark.0 means the offset unit is pulse, 0 means the offset unit is 0.001 degree.


- (2). Please make Pr.1056 to be 0(Offset of spindle points and benchmark), Pr.0839 to be 2000.
(Spindle positioning allowable difference) press RESET to make the change to be valid.
- (3). Confirm spindle encoder feedback signal's CW/CCW, use manual mode to turn spindle to be CW rotation (the same with M3 direction). Monitor if the system info 10's change to be incremental, if for decreasing, please set Pr.0185's BIT4 to be 1 or change the spindle encoder a (feedback to NC) with signal cable.
- (4). Switch to MDI mode, execute M19 and monitor if spindle rotation direction is the same with M3. If it's different, please set Pr.0116 BIT4 to be 1, or change inverter's command signal cable A with signal cable.
- (5). Spindle rotation stops after 2 laps, system situation from 【cycle start】 to be 【preparation complete】
At this time, spindle is still on lock situation, cannot be turned by hand.
- (6). Press RESET to clear spindle lock, use hand to turn spindle to positioning point along with CW direction.
- (7). After confirmation of positioning point, set system info 10 value into Pr.1056, press RESET to make it valid.
- (8). Re-do M19 and confirm action complete, spindle position will be the same to setting position.
- (9). Confirm spindle positioning action is correct, to speed up positioning rotation
speed(recommendation value is 300) and minimum allowable difference (recommendation value is 1000)

5.5 Digital communication adjust instruction

1. Set the machine parameter and servo drive parameter as your machine combination, check following chart as reference.

Controller parameter Hardware: 3 axis engraving machine. XYZ, with M-II Servo. 1st SP DA control. Switch to controller PARAMETER page and enter machine maker permission. Then set as following sample. Remind: reboot controller after set the parameter.	
1	P1929 : M-II ON/OFF
2500	P1930 : M-II communication time (us)
101	P24 : X corresponds Servo name (Set X M-II servo drive nub to 1)
102	P25 : Y corresponds Servo name (Set Y M-II servo drive nub to 2)
103	P26 : Z corresponds Servo name (Set Z M-II servo drive nub to 3)
	Open the cover for the nub on Servo drive 
1	P29 : 1st SP corresponds Servo name must be 1
As re	P104 : Set X screw pitch (screw 5mm= 5000)
Based on actual	P105 : Set Y screw pitch (screw 5mm= 5000)
Based on actual	P106 : Set Z screw pitch (screw 5mm= 5000)
0	P156 : X command type 0)AB 1)CW 2)PD 3)V (must set to 0)
0	P157 : Y command type 0)AB 1)CW 2)PD 3)V (must set to 0)
0	P158 : Z command type 0)AB 1)CW 2)PD 3)V (must set to 0)
0	P191 : X ENCODER signal type (must set to 0)
0	P192 : Y ENCODER signal type (must set to 0)
0	P193 : Z ENCODER signal type (must set to 0)
1	P54 : Set X Feedback rate factor 1/2/4 (must set to 1)
1	P55 : Set Y Feedback rate factor 1/2/4 (must set to 1)

1	P56 : Set Z Feedback rate factor 1/2/4 (must set to 1)
0	P185 : Servo feedback reverse BIT(Must set to 0)
Based on actual	P1112 : X Pulse count for Encoder one turn(Please set same value with X Servo drive Pn.210)
Based on actual	P1113 : Y Pulse count for Encoder one turn Please set same value with Y Servo Pn.210)
Based on actual	P1114 : Z Pulse count for Encoder one turn (Please set same value with X Servo drive Pn.210.)
2	P116 : Servo output reserve BIT (Please set as axis moving direction.)
0	P195 : 1st SP encoder signal type(Must be 0)
1	P57 : 1st SP feedback ratio (Must be 1)
0	P171 : Spindle feedback reverse BIT(must be 0)
Based on actual	P1116 : 1st SP Pulse count for Encoder one turn, set as encoder spec.
0	P226 : Spindle output reverse BIT(must be 0)
0	P183 : 1st SP speed command type(must be 0)
0	P190 : 1st SP position command type(must be 0)
2	P15 : Set MPG stimulates mechanical axis name(Must be 2)
2	P28 : Set X MPG connecting axis(Must be 2)
2	P87 : Set Y MPG connecting axis(Must be 2)
2	P88 : Set Z MPG connecting axis(Must be 2)
X 、 Y 、 Z Servo parameter list <p>When set M-II Servo and M-II Spindle number, reboot the controller. Switch to machine maker, in the parameter page. It will have Servo parameter. Press EMG, under NOT RDY. Move the cursor to X parameter, press initial parameter then confirm the pop up window. The initialize complete.</p>	



Remind: must Servo must reboot after parameter setup.

1400H	Pn170 : Tuning-less Switch(cancel Tuning-less gain adjust will affect)
1048576	Pn20E : electric gear ratio (Numerators) (20Bit: 1048576)
5000	Pn210 : electric gear ratio (denominators) (screw 5mm=5000)
8881H	Pn50A : Input signal select 1[cancel (+) over travel signal (P-OT)].
8888H	Pn50B : Input signal select 2 [cancel (-) over travel signal (N-OT)]
211H	Pn50E : Output signal select 1[set when it has brake, as the pin define]
300H	Pn50F : Output signal select 2[set when it has brake, as the pin define]
65D3H	Pn511 : Input signal select 5 (use when it has measurement, as the pin define)
100H	Pn140 : mode Tracing switch(must be 100H)
10H	Pn160 : Vibration prevent switch(must be 10H)

2. Enter controller, move X, Y, Z to check if it can move correctly. If there has odd sounds and vibration, please check the machine mechanism. Due to the servo setting is soft enough, if the machine still has vibration issue, please check motor, flange and coupling.


Remind: Must adjust them properly, or it may unable to process next steps.

3. Use USB adjusts wire with SigmaWin+ to get each axis inertia ratio Pn103. Next use the heavy loads axis to do the Auto tuning, record the Pn100 value then initial the Servo parameter. Next, **Reset the power** then initialize the X, Y, Z as the instruction above, then **reset power** again.
4. Use the record Pn100 value, e.g. 1320. Please use Pn100:1300 level [Safety first] or [locating first] to

pick Pn101, Pn102, Pn 401 value. After each axis servo setup, move JOG check if there has odd sounds. If not, it can process the cutting test. If any servo has resonance tones, use the Servo parameter Pn408 and Pn409 to set resonance filter. If still have resonance tones, try to look up from mechanism.

Machine rigidity	Safety first (Engraving, machine center)			Locating ability		
Pn100_Kv [Hz]	Pn101_Ti [*0.01ms]	Pn102_Kp [1/s]	Pn401_Tf [*0.01ms]	Pn101_Ti [*0.01ms]	Pn102_Kp [1/s]	Pn401_Tf [*0.01ms]
500	1592	523	80	1273	785	80
550	1447	576	72	1157	863	72
600	1326	628	66	1061	942	66
650	1224	680	61	979	102	61
700	1137	733	57	909	109	57
750	1061	785	53	849	1178	53
800	995	837	50	796	1256	50
850	936	890	47	749	1335	47
900	884	942	44	707	1413	44
950	838	994	42	670	1492	42
1000	796	1047	40	637	1570	40
1050	758	1099	38	606	1649	38
1100	723	1151	36	579	1727	36
1150	692	1204	35	554	1806	35
1200	663	1256	33	531	1885	33
1250	637	1309	32	509	1963	32
1300	612	1361	31	490	2042	31
1350	589	1413	29	472	2120	29
1400	568	1466	28	455	2199	28
1450	549	1518	27	439	2277	27
1500	531	1570	27	424	2356	27
1550	513	1623	26	411	2434	26
1600	497	1675	25	398	2513	25
1650	482	1727	24	386	2591	24
1700	468	1780	23	374	2670	23
1750	455	1832	23	364	2748	23
1800	442	1885	22	354	2827	22

5. Use SigmaWin+ monitor the wave, check the final wave is normal or not. Adjust till normal.
6. If no problem, enter system then use JOG to check if there have odd sounds. If it is finem use cutting test to adjust.
7. Please combine with LNC digital controller tuning SOP to check if the operation goes correct.



$$Y = \frac{K_p \cdot 10 / 32767 \cdot 200 \cdot 1 / 60 \cdot \frac{1}{S} \cdot 10000}{1 + K_p \cdot 10 / 32767 \cdot 200 \cdot 1 / 60 \cdot \frac{1}{S} \cdot 10000} X = \frac{10.17284 K_p}{S + 10.17284 K_p} X$$

At this time, the position feedback loop gain is $10.17284 K_p$. Since the user requires the desired position loop gain is 30, so the K_p value needs to be set as $\frac{30}{10.17284} = 2.949$ on motion control board.

Testing Method :

$e = \frac{F}{K}$, e is the following error under stable condition (X axis reaches equal speed), please check system


data # 000, unit is the smallest unit of the system; F is the feedrate; K is the position feedback loop gain. In this example, when K is 30 and under the condition that feedrate is 2000mm/min, following error should be

$$e = \frac{2000000}{30} \cdot \frac{1}{60} = 1111 \text{ when X axis is in equal speed. When X axis is already in equal speed and the}$$

value of system data #000 is 1111 (or close to this number, sometimes there will be some difference due to moving forward one space), it means the parameter setting is correct.

A2 Parameter Adjustment when Encoder is installed besides Ball Screw

1. Connecting ball screw encoder feedback signal to NC, using it as position control.
2. Connecting motor encoder feedback signal to motor driver, using it as speed (velocity) and voltage control.



1. Since the position feedback V signal is returning to motor rpm, ball screw at this time, must set gear ratio to 1 even there is gear ratio is between motor and ball screw rpm. Adding the gear ratio factor into the position control feedback.
2. Assumed the initial parameter # 1112 is to set the encoder total output pulse value per rotation of motor. At this time, changing it to as the encoder total output pulse value per rotation of ball screw.

Example : X axis selects 2000rpm/10V motor , encoder total output pulse value per rotation of motor is 2500;
For machine structure, gear ratio is 4; pitch is 10mm, Please to install an additional 3000pulses/rev encoder on the ball screw side and also to connect the feedback signal to NC for position control. Under the condition that V command control method and the system loop gain is 30, how to set the related parameters?

Answer : Parameter #0001 : 30 (system feedback loop gain) .

Parameter #0054 : 4 (X axis multiple feedback factor) .

Parameter #1112 : 3000 (encoder total output pulse value per rotation of X axis ball screw) .

Parameter #0108 : ???? (X axis motor loop gain) →explain later.

Parameter #0156 : 3 (X axis control commanding mode) .

Parameter #0068 : 1 (denominator of X axis motor) .


Parameter #0100 : 1 (numerator of X axis ball screw) .

Parameter #0104 : 10000 (Pitch of X axis ball screw) .


$$CMR = \frac{3000 * 4}{10000} = 1.2 \text{ pulses/um} , \text{ which means 1um on X axis is correspond to 1.2 pulses that is}$$

the encoder total output signal of ball screw.

Control Loop is as below :



But, since there is no extra parameters for GR factor setting in position screw back, modification is as following:



Input and Output Relationship :

$$Y = \frac{K_p \cdot 10/32767 \cdot 200 \cdot 1/4 \cdot 1/60 \cdot 1/S \cdot 12000}{1 + K_p \cdot 10/32767 \cdot 200 \cdot 1/4 \cdot 1/60 \cdot 1/S \cdot 12000} X$$

$$= \frac{K_p \cdot 10/32767 \cdot 200/4 \cdot 1/60 \cdot 1/S \cdot 12000}{1 + K_p \cdot 10/32767 \cdot 200/4 \cdot 1/60 \cdot 1/S \cdot 12000} X = \frac{3.05185 K_p}{S + 3.05185 K_p} X$$


So, in this application example, parameter #0108 setting value is $200/4=50$ and the K_p setting value

$$\text{is } \frac{30}{3.05185} = 9.83 \text{ on PCC1620 motion control board.}$$

Weakness: under the present structure, when the motor actual loop gain cannot be completely divided by gear wheel ratio, please enter the closest integrate value. Also, there is a little bit difference between the whole position loop gain values and Parameter #0001 value. But, the position control has no problem at all. Strength: able to clear backlash error.

A3 Parameter Adjustment when using Linear Scale Control Method

1. Connecting linear scale feedback signal to NC, using it as position control.
2. Connecting motor encoder feedback signal to motor driver, using it as velocity (speed) and voltage control.



Example : X axis selects 2000rpm/10V motor, the total

Encoder output pulse value per rotation of motor is 2500; for the

machine structure, gear ratio is 4, pitch is 10mm. Also, please install an addition linear scale: every 20um will output one A/B pulse set; every 50mm will output one Z phase pulse and also sending the feedback signal to NC. Under the condition of V command control method and the system loop gain value is 30, how to set the related parameters?

Answer : Parameter #0001 : 30 (system loop gain) .

Parameter #0054 : 4 (X axis multiple feedback factor) .

Parameter #1112 : ???? (total encoder output pulse value per rotation of X axis motor) .→Explain later.

Parameter #0108 : ???? (X axis motor loop gain) .→Explain later.

Parameter #0156 : 3 (X axis control commanding mode) .

Parameter #0068 : 1 (denominator of X axis motor) .

Parameter #0100 : 1 (numerator of X axis ball screw) .

Parameter #0104 : ???? (X axis pitch) .→Explain later.



(Parameter #1112 * Parameter #0054) the initial definition is the total encoder output pulse value per rotation of X axis motor. This value is used as the distance between each index in zero return procedure. So after changing to linear scale, Parameter #1112 also needs to change to the pulse value that is sent out by linear scale. In this example, every 50 mm linear scale will produce one Z phase pulse, every 20 um will produce one A/B pulse set, so the pulse value that is produced by linear scale between each index is $50 * 1000 / 20 = 2500$ → the setting value of Parameter #1112 is 2500. For linear scale, every 20 um will produce one A/B pulse set. This means every 5um will produce one pulse after 4 ratio so the $CMR = 1 / 5 = 0.2$. But for NC,

$$CMR = \frac{P0058 \times P0054}{P0104} \times \frac{P100}{P68}$$

Since Parameter #1112 is to set the pulse value, which is produced by linear scale, between each index,

Parameter #0104 must set the distance between each linear scale index in order to make the CMR in NC the same as that in linear scale. In this example, Parameter #0104 must be set as 50000.

Control loop is as below :



Output and Input Relationship:

$$Y = \frac{K_p \cdot 10/32767 \cdot 200 \cdot 1/4 \cdot 1/60 \cdot 1/S \cdot 10000 \cdot 10000/50000}{1 + K_p \cdot 10/32767 \cdot 200 \cdot 1/4 \cdot 1/60 \cdot 1/S \cdot 10000 \cdot 10000/50000} X$$

$$= \frac{K_p \cdot 10/32767 \cdot (200 \cdot 10000)/(4 \cdot 50000) \cdot 1/60 \cdot 1/S \cdot 10000}{1 + K_p \cdot 10/32767 \cdot (200 \cdot 10000)/(4 \cdot 50000) \cdot 1/60 \cdot 1/S \cdot 10000} X = \frac{0.50864}{S + 0.50864 K_p} X$$

So, in this application case, the setting value of Parameter 0108 is $200 \cdot 10000 / (4 \cdot 50000) = 10$. The K_p setting value is

$$\frac{30}{0.50864} = 58.9808 \text{ On PCC1620 Motion Control Board.}$$

Weakness: Under current structure, when Parameter 0108 cannot be an integrate number, please enter the closest integrate number. At this time, there will be some difference between the whole position loop gain and parameter 0001, but the position control will not have any problem. Strength: able to clear backlash error and pitch error.

Appendix E Internet Setting Description

Network Connection Settings for the Controller

This controller can obtain the resource of a remote disk in Microsoft Network by "Internet Connection Sharing." Below are the steps to be made at the controller side & PC side, respectively, to install and to make relative settings to enable network connection sharing function.

At the controller side:

Install network software at the controller side. To install, boot the system with an OS floppy disk and select the installation option 3 "INSTALL NETWORK UTILITIES." (This step can be skipped if there is already a NET directory in the path of "C:\NET.")

Modify network configuration of the controller. There are two ways to make the modifications: **Method 1 : By DOS or by the operating interface of LNC software.**

Modify the file "C : \config.sys" of the controller

Modify

REM device=C : \NET\ifshlp.sys

Into

device=C : \NET\ifshlp.sys

Edit "C:\Net\2net.bat." Modify this line according to your needs:

C : \NET\net△use△N : △\\PCNET\share△12345△YES

Below are the definitions for each field in the line.

△represents a blank character.

PCNET" is the computer name in the Network, and "share" is the folder name shared by the computer.

"N" is the (virtual) disk of N: which is mapping to the sharing resource "\\PCNET\ share" in the network. (Please do not use "D:" which is used for different purposes; using "D:" will cause errors.)

"12345" indicates the password to log on PC. Passwords may or may not be required for different operating systems.

Window98 : For this system, instead of adding a new account, users can connect some network disk by sharing a folder with each other. Therefore, users must log on with the same password as set by PC for "folder-sharing" function.

Window2000 and WindowXP : The two systems have higher security levels for access permissions, so users of different identifications are required to enter different passwords as set by PC. If no password is set at PC side, network connection would fail unless PC permission is open for guest access (the setup of guest access is described in the later chapter).

For OS versions Ver.2.5 or versions earlier than Ver.2.5, some disk codes that are no longer applicable can still be shown. If this occurs when the controller is on-line, add the line C:\NET\net stop /yes before the line C:\NET\net initialize.

Verify if the settings are correct for the controller's file C : \NET\SYSTEM.INI and also for other relative settings in Network Neighborhood. Some programs might need to be modified as below (Please DO NOT change the settings that are not mentioned here) :

[network]

:

computername=LNCDOS

:

username=LNCDOS

:

workgroup=WORKGROUP

:

logondomain=WORKGROUP

:

- a. "computername=" is the controller name in the Network. Each controller should have its own unique name that is different from other disks in the Network. The default computer name is LNCDOS. Therefore, if there is more than one controller in a domain, this default name must be modified.
- b. "username=" is the controller name to log on PC. Except for Window98, all other operating systems require PC side to add a new user with the same name at the same time unless access permission is open to guests. The default user name is LNCDOS. Since a user can use the same name to log on repeatedly, there is no need to modify this name even if there is more than one controller in a domain.

"workgroup=" is the work group name of the controller when logging on the internet. Please set this value according to the Network which the controller belongs to. By default, it is set as "WORKGROUP."

"logondomain=" is the domain name of the controller when logging on the internet. Please set this value according to the domain that the controller belongs to. The setting method is basically the same as that of "WORKGROUP."

Method 2. By the operating interface of LNC software

- I. For 600 & 520 Series, the path to go to the configuration interface is <PARAM> NET SET;
for 500i/510i & 300i/310i Series, it is <PARAM> NET, as shown in the figures below

00000	N000000	EDIT	M-RDY	LNC																																												
NC NAME: LNCDOS USERNAME: LNCDOS GROUP: WORKGROUP				SAVE																																												
<table border="1"> <thead> <tr> <th>STATUS</th> <th>PC NAME</th> <th>SHARE DIR</th> <th>PWD.</th> </tr> </thead> <tbody> <tr> <td>E) O</td> <td>UICHAIN</td> <td>FORCNC</td> <td>*****</td> </tr> <tr> <td>F) O</td> <td>CHING-YI</td> <td>CNC</td> <td>*****</td> </tr> <tr> <td>G) O</td> <td>JESS</td> <td>TEST</td> <td>*****</td> </tr> <tr> <td>H) O</td> <td>ERIC</td> <td>CNC</td> <td>*****</td> </tr> <tr> <td>I) X</td> <td></td> <td></td> <td></td> </tr> <tr> <td>J) X</td> <td></td> <td></td> <td></td> </tr> <tr> <td>K) X</td> <td></td> <td></td> <td></td> </tr> <tr> <td>L) X</td> <td></td> <td></td> <td></td> </tr> <tr> <td>M) X</td> <td></td> <td></td> <td></td> </tr> <tr> <td>N) X</td> <td></td> <td></td> <td></td> </tr> </tbody> </table>				STATUS	PC NAME	SHARE DIR	PWD.	E) O	UICHAIN	FORCNC	*****	F) O	CHING-YI	CNC	*****	G) O	JESS	TEST	*****	H) O	ERIC	CNC	*****	I) X				J) X				K) X				L) X				M) X				N) X				RECON
STATUS	PC NAME	SHARE DIR	PWD.																																													
E) O	UICHAIN	FORCNC	*****																																													
F) O	CHING-YI	CNC	*****																																													
G) O	JESS	TEST	*****																																													
H) O	ERIC	CNC	*****																																													
I) X																																																
J) X																																																
K) X																																																
L) X																																																
M) X																																																
N) X																																																
PARAM. 1806OVER RANGE																																																
NC-SYS	USROPT	TLIM	NET SET																																													

Networking configuration screen for 600 & 520 Series

00000	EDIT	NRDY																								
NC NAME: LNCDOS USERNAME: LNCDOS GROUP: WORKGROUP																										
<table border="1"> <thead> <tr> <th>STAT</th> <th>PC NAME</th> <th>SHARE DIR</th> <th>PWD.</th> </tr> </thead> <tbody> <tr> <td>E) O</td> <td>UICHAIN</td> <td>FORCNC</td> <td>*****</td> </tr> <tr> <td>F) O</td> <td>CHING-YI</td> <td>CNC</td> <td>*****</td> </tr> <tr> <td>G) O</td> <td>JESS</td> <td>TEST</td> <td>*****</td> </tr> <tr> <td>H) O</td> <td>ERIC</td> <td>CNC</td> <td>*****</td> </tr> <tr> <td>I) X</td> <td></td> <td></td> <td></td> </tr> </tbody> </table>			STAT	PC NAME	SHARE DIR	PWD.	E) O	UICHAIN	FORCNC	*****	F) O	CHING-YI	CNC	*****	G) O	JESS	TEST	*****	H) O	ERIC	CNC	*****	I) X			
STAT	PC NAME	SHARE DIR	PWD.																							
E) O	UICHAIN	FORCNC	*****																							
F) O	CHING-YI	CNC	*****																							
G) O	JESS	TEST	*****																							
H) O	ERIC	CNC	*****																							
I) X																										
SAVE	RECO	RTN																								

Networking configuration screen for 500 & 300 Series

II. FIELD DEFINITIONS :

A. LNCDOS ◦ NC NAME: "computername" in the C:\Net\system.ini file. One name should not be used twice in the same domain. The default name is LNCDOS.

USERNAME: "username" in the C:\Net\system.ini file. This is the user to log on PC. The default name is LNCDOS

GROUP: "workgroup" in the C:\Net\system.ini file. This is the work group name of the controller when logging on the internet. The default name is WORKGROUP.

STATUS (for 600 & 520 Series) or STAT (for 500i & 300 Series):

Disk codes are used in C:\Net\2net.bat when logging on the internet.

Disk codes start from "E" to "N." There are 10 codes in total.

The drive codes are assigned by the system; users are not allowed to set the codes by themselves.

◦ & X after drive codes indicate the network status of the drive. X means off-line; ◦ means on-line.

Disk codes other than E ~ N existing before network setting is configured will be deleted after networking configuration is finished.

PC NAME: Enter the full computer name for the controller to get connected with PC. The maximum length allowed is 12 characters.

SHARE DIR: Enter the share folder name for the controller to get connected with PC. The maximum length allowed is 12 characters.

PWD. Set the password to get connected with PC. The content of the password is visible when being entered, but it will be converted into "*****" as soon as "Enter" key is pressed. The maximum length allowed is 12 characters.

DEFINITIONS OF FUNCTION KEYS :

B. Press the keys UP, DOWN, LEFT, & RIGHT to move cursor to the desired field.

Enter the information in the input text box, then press INPUT to upload the information to the field assigned by cursor.

Pressing INPUT without any information in the input text box will delete the original information in the field

Press PageUp & PageDown to switch between pages.

CANCEL : Leave this network setting and do not save changes.

ESC : The same to CANCEL button.

SAVE: Press SAVE to save changes, the network setting need to re-boot and make the setting valid.

Due to connectivity issues, sometimes the controller fails to log on the network. If this happens when the above functions are in use, the controller will try to connect to the same disk for 3 times before connecting to the next disk. After all connections are tried, the controller will then enter the system

NETWORK SETTINGS AT PC SIDE

Network Settings for Windows 98


Verify if the network card, internet cables, and relative protocols have been installed properly.

Verify if the “NetBEUI” protocol & the “File and printer sharing for Microsoft Networks” service have been installed. (Caution: DO NOT activate the network protocol “NWlink NetBIOS” which would cause network connection to fail.)


Click Start → Settings → Control Panel




Double-click on the Network icon to configure network settings




If the two network protocols "File and Printer Sharing for Microsoft Networks" & "NetBEUI" are not installed, please press Add.




If “File and Printer Sharing for Microsoft Networks” is not installed, please select Service; if “NetBEUI” protocol is not installed, please select Protocol. Then click Add.



If “File and Printer Sharing for Microsoft Networks” is not installed, highlight it on the service menu then click OK to complete installation.



If the network protocol “NetBEUI” is not installed, please highlight it on the menu as shown in the diagram below then click OK to complete installation.




Verify if Computer Name & Workgroup are set correctly.

(The setting of workgroup and logondomain in C : \net\system.ini must be the same as those at PC side. The computername in C:\net\2net.bat must be the same as PC's computer name.)


- A. Select Start→Settings→Control Panel.
- B. Double-click on the Network icon.

Verify if the settings of Computer Name & Workgroup are the same as those in C:\NET\2net.bat & C:\NET\system.ini. (Take the diagram below as an example, computername of 2net.bat should be set to “tenwho” ; workgroup of system.ini should be set to “Workgroup”).




Share a directory at PC side

- C. Go to Windows Explorer and create a new folder with the name "tmp" (The folder can be named differently by users).



- D. Left-click to select the “tmp” folder, then right-click and choose Sharing.




Please follow the steps below for configuration:

Click the Sharing tab.

By default, the Share Name and the newly-created folder are the same. Users can change name of the new folder, but it must be the same as the folder name in 2net.bat.

Verify the box of Full for Access Type.

You can choose either to set a password or not. If set, the password must be the same as that in 2net.bat.




NETWORK SETTING FOR WINDOWS 2000


1. Verify if a network card, internet cables, and the relative protocols have been installed properly.

Verify if the “NetBEUI” protocol & the “File and printer sharing for Microsoft Networks” service have been installed. (Caution: DO NOT activate the network protocol “Nwlink NetBIOS” which would cause network connection to fail.)


Select Start→Settings→Control Panel.




Double-click on the Network and Dial-up Connections icon.




Right-click on the Local Area Connection icon and left-click properties.




If the two network protocols “File and Printer Sharing for Microsoft Networks” & “NetBEUI Protocol” are not installed, verify the boxes and press Install to install them.




If “File and Printer Sharing for Microsoft NetWorks” is not installed, please select Service; if “NetBEUI Protocol” is not installed, please select Protocol. Then click Add.



If “File and Printer Sharing for Microsoft Networks” is not installed, highlight it on the menu then click OK to complete the installation.



If “NetBEUI Protocol” is not installed, highlight it on the menu then click OK to complete the installation.




Verify if “computername” & “workgroup” are set correctly.


(The setting of workgroup and logondomain in C:\net\system.ini must be the same as those at PC side.

The computername in C:\net\2net.bat must be the same as PC's computer name.)

- A. Right-click on “My Computer” icon on the desktop then left-click properties.
- B. Select the Network Identification tab. Verify if the settings of Full computer name & Workgroup are the same as those in C:\NET\2net.bat & C:\NET\system.ini. (Take the diagram below as an example, computername of 2net.bat should be set to “mark-nb” ; workgroup of system.ini should be set to “WORKGROUP”). Press Properties to change Full computer name & Workgroup.




To change a computer or workgroup name, modify it directly in the corresponding text box.




Share a directory at PC side


- C. Press Start → Run, enter “explorer,” and press OK to open explorer.




Create a new folder for sharing.




Left-click the new folder, and then right-click Sharing.



Click the Sharing tab, click to select Share this folder, and verify if the name in the Share name text box is the same as that in the 2net.bat file. Then click Permissions.



Select "Everyone" in the Share Permissions section, and check all the Allow boxes in the Permissions section. Then press OK.




ENABLE USER ACCESS :


There are two ways to enable user access. Please choose either one according to your need. The advantage of method 1 (recommended) is its convenience for installation, and there is no need to add a new user if each controller has its own username; however, the disadvantage is that its security level is low. On the contrary, the second method has a higher security level. But if there are different user names for different controllers, users are required to add a new user each time. Depending on the types of operating systems, there are different steps for setup as listed below :

Method 1 :


- D. Right-click the My Computer icon on the desktop and Left-click Manage.
- E. In the Manage pop-up menu, in the Users folder, left-click Guest, right-click, and then left-click "Set Password."



Leave the password boxes blank, and press OK.




Press OK again, and finish the procedure of password modification.




If there is a red cross over the Guest icon in the Users folder, right-click on Guest and select Properties.


A dialogue box will appear as the figure below, check the boxes of “User cannot change password” & “Password never expires” and uncheck the box of “Account is disabled.”




Next, set a higher access level for Guest. To do so, click Start>Run, and enter secpol.msc in the text box. Then press OK.




Click Local Policies → User Rights Assignment. Right-click the Access this computer from the network method, and then left-click Security



Click the Add button




After Add is clicked, a new dialog box will appear as the figure below. Click Guests, click Add, and press OK. Then the procedure to enable guest access is finished.




Method 2 :

- F. Right-click the My Computer icon on the desktop and Left-click Manage.
- G. Right-click the User folder and left-click New User.



A dialog box will appear as the figure below. Please enter the username same as that in the system.ini file, and enter the password same as that in the 2net.bat file. Check the boxes as the figure shown below, and then press Create to finish the procedure of enabling user access.



Network Settings for Windows XP Professional

2. Verify if a network card, internet cables, and the relative protocols have been installed properly.
Verify if the “NetBEUI Protocol” & the “File and printer sharing for Microsoft Networks” service have been installed. (Caution: DO NOT activate the network protocol “NWlink NetBIOS” which would cause network connection to fail.)

H. Because Microsoft does not support the network protocol “NetBIOS” (NetBEUI) in Windows XP, users must install the network protocol NetBEUI additionally from the Windows XP CD. Please follow the steps below for installation :

Insert the Windows XP CD-ROM into the CD-ROM drive.

Browse the Valueadd\MSFT\Net\NetBEUI folder.

Copy Nbf.sys to the directory %SYSTEMROOT%\System32\Drivers.

Copy Netnbfs.inf to the hidden directory %SYSTEMROOT%\Inf.



Note: To make the hidden directory visible, execute the following steps: :

Click Start, click Run, enter “explorer” in the text box, and then press ENTER.

Click Tools, click Folder Options, and then click the View tab.


Under Advanced Settings, and under Hidden files and folders, click Show hidden files and folders.




Note: %SYSTEMROOT% is a Windows environment variable for discerning the directory installed in Windows XP (Ex. C:\Windows). If users want to view the relative values of %SYSTEMROOT% or other environment variables, please enter “set” in the Command

Prompt window, then press “ENTER.”

Click Start → Control Panel.




Double-click Network Connections.




Right-click the Local Connection icon, then left-click properties.


If the two network protocols “File and Printer Sharing for Microsoft Networks” & “NetBEUI Protocol” are not installed, please press Install for installation.




If “File and Printer Sharing for Microsoft Networks” is not installed, please select Service; if “NetBEUI Protocol” is not installed, please select Protocol. Then click Add.



If “File and Printer Sharing for Microsoft Networks” is not installed, highlight it on the service menu then click OK to complete installation.



If the “NetBEUI Protocol” is not installed, please highlight it on the menu as shown in the diagram below then click OK to complete the installation. To validate the configuration, please reboot the system.




Verify if Computer name & Workgroup are set correctly.


(The settings of workgroup & logondomain in C : \net\system.ini must be the same as those at PC side.

The computername in C:\net\2net.bat must be the same as PC's computer name.)


- I. Click Start → Control Panel
- J. Double-click System



Select the Computer Name tab, and verify if the settings of Full computer name & Workgroup are the same as those in C:\NET\2net.bat & C:\NET\system.ini at the controller side. (Take the figure below for example, computername of 2net.bat must be set to “uichain1,” and workgroup of system.ini must be set to “WORKGROUP.” If you need to change the computer name or workgroup name, click Change to modify it.




To modify the computer name or workgroup name, make the revision directly in the corresponding text box.




Share a directory at PC side


- K. Click Start→Run, enter “explorer” in the text box, and then press OK.




- L. In Windows Explorer, select File → New → Folder. Name the new folder after the corresponding folder at the controller side such as share, pcscan, and so on




Uncheck Use simple file sharing mode. In Windows Explorer, select Tools→Folder Options, click the View tab, and uncheck the box of Use simple file sharing.




Right-click the new folder and left-click Sharing and Security.




Click the Sharing tab, check the box of Share this folder, and verify if the name in the Share name text box is the same as that in the 2net.bat file. Then click [Permissions].




Select "Everyone" as Group or user names, and checks all the Allow boxes in the Permissions for Everyone section.




If there is no Security tab in the dialog box, the steps for folder sharing is then finished. If there is, please click the Security tab, and the following figure is shown.




Click the Add button, and the Select users or Groups dialog box will appear as the figure below.



Click the Advanced button, and the following dialog box will be shown.




Press the Find Now button, and a list of users will appear in the bottom section of the dialog as shown below.




Click to select in the list the user that needs to be added. There are two ways to do this :

Method 1 : Open permissions to everyone by selecting everyone in the menu.


Method 2 : Add the user "lncdos" as assigned by "username=lncdos" in the c:\net\system.ini file. The username may not be "lncdos;" for its setting, please refer to the setting in system.ini.



Take the example of adding the new user "lncdos," after clicking to select the new user in the list, press OK, and the following figure will be shown.



Press OK again, and the following dialog box will appear. Please check the box of Full Control, and then press OK to complete the procedure of adding a new folder.



ENABLE USER ACCESS :


There are two ways to enable user access. Please choose either one according to your need. The advantage of method 1 (recommended) is its convenience for configuration, and there is no need to add a new user for controllers with different usernames; however, it has the disadvantage of a low security level. On the contrary, the second method has a higher security level. But if there are multiple controllers with different names, users are required to add a new user for each controller separately. Depending on the types of operating systems, there are different steps for setup as listed below :

Method 1 :

M. Press Start → My Computer → Manage.



Click to select the folder Local Users and Group → Users, Right-click Guest, and then left-click Set Password.



The following dialog box will appear, press the Proceed button to close the dialog box.



Leave the password boxes blank, and press OK.



Press OK again to finish password modification.




If there is a red cross over the Guest icon in the Users folder, right-click on Guest and select Properties.


A dialogue box will appear as the figure below, check the boxes of User cannot change password & Password never expires and uncheck the box Account is disabled :




Next, set a higher access level for Guest. To do so, click Start→Run, and enter secpol.msc in the text box. Then press OK.




Click Local Policies → User Rights Assignment, right-click the Deny logon locally policy, and then left-click properties.




Left-click Guest, and press the Remove button. After the access permission for Guest is open, press OK to close the dialog box.




Right-click the Access this computer from the network policy, left-click properties.




Click the Object Types button.



Check the box of Groups, and then press OK.




Press the Advanced button, press the Find Now button, and a list of users will be shown in the bottom section of the dialog box. Select Guests in the list, and press OK to complete the procedure of enabling guest access.




Method 2 :

- N. Click Start → My Computer → Manage
- O. Right-click the Users folder and left-click New User.



A dialog box will appear as the figure below. Please enter the username same as that in the system.ini file, and enter the password same as that in the 2net.bat file. Verify the boxes as the figure shown below, and then press **Create** to finish the procedure of enabling guess access.



Network Settings for Windows XP HOME Edition

3. Verify if the network card, internet cables, and relative protocols have been installed properly.


For this section, please refer to the above setting procedure of Windows XP Professional.

Verify if Computer name and Workgroup have been set correctly.


For this section, please refer to the above setting procedure of Windows XP Professional.

Share a directory at PC side


- P. Click Start → Run, enter “explorer” in the text box, and then press OK.




In Windows Explorer, select File → New → Folder. Name the new folder after the corresponding folder at the controller side such as share, pcscan, and so on.



Right-click the new folder and left-click Sharing and Security.



Click the Sharing tab, and verify the boxes of Share this folder on the network & Allow network users to change my files. Check that the name in the Share name text box is the same as that in the 2net.bat file, and then press OK to complete the procedure of file-sharing.




NETWORK WIRING

STEPS TO WIRE A CONNECTOR WITH CABLE

Network cable from controller to HUB :

Internal network wiring


PC side



This is the conductor side

White/Orange
Orange
White/Green
Blue
White/Blue
Green
White/Brown
Brown

Controller side




This is the conductor side

White/Orange
Orange
White/Green
Blue
White/Blue
Green
White/Brown
Brown

Network cable from the controller to PC :

One to one network wiring


PC side



This is the conductor side

White/Orange
Orange
White/Green
Blue
White/Blue
Green
White/Brown
Brown

Controller side



This is the conductor side

White/Green
Green
White/Orange
Blue
White/Blue
Orange
White/Brown
Brown

DISCONNECTION & IDLE TIME-OUT SETTINGS

There are two possible causes for users to experience a disconnection problem for “over idle time-out limit” when sharing a folder with network disks on-line :

Operating system: For the operating system at PC side that is Windows 2000 or Windows XP, by default, the idle time-out limit is set to 15 minutes.


Network card: PC side automatically shuts down the power of network cards. This usually happens for laptop users.

Below are the procedures to disable idle time-out limit ◦


OPERATING SYSTEMS :

For Windows 2000 :


1. Click **Start** → **Run**, enter “gpedit.msc” in the text box, and press **OK** to open the **Group Policy** configuration dialog box :



2. Set the policy Amount of idle time required before disconnecting session in Computer Configuration\ Windows Settings\ Security Settings\ Local Policies\ Security Options.




3. Double-click on the principle, and a dialog box will appear as the figure below. Enter "0" in the text box, which means no disconnection at all time. To validate the configuration, please reboot the system.

**For Windows XP :**

Click Start → Run, enter "gpedit.msc" in the text box, and press OK to open the Group Policy configuration dialog box.

Set the policy Microsoft network server: Amount of idle time required before suspending session in Computer Configuration\ Windows Settings\ Security Settings\ Local Policies\ Security Options.


Double-click on the principle, and a dialog box will appear as the figure below. Enter "0" in the text box, which means no disconnection at all time. To validate the configuration, please reboot the system.



NETWORK CARD :


For Windows 2000 :

Click **My Network Places** → Right-click properties → **Local Area Connection** → Right-click properties → Click the **Configure** button of **General** tab → Click the **Power Management** tab, and uncheck the box of **Allow the computer to turn off this device to save power** as the figure below :



For Windows XP :


Click My Network Places → Right-click properties → Local Area Connection → Right-click properties → Click the Configure button of General tab → Click the Power Management tab, and uncheck the box of Allow the computer to turn off this device to save power as the figure below :



VIRUS SCAN BY A NETWORK DRIVE :

If the controller is infected with a virus, enter the system and scan for virus. If the virus cannot be removed, you can try to scan the virus by a network drive. The setting procedure is as below.

1. Follow the installation method of the virus scan program to install the program in the C:\PCSCAN directory at PC side. Or, double-click the PCSCAN.EXE file in the directory of network settings to decompress and move the files automatically to the C:\PCSCAN directory.
2. Please set access permission of the **PCSCAN** file to “read-only”.



3. Make an emergency boot disk :
 - a. Insert a disk into the PC drive.
 - b. Double-click the program NRC1.0.exe.
 - c. “1.0” of NRC1.0.exe indicates the version of the program.
4. Modify the following contents in the boot disk :
 - a. A:\NET\SYSTEM.INI
 - b. The shared file PCSCAN in A:\NET\2NET.BAT
 For example A:\net\net use u: \\uichain1\pcscan /yes
 For further details, please refer to Appendix D “Networking Settings.”
5. After the boot disk has been reconfigured and set to “read-only,” insert the disk into the controller drive

and reboot the system. Please change the system configuration to boot off by a disk; in so doing, the controller will connect to network disks at the same time as entering the system.

6. During initial connection, because the disk is set to “read-only” and the network drive cannot write to the disk, the message “Write protect error writing drive A, Abort, Retry, Fail?” will appear. When this occurs, please press “f” to discharge the message and continue to connect to the network.
7. When the connection is successful, switch manually to the pcscan directory. For the above example, switch to U disk (U:\\pcscan).
8. Execute pcscan.exe

COMMON PROBLEMS OF NETWORK DISKS :

Common network errors at the controller side :

Error 5: Access has been denied

Definition: Access has been denied.

Troubleshooting:

Verify if there is any new username in the system.ini file at PC side; and also verify if guest access of the file is enabled.

Verify if the file names at PC side and in the 2net.bat file are the same.

Error 52: duplicate workgroup or computer name exists on the network.

Definition: Duplicate workgroup or computer name exists on the network.

Troubleshooting: Change the computer name of the controller; meaning, change "computername" in the system.ini file.

Error 53: The computer name specified in the network path cannot be located.

Definition: The specified computer name does not exist or is not open for access.

Troubleshooting:

a. Verify if the network connection light of network cable has turn on.

Verify if the NetBEUI Protocol has been installed.

Verify if the contents of computername and workgroup are the same as those in 2net.bat & system.ini at the controller side.

Reboot the system with the emergency boot disk to connect to a network disk and scan the system by using the connected disk.

Error 55: This resource does not exist on the network.

Definition: The share file does not exist, or the share file at the controller side does not have authority to access.

Troubleshooting:

b. Verify if the file names at PC side and in the 2net.bat file at the controller side are the same.

Verify if the file at PC side is open for access, and the access method is set to full control.

Verify if the user password at PC side has expired. To verify, reset the user password and check the box of Password never expires. Then reconnect to see if the connection works.

Error 58: The network has responded incorrectly.

Definition: Incorrect response of the network.

Troubleshooting:

c. Verify if the user password at PC side has expired.

Verify if the user password at PC side is the same as that in the 2net.bat file at the controller side.

Error 67: The specified shared directory cannot be found.

Definition: The specified share directory cannot be found.

Troubleshooting:

d. Verify if the file of PC side has the permission for file sharing.

Verify if the file names at PC side and in the 2net.bat file are the same.

Error 85: The local device name is already in use.

Definition: The local device name is already in use.

Troubleshooting: Verify if there is any duplicate disk code in the 2net.bat file at the controller side.

Error 2184: The service has not been started.

This error message can be ignored.

Error 3658: The IFSHLP.SYS driver is not installed.

Definition: The IFSHLP.SYS driver is not installed.

Troubleshooting: Verify if "rem" of rem device=C:\NET\ifshlp.sys in the C:\config.sys file has been deleted.

Appendix C Key Code switch

1 Summary


This controller offers the standard keyboard and the transformation between C bit and S bit codes, this can increase the convenience of CNC controller operates and controls.

2 Applicable edition


Milling machine V3, V6 and lathe V3 are applicable.

3 Instruction

How C bit transfer to the ASCII Code



How ASCII transfer to the S bit



HMI operating instruction

- From ASCII Code to S bit is a real-time output. When the related key activates, the S bit and HMI will response the input method.
- C bit to ASCII Code is for stimulation the standard keyboard by C bit. While the settled C bit been activating, HMI will output to the remaining key, also activate the code relay to the key.
- Except the Shift key function, the C bit and ASCII Code only activate single C bit.

C/S bit range

- C bit to ASCII range located at C401~ C488

- ASCII to S bit range located at S401~ S488

Standard PC keyboard corresponds to S bit

Keyboard button	S bit	Keyboard button	S bit	Keyboard button	S bit	Keyboard button	S bit
ESC	401	[426	,	451	Num5	476
1	402]	427	.	452	Num6	477
2	403	Enter	428	/	453	+	478
3	404	Left Ctrl	429	Right Shift	454	Num1	479
4	405	A	430	*	455	Num2	480
5	406	S	431	Left Alt	456	Num3	481
6	407	D	432	Space	457	Num0	482
7	408	F	433	Caps Lock	458	.	483
8	409	G	434	F1	459	F11	487
9	410	H	435	F2	460	F12	488
0	411	J	436	F3	461		
-	412	K	437	F4	462		
=	413	L	438	F5	463		
BackSpace	414	;	439	F6	464		
Tab	415	'	440	F7	465		
Q	416	`	441	F8	466		
W	417	Left Shift	442	F9	467		
E	418	\	443	F10	468		
R	419	Z	444	Num Lock	469		
T	420	X	445	Scroll Lock	470		
Y	421	C	446	Num7	471		
U	422	V	447	Num8	472		
I	423	B	448	Num9	473		
O	424	N	449	-	474		
P	425	M	450	Num4	475		

C bit corresponds to standard PC keyboard, table 1

C bit	Shift key status		C bit	Shift key status	
	OFF	ON		OFF	ON
401	Esc	Esc	426	[{
402	1	!	427]	}
403	2	@	428	Enter	Enter
404	3	#	430	A	A
405	4	\$	431	S	S
406	5	%	432	D	D
407	6	^	433	F	F
408	7	&	434	G	G
409	8	*	435	H	H
410	9	(436	J	J
411	0)	437	K	K
412	-	_	438	L	L
413	=	+	439	;	:
414	BackSpace	BackSpace	440	'	"
415	Tab	Tab	441	`	~
416	Q	Q	442	Left Shift	Left Shift
417	W	W	443	\	
418	E	E	444	Z	Z
419	R	R	445	X	X
420	T	T	446	C	C
421	Y	Y	447	V	V
422	U	U	448	B	B
423	I	I	449	N	N
424	O	O	450	M	M
425	P	P	451	,	<

C bit corresponds to standard PC keyboard, table 2

C bit	Shift key status		C bit	Shift key status	
	OFF	ON		OFF	ON
452	.	>	481	Num3	PgDn
453	/	?	482	Num0	Ins
454	Right Shift	Right Shift	483	.	Del
455	*	*	487	F11	F11
457	Space	Space	488	F12	F12
459	F1	F1			
460	F2	F2			
461	F3	F3			
462	F4	F4			
463	F5	F5			
464	F6	F6			
465	F7	F7			
466	F8	F8			
467	F9	F9			
468	F10	F10			
471	Num7	Home			
472	Num8	UP			
473	Num9	PgUp			
474	-	-			
475	Num4	Left			
476	Num5				
477	Num6	Right			
478	+	+			
479	Num1	End			
480	Num2	Down			

Notes

- Due to HMI used some of the keyboard for controlling the interface, users should be careful on C bit to ASCII transferring.
- Because of ASCII to S bit is real-time output, the application of the activated S bit will decide by Ladder.

HMI keyboard table

Keyboard button	C/S bit	HMI Operate instruction
`	441	CNC Reset
F2	460	Main Menu 01
F3	461	Main Menu 02
F4	462	Main Menu 03
F5	463	Main Menu 04
F6	464	Main Menu 05
F7	465	Main Menu 06
F8	466	Sub Menu 01
F9	467	Sub Menu 02
F10	468	Sub Menu 03
F11	487	Sub Menu 04
F12	488	Sub Menu 05
Num0	482	<POS> Group
Num1	479	<PROG> Group
Num2	480	<OFFSET> Group
Num3	481	<CAM> Group
Num4	475	<GRAPH> Group
Num5	476	<DGNOS> Group
Num6	477	<SOFTPL> Group
Num7	471	<PARAM> Group

4 Add and edit the parameter

4.1 Parameter 0658

Add and Modify	Modification
Chinese Display	Parameter 0658 Keyboard trasfrmation 0)Disable 1)Enable
English Display	Pr0658 KEY CODE 0)DISABLE 1)ENABLE
Classification	Operation
Enable time	Restart
Permissions	Manufacturers
Setting range	0~1
Dufalt Value	0
Unit	Non
Applicable model	Milling machine V3, milling machine V6 and V3 series system of lathe
Note	0 : Disable. 1 : Enable.

5 Add and Edit MLC Signal

5.1 S401~488

Chinese Display	S401~488 Key code:
English Display	S401~488 Key code:
Applicable model	Milling machine V3, milling machine V6 and V3 series system of lathe
Note	Please follow the instruction

5.2 C401~488

Chinese display	C401~488 Key code:
English display	C401~488 Key code:
Applicable model	Milling machine V3, milling machine V6 and V3 series system of lathe
Note	Please follow the instruction

- 6 Add and Edit the alarm and warning**
 - 7 Add and Edit the system information**
 - 8 Add and Edit the G code and M code**
 - 9 Add and Edit the system variable**
 - 10 Remark**
-