

RS OEMax

CSD5 Servo Drive

Index Manual

Catalog Number(s): CSD5_xxBX1

Important User Information

Solid state equipment has operational characteristics differing from those of electromechanical equipment. Because of this difference, and also because of the wide variety of uses for solid state equipment, all persons responsible for applying this equipment must satisfy themselves that each intended application of this equipment is acceptable.





In no event will RS Automation Co., Ltd. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, RS Automation Co., Ltd. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by RS Automation Co., Ltd. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of RS Automation Co., Ltd. is prohibited.

Throughout this manual, when necessary, we use notes to make you aware of safety considerations.

| | |
|---|--|
| WARNING  | Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss. |
| IMPORTANT | Identifies information that is critical for successful application and understanding of the product. |
| ATTENTION  | Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss. Attentions help you identify a hazard, avoid a hazard, and recognize the consequence |
| WARNING  | Labels may be located on or inside the equipment, for example, a drive or motor, to alert people that dangerous voltage may be present. |
| BURN HAZARD  | Labels may be located on or inside the equipment, for example, a drive or motor, to alert people that surfaces may be at dangerous temperatures. |

Summary of Change

You will see change bars to the left or right of a paragraph throughout this manual to help you quickly indentify revisions.

| Manual Revision | Changes | Date |
|-----------------|---------|-----------|
| A | N/A | June 2011 |

Preface

Read this preface to familiarize yourself with the rest of the manual.

About This Publication

This manual provides detailed information for the indexing of the CSD5 Servo Drive.

Who Should Use this Manual

This manual is intended for engineers or technicians directly involved in the installation and wiring of the CSD5 Servo Drive, and programmers directly involved in the operation, field maintenance, and integration of the CSD5 Servo Drive.

If you do not have a basic understanding of the CSD5 Servo Drive, contact your local RS Automation Co., Ltd. sales representative before using this product, for information on available training courses.

Additional Resources

The following documents contain additional information concerning related CSD5 servo drive products.

| For | Read This Document |
|--|--|
| Information on the installation of your CSD5 servo drive | CSD5 Servo Drive Installation Instructions |
| Information about the operation of your CSD5 Servo Drive | CSD5 Servo Drive User Manual |

You can view or download publications at <http://www.oemax.co.kr> or <http://www.rsautomation.co.kr> To order paper copies of technical documentation, contact your local RS Automation distributor or sales representative.

Summary of Change

| | | |
|---------|--------------------------------------|-----|
| Preface | About This Publication | P-1 |
| | Who Should Use this Manual | P-1 |
| | Additional Resources | P-2 |

Chapter 1

| | | |
|----------|--|-----|
| Overview | Introduction | 1-1 |
| | What is indexing. | 1-1 |
| | Index function | 1-2 |
| | Index Elements | 1-2 |
| | Indexing Types | 1-2 |
| | Position/Distance | 1-3 |
| | Velocity, Acceleration, Deceleration | 1-4 |

Chapter 2

| | | |
|--------|---------------------------------------|-----|
| Wiring | Introduction | 2-1 |
| | Control Mode Setting. | 2-1 |
| | I/O Signal(I/O) | 2-4 |
| | Function of I/O Signal. | 2-6 |
| | I/O Signal Allocation Method. | 2-9 |

Chapter 3

| | | |
|----------|---|-----|
| Operator | Introduction | 3-1 |
| | Operator of Parameter Setting | 3-1 |
| | Index Mode Setting | 3-4 |
| | Index Parameter Setting. | 3-5 |

Chapter 4

| | | |
|-------|----------------------------------|------|
| Index | Introduction | 4-1 |
| | I/O Signal Description | 4-1 |
| | Auto Start Index. | 4-5 |
| | Software Limit | 4-6 |
| | Homing. | 4-11 |
| | Index Option | 4-24 |
| | Dwell Time. | 4-28 |
| | Operation Mode Function. | 4-29 |
| | Monitor Mode Function | 4-29 |

Chapter 5

| | | |
|--------|----------------------------------|-----|
| Tuning | Introduction | 5-1 |
| | Tuning by Gain Setting | 5-1 |
| | Gain Setting Flowchart | 5-5 |
| | Automatic Gain Setting | 5-8 |

| | | |
|-------------------------------------|--|------|
| | Chapter 6 | |
| Applications | Introduction | 6-1 |
| | Basic Setting of Servo Drive | 6-1 |
| | Basic Setting of Index Operation | 6-5 |
| | Homing Setting | 6-9 |
| | Index Operation Setting. | 6-17 |
| | Index Operation. | 6-23 |
| | Chapter 7 | |
| Inspection and Protection Functions | Introduction | 7-1 |
| | Inspection Function. | 7-1 |
| | Protection function | 7-3 |
| | Appendix A | |
| Parameter List | Introduction | A-1 |
| | Standard Parameter List. | A-1 |
| | Standard Parameter Description | A-9 |
| | Index Parameter List | A-51 |
| | Index Parameter Description. | A-55 |
| | Appendix B | |
| RSWare | Introduction | B-1 |
| | RSWare | B-1 |

Overview

Introduction

Use this chapter to briefly understand the idea of indexing of a servo drive. This chapter also describes the elements for indexing, such as position unit and acceleration, etc.

| Topic | Page |
|--------------------------------------|------|
| Introduction | 1-1 |
| What is indexing | 1-1 |
| Indexing Function | 1-2 |
| Index Elements | 1-2 |
| Indexing Types | 1-2 |
| Position/Distance | 1-3 |
| Velocity, Acceleration, Deceleration | 1-4 |

What is indexing

Servo drive is a device to control a servo motor with a pulse train or an analog signal coming from an external controller, which is responsible for the control of physical dimensions such as displacement, speed or torque. It means that a servo drive is an actuator but not a controller, just implementing the control with a command from the external controller.

An external controller determines a position, speed or torque depending on control scheme, usually based on the feedback from a servo drive. However, some applications do not require feedback-based command from the controller, but a servo drive just follows a pre-defined sequence from the controller. Especially, indexing requirement is much simpler in such applications. They just need a movement with an accurate position information regardless of other control inputs.

Now, the CSD5 Servo Drive provides a simple indexing for one axis, not requiring any command from a controller, but providing programmed position control. It is quite simple function. Given an index in a parameter, then the CSD5 Servo Drive starts indexing. Since any other external device is not required, the system configuration would be so simple and implemented very fast.

The CSD5 Servo Drive has a special routine to provide indexing. Indexing starts to work when the control mode is set to Indexing. The CSD5 Servo Drive is able to support 8 indexes with each different speed and provide various travel modes over 8 indexes. The operation can be paused or aborted


by I/O signals. Also, the CSD3 Plus Servo Drive provides various homing modes.

Indexing Function

The CSD5 servo drive indexing supports 64 indexes. The position counter for indexing uses 32bit signed long type. Its range is -2,147,483,648 ~ 2,147,483,647. Therefore, the indexing of absolute type is available within this range. If the absolute indexing is operated in the position exceeding this range, a fault is generated.

Index Elements

In order to make a movement, it is necessary to define four elements: a position (where to move), a velocity (how fast it moves), acceleration time and deceleration time to reach the speed and make a stop. The position is defined as a number of pulses or μm , and either in the incremental or in the absolute coordinate. Up to 8 index data can be programmed. The CSD5 supports only trapezoidal velocity profile. The S-curve is not available.



Indexing Types

There are two kinds of coordinate systems to express position. In the absolute coordinate system, all the Indexes are expressed based on one reference location, called as Home or Origin. In the incremental coordinate system, a position is defined with a relative distance from its previous position.

A user can select either option in the 1st digit of IN02.00~63 (absolute and incremental). When this value is 0, the coordinate system is absolute and When this value is 1, the coordinate system is incremental.


TIP

A 7-Seg. digits increase from right to left.

Absolute

The move from its starting position to the specified Position: absolute coordinate base.

The axis must be homed before the drive can execute an absolute index.



Incremental

The moves from its starting position the specified Distance.

Position/Distance

Position

For Absolute mode moves, the fixed position to which the motor will travel.

Distance

For Incremental moves, the relative distance the motor will travel.

A user can enter total 64 Position/Distance for 64 indexes. For the Index 0 to the Index 63, use IN04.00~63 to enter its Position/Distance. The input range is -2,147,483,647~2,147,483,647 and its unit is Counts.

TIP

The CSD5 servo drive supports only pulse unit coordinate systems. The other coordinate systems are not available. But a user can use "User Defined Distance Per Motor Revolution" from Firmware Version 1.20

And the CSD5 servo drive uses 4 multiplier counts in index mode.

Velocity, Acceleration, Deceleration

Velocity

Maximum velocity during an index move.

Enter velocity for each movement into the velocity parameter of IN08.00~63. The input range is 0~6000 and its unit is rpm. The default value is 750.

TIP

Refer to the A-52 page "Index Velocity" for the velocity parameter.

TIP

The velocity input range is 0~6000 but maximum velocity must be lower than motor's maximum velocity.

Acceleration

Maximum acceleration during an index move.

A user can enter total 64 acceleration for 64 indexes. Enter acceleration for each movement into the acceleration parameter of IN10.00~63. The input range is 1~2,147,483,647 and its unit is 10^2 rev/sec . The default value is 6250. The Acceleration slope is calculated by velocity, resolution and distance as shown below.

Acceleration calculation for rotary motor

Acceleration parameter unit : rev/sec^2

$$\text{Acceleration (Counts/sec}^2\text{)} = (\text{acceleration parameter value} \times 0.01) (\text{rev/sec}^2) \times 4 \times \text{resolution(Counts/rev)}$$

Acceleration calculation for linear motor

Acceleration parameter unit : mm/sec^2

$$\text{Acceleration}(\text{Counts}/\text{sec}^2) = \text{acceleration parameter value} (\text{rev}/\text{sec}^2) \times 4 \times \text{lines per meter}(\text{Counts}/\text{m}) \times (\text{m}/1000\text{mm})$$

TIP

Refer to the A-53 page "Index Acceleration" for the Acceleration parameter.

Deceleration

Maximum deceleration during an index move.

A user can enter total 64 deceleration for 64 indexes. Enter deceleration for each movement into the deceleration parameter of IN11.00~63. The input range is 1~2,147,483,647 and its unit is $10^2\text{rev}/\text{sec}$. The default value is 6250. The deceleration slope is calculated by the same to calculate acceleration slope.

TIP

Refer to the A-53 page "Index Deceleration" for the Deceleration parameter.

TIP

'Enable' means a status that it's using or can use I/O signal and 'Disable' means a status that it's not using or can not use I/O signal

Wiring

Introduction

This chapter describes the information on wiring connected to the servo drive and control mode for indexing.

| Topic | Page |
|----------------------|------|
| Introduction | 2-1 |
| Control Mode Setting | 2-1 |
| I/O Signal(I/O) | 2-4 |
| I/O Signals | 2-6 |
| I/O Settings | 2-9 |

For indexing, the CSD5 servo drive uses general servo parameters, position data, travel mode and I/O signals. Since general servo parameters are also used for Indexing, refer to The CSD5 Servo Drive User Manual (The CSD5-UM001) for more information about parameters related to general servo operations.

Control Mode Setting

Control Mode Type

As in the table below, there are 5 kinds of basic control modes and 6 kinds of associated control modes. Combinational control mode cannot be used by combining more than 3 types. Make sure to combine two types only. The table below shows the control mode types.

Table 2.1 Control Mode Type












| | Display | Description |
|--------------------|--|-----------------|
| Basic control Mode |  | Position mode |
| |  | Speed mode |
| |  | Torque mode |
| |  | Multi-step mode |
| |  | Index mode |

Table 2.1 Control Mode Type


| | Display | Description |
|-------------------------|--|----------------------------------|
| Associated control Mode |  | Speed + position mode |
| |  | Torque + speed mode |
| |  | Torque+ position mode |
| |  | Multi-step speed + position mode |
| |  | Multi-step speed + speed mode |
| |  | Multi-step speed + torque mode |

Control Mode Setting Method

Describes control mode setting method focusing on the key button manipulation.

Apply the power and set it as shown in the flowchart below.

Flowchart of the Control Mode




Black key button represents that it is pressed.

I/O Signal (I/O)

A user can configure I/O signals in the CSD5 servo drive.

I/O Connection Diagram

This is the circuit diagram of a connector for I/O signal. It is divided into input on the left and output on the right.



(1) Factory default values

ON, OFF signal as per high/low level can change in input because photocoupler is possible for two-way wiring. But the signal turns ON at low level in output.

Table 2.2 I/O) Pin Arrangement for host controller connections

| Pin | Symbol | Description | Pin | Symbol | Description |
|-----|-----------|---|-----|----------------|---|
| 1 | +24V IN | External 24 [V] input for contact point input | 26 | INPUT8 | Digital input 8 |
| 2 | +24V IN | External 24 [V] input for contact point input | 27 | INPUT9 | Digital input 9 |
| 3 | INPUT1 | Digital input 1(/SV-ON) ⁽¹⁾ | 28 | INPUT10 | Digital input 10 |
| 4 | INPUT2 | Digital input 2(P-OT) ⁽¹⁾ | 29 | AM+ | Encoder signal output A+ |
| 5 | INPUT3 | Digital input 3(N-OT) ⁽¹⁾ | 30 | AM- | Encoder signal output A- |
| 6 | INPUT4 | Digital input 4(P-CON) ⁽¹⁾ | 31 | BM+ | Encoder signal output B+ |
| 7 | INPUT5 | Digital input 5(A-RST) ⁽¹⁾ | 32 | BM- | Encoder signal output B- |
| 8 | INPUT6 | Digital input 6(N-TL) ⁽¹⁾ | 33 | IM+ | Encoder signal output Z+ |
| 9 | INPUT7 | Digital input 7(P-TL) ⁽¹⁾ | 34 | IM- | Encoder signal output Z- |
| 10 | ESTOP | ESTOP(Default: Disable) | 35 | PS+ | Absolute Encoder Position data output+ |
| 11 | PLUS+ | Position command pulse input+ | 36 | PS- | Absolute Encoder Position data output- |
| 12 | PLUS- | Position command pulse input- | 37 | FAULT1/OUTPUT4 | Alarm code output 1/Digital output 4 |
| 13 | SIGN+ | Position command sign input+ | 38 | FAULT2/OUTPUT5 | Alarm code output 2/Digital output 5 |
| 14 | SIGN- | Position command sign input- | 39 | FAULT3/OUTPUT6 | Alarm code output 3/Digital output 6 |
| 15 | HF_PULS+ | High frequency position command pulse input+ | 40 | FCOM/OUTCOM | Alarm code/Output ground |
| 16 | HF_PULS- | High frequency position command pulse input- | 41 | OUTPUT1+ | Digital output 1+(P_COM+) ⁽¹⁾ |
| 17 | Z-PULSE+ | Encoder Z-pulse output (Open collector) | 42 | OUTPUT1- | Digital output 1-(P_COM-) ⁽¹⁾ |
| 18 | Z-PULSE- | Encoder Z-pulse output (Open collector) | 43 | OUTPUT2+ | Digital output 2+(TG_ON+) ⁽¹⁾ |
| 19 | VCMD+ | Speed command input+ | 44 | OUTPUT2- | Digital output 2-(TG_ON-) ⁽¹⁾ |
| 20 | VCMD- | Speed command input- | 45 | FAULT+ | Alarm generation signal output+ |
| 21 | ICMD+ | Current command input+ | 46 | FAULT- | Alarm generation signal output- |
| 22 | ICMD- | Current command input- | 47 | OUTPUT3+ | Digital output 3+(BK+) ⁽¹⁾ |
| 23 | HF_SIGN+ | High speed position command sign input+ | 48 | OUTPUT3- | Digital output 3-(BK-) ⁽¹⁾ |
| 24 | HF_SIGN- | High speed position command sign input- | 49 | 24V_PULS+ | Open collector pulse input + for 24 [V] level |
| 25 | 24V_SIGN+ | Open collector sign input + for 24 [V] level | 50 | NC | Not Available |

⁽¹⁾ Factory default values

I/O Signals

I/O Signals are actual control signals for Indexing, i.e. starting a movement and making a stop. Once all index data is set up, I/O signals control indexing.

I/O Signal Configuration

A user can configure I/O signals in the CSD3 servo drive.

Index parameters can set Modbus because all index parameters had mapped Modbus address. The table below added Modbus Address. Refer to the CSD5 Servo Drive Modbus Manual for more information

Digital Input signals

Table 2.3 I/O Sequence Input Signal

| Type | Description | Mode | Modbus Address [Position] |
|---|---|---------------------------------|---------------------------|
| </SV-ON> Servo-ON | When the servo is set to ON, voltage is applied to the servo motor; when it is set to OFF, voltage is cut off. | All | 3000 [0] |
| </A-RST> Alarm Reset | It disables the Servo's Alarm. | All | 3000 [4] |
| </G-SEL> Gain Group Conversion | Use 2-group gain where it is set to ON and use current gain where it is set to OFF. It converts gain of 2 groups. | All | 3000 [14] |
| </P-TL> Forward Torque Limit | When it is set to ON, limit the forward torque by the set value [Ft-4.03]. | All | 3000 [6] |
| </N-TL> Reverse Torque Limit | When it is set to ON, limit the reverse torque by the set value [Ft-4.04]. | All | 3000 [5] |
| </P-OT> Prohibit Forward Rotation | It prohibits the motor from rotating forward when the load device reaches the limit of the available section. | All | N/A |
| </N-OT> Prohibit Reverse Rotation | It prohibits the motor from rotating reversely when the load device reaches the limit of the available section. | All | |
| </P-CON> P Control Conversion | It converts the Seed Controller from PI type controller to P type controller. It is used to suppress the overshoot of the excessive response and complete a faster response. | F, S, P, I | 3000 [3] |
| </C-SEL> Control Mode Conversion | It is used to convert Control Mode when using it as Combination Control Mode. | Combinational Control Mode Only | 3000 [7] |
| </C-DIR> </C-SP1> </C-SP2> </C-SP3> </C-SP4> Contact Speed Command | At the Contact Speed Control Mode, these input combinations decide the rotation direction of the motor </C-DIR> and the rotation speed </C-SP1 ~ /C-SP4>. The rotation speed for </ C-SP1~/C-SP3> input is set in [Ft-2.05~Ft-2.11]. The analogue speed command voltage decides the rotation speed for </C-SP4>. </C-DIR> is used to change the motor rotation direction in Speed Control Mode. | P | 3000 [8, 9, 10, 11, 12] |
| </Z-CLP> Zero Clamp | Ignores the input value in the Speed Control when the command value is lower than the value set in the Speed Zero Clamp Level [Ft-5.05]. | S | 3001 [2] |
| </INHIB> Inhibit Pulse Command | Inhibits the position command pulse where it is ON. | F | 3000 [13] |
| </ABS-DT> Absolute Encoder Data Transmission | When it is set to ON, transmits the absolute encoder data to a higher level through AM, BM signals. | F, I | 3001 [0] |
| </PCLR> Position Error Clear | Clears position command, position feedback, and position error. | F, I | 3000 [15] |
| </START> Start | Set to start or stop the motor rotation by using the contact signal in Speed/Contact Speed Control Mode. | S, P | 3001 [1] |

Table 2.3 I/O Sequence Input Signal

| Type | Description | Mode | Modbus Address [Position] |
|--|--|------|------------------------------|
| </GEAR> Electronic Gear Rate Shift | In the Position Control Mode, use the 2nd electronic gear parameter [$\frac{2}{Ft} > \frac{2}{Ft} < \frac{2}{Ft} - 3.05$] and [$Ft - 3.06$] where it is ON, use the basic electronic gear parameter [$Ft - 3.01$] and [$Ft - 3.02$] where it is OFF. It shifts between two electronic gear ratios. | F | 3001 [3] |
| </R_ABS> Absolute Encoder Multi-rotation Data Reset | Reset the multi-rotation data of the absolute motor. | All | 3001 [4] |
| </BANK_SEL> Gain Bank Select | Uses the 3rd and the 4th Gain Bank when it is set to ON. | All | 3002 [1] |
| </A-CL> Analog Torque Limit | Current Limit Function is activated by the analogue torque command input values when it is set to ON. | S, P | 3002 [2] |
| </H_SENS> Home Sensor | When activated, the sensor indicates the Return to Home sequence that is detected. | I | N/A |
| </SHOME> Start Homing | When activated, the system starts returning to home. | I | 3001 [6] |
| </PAUSE> Index Pause | When activated, it decelerates until stop and pause the index sequence. It decides whether to stop or to continue the motion by constantly monitoring the input status. | I | 3001 [8] |
| </STOP> Index Stop | When activated, index movement ends. | I | 3001 [7] |
| </I_SEL0> Index Selection 0 Input </I_SEL1> Index Selection 1 Input </I_SEL2> Index Selection 2 Input </I_SEL3> Index Selection 3 Input </I_SEL4> Index Selection 4 Input </I_SEL5> Index Selection 5 Input | Used for the combinations to allocate indexes. | I | 3001 [9, 10, 11, 12, 13, 14] |
| </H_STOP> Homing Stop | Stops Homing operation when it is set to ON. | I | 3001 [15] |
| </START_I> Start Indexing | Starts Indexing when it is set to ON. | I | 3002 [0] |
| </ABS-MD> Absolute Position Data Transfer Mode | Absolute Data transfered to host controller by photo coupler output which output Fault Code when it is set to ON. | F | 3002 [3] |

Digital Output signals

Table 2.4 I/O Sequence Output Signal

| Type | Description | Mode | Modbus Address [Position] |
|--|--|------|---------------------------|
| </S_ALM> Alarm | Outputs when Servo Alarm sets off. | All | 200 [0] |
| </P-COM (+, -)> Position Completion Detection | Turns to ON, when the position error is within the set value of the position completion range [$Ft - 5.00$]. | F, I | 200 [1] |
| </NEAR (+, -)> Position Proximity Detection | Turns to ON, when the position error is within the set value of the position completion range [$Ft - 5.02$]. | F, I | 200 [9] |

Table 2.4 I/O Sequence Output Signal

| Type | Description | Mode | Modbus Address [Position] |
|--|--|------------|---------------------------|
| </V-COM (+, -)> Speed Match Detection | Turns to ON when the deviation between the speed command and the motor rotation speed is within the set value of the speed match decision range [Ft-5.03]. | F, S, P, I | 200 [4] |
| </TG-ON (+, -)> Rotation Detection | Turns to ON when the motor is rotating above the set value of the rotation detection level [Ft-5.04]. | All | 200 [2] |
| </T-LMT (+, -)> Torque Limit Detection | Turns to ON when torque reaches the set value of the torque limit. | All | 200 [7] |
| </V-LMT (+, -)> Speed Limit Detection | Turns to ON when speed reaches the set value of the speed limit. | All | 200 [8] |
| </BK (+, -)> Brake Control | It is the signal for the brake control installed inside or outside of the servo motor. | All | 200 [3] |
| </A_VLD> Absolute Position Valid | Turns to ON when the absolute position data is valid while using the absolute motor. | All | 200 [5] |
| </RDY> Drive Ready | Means getting the operation ready while in the Servo-OFF status. | All | 200 [6] |
| </WARN (+, -)> Warning | Turns to ON when a Servo warning is detected. | All | 200 [10] |
| </HOMC (+, -)> Axis Homing | When activated, it shows the completion of the Homing operation. | I | 200 [15] |
| </IMO (+, -)> In Motion | Turns to ON when in motion. | I | 200 [13] |
| </I_DW> In Dwell | When activated, it indicates that the motor is on the hold position in the index movement and on stand-by for the dwell time assigned. | I | 200 [14] |
| </O_ISEL0> Index Selection 0 Output </O_ISEL1> Index Selection 1 Output </O_ISEL2> Index Selection 2 Output </O_ISEL3> Index Selection 3 Output </O_ISEL4> Index Selection 4 Output </O_ISEL5> Index Selection 5 Output | Used to output the index number in use in the selected indexing operation. | I | 201 [0, 1, 2, 3, 4, 5] |
| </E_SEQU> Sequence Operation Completion | Turns to ON when the index movement is complete. | I | 201 [6] |

Fault Code Output

Table 2.5 Alarm Code Output Signal

| Signal Name | Symbol | Function | Mode | Modbus Address [Position] |
|-------------|---|--|------|---|
| Alarm code | FAULT1/OUTPUT4 (Alarm1/Digital output 4) FAULT2/OUTPUT5 FAULT3/OUTPUT6 | Upon servo alarm generation, it outputs the types of the servo alarm with the 3-bit. Maximum rating of open collector: DC 30 [V], 20 [mA] | All | 23 [0x0000] AL1, AL2, AL3 from right |

I/O Settings

Input Signal Allocation Method

Refer to the table below to allocate to I/O pin by searching the function that is suitable for your condition. As shown in the table below, the related function is already allocated to the sequence input parameter and its position in the setting window and it means that you use the related function as setting certain value among '1 to 9', A except '0' to the setting position.

For example, if you want to put certain function to I/O No. 5 pin, you can find the related parameter of that signal and the position in the setting window according to the table below and enter '3' as the setting value.

Enter '0' when the function of input signal is not used. If you want to make input signal 'ON' all the time regardless of the wiring, set as 'b'.

Table 2.6 I/O Input Signal Allocation

| Setting Value | b | A | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
|-------------------|--------------|-----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------------|
| Input Channel No. | Always valid | INPUT# 10 | INPUT# 9 | INPUT# 8 | INPUT# 7 | INPUT# 6 | INPUT# 5 | INPUT# 4 | INPUT# 3 | INPUT# 2 | INPUT# 1 | Always invalid |
| I/O Pin No. | | 28 | 27 | 26 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | |

The following table is to arrange the parameter for each function and 7-segment number position in the setting window. Set so that the related parameter of each signal and the number position in the setting window is not in the wrong.

Table 2.7 7-Segment Number Position of Input Signal Parameter







| Parameter | 7-Segment Position | | | |
|---|------------------------------|-----------------------------|-----------------------------|------------------------------|
| | 3 | 2 | 1 | 0 |
|  | </P-CON> Initial value: 4 | <N-OT> Initial value: b | <P-OT> Initial value: b | </SV-ON> Initial value: 1 |
|  | </C-SEL> | </P-TL> Initial value: 7 | </N-TL> Initial value: 6 | </A-RST> Initial value: 5 |
|  | </C-SP3> | </C-SP2> | </C-SP1> | </C-DIR> |
|  | </PCLR> | </G-SEL> | </INHIBIT> | </Z-CLP> |
|  | </GEAR> | </C-SP4> | </START> | </ABS-DT> |
|  | </ABS-MD> | </A-CL> | </BANK_SEL> | </R_ABS> |

Table 2.7 7-Segment Number Position of Input Signal Parameter

| | | | | |
|--|------------|-----------|-----------|-----------|
| | </PAUSE> | </STOP> | </SHOME> | </H_SENS> |
| | </I_SEL3> | </I_SEL2> | </I_SEL1> | </I_SEL0> |
| | </START_I> | </H_STOP> | </I_SEL5> | </I_SEL4> |

TIP

If you want to make input signal 'ON' all the time regardless of the wiring, set as 'b'. You can make /SV-ON, P-OT, N-OT signals 'ON' all the time regardless of the wiring, set as 'b'.

The table below is the example to allocate sequence input signal.

Example

| | | | |
|-----------------|-----|---|-----------------------------------|
| | | Enter '7' in the 3rd position in setting window of the parameter [Ft-0.01]. This value is set to use </P-CON> function. It means that the I/O INPUT#7 pin is used as an input pin. | |
| Applicable Mode | All | Other Details | Drive Disable>Configure>Completed |

Output Signal Allocation Method

Refer to the table below to allocate to I/O pin after searching the function that is suitable for your condition.

Set the setting value as '0' when the output of the related signal is not used.







Sequence output is displayed when situation that is meets the condition of each output in drive was produced.

Table 2.8 I/O Output Signal Allocation



| Setting Value | | | | | | | |
|-------------------|-----------|-----------|-----------|-----------|-----------|-----------|----------------|
| Input Channel No. | OUTPUT #6 | OUTPUT #5 | OUTPUT #4 | OUTPUT #3 | OUTPUT #2 | OUTPUT #1 | Always invalid |
| I/O Pin No. | 39, 40 | 38, 40 | 37, 40 | 47, 48 | 43, 44 | 41, 42 | |

The following table is to arrange the parameter for each function and 7-segment number position in the setting window. Set so that the related parameter of each signal and the number position in the setting window is not in the wrong.

Table 2.9 7-Segment Number Position of Output Signal Parameter

| Parameter | 7-Segment Position | | | |
|---|--------------------|---------------------------|------------------------------|------------------------------|
| | 3 | 2 | 1 | 0 |
|  | </V-COM> | </BK> Initial value: 3 | </TG-ON> Initial value: 2 | </P-COM> Initial value: 1 |
|  | </WARN> | </NEAR> | </V-LMT> | </T-LMT> |
|  | Reserved | Reserved | </RDY> | </A_VLD> |
|  | </O_ISEL0> | </HOMC> | </I_DW> | </IMO> |
|  | </O_ISEL4> | </O_ISEL3> | </O_ISEL2> | </O_ISEL1> |
|  | Reserved | Reserved | </E_SEQU> | </O_ISEL5> |

The table below is the example to allocate sequence output signal.

| Example | | | |
|--|-----|--|-----------------------------------|
|   | | Set '3' in the 3st position in setting window of the parameter [Ft-0.23]. It is set to use </WARN> function and it means that we will use I/O No. Output#47,48 pin as output pin. | |
| Applicable Mode | All | Other Details | Drive Disable>Configure>Completed |

Operator

Introduction

This chapter introduces the operator mounted on the servo drive.

| Topic | Page |
|--|------|
| Introduction | 3-1 |
| Operator Instructions of the Parameter Setting | 3-1 |
| Index Mode Setting | 3-4 |
| Index Parameters Setting | 3-5 |

Operator Instructions of the Parameter Setting

Operator

Name and Function of Each Part

The servo drive has a built-in operator for various status displays, parameter setting, operation command, and monitoring.

- Displays various contents with six 7-segment LED display.
- Provides all key manipulation function without a separate external operator.

The following figure shows the front side of the operator on the servo drive.





Table 3.1 Name and Function of Each Part

| No. | Name | Function |
|-----|-----------------------------|---|
| 1 | 7-Segment LED Display | Displays the status with 6-digit 7-segment LED display, sets parameter, commands operation and displays monitoring. |
| 2 | MODE/SET Key | Enters display mode shift and parameter setting value. |
| 3 | ENTER Key | Enters into each window after changes the display mode. Completes setting and exits from it. |
| 4 | Top, Bottom, Left/Right Key | Moves the digit of 7-segment LED display and functions as the UP/DOWN of the number. |

Structure of the Entire Mode

As shown in the figure below, the servo drive is divided into 5 types of control modes:




The mode displayed after the power ON is the status display mode.
Mode is changed whenever the MODE/SET key is pressed.

Status Display Mode



The figure below is an example of display for the description of the status mode.



Parameter Setting Mode



The Parameter sets and saves various functions to make drive suitable for equipment. There is a parameter that can be always set regardless of the status of the drive, and those that must be in certain status of the drive when setting them.

Monitor Mode



Displays several numerical data generated as the motor is controlled by the drive. The contents of the monitor mode can be checked regardless of the status of the drive.

Operation Mode




The motor can be run in operation mode. Each item provides a special function, which can be used. Just as in the parameter setting mode, there is a status where the operation is possible/impossible according to the status of the servo drive, during the use of the operation mode.

Index Mode Setting

Describes index mode setting method focusing on the key button manipulation.

Apply the power and set it as shown in the flowchart below.

Flowchart of the Index Mode Setting




Index Parameter Setting

Describes index parameter setting method focusing on the key button manipulation.

The flowchart below is the example to set Position/Distance parameters value.

Flowchart of the Index Parameter Setting



Setting input value is same for IN04.00~63.

The other groups(Dwell, Velocity, Accelerate, Decelerate, Next Index etc.) can set input value as the same way.

Indexing

Introduction


This chapter describes index operation of the CSD5 servo drive.

| Topic | Page |
|-------------------------------|------|
| Introduction | 4-1 |
| Description of I/O signal | 4-1 |
| Auto Starting Index | 4-5 |
| S/W Limit | 4-6 |
| Homing | 4-11 |
| Index Option | 4-24 |
| Dwell Time | 4-28 |
| Run Function | 4-29 |
| Monitoring Modes for Indexing | 4-29 |

Description of I/O Signal

Digital Input

The sampling time for digital inputs is two milliseconds in CSD5 servo drive. When the drive read inputs a signal, the drive checks the signal for three times per two milliseconds. If signal states are same for three times, the drive applies the signal state to the control system. It means that the CSD5 servo drive has a delay time for six milliseconds at least from detected a signal input to apply the signal state to the control system.



</START_I>


</START_I> signal uses the start command for indexing.

When the CSD5 servo drive is under homing or indexing, this signal input is ignored.

</STOP>


</STOP> signal is a input signal to cancel indexing. When this signal turns on during indexing, the motor starts to decelerate and stop.

</STOP> function is enabled at the active going edge of the </STOP> input.

**</PAUSE>**

</PAUSE> signal is a pause signal. When the </PAUSE> turns on during indexing, the motor starts to decelerate and stops. The state of the </PAUSE> input is continuously monitored to determine if the motion should be stopped or if it may continue.

The acceleration/deceleration slope uses the abort index deceleration value during the Pause operation.



</SHOME>

</SHOME> is an input signal to start Homing. The homing is begun when the falling edge of the </SHOME> signal is occurred. Any starting signal in the middle of homing process is ignored.

</H_STOP>

</H_STOP> is an input signal to cancel Homing. When this signal turns on during homing, the motor starts to decelerated and stops. </H_STOP> function is enabled at the falling edge of </H_STOP> input.

</I_SEL0~5>

</I_SEL0~5> are selection signals to define an index among 64 indexes in the index table. In the selective position travel mode, the CSD5 servo drive determines the index by using the combination of these signals at the falling edge of the START signal. </I_SEL0~5> signals are valid only when the signals maintain their status for at least 4ms before the falling edge of START signal and at least for 8 msec after the falling edge of START signal. If </I_SEL0~5> signals are detected during motion, they are ignored.

Digital Output

</IMO>

</IMO> is In Motion signal. An active state indicates an index move is active and the motor is moving.

</P-COM>

</P-COM> is Position Complete signal.

When the position error has been less than the in position size, the within position window signal turns on.

</HOMC>

</HOMC> is Axis Homed signal. When the homing procedure involved the home offset moving is complete, the axis homed signal turns on. When the fault related encoder is generated or the motor moves beyond the index position range or the motor forward direction is changed in power on state, this signal becomes inactive.

</E_SEQU>

</E_SEQU> is End of Sequence signal.

An active state indicates all iterations of the index move have been completed.

</I-DW>

</I-DW> is In Dwell signal.

An active state indicates the motor is holding position in an index move and waiting for the commanded dwell time. Any starting signal in the middle of </I-DW> is ignored.


</O_ISEL0~5>

The drive outputs the executing index number in motion. If the motor stops, the drive outputs previously the completed index number. From 0 to 5, 6 signals repeats ON and OFF, and shows one index combination out of 64 indexes.


Auto Starting Index

If the auto starting indexing turns on, an indexing move starts at when the drive is enabled. Using this function, the drive can start an indexing without an input signal as motor moving enable.

Auto Starting Indexing : ON



Auto Starting Indexing : OFF



If the Auto Starting Indexing and Auto Starting Homing are set simultaneously, the drive operates like the following table.

| Auto Starting Homing | Auto Starting Indexing | Motion Sequence (Drive Enable inputs When an Axis is not homed) | Motion Sequence (Drive Enable inputs When an Axis is homed) |
|-------------------------------|------------------------|---|---|
| Active | ON | Homing → Indexing | Homing → Indexing |
| Active after drive reset only | ON | Homing → Indexing | Indexing |

The Auto Starting Indexing can set IN00.00. As the value of setting window, 0 is OFF and 1 is ON. The Auto Starting Indexing setting value You can change always the Auto Starting Indexing setting value. But the setting is applied after Power Off & On.

For Example)

1200.00



8888.80

8888.81



Press ENTER key and Enter into the Setting Window

→ Auto Starting Indexing OFF

→ Auto Starting Indexing ON



Press MODE/SET key to save it.

S/W Limit

Software Overtravel

If the motor position feedback is over the software overtravel range, the drive operates the software overtravel limit. The software overtravel does not operate unless the drive was previously homed.

Enable Software Limits : If Enable Software Limits is set to on, the drive turns on soft overtravel checking. Enable Software Limits can set IN00.00. As the value of setting window, 0 is OFF and 1 is ON. You can change this setting value only Servo-Off status.

For Example)

1200.04



8888.80

8888.81



Press ENTER key and Enter into the Setting Window

→ Software Limits OFF

→ Software Limits ON



Press MODE/SET key to save it.

Positive Software Limit : If the motor feedback position is greater than this value, the drive has exceeded the software overtravel limit. This value can set IN00.05 and change only Servo-Off. status. The input range is -2,147,483,647~2,147,483,647 and the default value is 2,147,483,647.

For Example)

1A0005



H21474

003647



Press ENTER key and Enter into the Setting Window

The default value is 2,147,483,647. Using the Direction key, Input the Setting Values.



Press MODE/SET key to save it.

Negative Software Limit : If the motor feedback position is less than this value, the drive has exceeded the software overtravel limit. This value can set IN00.06 and change only Servo-Off. status. The input range is -2,147,483,647~2,147,483,647 and the default value is -2,147,483,647.

For Example)

1A0006



H21474

003647



Press ENTER key and Enter into the Setting Window

The default value is -2,147,483,647. H digits blinks and display '-' signal. Using the Direction key, Input the Setting Values.



Press MODE/SET key to save it.

Overtravel Stopping Method

The Overtravel Stopping Method can be set in the Digit 1 of Ft-0.02. If the value of the Digit 1 of Ft-0.02 is '0', the Overtravel Stopping Method is 'Current Stop'. In case of indexing mode, the Overtravel Stopping Method is 'Decelerating and Stop' with same parameter value.

| Digit 1 of Ft-0.02 | Actions for Physical & Soft Limits in Indexing |
|--------------------|--|
| 0 | Current Stop(Decelerating and Stop) |
| 1 | Dynamic Brake |

$$\text{Deceleration Slope} = \text{Current Velocity}^2 / (2 \times \text{Overtravel Deceleration Distance})$$

For Example)



Press ENTER key and Enter into the Setting Window



Input the Setting Value in this digit. When the Setting Value is 0, Using Current Stop

Positive Decel Distance : The stopping distance is used when the drive encounters a positive overtravel limit. Overtravel limit is the setting value to stop the motor when overtravel occurred. This value can set IN00.02. The input range is 0~2,147,483,647 and the default value is 0.

For Example)



Press ENTER key and Enter into the Setting Window



The default value is 0. Using the Direction key, Input the Setting Values.

Negative Decel Distance : The stopping distance is used when the drive encounters a negative overtravel limit. This is also the setting value to stop the motor when overtravel occurred. The input range is 0~2,147,483,647 and the default value is 0.

For Example)




Press ENTER key and Enter into the Setting Window

The default value is 0. Using the Direction key, Input the Setting Values.



Press MODE/SET key to save it.



Current Velocity : counts/sec

Deceleration Time : sec

Overtravel Deceleration Distance : counts

Deceleration Slope : counts/sec^2

$$\text{Overtravel Deceleration Distance} = 1/2 \times \text{Current Velocity} \times \text{Deceleration Time}$$

$$\text{Deceleration Time} = 2 \times \text{Overtravel Deceleration Distance} / \text{Current Velocity}$$

$$\text{Deceleration Slope} = \text{delta velocity} / \text{delta time} = \text{Current Velocity} / \text{Deceleration Time}$$

$$= \text{Current Velocity}^2 / (2 \times \text{Overtravel Deceleration Distance})$$


Motor Forward Direction

A change for the Motor Forward Direction is possible in the drive disable. When changing the Motor Forward Direction, the index position feedback value maintains the existing value.

The axis homed signal is became the inactive state if the motor direction is changed. The Motor Forward Direction can set Ft-0.02N2. The Motor Forward Direction is CW when the Setting Value is 0. The Motor Forward Direction is CCW when the Setting Value is 1.


1. Move to Index0.

Motor Forward Direction: Normal(CW)
Index0 Type: Incremental
Distance: 8000 counts
Axis Homed Output: Active



2. Change the Motor Forward Direction.

Motor Forward Direction: Reverse(CCW)
Axis Homed Output: Inactive



TIP

When the homing procedure involved the home offset moving is complete, the axis homed signal turns on. When the fault related encoder is generated or the motor moves beyond the index position range or the motor forward direction is changed in power on state, this signal becomes inactive.

Homing

Homing Methods

The CSD5 servo drive supports the following homing methods.

- Axis must be homed before the drive executes an absolute index.
- If Axis homed with 17bit serial absolute motor, the drive maintains home after power cycling.
- A start homing command is ignored when the homing or index is already in progress.
- The drive loses home if the drive detects faults related to encoder.

For a proper homing operation, the following parameters need to be set.

- Homing Type(IN01.00), the distance to Home(IN01.02)
- Automatic Homing when activated(IN01.01)
- Homing Velocity(IN01.02)
- Creep Velocity(IN01.03)
- Homing Offset(IN01.05)
- Moving Distance Sensor after Homing(IN01.08)
- Home Current(IN01.09)
- Home Current Time(IN01.10)

When an incremental motor is used, the position feedback is set to 0 when the homing operation is complete. (when Offset is 0).

ATTENTION



The alarm goes off when a user tries indexing while the homing operation is incomplete. (i.e., HOMC (Axis Homing) is not activated). Refer to the Index E-30 page Axis not homed for more information about Fault .

ATTENTION



When an absolute motor is used, the position feedback is set to 0 even when the Homing is complete and the multi-rotation data of the absolute encoder is not reset. The multi-rotation data of an absolute motor is not automatically reset. It can be reset only by a user.

ATTENTION



A homing type that uses a sensor for homing does not complete a homing if the homing starts outside the sensor.

Homing types

The Index supports 11 homing types by using homing sensor, limit (+)/(-) sensor, stopper and marker. Homing types can set IN01.00 and the setting is applied after Power Off & On.

For Example)



Press ENTER key and Enter into the Setting Window

Using the Direction key, Setting homing types.



Press MODE/SET key to save it.

TIP

Marker is 'Z' phase or 'C' phase. This is the signal to output the same position every motor's revolution.


Homing Type 0 : Home to Present Position

Homing type 0 does not allow home searching. If you set the automatic start homing to 0 when you activate IN01.01, CDS5 Servo Drive defines the current position as home when the drive is activated. If you set the automatic start homing to 1 when you activate IN01.01, SHOM's position is set as home.

Homing Type 1 : To Home sensor/Back to Marker

Homing Type 1 defines home by using the home sensor and markers.


When the home searching begins, the motor moves to homing direction (IN01.01) with homing velocity (IN01.02) until detecting the homing sensor. At this point, the motor decelerates and stops; it starts moving reversly with the creep velocity (IN01.03). When it hits the first marker after losing the signal input from the home sensor, the deceleration stops, and it returns to the position where it detected the active-going edge of the first marker.



Homing Type 2 : To Limit/Back to Marker

Homing Type 2 uses the limit sensor (+) or (-) and markers.


Only the limit sensor installed in the homing direction is used, and the hardware limit fault is deactivated. Operating principles are same as Homing Type 1. The only difference is that it uses the limit sensor instead of the home sensor.



Homing Type 3 : To Home sensor/Fwd to Marker


Similar to the Homing Type 1, the Homing Type 3 also uses the homing sensor and markers to define Home. However, the mechanism is different.

When the home sensor is detected, the speed decelerates to the creep velocity and maintains until the active-going edge is detected. After it decelerates again and stops, it moves reversly to the position where the active-going edge was detected.



Homing Type 4 : To Limit/Fwd to Marker


Similar to Homing Type 2, Homing Type 4 uses the limit sensor (+) or (-) and markers. Only the limit sensor in the home direction is used, and hardware Limit Fault is deactivated. Operating principles are same as Homing Type 3. The only difference is that it uses the limit sensor instead of the home sensor.



Homing Type 5 : Home to Current Value


The Homing Type 5 performs a mechanical stop by using the stopper.

Once the home searching begins, it moves in the homing direction with the homing velocity (IN01.02). When the current is maintained higher than the current of the home current time, it stops; Home is defined where it stops. The home current is defined in the parameter IN01.09.



Homing Type 6 : Home to Current Value/Back to Marker


The operation is similar to that of the Homing Type 5, but in this mode, it moves reversly until it detects the falling edge of a marker when the current maintains higher than the current of the home current time. After detecting the active-going edge of a marker, it stops after decelerating. Then, it returns to the position where it detected the active-going edge of the first marker.



Homing Type 7 : To Home sensor/Move/Fwd to Marker


Similar to the Homing Type 3, the Homing Type 7 uses the home sensor and moving distance, after home sensing and marking.

When the distance between the home sensor and a marker is minuscule, it might not detect the first marker. To prevent this from happening, there is one more parameter in this mode to define the minimum moving distance to detect the marker. The minimum moving distance is defined in the parameter IN01.10 as time. After detecting the home input, speed decelerates to the 2nd homing velocity and is maintained until the active-going edge of a marker is detected. The active-going edge of the marker is set as home.




Homing Type 8 : Home to Marker

The Home Type 8 uses only markers. In this mode, additional sensors such as home sensor or limit (+) or (-) are not required. Once the home searching begins, it moves in the homing direction with the creep velocity. When it detects a marker, it decelerates and stops. It moves to the position where the active-going edge of a marker was detected and sets this position as Home.




Homing Type 9: To Home sensor

Homing Type 9 defines home by using the home sensor only. When the home searching begins, the motor moves to homing direction (IN01.02) with homing velocity (IN01.02) until detecting the homing sensor. When it detects home sensor, it decelerates and stop, then it moves in the reverse direction with creep velocity (IN01.03). It returns to the position where it detected the home sensor signal.



Homing Type 10: To Limit sensor

Homing Type 9 defines home by using the limit sensor only. When the home searching begins, the motor moves to homing direction (IN01.02) with homing velocity (IN01.02) until detecting the limit sensor. When it detects home sensor, it decelerates and stop, then it moves in the reverse direction with creep velocity (IN01.03). It returns to the position where it detected the limit sensor signal.



Auto Starting Homing on Enable

The drive starts the homing procedure automatically when the drive is enabled. Auto Starting Homing can set IN01.01 and the setting is applied after Power Off & On.

For Example)



Press ENTER key and Enter into the Setting Window

Using the Direction key, Setting Auto Starting Homing value between 0~2 at first digit.




Press MODE/SET key to save it.


If the Auto Starting Indexing and Auto Starting Homing are set simultaneously, the drive operates like the following table.

| Auto Starting Homing | Auto Starting Indexing | Motion Sequence (Drive Enable inputs When an Axis is not homed) | Motion Sequence (Drive Enable inputs When an Axis is homed) |
|-------------------------------|-------------------------------|--|--|
| Active | ON | Homing → Indexing | Homing → Indexing |
| Active after drive reset only | ON | Homing → Indexing | Indexing |


Active[Setting value: 0] : Automatically starts homing every time the drive is enabled.



Active after drive reset only [Setting value: 1] : Automatically starts homing when a drive is enabled, if the drive has not already been homed



Inactive [Setting value: 2] : Starts homing when drives is inputted Stare Homing.



Homing Velocity

Homing velocity is using velocity during an index homing. A +/- sign of this value means a move direction during an index homing.

Homing velocity can set IN01.02. The input range is -6000~6000 and the default value is 100. You can change this setting value only Servo-Off. status.

For Example)

1100102



000100



Press ENTER key and Enter into the Setting Window

Using the Direction key, Setting value between -6000~6000.



Press MODE/SET key to save it.

TIP

A +/- sign of homing velocity means a move direction during an index homing. A homing is Positive direction when it's '+' sign and negative direction when it's '-' sign.

Creep Velocity

For the To Sensor, then Back to Marker Homing Type, the velocity used for all remaining homing motion after the motor decelerates to a stop when it finds the sensor edge. This velocity uses all of the other homing types.

Creep velocity can set IN01.03 and the input range is -6000~6000. The default value is 100 and its unit is rpm.. You can change this setting value only Servo-Off status.

For Example)

120103



0020



Press ENTER key and Enter into the Setting Window

Using the Direction key, Setting value between 0~6000.



Press MODE/SET key to save it.

Home Offset Move

The home offset move means the moving distance after the homing procedure specified homing methods is complete. A user can use this option to set up an origin which is different from the origin defined in the homing operation.

The position where the motor stops after the moving for the home offset move is complete is the new home. The home offset move is not applicable for the 17-bit Absolute Motor. The Offset Move Distance is set up in the IN01.05. Its range is -2,147,483,647~2,147,483,649 and the default value is 0. Its unit is counts and it can change this setting value only Servo-Off. status.

For Example)



Press ENTER key and Enter into the Setting Window

Using the Direction key, Setting values between -2,147,483,647~2,147,483,647.



Press MODE/SET key to save it.

Home Sensor Polarity

This function is to choose the active state of home sensor input; Inactive to active transition and Active to inactive transition.

This value is set up in the IN01.06. Home sensor is enable when the input value is set 0 and it is disable when the input value is set 1. It can change this setting value only Servo-Off. status.

For Example)



Press ENTER key and Enter into the Setting Window

Using the Direction key, Setting values 0 or 1.



Press MODE/SET key to save it.

Home Position

This value is used as the home position at the completion of a homing procedure. If this value is 1000, the index position is 1000 when the moving for the home offset is complete.

The HomePosition is set up in the IN01.07. Its range is -2,147,483,647~2,147,483,649 and the default value is 0. Its unit is counts and it can change this setting value only Servo-Off. status.

For Example)

1.001.007



0.000.000



Press ENTER key and Enter into the Setting Window

Using the Direction key, Setting values between -2,147,483,647~2,147,483,647.



Press MODE/SET key to save it.

Moving Distance After Home Sensor

When Homing Mode 7 is selected, markers which appear between the active going edge of the home sensor and the end position of Moving distance After Home Sensor are all ignored.

Moving distance After Home Sensor is set up in IN01.08. Its range is 0~2,147,483,649 and the default value is 0. It can change this setting value only Servo-Off. status.

For Example)

1.001.008



0.000.000



Press ENTER key and Enter into the Setting Window

Using the Direction key, Setting values between -2,147,483,647~2,147,483,647.



Press MODE/SET key to save it.

Home Current, Home Current time

When Homing Mode 5 or 6 is used for Homing, the system judges it actually hits the Stopper if the torque higher than the Home Current is maintained for the Home Current time.

The Home Current is set up in IN01.09, about 0~250% of its rated torque. The default value is 100. Home Current time is set up in IN01.10. It can be

0~1000 msec. Its default is '0'. It can change this setting value only Servo-Off status.

For Example)

1A01.09



8.8.8.100



Press ENTER key and Enter into the Setting Window

Using the Direction key, Setting values between 1~250.



Press MODE/SET key to save it.

For Example)

1A01.10



8.8.0000



Press ENTER key and Enter into the Setting Window

Using the Direction key, Setting values between 0~1000.



Press MODE/SET key to save it.

Index Option

The CSD5 servo drive can store 64 indexes and provide 3 types of option modes for the 64 indexes. The three types are Stop, Start next Index, and Wait for Start. Except the Selective position option, 64 indexes are pre-defined in a memory.

ATTENTION




The alarm goes off when a user tries indexing while the homing operation is incomplete. (i.e., HOMC (Axis Homing) is not activated). Refer to the Index E-30 page Axis not homed for more information about Fault .

Action When Complete

The indexing action when the index has completed is defined to be one of the below options.


Stop [Setting Value: 0]

This action ends the execution of indexed move commands (default).




Start Next Index [Setting Value: 1]

Only one START signal is required to move over all the Indexes. This action commands execution of the next index move without additional input, but after the scheduled dwell. The duration of stop at each index depends on the Dwell time defined in the index data. IMO is active when the movement starts and maintains the state until the last index.




Wait for Start [Setting Value: 2]

In this mode, whenever there is the START signal, it moves to the next index, not like the Start Next Index where only one START signal is required to move over all the Indexes. Whenever it arrives at each position, the IMO signal is turned OFF.



Action When Complete is set up in IN02.00~63N1.

For Example)



Next Index

The number (0 - 63) of the next indexed move to execute when Action When Complete is not set to "Stop".

Next Index is set up in IN12.00~63.

For Example)




Press ENTER key and Enter into the Setting Window

Using the Direction key, Setting value between 0~63.



Press MODE/SET key to save it.

Dwell Time

The dwell is the time when the drive holds position after the motor position feedback reached the target position.

After the drive spends dwell, the drive waits commands or executes the next index. The dwell function operates with all indexing (all index types and all options of 'action when complete').

Dwell is set up in IN07.00~63. Its range is 0~65,535 and its default is '0'.

For Example)




Press ENTER key and Enter into the Setting Window

Using the Direction key, Setting value between 0~65,535.



Press MODE/SET key to save it.

Run Function

The CSD3 servo drive supports total 13 Run functions, i.e. Run-00~Run-12. Run-02, Run-05~07, Run-09 are not supported in the Indexing, but Run-00~01, Run-03~04, Run-08, Run-10~12 provide the same functions in the Indexing.

The Description of each Run function is shown below.

| Function | Description |
|----------|--|
| run-00 | Jog Operation |
| run-01 | Off-Line Auto Tuning |
| run-03 | Auto Adjustment of Speed Command Offset |
| run-04 | Auto Adjustment of CurrentCommand Offset |
| run-08 | Alarm Reset |
| run-10 | Absolute Encoder Reset |
| run-11 | 2-Group Gain Storing |
| run-12 | Parameter Initialization |

Monitoring Modes for Indexing

The monitor modes help a user conveniently check Indexing Position Feedback and Indexing Position Command.

-dis-04 : Indexing Position Feedback

-dis-05 : Indexing Position Command

Tuning

Introduction


This chapter explains the servo drive setting that can achieve its optimum performance to satisfy different load system as controlling servo motor.

| Topic | Page |
|----------------------------|------|
| Introduction | 5-1 |
| Tuning by Gain Srtting | 5-1 |
| Gain Srtting Configuration | 5-5 |
| Auto Gain Setting | 5-8 |

Tuning by Gain Setting

Mark Description

The following icon is used for tuning.



Gain Introduction

As the audio system has equalizer to adjust the audio quality, the drive also requires adjustment to achieve the optimum performance for each load. Equalizer adjustment is not essential for the audio system, but the adjustment is important fact that is directly connected to performance for servo drive.


You should adjust servo drive to satisfy load condition in order to achieve optimum performance for each control.

In addition, the adjustment made to the motor that is connected to drive, to achieve the optimum performance through gain setting, is called Tuning.

Servo Drive Gain

What kind of drive gains are there that acts like equalizers of audio system
Parameter group 1 has gain setting parameter for tuning and it is classified as follows.

System Gain



It is the same as the Bandwidth of overall speed control loop of the servo drive.


It can adjust five basic gains at the same time.

IMPORTANT

In case of CSD5 servo drive, the system gain is limited to 10Hz at its minimum to guarantee a proper level of motion characteristics when speed response level [Ft- 1.00] is set too low. For more information about speed response level, refer to 6-8 page "Speed Response Level [Ft-1.00]".





Basic Gain

They are five fundamental gains for tuning.







Applicable Gain

They are four gains that with separate functions.

| | | | |
|---|--|--|--|
|  <p>Position Command Filter [Hz]</p> |  <p>Vibration Suppression Filter [Hz]</p> |  <p>Position FF Gain [%]</p> |  <p>Position FF Filter [Hz]</p> |
|---|--|--|--|

Others

They are four parameters with supplementary function that is required for tuning.

| | | | |
|---|---|---|---|
|  <p>P Control Conversion Switch [N/A]</p> |  <p>P Control Conversion Standard Value</p> |  <p>Speed Bias [rpm]</p> |  <p>Speed Bias Standard Width [pulse]</p> |
|---|---|---|---|

As mentioned above, gains in parameter group 1 and 13 parameters related to gain are explained and the details refer to user manual.


Parameter That is Most Important for Tuning, Inertia Ratio

The parameter that is considered to make motor, that is connected to servo drive achieve the optimum performance in tuning, is the inertia ratio setting parameter. First of all, you should understand that inertia ratio and gain settings are interlocked, and refer to the explanation hereinafter.

Inertia Ratio

What is Inertia Ratio?

The following figure explains the inertia ratio.



It shows the ratio of load inertia compared to the motor (rotor) inertia.

If the motor (rotor) inertia is 3 [gfcms²] and the load inertia is 30 [gfcms²], the inertia ratio is 10 [times]. For the motor inertia table, refer to the motor specification in the appendix.

Setting Unit


Setting value of Inertia Ratio uses the unit, [times]. For example, if the motor inertia is same as the load inertia, the Inertia Ratio is 1 [time] and the setting value is 1.00.

The setting value of the Inertia Ratio is determined by the following formula.

$$\text{Inertia Ratio} = \frac{\text{Load Inertia}}{\text{Motor Rotor Inertia}}$$

Setting Parameter

Set the Inertia Ratio to the following parameter.

| | |
|----------------|--|
| Parameter |  |
| Parameter Name | Inertia Ratio |
| Descirption | It can be automatically set by off-line auto tuning function in the page 7-44 "Off-Line Auto Tuning (run-01)". |
| Setting Value | 0.00~60.00 |
| Initial Value | 1.00 |

| | |
|-----------------|---------------|
| Unit | Times |
| Applicable Mode | All |
| Others | Setting > End |


IMPORTANT Based on the motor type and the rated output, the maximum allowed inertia ratio is as below. When the allowed inertia ratio exceeds the maximum, you cannot expect a fast response.

| Motor | Capacity | Maximum Allowable Inertia Rotation |
|----------------|--------------|------------------------------------|
| CSMT/R | less 100 [W] | 30 [Times] |
| RSMQ/Z | less 1 [kW] | 20 [Times] |
| | 1 [kW] | 10 [Times] |
| RSMS/D/H/F/K/L | All | 10 [Times] |

Inertia Ratio and Gain

If the Inertia Ratio is adjusted by certain reason, it automatically changes the following two basic gains at the same time with the adjustment. Therefore, the Inertia Ratio setting means gain setting, so that you should be careful when adjusting or setting the Inertia Ratio.

Two basic gains that are changed according to the adjustment of Inertia Ratio.



Gain Setting Configuration

This chapter explains the overall configuration (Position, Speed, and Torque) related to the gain setting.

The following diagram will help you understand the gain configuration related


to position, speed and torque.

| | |
|---|--|
| Starting point for position mode gain setting | <p>Position mode using the position pulse command of host controller includes all gains related to speed and torque from starting point to the servo motor as shown in the figure below.</p> <p>Servo drive first generates the speed command using the position command of the host controller, speed command generates the torque command and finally, it transfers the torque command to the servo motor. Therefore, when you use the position mode, the gain can be set properly.</p> <p>If gain related to position control is set properly but the gain related to torque or speed is not set properly, the optimum tuning cannot be achieved.</p> |
| Starting point for speed mode gain setting | <p>Speed mode using speed command of the host controller includes all gains related to torque from starting point to the servo motor as shown in the figure below.</p> <p>Servo drive first generates torque command using speed command of the host controller and finally, it transfers the torque command to the servo motor. Therefore, when you use the speed mode, the gains related to speed and torque can be set properly.</p> <p>If gain related to speed control is set properly but gain related to torque is not set properly, the optimum tuning cannot be achieved.</p> |
| Starting point for torque mode gain setting | <p>Torque mode using torque command of host controller includes all gains related to torque from starting point to servo motor as shown in the figure below.</p> <p>You can adjust gains related to torque in torque mode.</p> |

TIP

If gains related to position are set in the condition that response quality is not sufficiently guaranteed through gain settings related to speed control, system becomes unstable. Therefore, firstly you should sufficiently secure the response quality of speed control loop to make the response quality of whole position control system good.

Gain Diagram related to Position, Speed and Torque



Auto Gain Setting

Auto Tuning

There are two functions, which automatically detects the load status inside servo drive.

- Off-line auto-tuning
- On-line auto-tuning

Off-line Auto Tuning

Tuning Function

Two basic gains are automatically set based on the detected data.

Tuning Mode

There are inertial identification mode, inertia identification and resonance frequency detection mode, and resonance frequency detection mode.

The operation mode of run-01 is set by the Auto tuning Mode Setting [Ft-0.03] N0 [Ft-0.03] N0 = 2 (Resonance Frequency Detection). This is a function that looks for only the resonance frequency of the system in a stationary position unlike the inertia moment identification function. This function is for the users who are interested in finding only the resonance frequency, unlike [Ft-0.03] N0 = 1 (inertia identification and resonance frequency detection). However, as this function also requires the system's inertia for an accurate operation, it can be useful when the vibration suppression filter needs to be corrected once more by feeling the vibration after performing [Ft-0.03] N0 = 0 (inertia moment identification) or [Ft-0.03] N0 = 1 (inertia moment identification and resonance frequency detection).


Operation (Tuning) Method

For Operation method for off-line auto tuning, refer to Off-line Auto Tuning Operation (run-01) on page 7-44 page “Off-line Auto Tuning Operation (run-01)”.

Speed Response Level [Ft-1.00]

This is used to automatically set an initial system gain by determining available max. bandwidth based on the inertia ratio which is obtained from (run-01).

After auto tuning, max. bandwidth is determined, and the system gain [Ft-1.01] is determined by [Ft-1.00].

| | |
|-----------------|--|
| Parameter |  |
| Parameter Name | Speed response level |
| Description | Define max. system gain % recommended by a system based on inertia measured from auto tuning |
| Setting Value | 1 ~ 150 |
| Initial Value | 50 |
| Unit | % |
| Applicable Mode | All |
| Others | Setting > End |


This parameter defines max. system gain [%] recommended by a system after execution of “Nertia Identification”. or ‘nertia identification and resonance frequency’ according to [Ft-0.03.N0] setting. For example, if ‘max. available frequency’ of a system is ‘100 [Hz]’ after auto tuning, its system gain [Ft-1.01] is set to ‘50Hz’ according to its default value.

‘Max. Available Frequency’ is determined based on estimated inertia and also system characteristics. Therefore, its default value is 50 [%] and the related gain values are automatically set to appropriate values when it is changed, and the related Gain Values are automatically set to appropriate values when it is changed. However, system gain [Ft-1.01] is limited to 10 [Hz] at its minimum to guarantee a proper level of motion characteristics when speed response level [Ft-1.00] is set too low.

Explanation of the Relationship Flow between Off-line Auto Tuning and Gain

When you run off-line auto tuning, drive automatically Inertia Ratio [Ft-0.04] of load system and automatically set two basic gains as being suitable for Inertia Ratio. Therefore, it is recognized that the response quality of servomotor is improved at the same time.

In addition, load system sometimes does resonant (vibration) in the specific frequency range because of vibration noise. For those situations, it intercepts vibration of load system using resonant frequency that is automatically detected by auto tuning. Resonant frequency of load system becomes the setting value for resonance suppression filter [Ft-1.10] and if you know the exact resonant frequency of the load, you can set it directly.

**TIP**

Only as operating off-line auto tuning, you can prevent resonant noise caused by resonant frequency of load system and three basic gains.

Off-line auto tuning automatically sets Inertia Ratio [Ft-0.04] and resonant suppression filter [Ft-1.07], but when you know exactly each value, you can directly set.

However, if the value set directly is not accurate, the response quality is degraded and becomes the reason of resonant noise. Therefore, be careful when setting it directly.

On-line Auto Tuning

Overview


On-line Auto Tuning is used when load is continuously changed during the operation. It continuously changes the gain value according to load state in order to maintain the regular response quality of system even though load state is changed.

Precautions

Do not use On-line Auto Tuning for the cases below if possible, and we recommend using the Off-line Auto Tuning or manual gain setting.

- When fine or large change is made to the Inertia ratio during the load operation.
- If Inertia ratio is changed in two types during load operation, you do not need to change. In this case, refer to the 6-36 page "</G-SEL> Function".
- When big torque does not occur during load operation because acceleration/deceleration time is long or maximum rotation speed or torque limit is set low.

On-line Auto Tuning Coefficient Setting

| | |
|------------------|---|
| Coefficient |  |
| Coefficient Name | Speed response level |
| Description | If this value is not '0', use on-line auto tuning function. The higher you set the value, the more delicately it responds to load change and respond quickly. |
| Applicable Mode | All |
| Others | Servo-OFF > Setting > End |

If load is quickly changed, you need to set the On-line Auto Tuning coefficient high, but it can be momentarily unstable in the load environment that the vibration is large. So, pay extra caution.

If the response quality of control loop is decreased during On-line Auto Tuning, increase the value of system gain [Ft-1.01] and if noise or vibration occurs, reduce that value.

On-line Vibration Suppression

Select Online Vibration Suppression Mode.

Three modes can be selected on the first 7 segment: Disable, Normal and High Speed Mode, and Slow Speed Mode without Initial Value.

Also, the second 7 segment supports Online Vibration Suppression Gain function.

On-line Vibration Suppression Mode Selection

- Ft-1.22.N0 = 0

Operates based on the value of the fixed vibration suppression filter in Ft-1.10 which is previously set by the offline tuning, and the online function does not work.

- Ft-1.22.N0 = 1

It is a function to suppress the vibration online in the most general motion conditions. However, for the online function to work properly, an initial offline tuning is necessary. The inertia ratio set by offline is essential for the maximum result of the online vibration suppression. Once the online function starts by this mode, the existing value of [Ft-1.10] becomes meaningless.

IMPORTANT

The suggested online function can adversely affect when the load condition is too great with a high strength or in no load status. It is strongly advised not to use this function and operate in Off-line Tuning Mode (its parameter setting value is 0 in [Ft-0.03]) for a better result in those cases.

Generally, the suggested load condition brings a good result when using a belt or a belt-incorporated system.

- Ft-1.22.N0 = 2

This function is used to detect the resonance frequency while in general motion when no proper value exists in [Ft-1.10] because only the inertia ratio was identified without measuring the resonance frequency in the initial offline tuning stage.

IMPORTANT

To use this function, it is extremely important that the system gain [Ft-1.01] should be set low between 10 ~15 [Hz], and the maximum speed for the motion should be lower than 100 [rpm].

Once the above conditions are met, while in general motion, and check what value [Ft-1.10] changes to. If the system cannot identify an appropriate resonance frequency, [Ft-1.10] does not change its initial value (10000).

Once the value is changed, it is difficult to increase the speed higher than 100 [rpm], but the gain can be increased within the bounds of the system; in that case [Ft-1.10] can change again.

Even if it changes to a certain value, when the [Ft-1.22] N0 is changed to another mode, the value of [Ft-1.10] that was measured online returns to the initial value, which was set in the Disable online Vibration Suppression mode in case [Ft-1.22] N0 is "0". That is because, the defined value of [Ft-1.22] N0 on "2" (Slow Speed mode without initial value) might not have the generality since it is a value guaranteed only in the low-speed operation mode. However, if a user decides that the device is always operated in the low-speed mode and wants to keep the value permanently, he can reset Ft-1.22.N0 = 0 and write the value measured online from [Ft-1.22] N0 "2" again onto Ft-1.10 then, the value is stored in the memory of the drive for good.

If only resonance (or vibration) frequency is needed, execution of [run-01] (offline auto tuning) after setting "[Ft-0.03] N0 = 2 (Resonance Frequency Detection)" enables the normal operation after locating the vibration frequency.

The advantage of this function is that all the operation conditions are in the low-speed range mentioned above (within 100 [rpm]); in case the gain is also relatively low, the operation can be continued while adjusting for the optimum [Ft-1.10].

IMPORTANT

This function is available only when both the gain and the operation speed (within 100 rpm) are low.

Online Vibration Suppression Gain Setting

As mentioned above "[Ft-1.22] N0 = 1" is the most suitable online function to be used in general. However, this function may be vulnerable depending on the load condition. Such an example is when the structure is complicated with many belts connected. Initial value "[Ft-1.22] N1 = 0" can be applicable in most cases; if there is a functional problem, set [Ft-1.22] N1 value to "1" so the online vibration suppression gain could increase, and use the higher value of [Ft-1.07] (Torque command filter) than 1000 [Hz] to get a good result.

In the meantime "[Ft-1.22] N1" affects only when "[Ft-1.22] N0 = 1".

Application

Introduction

This chapter describes settings to operate the servo motor by indexing once again. And describes indexing in order after basic settings.

| Topic | Page |
|----------------------------------|------|
| Introduction | 6-1 |
| Basic Setting of the Servo Drive | 6-1 |
| Basic Setting for Indexing | 6-5 |
| Homing Setting | 6-8 |
| Indexing Setting | 6-16 |
| Index Operation | 6-22 |


Basic Setting of the Servo Drive

A user has to set basic parameters to operate servo drive by indexing. This chapter describes to set the standard Parameters. For more detail information, please refer to “CSD5 Servo Drive User Manual”.

Index Mode Setting

The control Mode is set up in Ft-0.00. Describes index mode setting method focusing on the key button manipulation. Apply the power and set it as shown in the flowchart below.

Flowchart of the Index Mode Setting




Servo Motor Setting

Motor setting should be done from the parameters [Ft-0.01]. For numerical data related to the installation of the servo motor, please refer to CSD5 Servo Drive User Manual.

Basic Mode Setting

Fault and Disable Braking, Overtravel stop method, Motor Forward Dir., Power Input is set up in Ft-0.02.



| | | | |
|---|-------|---|--|
|  | | Selection of 4 Basic Mode | |
| Digit 0 | | Fault and Disable Braking | |
| Range | Value | Description | |
| | 0 | Keep DB after DB stop | |
| | 1 | DB is released after DB stop | |
| | 2 | Stop Free run (operation) without DB stop | |
| | 3 | Keep DB after stop Free run | |
| Initial Value | | 0 | |
| Digit 1 | | Overtravel stop method | |
| Range | Value | Description | |
| | 0 | Stop by normal torque control during overtravel. At this moment, can control torque by setting overtravel torque limit [Ft-4.05]. | |
| | 1 | Stop by the method set at the DB stop method selection in [Ft-0.02] when overtravel occurs. | |
| Initial Value | | 0 | |
| Digit 2 | | Motor Forward Dir. | |
| Range | Value | Description | |
| | 0 | The command signal is not inverted so that a positive command value results in CW Rotation, (as viewed from shaft end). | |
| | 1 | The command signal is inverted so that a positive command value results in CCW Rotation, (as viewed from shaft end). | |
| Initial Value | | 0 | |
| Digit 3 | | Power Input | |
| Range | Value | Description | |
| | 0 | Check input power 50~400W Servo Drive: Enable single-phase open check 800~1.5kW Servo Drive: 3-phase open check | |
| | 1 | Do not check the input power | |
| | 2 | Single-phase input | |
| Initial Value | | 0 | |

- A.** Select Parameter Setting Mode(Ft-0.00) by MODE/SET key.
- B.** Using the Direction key, move to Ft-0.02.
- C.** Press ENTER key and enter into the Setting Window.

- D. Fault and Disable Braking, Overtravel stop method, Motor Forward Dir. and Power Input are set up in Ft-0.02, refer to the table above.
- E. To complete the setting, press MODE/SET key to save it.
- F. Press ENTER key and go out the Setting Window.

Supplementary Function Setting

In Position Size and Near Position Size are set up in Ft-5.00, Ft-5.02.

| | |
|---|--|
|  | In Position Size |
| Description | If position error < In Position Size for 1 ms and the In Position Size output signal is assigned, the In Position output is turned ON. |
| Range | 0~2500 |
| Initial Value | 10 |
| Unit | pulse |
|  | Near Position Size |
| Description | If position error < Near Position Size and the Near Position output signal is assigned, the Near Position output is turned ON. |
| Range | 0~2500 |
| Initial Value | 20 |
| Unit | pulse |

- A. Select Parameter Setting Mode(Ft-0.00) by MODE/SET key.
- B. Using the Direction key, move to Ft-5.00.
- C. Press ENTER key and enter into the Setting Window.
- D. In Position Size is set up in Ft-5.00, refer to the table above.
- E. To complete the setting, press MODE/SET key to save it.
- F. Press ENTER key and go out the Setting Window.
- G. Near Position Size is set up in Ft-5.02 as the same way.


Basic Setting for Indexing

A user has to set up the basic parameter for indexing after setting the basic parameter of the servo drive. This chapter describes to set the Parameters for the index system.

Auto Starting Indexing

If the auto starting indexing turns on, an indexing move starts at when the drive is enabled. Using this function, the drive can start an indexing without an input signal as motor moving enable.


Auto Start Indexing is set up in IN00.00. Auto Start Indexing is set up, refer to the table below.

| | |
|---|--|
|  | Auto Start Indexing |
| Description | When this field is set to "on", the drive will begin executing the selected index whenever the drive enables. 0-OFF 1-ON |
| Range | 0~1 |
| Initial Value | 0 |

- A.** Select Index Setting Mode(IN00.00) by MODE/SET key.
- B.** Using the Direction key, move to IN00.00.
- C.** Press ENTER key and enter into the Setting Window.
- D.** Set up a Auto Start Indexing, refer to the table above.
- E.** To complete the setting, press MODE/SET key to save it.
- F.** Press ENTER key and go out the Setting Window.

Abort Index Deceleration



A user can set up the deceleration used to stop motion when the Stop Index input terminates an index move. Abort Index Deceleration is set up in IN00.01.

| | |
|---|--|
|  | Abort Index Deceleration |
| Description | The deceleration used to stop motion when the Stop Index input terminates an index move. |
| Range | 0~2147483647 |
| Initial Value | 6250 |

- A. Select Index Setting Mode(IN00.00) by MODE/SET key.
- B. Using the Direction key, move to IN00.01.
- C. Press ENTER key and enter into the Setting Window.
- D. Set up a Abort Index Deceleration, refer to the table above.
- E. To complete the setting, press MODE/SET key to save it.
- F. Press ENTER key and go out the Setting Window.

Positive/Negative Deceleration Distance




A user can set up the stopping distance used when the drive encounters a positive/negative overtravel limit. Positive/Negative Deceleration Distance is set up in IN00.02~03.

| | |
|---|---|
|  | Positive Deceleration Distance |
| Description | The stopping distance used when the drive encounters a positive overtravel limit. |
| Range | 0~2147483647 |
| Initial Value | 0 |
|  | Negative Deceleration Distance |
| Description | The stopping distance used when the drive encounters a negative overtravel limit. |
| Range | 0~2147483647 |
| Initial Value | 0 |

- A. Select Index Setting Mode(IN00.00) by MODE/SET key.
- B. Using the Direction key, move to IN00.02.
- C. Press ENTER key and enter into the Setting Window.
- D. Set up a Positive Deceleration Distance, refer to the table above.
- E. To complete the setting, press MODE/SET key to save it.
- F. Press ENTER key and go out the Setting Window.
- G. Negative Deceleration Distance is set up in IN00.03 as the same way.

S/W Limit

If the motor position feedback is over the software overtravel range, CSD5 servo drive operates the software overtravel limit. The parameters for Software Limit are set up in IN00.04~06 IN00.04~06.


| | |
|---|--|
|  | Enable Software Limits |
| Description | Select: 0-OFF: Turns off software overtravel limit checking 1-ON: Causes the drive to compare the motor feedback position to the Positive and Negative Software Limits, below, to determine if the drive has exceeded an overtravel limit. |
| Range | 0~1 |
| Initial Value | 0 |
|  | Positive Software Limit |
| Description | If the motor feedback position is greater than this value, the drive has exceeded the software overtravel limit. |
| Range | -2147483647~2147483647 |
| Initial Value | 2147483647 |
|  | Negative S/W Limit |
| Description | If the motor feedback position is less than this value, the drive has exceeded the software overtravel limit. |
| Range | -2147483647~2147483647 |
| Initial Value | -2147483647 |

- A. Select Index Setting Mode(IN00.00) by MODE/SET key.

- B.** Using the Direction key, move to IN00.04.
- C.** Press ENTER key and enter into the Setting Window.
- D.** Set up a Enable Software Limit, refer to the table above.
- E.** To complete the setting, press MODE/SET key to save it.
- F.** Press ENTER key and go out the Setting Window.
- G.** Positive/Negative Software Limit is set up in IN00.05~06 as the same way.

User Defined Distance

A user intuitively can set up the Index Position/Distance by a user defined the unit and distance per motor revolution of the load. User Defined Distance Per Motor Revolution is set up in IN00.07. Default 0 mean to use count unit, not use User Defined distance.

|  | User Defined Distance Per Motor Revolution |
|--|--|
| Description | Define user defined distance per motor revolution. |
| Range | 0~99999 |
| Initial Value | 0 |


- A.** Select Index Setting Mode(IN00.00) by MODE/SET key.
- B.** Using the Direction key, move to IN00.07.
- C.** Press ENTER key and enter into the Setting Window.
- D.** Set up a User Defined Distance Per Motor Revolution, refer to the table above.
- E.** To complete the setting, press MODE/SET key to save it.
- F.** Press ENTER key and go out the Setting Window.

Homing Setting

Axis must be homed before the drive executes an absolute index. This chapter describes to set the Parameters for the homing.

Homing Type


CSD5 Servo Drive supports 11 homing types. Homing types can set IN01.00 and the setting is applied after Power Off & On.

|  | Homing Type |
|---|--|
| Description | Select the type of homing operation the drive will perform. 0-Home to Present Position 1-To Home sensor/Back to Marker 2-To Limit/Back to Marker 3-To Home sensor/Fwd to Marker 4-To Limit/Fwd to Marker 5-Home to Current Value 6-Home to Current Value/Back to Marker 7-To Home sensor/Move/Back to Marker 8-Home to Marker 9-To Home sensor 10-To Limit sensor |
| Range | 0~10 |
| Initial Value | 1 |

- A.** Select Index Setting Mode(IN00.00) by MODE/SET key.
- B.** Using the Direction key, move to IN01.00.
- C.** Press ENTER key and enter into the Setting Window.
- D.** Set up a Homing Type, refer to the table above.
- E.** To complete the setting, press MODE/SET key to save it.
- F.** Press ENTER key and go out the Setting Window.

Auto Start Homing

The drive starts the homing procedure automatically when the drive is enabled. Auto Starting Homing can set IN01.01 and the setting is applied after Power Off & On.

|  | Auto Start Homing on Enable |
|---|-----------------------------|
|---|-----------------------------|

| | |
|---------------|---|
| Description | Causes the drive to begin the homing procedure automatically when the drive is enabled. 0 - Active: Automatically starts homing every time the drive is enabled. 1 - Active After Reset Only: automatically starts homing when a drive is enabled, if the drive has not already been homed. 2 - Inactive |
| Range | 0~2 |
| Initial Value | 2 |


- A. Select Index Setting Mode(IN00.00) by MODE/SET key.
- B. Using the Direction key, move to IN01.01.
- C. Press ENTER key and enter into the Setting Window.
- D. Set up a Auto Starting Homing, refer to the table above.
- E. To complete the setting, press MODE/SET key to save it.
- F. Press ENTER key and go out the Setting Window.


If the Auto Starting Indexing and Auto Starting Homing are set simultaneously, the drive operates like the following table.

| Auto Starting Homing | Auto Starting Indexing | Motion Sequence (Drive Enable inputs When an Axis is not homed) | Motion Sequence (Drive Enable inputs When an Axis is homed) |
|-------------------------------|------------------------|---|---|
| Active | ON | Homing → Indexing | Homing → Indexing |
| Active after drive reset only | ON | Homing → Indexing | Indexing |

Homing Velocity

Homing velocity is using velocity during an index homing. A +/- sign of this value means a move direction during an index homing. For the To Sensor, then Back to Marker Homing Type, creep velocity used for all remaining homing motion after the motor decelerates to a stop when it finds the sensor edge. This velocity uses all of the other homing types.


| | |
|---|--|
|  | Homing Velocity |
| Description | The commanded velocity used during homing. The sign of this value (+/-) indicates the direction of motion during homing. |
| Range | -6000~6000 |
| Initial Value | 100 |

| | |
|---|--|
|  | Creep Velocity |
| Description | For the To Sensor, then Back to Marker Homing Type, the velocity used for all remaining homing motion after the motor decelerates to a stop when it finds the sensor edge. |
| Range | 0~6000 |
| Initial Value | 20 |

- A. Select Index Setting Mode(IN00.00) by MODE/SET key.
- B. Using the Direction key, move to IN01.02.
- C. Press ENTER key and enter into the Setting Window.
- D. Set up a Homing Velocity, refer to the table above.
- E. To complete the setting, press MODE/SET key to save it.
- F. Press ENTER key and go out the Setting Window.
- G. Creep velocity is set up in IN01.03 as the same way.

Homing Acceleration/Deceleration

A user can set up the rate of acceleration and deceleration used during homing.


| | |
|---|---|
|  | Homing Acceleration/Deceleration |
| Description | The rate of acceleration and deceleration used during homing. |
| Range | 1~2147483647 |
| Initial Value | 6250 |

- A. Select Index Setting Mode(IN00.00) by MODE/SET key.
- B. Using the Direction key, move to IN01.04.
- C. Press ENTER key and enter into the Setting Window.
- D. Set up a Homing Acceleration/Deceleration, refer to the table above.
- E. To complete the setting, press MODE/SET key to save it.
- F. Press ENTER key and go out the Setting Window.

Home Offset Move

The home offset move means the moving distance after the homing procedure specified homing methods is complete. A user can use this option to set up an origin which is different from the origin defined in the homing operation. The position where the motor stops after the moving for the home offset move is complete is the new home.


The home offset move is not applicable for the 17-bit Absolute Motor. The Offset Move Distance is set up in the IN01.05.

| | |
|---|--|
|  | Offset Move Distance |
| Description | The distance the motor position will be from the marker edge (or sensor edge for Sensor only Homing Type) after the homing sequence is complete. |
| Range | -2147483647~2147483647 |
| Initial Value | 0 |

- A. Select Index Setting Mode(IN00.00) by MODE/SET key.
- B. Using the Direction key, move to IN01.05.
- C. Press ENTER key and enter into the Setting Window.
- D. Set up a Offste Move Distance, refer to the table above.
- E. To complete the setting, press MODE/SET key to save it.
- F. Press ENTER key and go out the Setting Window.

Home Sensor Polarity


This function is to choose the active state of home sensor input; Inactive to active transition and Active to inactive transition. This value is set up in the IN01.06. Home sensor is enable when the input value is set 0 and it is disable when the input value is set 1.

| | |
|---|---------------------------------|
|  | Home Sensor Polarity |
| Description | 0-NORMAL CLOSE 1-NORMAL OPEN |
| Range | 0~1 |
| Initial Value | 0 |

- A. Select Index Setting Mode(IN00.00) by MODE/SET key.
- B. Using the Direction key, move to IN01.06.
- C. Press ENTER key and enter into the Setting Window.
- D. Set up a Home Sensor Polarity, refer to the table above.
- E. To complete the setting, press MODE/SET key to save it.
- F. Press ENTER key and go out the Setting Window.

Home Position

This value is used as the home position at the completion of a homing procedure. If this value is 1000, the index position is 1000 when the moving for the home offset is complete.


| | |
|--|---|
|  | Home Position |
| Description | The home position when a homing procedure is completed. |
| Range | -2147483647~2147483647 |
| Initial Value | 0 |

- A. Select Index Setting Mode(IN00.00) by MODE/SET key.
- B. Using the Direction key, move to IN01.07.
- C. Press ENTER key and enter into the Setting Window.
- D. Set up a Home Position, refer to the table above.
- E. To complete the setting, press MODE/SET key to save it.
- F. Press ENTER key and go out the Setting Window.

Moving Distance After Home Sensor

When Homing Mode 7 is selected, markers which appear between the active going edge of the home sensor and the end position of Moving distance After Home Sensor are all ignored. Moving distance After Home Sensor is set up in

IN01.08. Its range is 0~2,147,483,649 and the default value is 0. It can change this setting value only Servo-Off. status.



| | |
|---|--|
|  | Moving distance After Home Sensor |
| Description | This value is distance that the drive ignores the marker inputs after the home sensor is detected. |
| Range | 0~2147483647 |
| Initial Value | 0 |

- A. Select Index Setting Mode(IN00.00) by MODE/SET key.
- B. Using the Direction key, move to IN01.08.
- C. Press ENTER key and enter into the Setting Window.
- D. Set up a Moving distance After Home Sensor, refer to the table above.
- E. To complete the setting, press MODE/SET key to save it.
- F. Press ENTER key and go out the Setting Window.

Home Current, Home Current time

When Homing Mode 5 or 6 is used for Homing, the system judges it actually hits the Stopper if the torque higher than the Home Current is maintained for the Home Current time.

The Home Current is set up in IN01.09, about 0~250% of its rated torque. The default value is 100. Home Current time is set up in IN01.10. It can be 0~1000 msec. Its default is '0'. It can change this setting value only Servo-Off. status.


| | |
|---|--|
|  | Home Current |
| Description | Specifies the torque feedback at which the drive stops moving the motor at the Homing Velocity. Unit : Percentages of a motor rating torque |
| Range | 0~250 |
| Initial Value | 100 |
|  | Home Current Time |
| Description | The time to when the torque feedback is more than the home current to when the drive detects stopper. |
| Range | 0~1000 |

| | |
|---------------|---|
| Initial Value | 0 |
|---------------|---|

- A.** Select Index Setting Mode(IN00.00) by MODE/SET key.
- B.** Using the Direction key, move to IN01.09.
- C.** Press ENTER key and enter into the Setting Window.
- D.** Set up a Home Current, refer to the table above.
- E.** To complete the setting, press MODE/SET key to save it.
- F.** Press ENTER key and go out the Setting Window.
- G.** Home Current Time is set up in IN01.10 as the same way.

Homing Time Limit


Axis must be homed before the drive executes an absolute index. A user can limit the homing time against to be late the homing. Drive fault occurs when time for homing is over the homing time limit.

| | |
|---|--|
|  | Homing Time Limit |
| Description | Drive fault occurs when time for homing is over the homing time limit. |
| Range | 0~65535 |
| Initial Value | 60 |

- A.** Select Index Setting Mode(IN00.00) by MODE/SET key.
- B.** Using the Direction key, move to IN01.11.
- C.** Press ENTER key and enter into the Setting Window.
- D.** Set up a Homing Time Limit, refer to the table above.
- E.** To complete the setting, press MODE/SET key to save it.
- F.** Press ENTER key and go out the Setting Window.

Stop Homing Deceleration

A user can set up the deceleration used to stop motion when the Stop Homing input terminates an index homing.

| | |
|---|---|
|  | Stop Home Deceleration |
| Description | The rate of drive deceleration used when homing is stopped. |
| Range | 1~2147483647 |
| Initial Value | 6250 |

- A. Select Index Setting Mode(IN00.00) by MODE/SET key.
- B. Using the Direction key, move to IN01.12.
- C. Press ENTER key and enter into the Setting Window.
- D. Set up a Stop Homing Deceleration, refer to the table above.
- E. To complete the setting, press MODE/SET key to save it.
- F. Press ENTER key and go out the Setting Window.


Indexing Setting

Start setup for Indexing after ending the basic setting for the indexing and the homing.

Indexing Types

CSD5 servo drive is two kinds of coordinate systems to express position. In the absolute coordinate system, all the Indexes are expressed based on one reference location, called as Home or Origin. Axis must be homed before the drive executes an absolute index. In the incremental coordinate system, a position is defined with a relative distance from its previous position.

A user can select either option in the 1st digit of IN02.00~63 (absolute and incremental). When this value is 0, the coordinate system is absolute and When this value is 1, the coordinate system is incremental.

| | | |
|---|---------|------------------------|
|  | Digit 0 | Index 0~63 Type |
|---|---------|------------------------|


| | |
|---------------|---|
| Description | Index 0 ~63 Setup Mode: 0-Absolute: moves from its starting position to the specified Position, below. 1-Incremental: moves from its starting position the specified Distance, below. Note: The axis must be homed before the drive can execute any index. |
| Range | 0~1 |
| Initial Value | 0 |

- A.** Select Index Setting Mode(IN00.00) by MODE/SET key.
- B.** Using the Direction key, move to IN02.00.
- C.** Press ENTER key and enter into the Setting Window.
- D.** Set up a Index Type, refer to the table above.
- E.** To complete the setting, press MODE/SET key to save it.
- F.** Press ENTER key and go out the Setting Window.

Index Action When Complete

The CSD5 servo drive can store 64 indexes and provide 3 types of option modes for the 64 indexes. The three types are Stop, Start next Index, and Wait for Start. Except the Selective position option, 64 indexes are pre-defined in a memory.


The indexing action when the index has completed is defined to be one of the below options.

| | | |
|---|--|--|
|  | Digit 1 | Index 0~63 Action When Complete |
| Description | 0: Stop: ends the execution of indexed move commands (default setting). 1: Start next index: commands execution of the Next Index move without additional input, but after the scheduled Dwell. 2: Wait for Start: commands execution of the Next Index move the next time the Start Index input becomes active. | |
| Range | 0~2 | |
| Initial Value | 0 | |

- A. Select Index Setting Mode(IN00.00) by MODE/SET key.
- B. Using the Direction key, move to IN02.00.
- C. Press ENTER key and enter into the Setting Window.
- D. Set up a Index Action When Complete in N1, refer to the table above.
- E. To complete the setting, press MODE/SET key to save it.
- F. Press ENTER key and go out the Setting Window.

Index Position/Distance

Enter the position or distance to move for the indexing. For Absolute mode moves, the fixed position to which the motor will travel. For Incremental moves, the relative distance the motor will travel.

|  | Index 0~63 Position/Distance |
|--|--|
| Description | <ul style="list-style-type: none"> • Position : For Absolute mode moves, the fixed position to which the motor will travel. • Distance : For Incremental and Registration mode moves, the relative distance the motor will travel. |
| Range | -2147483647~2147483647 |
| Initial Value | 0 |


- A. Select Index Setting Mode(IN00.00) by MODE/SET key.
- B. Using the Direction key, move to IN04.00.
- C. Press ENTER key and enter into the Setting Window.
- D. Set up a Index Position/Distance, refer to the table above.
- E. To complete the setting, press MODE/SET key to save it.
- F. Press ENTER key and go out the Setting Window.
- G. Index Position/Distance is set up in IN04.01~63 as the same way.

Index Dwell Time

The dwell is the time when the drive holds position after the motor position feedback reached the target position.

After the drive spends dwell, the drive waits commands or executes the next index. The dwell function operates with all indexing (all index types and all options of 'action when complete').

Dwell is set up in IN07.00~63. Its range is 0~65,535 and its default is '0'.


| | |
|---|---|
|  | Index 0~63 Dwell |
| Description | Milliseconds to remain at current position before exec. |
| Range | 0~65535 |
| Initial Value | 0 |

- A.** Select Index Setting Mode(IN00.00) by MODE/SET key.
- B.** Using the Direction key, move to IN07.00.
- C.** Press ENTER key and enter into the Setting Window.
- D.** Set up a Index Dwell, refer to the table above.
- E.** To complete the setting, press MODE/SET key to save it.
- F.** Press ENTER key and go out the Setting Window.
- G.** Index Dwell is set up in IN07.01~63 as the same way.

Index Velocity

Maximum velocity during an index move.


Enter velocity for each movement into the velocity parameter of IN08.00~63. The input range is 0~6000 and its unit is rpm. The default value is 750.

| | |
|---|-----------------------------------|
|  | Index 0~63 Velocity |
| Description | Maximum velocity while in motion. |
| Range | 0~6000 |
| Initial Value | 750 |

- A. Select Index Setting Mode(IN00.00) by MODE/SET key.
- B. Using the Direction key, move to IN08.00.
- C. Press ENTER key and enter into the Setting Window.
- D. Set up a Index Velocity, refer to the table above.
- E. To complete the setting, press MODE/SET key to save it.
- F. Press ENTER key and go out the Setting Window.
- G. Index Velocity is set up in IN08.01~63 as the same way.

Index Acceleration


Maximum acceleration during an index move. A user can enter total 64 acceleration for 64 indexes. Enter acceleration for each movement into the acceleration parameter of IN10.00~63. The input range is 1~2,147,483,647 and its unit is 10^2rev/sec . The default value is 6250.

| | |
|---|---------------------------------------|
|  | Index 0~63 Acceleration |
| Description | Maximum acceleration while in motion. |
| Range | 1~2147483647 |
| Initial Value | 6250 |

- A. Select Index Setting Mode(IN00.00) by MODE/SET key.
- B. Using the Direction key, move to IN10.00.
- C. Press ENTER key and enter into the Setting Window.
- D. Set up a Index Acceleration, refer to the table above.
- E. To complete the setting, press MODE/SET key to save it.
- F. Press ENTER key and go out the Setting Window.
- G. Index Acceleration is set up in IN10.01~63 as the same way.

Index Deceleration


Maximum deceleration during an index move. A user can enter total 64 deceleration for 64 indexes. Enter deceleration for each movement into the deceleration parameter of IN11.00~63. The input range is 1~2,147,483,647 and its unit is 10^2rev/sec . The default value is 6250.

| | |
|---|---------------------------------------|
|  | Index 0~63 Deceleration |
| Description | Maximum deceleration while in motion. |
| Range | 1~2147483647 |
| Initial Value | 6250 |

- A. Select Index Setting Mode(IN00.00) by MODE/SET key.
- B. Using the Direction key, move to IN11.00.
- C. Press ENTER key and enter into the Setting Window.
- D. Set up a Index Deceleration, refer to the table above.
- E. To complete the setting, press MODE/SET key to save it.
- F. Press ENTER key and go out the Setting Window.
- G. Index Deceleration is set up in IN11.01~63 as the same way.

Next Index

"The number (0 - 63) of the next indexed move to execute when Action When Complete is not set to "Stop". Next Index is set up in IN12.00~63.

| | |
|---|---|
|  | Index 0~63 Next Index |
| Description | The number (0 - 63) of the next indexed move to execute when Action When Complete is not set to "Stop". |
| Range | 0~63 |
| Initial Value | 0 |

- A. Select Index Setting Mode(IN00.00) by MODE/SET key.
- B. Using the Direction key, move to IN12.00.
- C. Press ENTER key and enter into the Setting Window.

- D. Set up a Next Index, refer to the table above.
- E. To complete the setting, press MODE/SET key to save it.
- F. Press ENTER key and go out the Setting Window.
- G. Next Index is set up in IN12.01~63 as the same way.

Index Operation


Start Indexing after ending the setting for the indexing.

Tuning

Start Off-line Auto Tuning when the drive is servo-off. Off-line Auto Tuning operate in run-01.

How to Operate

Refer to the below flow chart to operate.



Servo-ON

Servo-ON signal should be applied to the drive. If the servo-ON signal is not applied after the power application, it is same as the servo driver and motor being separated completely. This is a ready status to run the motor.

Homing

Axis must be homed before the drive executes an absolute index. 'Auto Starting Homing on Enable' turns on, an index homing starts at when the drive is enabled. If 'Auto Starting Homing on Enable' turns off, an index homing completes as entering the start homing signal. The stop homing is a

signal to cancel homing. A stop or start indexing command is ignored when the homing is already in progress.

Start Index

Start index operation after homing. If the auto starting indexing turns on, an indexing move starts at when the drive is enabled. If the auto starting indexing turns off, enter the start index signal.

a user can stop to move by 'Stop', 'Pause' signal during index move. When the stop signal turns on during indexing, the motor starts to decelerate and stop. When the pause signal turns on during indexing, the motor starts to decelerate and stops and wait next signal. The pause signal input is continuously monitored to determine if the motion should be stopped or if it may continue.

If the Action When Complete is set the Wait for Start, whenever there is the START signal, it moves to the next index. When the CSD5 servo drive is under homing or indexing, this signal input is ignored. Any starting signal in the middle of In Dwell is ignored.

Inspection and Protection

Introduction

In this chapter, the inspection and the protective function of servo drive are described.

| Topic | Page |
|---------------------|------|
| Introduction | 7-1 |
| Inspection Function | 7-1 |
| Protection Function | 7-3 |

Inspection Function

It describes the basic inspection, abnormality diagnosis and how to take action of servo motor and drive. Also, it describes the protection function of drive and action to take in times of alarm occurs as well as any action to take in times of breakdown following the alarm code.

Inspection of Motor

Motor does not have a brush that causes mechanically abrasive part. A simple inspection is sufficient as follow. By considering the use environment, determine the appropriate inspection time.

Table 7.1 Motor Inspection

| Item | Period | Inspection and Repair | Action |
|--|-----------------------|---|--|
| Vibration and Noise | Daily Check | Determine with Sense and Hearing | It shall not be larger than normal times |
| Presence of External Foreign Substance | In Occurrence | Cleaning with Vacuum Cleaner | |
| Insulation Resistance | 1 Year | Measure with Insulation resistance meter 500 [V] 10 [MΩ] | Inquiry to the company if the measuring value is 10 [M Ω] or less |
| Oil Seal | 5000 Hours | Oil Seal Replacement | Only for motor that has oil seal |
| Overall Inspection | 20000 Hours (5 Years) | Inquiry to the Company | Disassembly and worn-out part replacement |

CAUTION



In the event of disassemble the servo motor for repair or inspection; a care shall be taken for A/S not available.

Inspection of Drive

Servo drive is equipped with electronic circuit. The dust and foreign substance may cause the breakdown or malfunction that the dust shall be cleaned and tighten the nuts on a regular basis (1-year).

Table 7.2 Servo Drive Inspection

| Item | Period | Inspection and Repair | Action |
|--------------------------------------|-----------------------|---|-------------------------------------|
| Cleaning of Main Body and Board | Once or more per year | Do not have dust or oil | Clean with compressed air or fabric |
| Socket, Connector, Nut | Once or more per year | Do not allow loosening of \ socket, connector, nut and others | Do not allow loosening |
| Abnormal Part on Main Body and Board | Once or more per year | There is no discoloration by heat, damage or open circuit | Inquiry to the company |

CAUTION



In the event of disassemble the servo drive for repair or inspection; a care shall be taken for A/S not available.

Part Inspection

The part below may have mechanical abrasion or material degradation. A regular inspection is needed for prevention and preservation.

The life of parts is as below if the ambient temperature annual average is 30 [°C], load rate is less than 80 [%], and operation rate is less than 20 hours/day.

Table 7.3 Servo Drive's parts life

| Part | Use Period |
|------------------------|----------------------------------|
| Capacitor | 3 Yeas |
| Cable | 3 Yeas (based on flexible cable) |
| Power Device | 3 Yeas |
| Regeneration Resister | 2 Yeas |
| Dynamic Break Resister | 2 Yeas |
| Fan | 2 Yeas |
| Cooling Fan | 4 - 5 Yeas |
| Fuse | 10 Yeas |

Protection Function

It describes the equipped protection function and actions taken in times of abnormal operation in order to protect the servo drive and load system. The protection function is classified into two types depending on the importance.

- Servo warning: It displays a minimal abnormality that does not require the suspension of operation when occurred.
- Servo alarm: It displays the very serious abnormality that requires the suspension of operation when occurred.

It is classified depending on the importance, but when an abnormality occurs, remove the cause immediately and use the servo drive in normal condition.

Servo Warning

There is a servo warning that displays a minimal abnormality as the protection function by the self-diagnosis.

Servo Warning Indication








It displays the mark that is applicable to a warning through the Status Display Mode.



The warning is displayed on the 3 digit of 7-segment as shown on the left. The character displayed the normal operation status does not flicker, but once the abnormality applicable for servo warning is sensed, the applicable character is displayed and flickers.

Servo Warning Types

Servo drive displays the warning characters for the following 7 situations.

| Indicator | Cause | Action |
|--|--|--|
|  Absolute Encoder Counter Overflow | In the event the Q Type Absolute Encoder is rotated forward or reverses over 32768 revolutions, it is displayed. | Reset the Absolute Encoder. |
|  Low Voltage of Absolute Encoder Battery | It occurs when the voltage of battery or external power supply of absolute encoder is 3.2 [V] or less. | Replace the battery or external power supply to make sure. ¹ |
|  Abnormal Initial Status of Absolute Encoder | During the drive motor for moving the control power has been applied. | After making sure that the motor stops turning off the control power. |
|  Over (external) Current Command | Analog current scale setting inadequate. | Check if the scale constant is suitable for range of the analog signal. |
| | The system does not support the motion profile. | <ul style="list-style-type: none"> • Check the speed loop tuning. • Check the capacity of the system. |
| | Current limit setting is inappropriate. | Check if the current limit lower than the current limited capacity of the system. |
|  Over(external) Speed Command | Analog current scale setting inadequate. | Check if the scale constant is suitable for range of the analog signal. |
| | The system does not support the motion profile. | <ul style="list-style-type: none"> • Check the position loop tuning. • Check the capacity of the system. |
|  Allocation Error of Sequence Input and Output | Digital input or output of the allocation is inappropriate. | <ul style="list-style-type: none"> • When working in the preset mode, check if it is allocated for preset. • When working in the normal / override mode, check if it is allocated for override function. |
|  Over Motor Capacity | It occurs when motor power is set higher than the drive rated output. | Use a motor suitable to the drive or set the torque limit below the drive capacity. |

¹ When replacing a battery, absolute position is lost. Homing may be required.

Servo Alarm

For protection function by the self-diagnosis, there is the servo alarm that displays the important errors.

Table 7.4 Servo Alarm Types

| Alarm Code | Text Message | Cause | Action |
|--|--------------|--|---|
| E00400 E0226E Motor overheating | | Occurs when the motor overheat switch trips by the following causes. ∞ High ambient temperature surrounding the motor ∞ Excessive current | <ul style="list-style-type: none"> • Operate within the continuous torque rating (not exceeding) according to the ambient temperature. • Lower the ambient temperature or increase the motor cooling. |
| | | Motor wiring error | <ul style="list-style-type: none"> • Check the wiring of the motor. |
| | | Unsuitable motor selection | <ul style="list-style-type: none"> • Check if the motor selected is suitable. |
| E00500 E1P0FE IPM Error | | Motor cable shorted | <ul style="list-style-type: none"> • Check if the motor power cable and the connector are not shorted. |
| | | Occurs when the winding wire of the motor is shorted internally. | <ul style="list-style-type: none"> • . Disconnect the motor power cable from the motor. If the motor will not be rotated by hand, a replacement may be needed. |
| | | Occurs when exceeding the continuous power rating while operating. | <ul style="list-style-type: none"> • Check if the ambient temperature is too high. • Operate within the continuous power rating. • Decrease the acceleration rate. |
| | | Occurs when an unsuitable IPM output, short circuit or over current exist in the drive. | <ul style="list-style-type: none"> • Check the wiring connections that go from U, V, and W motor terminals to the DC BUS after disconnecting the power and the motor. If the connections are normal, check the wires between terminals or have the drive repaired. |
| E00900 E000E0 BUS Low Voltage | | AC line/AC power input is low. | <ul style="list-style-type: none"> • Check the voltage level of the incoming AC power. • Check the noise pulse of the AC power or for a voltage drop. • Install an Uninterruptible Power Supply (UPS) to the AC input. |
| | | Attempted to activate the drive without turning on the main power. | <ul style="list-style-type: none"> • Before activating the drive, turn on the main power. |
| E01000 E000E0 BUS Over Voltage | | Occurs when the power regeneration is excessive. That is, the drive generates an error to protect itself from the overload when its main power supply regenerates excessive peak energy while the motor is run by the external mechanical power. | <ul style="list-style-type: none"> • Check the regenerative circuit. • Adjust the motion profile and keep the regeneration resistance within the limit. • Replace the regenerative transistor. • Replace the drive. |
| | | Excessive AC input voltage | <ul style="list-style-type: none"> • Confirm the input value. |
| E01200 E0FA1L Home Searching Failed | | Homing is incomplete within the time assigned in Homing Time Limit (IN-01.11). | <ul style="list-style-type: none"> • Increase the time assigned in Homing Time Limit (IN-01.11). • Set the value other than '0' in Homing Speed (IN-01.02) and Creep Speed (IN-01.03). • Check for an obstruction in homing. • Check the homing related parameter setting and mechanical parts. |

Table 7.4 Servo Alarm Types

| Alarm Code | Text Message | Cause | Action |
|------------|------------------------------------|--|---|
| E018 | Motor Over Speed | Motor speed exceeds the maximum. | <ul style="list-style-type: none"> Check the wiring of the encoder. Retune the drive system. Check the input gain of the torque or the external speed command. |
| E019 | Over the Position Error Limit | Occurs when the position error exceeds the allowed value.. | <ul style="list-style-type: none"> Increase the Following Error Limit value. Check the position loop tuning. |
| E022 | Motor Continuous Current Overload | Occurs when the internal filter that protects the motor from overheating trips. | <ul style="list-style-type: none"> Decrease the acceleration rate. Decrease the duty cycle (ON/OFF) of the motion assigned. Increase the time for the motion allowed. Use a drive or motor with bigger capacity. Check the tuning. |
| E023 | Drive Overload | Occurs when the drive average current exceeding the rated capacity is needed for the motion application. | <ul style="list-style-type: none"> Decrease the acceleration rate. Decrease the duty cycle (ON/OFF) of the motion assigned. Increase the time for the motion allowed. Use a drive or motor with bigger capacity. Check the tuning. |
| E024 | Absolute Position Transfer Timeout | /ABS-DT input is not turned on within 5s from Absolute Position Transfer Ready-On during Absolute Position Transfer Mode using photo coupler output. | <ul style="list-style-type: none"> Verify the sequential timing of Absolute Position Transfer Ready & /ABS-DT, Absolute Position Transfer Mode input. Verify continuity of I/O cable and connector. |
| | | /ABS-DT input is not turned off within 5s from Absolute Position Transfer Ready-Off during Absolute Position Transfer Mode using photo coupler output. | |
| | | Absolute Position Transfer Mode input is not turned off within 5s after absolute data transfer completion. | |
| E027 | Homing Incomplete | Occurs when an axis didn't return to home before the drive can operate an absolute coordinate index. | <ul style="list-style-type: none"> Increase the time defined Homing Time Limit(IN-01.11). Check for an obstruction in homing. |
| E028 | Encoder Date Range Error | Occurs when the encoder is not properly programmed. | <ul style="list-style-type: none"> Replace the motor. |
| | | Occurs when the memory of the encoder is damaged. | |
| E030 | Encoder Cable Open | Occurs when the communication with the interactive encoder cannot be established. | <ul style="list-style-type: none"> Check the motor selected. Check whether the motor supports an auto detection. Check the wiring of the encoder. |
| | | Hall Error | |
| E031 | Encoder Date Parameter Error | Occurs when the encoder is not properly programmed. | <ul style="list-style-type: none"> Replace the motor. |
| | | Occurs when the memory of the encoder is damaged. | |



Table 7.4 Servo Alarm Types

| Alarm Code | Text Message | Cause | Action |
|------------|--------------------------------------|--|--|
| E036 | Drive Overheating | Occurs when the drive overheats. | <ul style="list-style-type: none"> Check if the cooling fan is working (only applicable to CSD5_08BX1, CSD5_10BX1 and CSD5_15BX1). Check the tuning. Decrease the acceleration rate. Decrease the duty cycle (ON/OFF) of the motion assigned. Increase the time for the motion allowed. Use a drive or motor with bigger capacity. |
| E037 | AC line Loss | Occurs when the power is low. | <ul style="list-style-type: none"> Increase the instant outage compensation time. |
| | | Attempted to activate the drive without turning on the main power. | <ul style="list-style-type: none"> Before activating the drive, turn on the main power. |
| | | A phase is not connected. | <ul style="list-style-type: none"> Disconnect the power and check all mechanical connections. |
| | | The alarm delay parameter is set too short. | <ul style="list-style-type: none"> Increase the Alarm delay parameter value. |
| E053 | User Parameter Initialization Error | An error exists in the parameter saved in the memory. | <ul style="list-style-type: none"> Initialize the parameter. Reset the values of the drive to the factory. |
| E054 | Current Feedback Offset | Defective Hardware | <ul style="list-style-type: none"> Replace the drive. |
| E055 | User Parameter Checksum Error | Checksum Error | <ul style="list-style-type: none"> Check the parameter and reset. Reset the values of the drive to the factory settings. |
| E056 | Watchdog Timeout | Excessive System Noise | <ul style="list-style-type: none"> Check the wiring and the installation method. |
| | | Defective Hardware | <ul style="list-style-type: none"> Replace the drive. |
| E057 | PWM Hardware Error | Defective Hardware | <ul style="list-style-type: none"> Contact your nearest dealer. |
| E058 | User Parameter Range Error | Parameter range is invalid. | <ul style="list-style-type: none"> Input the parameter within the range. Reset the values of the drive to the factory settings. |
| E060 | Drive Initialization Error | Hardware Error | <ul style="list-style-type: none"> Replace the drive. |
| E075 | Regenerative Overload Protection | Exceeds the value allowed by the voltage of the regeneration resistance. | <ul style="list-style-type: none"> Adjust the motion profile and keep the regeneration resistance within the limit. |
| | | Regeneration resistance is separated or damaged. | <ul style="list-style-type: none"> Check the connection of the regeneration resistance. Check the values of the regeneration resistance. |
| E079 | Regenerative Over current Protection | The regenerative current exceeds the allowable instant value. | <ul style="list-style-type: none"> Check if the regeneration resistance is shorted or damaged. Check if the overload energy is excessive while decelerating. |

Table 7.4 Servo Alarm Types

| Alarm Code | Text Message | Cause | Action |
|---|--------------|--|--|
| E083 EEAB5bE Regenerative Over current Protection | | The constant of the encoder backup battery is set as 'installed,' but the battery is not installed. | <ul style="list-style-type: none"> Set the constant of the encoder backup battery as 'not installed.' |
| | | The battery voltage is detected under 2.7 [V] DC. | <ul style="list-style-type: none"> Check the battery voltage and the connections. Replace the battery. |
| E084 EEAB5b5 Absolute Encoder Over Speed | | The encoder rotates mechanically at high speed while turning off the drive, when it is powered by the battery. | <ul style="list-style-type: none"> Remove the motor from the system. Turn off and on the drive and reset the Warning. |
| E085 EEAB5cE Absolute Encoder Multi-turn Count Error | | Noise from Encoder | <ul style="list-style-type: none"> Turn off and on the drive and reset the Warning. |
| | | Defective Encoder | <ul style="list-style-type: none"> Replace the motor. |
| E100 EE5EEUP Drive Setting | | The drive operation mode and the motor selection are not compatible. | <ul style="list-style-type: none"> Change the operation mode and/or motor selection, and reset the drive. |
| E101 EEAB6LE Motor Power Cable Open | | The motor cable is not connected. | <ul style="list-style-type: none"> Check the power connection between the motor and the drive. |
| E102 EE1A5DL Motor continuous current overload | | The motion profile requires peak current for a lengthy time. | <ul style="list-style-type: none"> Check the wiring of the motor. Adjust the acceleration/deceleration time. Check if the motor selected is suitable. |
| | | There is a defect in the current feedback detection. | <ul style="list-style-type: none"> Check the phase current. |
| E103 EEAAECH Motor Mismatch Fault | | The dynamic control current of the selected motor exceeds double the value of the drive peak current rating. | <ul style="list-style-type: none"> Install a different motor. |
| E105 EEAECEP Encoder Type Mismatch | | The motor encoder signal does not match the drive configuration. | <ul style="list-style-type: none"> Check the motor selected. |
| | | Defective Encoder | <ul style="list-style-type: none"> Replace the motor. |
| E106 EEAECEE Encoder Communication Error | | The wiring between the drive and the encoder is cut off or problematic. Or encoder signals are interrupted by the EMI (noise). | <ul style="list-style-type: none"> Check the wiring of the encoder. Contact your nearest dealer. |
| E107 EE5EPEE Serial Communication Error | | Communication error between the host and the drive (noise) | <ul style="list-style-type: none"> Check the serial communication cable. Check the noise of the serial communication interface. |
| E108 EEAEFEF Position Command Frequency Error | | The input frequency value exceeds that limit. | <ul style="list-style-type: none"> Check if the hardware type selected in the drive matches the physical hardware. Change from an open collector to a line drive. Decrease the speed command. Manipulate the gear. |
| E112 EE5E6EP Emergency Stop | | Emergency Stop (E-STOP) is detected. | <ul style="list-style-type: none"> Remove the emergency stop condition.. Erase E-STOP signal. |
| E113 EE1AAGG Index Position Range Overflow | | The constant of the index position deviate the range. | <ul style="list-style-type: none"> Use a value in the range between -2,147,483,647 ~ +2,147,483,647. |

Table 7.4 Servo Alarm Types

| Alarm Code | Text Message | Cause | Action |
|---|--------------|---|---|
|   Motor Phase Over current | | <ul style="list-style-type: none">• When the error occurs while turning on the power, there is a problem in the control or main power circuit.• When this error occurs while in operation, over current exists. (Current that is 300 [%] over the rated current is supplied to the motor at more than 250 [ms]). | <ul style="list-style-type: none">• Check the wiring and the power.• Check the power and set or adjust the acceleration/deceleration time. |

Parameter List





Introduction














Parameters control CSD5 Servo drive operations. They are grouped by the type of drive, Standard or Indexing, and the settings they define.

















| Topic | Page |
|--------------------------------|------|
| Introduction | A-1 |
| Standard Parameter List | A-1 |
| Standard Parameter Description | A-9 |
| Index Parameter List | A-50 |
| Index Parameter Description | A-54 |

Standard Parameter List



















Standard Group 0



















| No. | Name | Modbus Address | Digit No. | Range | Init. | Note |
|---|-----------------------------------|----------------|-----------|----------------------|---------------------------|------------------|
|  | Operation Mode | 0000 | N/A | 1~12(F~I) | 1(F) | - |
|  | Motor Configuration | 0001,0002 | N/A | | | |
| | Encoder Type | | 0 | 0x0~0xF | 0x1(9 Line) | - |
| | Rated Power | | 1~2 | A5,01,02,04,08,10,15 | 04(400W) | Power |
| | Motor Type | | 3~4 | | 0x11(CSMT) | Motor ID |
|  | Selection of 4 Basic Mode | 0003 | N/A | | | |
| | Fault and Disable Braking | | 0 | 0~3 | 0(Brake and Hold) | - |
| | Over Travel stop method | | 1 | 0~1 | 0(Current control) | 1: Dynamic Brake |
| | Command Polarity | | 2 | 0~1 | 0(Normal) | 1: Inverted |
| | AC Lime Loss Check | | 3 | 0~2 | 0(Enable) | - |
|  | Selection of Auto Tuning Function | 0004 | N/A | | | |
| | Off-line Tuning Mode | | 0 | 0~2 | 1(Inertia Moment and RFD) | - |
| | Auto Tuning Speed | | 2 | 2~9 | 7(700 [rpm]) | Value*100 [rpm] |








| | | | | | | |
|---|--|------|---------------|--------|------------------------------|-----------|
|  | Inertia Ratio | 0005 | N/A | 0~6000 | 100 | Value/100 |
|  | Auxiliary Function Selection 1 | 0006 | N/A | | | Bit Field |
| | Encoder Backup Battery | | 0 | 0~1 | 0(Installed) | - |
| | Selection of Speed Observer | | 1 | 0~1 | 0(Disabled) | - |
| | Gain Change Enable | | 2 | 0~1 | 0(Disabled) | - |
| | Emergency Stop Input | | 3 | 0~1 | 0(Disabled) | - |
|  | Auxiliary Function Selection 2 | 0007 | N/A | | | Bit Field |
| | Automatic Motor Identification | | 0 | 0~1 | 1(Enable) | - |
| | Incremental Feedback Loss | | 1 | 0~1 | 0(Monitored) | - |
| | Mode of Gain Change | | 2 | 0~9 | 0 | - |
| | Absolute Feedback Conversion | | 3 | 0~2 | 0 | - |
|  | Drive Address | 0008 | N/A | 1~247 | 1 | - |
|  | Password | 0009 | N/A | 0~9999 | 0 | - |
|  | Serial Port Configuration | 0010 | N/A | | | Bit Field |
| | RS-232,485 Communication Speed (Baud rate) | | 0 | 0~5 | 5(57600 [bps]) | - |
| | Data bits, Parity, Stop bit | | 1 | 0~5 | 0(88bits, No parity, 1 stop) | - |
| | Protocol | | 2 | 0~1 | 0(ASCII) | - |
| | Communication Method | | 3 | 0~1 | 0(RS232)/1(RS485) | - |
|  | Allocation of Input Signal 1 | 0011 | 0x0000~0xabbb | - | 0x4bb1 | Bit Field |
|  | Allocation of Input Signal 2 | 0012 | 0x0000~0xaaaa | - | 0x0765 | Bit Field |
|  | Allocation of Input Signal 3 | 0013 | 0x0000~0xaaaa | - | 0x0000 | Bit Field |
|  | Allocation of Input Signal 4 | 0014 | 0x0000~0xaaaa | - | 0x0000 | Bit Field |
|  | Allocation of Input Signal 5 | 0015 | 0x0000~0xaaaa | - | 0x0000 | Bit Field |
|  | Allocation of Input Signal 6 | 0016 | 0x0000~0xaaaa | - | 0x0000 | Bit Field |
|  | Allocation of Input Signal 7 | 0017 | 0x0000~0xaaaa | - | 0x0000 | Bit Field |

| | | | | | | |
|---|-------------------------------|------|---------------|---|--------|-----------|
|  | Allocation of Input Signal 8 | 0018 | 0x0000~0xaaaa | - | 0x0000 | Bit Field |
|  | Allocation of Input Signal 9 | 0019 | 0x0000~0xaaaa | - | 0x0000 | Bit Field |
|  | Reserved | 0020 | - | - | - | - |
|  | Reserved | 0021 | - | - | - | - |
|  | Reserved | 0022 | - | - | - | - |
|  | Allocation of Output Signal 1 | 0023 | 0x0000~0x6666 | - | 0x0321 | Bit Field |
|  | Allocation of Output Signal 2 | 0024 | 0x0000~0x6666 | - | 0x0000 | Bit Field |
|  | Allocation of Output Signal 3 | 0025 | 0x0000~0x0066 | - | 0x0000 | Bit Field |
|  | Allocation of Output Signal 4 | 0026 | 0x0000~0x6666 | - | 0x0000 | Bit Field |
|  | Allocation of Output Signal 5 | 0027 | 0x0000~0x6666 | - | 0x0000 | Bit Field |
|  | Allocation of Output Signal 6 | 0028 | 0x0000~0x0066 | - | 0x0000 | Bit Field |
|  | Reserved | 0029 | - | - | - | - |
|  | Reserved | 0030 | - | - | - | - |
|  | Reserved | 0031 | - | - | - | - |
|  | Reserved | 0032 | - | - | - | - |
|  | I/O Control Authority | 0033 | 0x00~0x12 | - | 0x00 | Bit Field |










Standard Group 1






| No. | Name | Modbus Address | Digit No. | Range | Init. | Note |
|---|---|----------------|-----------|---------|-------------|-----------|
|  | Speed Regulator Response Level | 0100 | N/A | 1~150 | 50 | [%] |
|  | System Gain | 0101 | N/A | 10~500 | 50 | [Hz] |
|  | Velocity Regulator P Gain | 0102 | N/A | 0~10000 | 60 | - |
|  | Velocity Regulator I Gain | 0103 | N/A | 0~60000 | 26 | - |
|  | Velocity Regulator D Gain | 0104 | N/A | 0~1000 | 0 | - |
|  | Velocity Error Filter | 0105 | N/A | 0~2500 | 30 | [Hz] |
|  | Position Regulator Kp Gain | 0106 | N/A | 0~700 | 20 | [Hz] |
|  | Current Command Lowpass Filter Bandwidth | 0107 | N/A | 0~10000 | 300 | [Hz] |
|  | Velocity Command Lowpass Filter Bandwidth | 0108 | N/A | 0~10000 | 1000 | [Hz] |
|  | Position Command Lowpass Filter Bandwidth | 0109 | N/A | 0~1000 | 0 | [Hz] |
|  | 1 st Resonant Frequency Suppression Filter | 0110 | N/A | 0~10000 | 10000 | [Hz] |
|  | 1 st Resonant Frequency Suppression Filter Width | 0111 | N/A | 1~20 | 10 | - |
|  | 2 nd Resonant Frequency Suppression Filter | 0112 | N/A | 0~10000 | 10000 | [Hz] |
|  | 2 nd Resonant Frequency Suppression Filter Width | 0113 | N/A | 1~20 | 10 | - |
|  | 2 nd Resonant Frequency Suppression Filter Depth | 0114 | N/A | 0~100 | 100 | - |
|  | Position Regulator Kff Gain | 0115 | N/A | 0~100 | 0 | % |
|  | Position Regulator Kff Bandwidth | 0116 | N/A | 0~2500 | 200 | [Hz] |
|  | Velocity Regulator I Gain mode | 0117 | N/A | 0~4 | 0 (PI Mode) | Bit Field |

| | | | | | | |
|---|---|------|-----|---------|-------------|-------------------|
|  | Velocity Regulator I Gain disable threshold | 0118 | N/A | 0~3000 | 100 | - |
|  | Position Regulator High Error Output Offset | 0119 | N/A | 0~450 | 0 | [rpm] or [mm/sec] |
|  | Position Regulator High Error Output Threshold | 0120 | N/A | 0~50000 | 1000 | pulse |
|  | Current Regulator Bandwidth | 0121 | N/A | 0~2 | 1 | Bit Field |
|  | On-line Vibration Mode | 0122 | N/A | - | - | - |
| | On-line Vibration Suppression Mode | | 0 | 0~2 | 0 (Disable) | - |
| | On-line Vibration Suppression Gain | | 1 | 0~1 | 0 (Low) | - |
|  | Velocity Command Filter on Follower | 0123 | 1 | 0~1 | 0 (Disable) | Bit Field |
|  | Delay Time of Gain Switching | 0124 | N/A | 0~10000 | 0 | - |
|  | Level of Gain Switching | 0125 | N/A | 0~10000 | 0 | - |
|  | Hysteresis of Gain Switching | 0126 | N/A | 0~10000 | 0 | - |
|  | Position Gain Switching Time | 0127 | N/A | 0~10000 | 0 | - |
|  | 2 nd Velocity Regulator P Gain | 0128 | N/A | 0~10000 | 60 | - |
|  | 2 nd Velocity Regulator I Gain | 0129 | N/A | 0~60000 | 26 | - |
|  | 2 nd Position Regulator Kp Gain | 0130 | N/A | 0~700 | 20 | [Hz] |
|  | 2 nd Current Command Lowpass Filter Bandwidth | 0131 | N/A | 0~10000 | 300 | [Hz] |
|  | 2 nd Velocity Command Lowpass Filter Bandwidth | 0132 | N/A | 0~10000 | 1000 | [Hz] |
|  | 3 rd Velocity Regulator P Gain | 0133 | N/A | 0~10000 | 60 | - |
|  | 3 rd Velocity Regulator I Gain | 0134 | N/A | 0~60000 | 26 | - |
|  | 3 rd Position Regulator Kp Gain | 0135 | N/A | 0~700 | 20 | [Hz] |










| | | | | | | |
|---|---|------|-----|---------|------|------|
|  | 3 rd Current Command Lowpass Filter Bandwidth | 0136 | N/A | 0~10000 | 300 | [Hz] |
|  | 3 rd Velocity Command Lowpass Filter Bandwidth | 0137 | N/A | 0~10000 | 1000 | [Hz] |
|  | 4 th Velocity Regulator P Gain | 0138 | N/A | 0~10000 | 60 | - |
|  | 4 th Velocity Regulator I Gain | 0139 | N/A | 0~60000 | 26 | - |
|  | 4 th Position Regulator Kp Gain | 0140 | N/A | 0~700 | 20 | [Hz] |
|  | 4 th Current Command Lowpass Filter Bandwidth | 0141 | N/A | 0~10000 | 300 | [Hz] |
|  | 4 th Velocity Command Lowpass Filter Bandwidth | 0142 | N/A | 0~10000 | 1000 | [Hz] |

Standard Group 2








| No. | Name | Modbus Address | Digit No. | Range | Init. | Note |
|---|----------------------|----------------|-----------|--------------|-------|---|
|  | Velocity Scale | 0200 | N/A | 10.0~2000.0 | 500.0 | [rpm/V] or [mm/sec/V] |
|  | Jog Velocity Command | 0201 | N/A | 0~6000 | 50 | [rpm] or [mm/sec] |
|  | Acceleration | 0202, 0203 | N/A | 1~2147483647 | 41667 | 10 ⁻² xRev/sec ² , or mm/sec ² |
|  | Deceleration | 0204, 0205 | N/A | 1~2147483647 | 41667 | 10 ⁻² xRev/sec ² , or mm/sec ² |
|  | S-Curve Time | 0206 | N/A | 0~5000 | 0 | [ms] |
|  | Preset Velocity 1 | 0207 | N/A | -6000~6000 | 0 | [rpm] or [mm/sec] |
|  | Preset Velocity 2 | 0208 | N/A | -6000~6000 | 0 | [rpm] or [mm/sec] |
|  | Preset Velocity 3 | 0209 | N/A | -6000~6000 | 0 | [rpm] or [mm/sec] |
|  | Preset Velocity 4 | 0210 | N/A | -6000~6000 | 0 | [rpm] or [mm/sec] |

| | | | | | | |
|---|-----------------------|------|-----|------------|------|-------------------|
|  | Preset Velocity 5 | 0211 | N/A | -6000~6000 | 0 | [rpm] or [mm/sec] |
|  | Preset Velocity 6 | 0212 | N/A | -6000~6000 | 0 | [rpm] or [mm/sec] |
|  | Preset Velocity 7 | 0213 | N/A | -6000~6000 | 0 | [rpm] or [mm/sec] |
|  | Manual Velocity Limit | 0214 | N/A | 1~6000 | 5000 | [rpm] or [mm/sec] |
|  | Velocity Limit Mode | 0215 | N/A | 0~3 | 0 | Bit Field |











Standard Group 3








| No. | Name | Modbus Address | Digit No. | Range | Init. | Note |
|---|--|----------------|-----------|---------|-----------------------------|-----------|
|  | Command Type | 0300 | 0 | 0~6 | 0 (Step Up/Step Down) | - |
| | Controller Output Type | | 1 | 0~2 | 0 (Line Drive) | - |
| | Encoder Output Forward Direction | | 2 | 0~1 | 0 (A lead B at Fwd Dir) | - |
| | 1 st Gear Ratio Change | | 3 | 0~1 | 0 (Enable Only on Disabled) | - |
|  | 1 st Gear Ratio, Follower count (Numerator) | 0301 | N/A | 1~65535 | 4 | - |
|  | 1 st Gear Ratio, Master count (Denominator) | 0302 | N/A | 1~65535 | 1 | - |
|  | Encoder Output Ratio, Output (Denominator) | 0303 | N/A | 1~32768 | 1 | - |
|  | Encoder Output Ratio, Motor (Numerator) | 0304 | N/A | 1~32768 | 1 | - |
|  | 2 nd Gear Ratio, Follower count | 0305 | N/A | 1~65535 | 4 | - |
|  | 2 nd Gear Ratio, Master count | 0306 | N/A | 1~65535 | 1 | - |
|  | Reserved | 0307 | - | - | - | - |
|  | Digital Filter Cutoff Frequency | 0308 | | N/A | - | Bit Field |
| | Line Drive | | 0 | 0~7 | 3 (1.00MHz) | - |
| | Open Collector | | 1 | 0~7 | 7 (0.525MHz) | - |
| | High Frequency Line Drive | | 2 | 0~7 | 0 (3.000MHz) | - |

Standard Group 4

| No. | Name | Modbus Address | Digit No. | Range | Init. | Note |
|---|---------------------------------|----------------|-----------|----------|-------|------------------------|
|  | Current Scale | 0400 | N/A | 0~1000 | 333 | [%] of motor rated/[V] |
|  | Positive Internal Current Limit | 0401 | N/A | 0~500 | 300 | [%] of motor rated |
|  | Negative Internal Current Limit | 0402 | N/A | 0~500 | 300 | [%] of motor rated |
|  | Positive External Current Limit | 0403 | N/A | 0~500 | 100 | [%] of motor rated |
|  | Negative External Current Limit | 0404 | N/A | 0~500 | 100 | [%] of motor rated |
|  | Over Travel Current Limit | 0405 | N/A | 0~500 | 300 | [%] of motor rated |
|  | Initial Current Bias | 0406 | N/A | -100~100 | 0 | [%] of motor rated |


Standard Group 5

| No. | Name | Modbus Address | Digit No. | Range | Init. | Note |
|---|------------------------|----------------|-----------|---------|-------|-------|
|  | In Position Size | 0500 | N/A | 0~2500 | 10 | pulse |
|  | Reserved | 0501 | N/A | - | - | - |
|  | Near Position Size | 0502 | N/A | 0~2500 | 20 | pulse |
|  | Speed Window | 0503 | N/A | 0~1000 | 10 | pulse |
|  | Up to Speed | 0504 | N/A | 0~5000 | 20 | pulse |
|  | Zero Clamp | 0505 | N/A | 0~5000 | 0 | [rpm] |
|  | Brake Inactive Delay | 0506 | N/A | 0~10000 | 0 | [ms] |
|  | Disable Delay | 0507 | N/A | 0~10000 | 0 | [ms] |
|  | Brake Active Delay | 0508 | N/A | 0~10000 | 500 | [ms] |
|  | Disabled Braking Speed | 0509 | N/A | 0~1000 | 100 | [rpm] |



| | | | | | | |
|---|-----------------------------|------------|-----|--------------|-----------------------|---------------------|
|  | Following Error Limit | 0510, 0511 | N/A | 0~2147483647 | 99999 | pulse |
|  | Reserved | 0512 | N/A | - | - | - |
|  | AC Line Loss Fault Delay | 0513 | N/A | 20~1000 | 20 | [ms] |
|  | Analog Output CH1 Selection | 0514, 0515 | N/A | 0~28 | 0 (Velocity Feedback) | - |
|  | Analog Output CH2 Selection | 0516, 0517 | N/A | 0~28 | 1 (Velocity Command) | - |
|  | Analog Output CH1 Scale | 0518, 0519 | N/A | 1~99999 | 500 | Depend on [Ft-5.13] |
|  | Analog Output CH2 Scale | 0520, 0521 | N/A | 1~99999 | 500 | Depend on [Ft-5.14] |


Standard Parameter Description

Standard Group 0


| | | |
|---|--|--|
|  | Operations Mode | |
| | RSWare : Drive - Operation Modes (Main/Override) | |
| Description | Set control mode (Optional) | |
| Display (Value) | Operating Mode | RSWare Name |
| F(1) | Position Control Mode | Follower/None |
| S(2) | Speed Control Mode | Analog Velocity Input/ None |
| C(3) | Torque Control Mode | Analog Current Input/ None |
| SF(4) | Speed+Position Control Mode | Analog Velocity Input/ Follower |
| CF(5) | Torque+Speed Control Mode | Analog Velocity Current/ Follower |
| CS(6) | Torque+Speed Control Mode | Analog Current Input/Analog Velocity Input |
| P(7) | Multi-Step Speed + Speed Control Mode | Preset Velocity / None |
| PF(8) | Multi-Step Speed + Position Control Mode | Preset Velocity / Follower |
| PS(9) | Multi-Step Speed + Torque Control Mode | Preset Velocity/ Analog Velocity Input |
| PC(10) | Multi-Step Speed + Torque Control Mode | Preset Velocity/ Analog Current Input |
| I(12) | Indexing | Indexing Input/ None |

| | |
|---------------------------|---|
| Initial Value | 1(F) |
| Applicable Operating Mode | All |
| When Enabled | Servo-Off > Setting > After Power Cycle |


| | |
|---|--|
|  | Motor Configuration |
| | RSWare : Drive - Motor - Motor Model |
| Applicable Operating Mode | All |
| Description | Set motor type |
| Setting Value | <ul style="list-style-type: none"> Set items such as motor type, motor rated output, and encoder type. Check out model name attached motor nameplate. With Up/Down direction key, Alphabet and Numbers of item are displayed. <p>Example displays of model attached motor nameplate is as follow. Fill correct information in corresponding position according to following picture.</p> <div style="text-align: center;">  </div> |


| | | | |
|---|--|---|--------------------|
|  | Selection of 4 Basic Mode | | |
| Applicable Operating Mode | All | | |
| Data Size | 4 digits | | |
| Digit 0 | Fault and Disable Braking RSWare : Drive - Stopping Functions - Fault and Disable Braking | | |
| Range | Value | Description | RSWare Name |
| | 0 | Keep DB after DB stop | Brake and hold |
| | 1 | DB is released after DB stop | Brake and release |
| | 2 | Stop Free run (operation) without DB stop | Free Stop |
| | 3 | Keep DB after stop Free run | Free Stop and hold |
| Initial Value | 0 | | |
| Digit 1 | Overtravel stop method RSWare : Drive - Stopping Functions - Overtravel Stop Method | | |
| Range | Value | Description | RSWare Name |
| | 0 | Stop by normal torque contorl during overtravel. At this monent,can contorl torque by setting overtravel torque linit [Ft-4.05]. | Current Control |
| | 1 | Stop by the method set at the DB stop method selection in [Ft-0.02] when overtravel occurs. | Dynamic Brake |

| | | | |
|---------------|---|---|--------------------|
| Initial Value | 0 | | |
| Digit 2 | Motor Forward Dir. RSWare : Drive - Command Polarity | | |
| Range | Value | Description | RSWare Name |
| | 0 | The command signal is not inverted so that a positive command value results in CW Rotation, (as viewed from shaft end). | Normal |
| | 1 | The command signal is inverted so that a positive command value results in CCW Rotation, (as viewed from shaft end). | Inverted |
| Initial Value | 0 | | |
| Digit 3 | Power Input RSWare : Drive - AC Line Loss Check | | |
| Range | Value | Description | RSWare Name |
| | 0 | Check input power 50~400W Servo Drive: Enable single-phase open check 800~1.5kW Servo Drive: 3-phase open check | Enable |
| | 1 | Do not check the input power | Disable |
| | 2 | Single-phase input | Single phase input |
| Initial Value | 0 | | |


| | | | |
|--|---|--|--|
|  | Selection of Auto Tuning Function | | |
| Applicable Operating Mode | All | | |
| Data Size | 4 digits | | |
| Digit 0 | Off-Line Tuning Mode RSWare : Drive - Tuning - Autotuning - Off-Line Tuning Mode | | |
| Range | Value | Description | RSWare Name |
| | 0 | Inertia Moment Estimation | Inertia Moment Estimation |
| | 1 | Inertia Moment Estimation and Resonant Frequency Detection | Inertia Moment Estimation and Resonant Frequency Detection |
| | 2 | Resonance frequency Detection | Resonant Frequency Detection |
| Initial Value | 1 | | |
| Digit 1 | Reserved | | |
| Digit 2 | Autotuning Speed RSWare : Drive - Tuning - Autotuning - Autotuning Speed | | |
| Range | Value | Description | |
| | 2-9 | The larger the setting value, the higher speed. | |
| Initial Value | 7 | | |
| Unit | Setting value* 100 [rpm] | | |
| Digit 3 | Dynamic Tuning Response RSWare: Online Tuning Response | | |
| Range | Value | Description | |
| | 0 | Off | |
| | 1 | Slowest | |

| | | |
|---------------|---------------------|-------------|
| | 2 | Slowest |
| | 3 | Slow |
| | 4 | Medium-Slow |
| | 5 | Medium |
| | 6 | Medium-Fast |
| | 7 | Fast |
| | 8 | Faster |
| | 9 | Faster |
| Initial Value | 0 | |
| When Enabled | Servo-Off > Setting | |


| | | | |
|---|--|--|--|
|  | | Inertia Ratio | |
| | | RSWare : Drive - Motor - Inertia Ratio | |
| Description | | Inertial Ratio shows Load Inertia to Motor | |
| Range | | 0 ~ 6,000 | |
| Initial Value | | 100 | |
| Unit | | (Load inertia/Motor inertia) / 100 | |
| When Enabled | | Immediately | |

| | | | |
|---|-------|--|-------------|
|  | | Auxiliary Function Selection 1 | |
| Applicable Operation Mode | | All | |
| Data Size | | 4 digits | |
| Digit 0 | | Encoder Backup Battery RSWare : Drive - Encoder - Encoder Backup Battery | |
| Range | Value | Description | |
| | 0 | Backup Battery Installed | |
| | 1 | Backup Battery Not Installed | |
| Initial Value | | 0 | |
| Digit 1 | | Velocity Observer RSWare : Drive - Auxiliary Function Selection 1 - Velocity Observer | |
| Range | Value | Description | RSWare Name |
| | 0 | Disable | Disable |
| | 1 | Enable | Enable |
| Initial Value | | 0 | |
| Digit 2 | | Gain Change Enable RSWare : Drive - Tuning - Gain Change Enable | |

| | | | |
|---------------|--|-------------|-------------|
| Range | Value | Description | RSWare Name |
| | 0 | Disable | Disable |
| | 1 | Enable | Enable |
| Initial Value | 0 | | |
| Digit 3 | Emergency Stop Input RSWare : Drive - Auxiliary Function Selection 1 - Emergency Stop Input | | |
| Range | Value | Description | RSWare Name |
| | 0 | Disable | Disable |
| | 1 | Enable | Enable |
| Initial Value | 0 | | |
| When Enabled | Servo-Off > Setting > After power cycle | | |

| | | | | |
|---|---|-------------|-------------|---------------------------------------|
|  | | | | Auxiliary function Selection 2 |
| Applicable Operation Mode | All | | | |
| Data Size | 2 digits | | | |
| Digit 0 | Automatic Motor Identification RSWare : Drive - Auto Motor Iden | | | |
| Range | Value | Description | RSWare Name | |
| | 0 | Disabled | Disable | |
| | 1 | Enabled | Enable | |
| Initial Value | 1 | | | |
| Digit 1 | Incremental Feedback Loss RSWare : Drive - Encoder - Incremental Feedback Loss | | | |
| Range | Value | Description | RSWare Name | |
| | 0 | Monitored | Monitored | |
| | 1 | Ignored | Ignored | |
| Initial Value | 0 | | | |
| Digit 2 | Mode of Gain Switching RSWare : Drive - Tuning - Mode of Gain Switching | | | |

| Range | Value | Description | RSWare Name |
|---------------|---|--|----------------------------|
| | 0 | Fixed to the 1 st gain. | 1st Gain Fix |
| | 1 | Fixed to 2 nd gain. | 2nd Gain Fix |
| | 2 | 2 nd gain selection when the gain switching input is turned on. | Digital Input (G-SEL) |
| | 3 | 2 nd gain selection when the torque command is larger than the setups (level of gain control switching and hysteresis of control switching). | Torque Command |
| | 4 | 2 nd gain selection when the command speed is larger than the setups (level of gain control switching and hysteresis of control switching). | Velocity Command |
| | 5 | 2 nd gain selection when the positional deviation is larger than the setups (level of gain control switching and hysteresis of control switching). | Position Error |
| | 6 | 2 nd gain selection when more than one command pulse exists between 200usec. | Position Command |
| | 7 | 2 nd gain selection when the positional deviation counter value exceeds the setup of Positioning completer range. | In-Position |
| | 8 | 2 nd gain selection when the motor actual speed exceeds the setup (level of gain control switching and hysteresis of control switching). Switches to the 2nd gain while the position command exists. | Velocity |
| | 9 | Switches to the 1 st gain when no-position command status lasts for the setup of delay time of gain switching [x 200usec] and the speed falls slower than the setups of gain control switching level and hysteresis of control switching. | Position command and Speed |
| Initial Value | 0 | | |
| Digit 3 | Absolute Feedback Transfer Type RSWare : Drive - Absolute Feedback Transfer Type | | |
| Range | Value | Description | RSWare Name |
| | 0 | Same as Command Polarity | Same as Command Polarity |
| | 1 | Always CCW | Always CCW |
| | 2 | Always CW | Always CW |
| Initial Value | 0 | | |
| When Enabled | Immediately | | |

|  | Drive Address |
|---|---|
| | RSWare : Drive - Communications - Drive Address |
| | Applicable Operating Mode All |
| | Range 1-247 |
| | Initial Value 1 |

| | |
|--------------|-------------|
| When Enabled | Immediately |
|--------------|-------------|

**Password**


| | |
|---------------------------|--|
| Applicable Operating Mode | |
| Range | |
| Initial Value | |
| When Enabled | |


**Serial Port Configuration**


RSWare : Drive - Communications

| | | | |
|---------------------------|---|--------------|---------------------------------|
| Applicable Operating Mode | All | | |
| Data Size | 4 digits | | |
| Digit 0 | RS-232C, RS-485 Baud Rate RSWare : Drive - Communications - Baudrate | | |
| Range | Value | Descriptions | RSWare Name |
| | 0 | 9600bps | 9600bps |
| | 1 | 14400bps | 14400bps |
| | 2 | 19200bps | 19200bps |
| | 3 | 38400bps | 38400bps |
| | 4 | 56000bps | 56000bps |
| | 5 | 57600bps | 57600bps |
| Initial Value | 5 | | |
| Digit 1 | Data bits, Parity, Stop bit RSWare : Drive - Communications - Frame Format | | |
| Range | Value | Description | RSWare Name |
| | 0 | 8, No, 1 | 8 Data, No Parity, 1 Stop bit |
| | 1 | 8, Even, 1 | 8 Data, Even Parity, 1 Stop bit |
| | 2 | 8, Odd, 1 | 8 Data, Odd Parity, 1 Stop bit |
| | 3 | 8, No, 2 | 8 Data, No Parity, 2 Stop bit |
| | 4 | 8, Even, 2 | 8 Data, Even Parity, 2 Stop bit |
| | 5 | 8, Odd, 2 | 8 Data, Odd Parity, 2 Stop bit |
| Initial Value | 0 | | |
| Digit 2 | Protocol RSWare : Drive - Communications - Protocol | | |
| Range | Value | Description | RSWare Name |
| | 0 | ASCII | ASCII |
| | 1 | MODBUS-RTU | MODBUS-RTU |
| Initial Value | 0 | | |


| | | | |
|---------------|----------------------|-------------|-------------|
| Digit 3 | Communication Method | | |
| Range | Value | Description | RSWare Name |
| | 0 | RS232 | RS232 |
| | 1 | RS485 | RS485 |
| Initial Value | 0 | | |
| When Enabled | Immediately | | |


| | | | | |
|---|---|-------|--------------------|-----------------------|
|  | Allocation of Input Signals 1 | | | |
| | RSWare : Drive - Digital Inputs | | | |
| Range for All Digits | 0-B, Where 0 is Off, B is On, and 1-A are digital input | | | |
| Data Size | 4 digits | | | |
| Digit | Description | Init. | Unmapped IO Status | RSWare Parameter |
| 0 | Drive Enable (/SV-ON) | 1 | ON | Drive Enable |
| 1 | Positive Over-travel (P-OT) | b | ON | Overtravel - Positive |
| 2 | Negative Over-travel (N-OT) | b | ON | Overtravel - Negative |
| 3 | Integrator Inhibit (/P-CON) | 4 | OFF | Integrator Inhibit |
| Applicable Operating Mode | All | | | |
| When Enabled | Seveo Off > Setting | | | |


| | | | | |
|---|---|-------|--------------------|--------------------------|
|  | Allocation of Input Signals 2 | | | |
| | RSWare : Drive - Digital Inputs | | | |
| Range for All Digits | 0-B, Where 0 is Off, B is On, and 1-A are digital input | | | |
| Data Size | 4 digits | | | |
| Digit | Description | Init. | Unmapped IO Status | RSWare Name |
| 0 | Fault Reset (/A-RST) | 5 | OFF | Fault Reset |
| 1 | Negative Current Limit (/N-TL) | 6 | OFF | Current Limit - Negative |
| 2 | Positive Current Limit (/P-TL) | 7 | OFF | Current Limit - Positive |
| 3 | Operation Mode Override (/C-SEL) | 0 | OFF | Operation Mode Override |
| Applicable Operating Mode | All | | | |
| When Enabled | Seveo Off > Setting | | | |


| | | | | |
|---|---|--|--|--|
|  | Allocation of Input Signals 3 | | | |
| | RSWare : Drive - Digital Inputs | | | |
| Range for All Digits | 0-B, Where 0 is Off, B is On, and 1-A are digital input | | | |


| | | | | |
|---------------------------|---------------------------|-------|--------------------|------------------|
| Data Size | 4 digits | | | |
| Digit | Description | Init. | Unmapped IO Status | RSWare Name |
| 0 | Preset Direction (/C-DIR) | 0 | OFF | Preset Direction |
| 1 | Preset Select 1 (/C-SP1) | 0 | OFF | Preset Select 1 |
| 2 | Preset Select 2 (/C-SP2) | 0 | OFF | Preset Select 2 |
| 3 | Preset Select 3 (/C-SP3) | 0 | OFF | Preset Select 3 |
| Applicable Operating Mode | All | | | |
| When Enabled | Seveo Off > Setting | | | |

| | | | | |
|---|---|-------|--------------------|-------------------------|
|  | Allocation of Input Signals 4 | | | |
| | RSWare : Drive - Digital Inputs | | | |
| Range for All Digits | 0-B, Where 0 is Off, B is On, and 1-A are digital input | | | |
| Data Size | 4 digits | | | |
| Digit | Description | Init. | Unmapped IO Status | RSWare Name |
| 0 | Zero Speed Clamp Enable (/Z-CLP) | 0 | OFF | Zero Speed Clamp Enable |
| 1 | Pause Follower (/INHIBIT) | 0 | OFF | Pause Follower |
| 2 | Alternate Gain Select (/G-SEL) | 0 | OFF | Alternate Gain Select |
| 3 | Position clear (/PCLR) | 0 | OFF | Position Clear |
| Applicable Operating Mode | All | | | |
| When Enabled | Seveo Off > Setting | | | |


| | | | | |
|---|---|-------|--------------------|--|
|  | Allocation of Input Signals 5 | | | |
| | RSWare : Drive - Digital Inputs | | | |
| Range for All Digits | 0-B, Where 0 is Off, B is On, and 1-A are digital input | | | |
| Data Size | 4 digits | | | |
| Digit | Description | Init. | Unmapped IO Status | RSWare Name |
| 0 | Position Strobe (/ABS-DT) | 0 | OFF | Position Strobe |
| 1 | Start (/START) | 0 | OFF | Motor Moving Enable |
| 2 | Analog Speed Command Select 4 (/C-SP4) | 0 | OFF | Analog Speed Command Enable |
| 3 | 2 nd Electronic Gear Bank Selection (/GEAR) | 0 | OFF | 2 nd Electronic Gear Bank Selection |
| Applicable Operating Mode | All | | | |
| When Enabled | Seveo Off > Setting | | | |


|  Allocation of Input Signals 6 RSWare : Drive - Digital Inputs | | | | |
|---|--|-------|--------------------|---------------------------------|
| Data Size | 4 digits | | | |
| Digit | Description | Init. | Unmapped IO Status | RSWare Name |
| 0 | Reset multi-turn data of Absolute Encoder (/R-ABS) | 0 | OFF | Reset Multiturn Data |
| 1 | Gain Bank Select (/BANK_SEL) | 0 | OFF | Gain Bank Select |
| 2 | Analog Current Limit (/A-CL) | 0 | OFF | Analog Current Limit |
| 3 | Absolute Position Data Transfer Mode (/ABS-MD) | 0 | OFF | Absolute Position Transfer Mode |
| Applicable Operating Mode | All | | | |
| When Enabled | Seveo Off > Setting | | | |


|  Allocation of Input Signals 7 RSWare : Drive - Digital Inputs | | | | |
|---|-------------------------|-------|--------------------|----------------|
| Data Size | 4 digits | | | |
| Digit | Description | Init. | Unmapped IO Status | RSWare Name |
| 0 | Home Sensor (/H_SENS) | 0 | OFF | Home Sensor |
| 1 | Start Homing (/SHOME) | 0 | OFF | Start Homing |
| 2 | Stop Indexing (/STOP) | 0 | OFF | Stop Indexing |
| 3 | Pause Indexing (/PAUSE) | 0 | OFF | Pause Indexing |
| Applicable Operating Mode | I | | | |
| When Enabled | Seveo Off > Setting | | | |

|  Allocation of Input Signals 8 RSWare : Drive - Digital Inputs | | | | |
|---|--------------------------------|-------|--------------------|-------------------------|
| Data Size | 4 digits | | | |
| Digit | Description | Init. | Unmapped IO Status | RSWare Name |
| 0 | Index Select 0 Input (/I_SEL0) | 0 | OFF | Indexing Select 0 Input |
| 1 | Index Select 1 Input (/I_SEL1) | 0 | OFF | Indexing Select 1 Input |
| 2 | Index Select 2 Input (/I_SEL2) | 0 | OFF | Indexing Select 2 Input |


| | | | | |
|---------------------------|--------------------------------|---|-----|-------------------------|
| 3 | Index Select 3 Input (/I_SEL3) | 0 | OFF | Indexing Select 3 Input |
| Applicable Operating Mode | I | | | |
| When Enabled | Seveo Off > Setting | | | |

| | | | | |
|---|--------------------------------|-------|--------------------|-------------------------|
|  Allocation of Input Signals 9 RSWare : Drive - Digital Inputs | | | | |
| Data Size | 4 digits | | | |
| Digit | Description | Init. | Unmapped IO Status | RSWare Name |
| 0 | Index Select 4 Input (/I_SEL4) | 0 | OFF | Indexing Select 4 Input |
| 1 | Index Select 5 Input (/I_SEL5) | 0 | OFF | Indexing Select 5 Input |
| 2 | Stop Homing (/H_STOP) | 0 | OFF | Stop Homing |
| 3 | Start Indexing (/START_I) | 0 | OFF | Start Index |
| Applicable Operating Mode | I | | | |
| When Enabled | Seveo Off > Setting | | | |


| | | | |
|--|-------------|-------|--------------------|
|  Allocation of Input Signals 10 RSWare : Drive - Digital Inputs | | | |
| Data Size | 4 digit | | |
| Digit | Description | Init. | Unmapped IO Status |
| 0 | Reserved | 0 | OFF |
| 1 | Reserved | 0 | OFF |
| 2 | Reserved | 0 | OFF |
| 3 | Reserved | 0 | OFF |
| Applicable Operating Mode | Reserved | | |
| When Enabled | Reserved | | |

| | | | |
|---|-------------|-------|--------------------|
|  Allocation of Input Signals 11 | | | |
| Data Size | 4 digit | | |
| Digit | Description | Init. | Unmapped IO Status |
| 0 | Reserved | 0 | OFF |
| 1 | Reserved | 0 | OFF |
| 2 | Reserved | 0 | OFF |

| | | | |
|---------------------------|----------|---|-----|
| 3 | Reserved | 0 | OFF |
| Applicable Operating Mode | Indexing | | |
| When Enabled | Reserved | | |


| | | | |
|---|---------------------------------------|-------|--------------------|
|  | Allocation of Input Signals 12 | | |
| Data Size | 4 digit | | |
| Digit | Description | Init. | Unmapped IO Status |
| 0 | Reserved | 0 | OFF |
| 1 | Reserved | 0 | OFF |
| 2 | Reserved | 0 | OFF |
| 3 | Reserved | 0 | OFF |
| Applicable Operating Mode | Reserved | | |
| When Enabled | Seveo Off > Setting | | |


| | | | | | | | | | | | | |
|-------------------------------|--------------------|----|----|----|---|---|---|---|---|---|---|---------------------|
| Setting Value (Ft-0.10~21) | B | A | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| Input Channel No. | Input Signal On | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | Input Signal Off |
| I/O Pin No. | | 28 | 27 | 26 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | |


| | | | |
|---|---|-------|------------------------|
|  | Allocation of Output Signals 1 | | |
| | RSWare : Drive - Digital Outputs | | |
| Range for All Digits | 0-3, Where 0 is Off, and 1-6 are digital output | | |
| Data Size | 4 digits | | |
| Digit | Description | Init. | RSWare Name |
| 0 | Within Position Window (/P-COM) | 1 | Within Position Window |
| 1 | Up to Speed (/TG-ON) | 2 | Up to Speed |
| 2 | Brake Contorl (BK) | 3 | Brake |
| 3 | Within Speed Window (/V-COM) | 0 | Within Speed Window |
| Applicable Operating Mode | All | | |
| When Enabled | Servo Off > Setting | | |


| | | | |
|---|---------------------------------------|--|--|
|  | Allocation of Output Signals 2 | | |
| | RSWare : Drive - Digital Outputs | | |


| | | | |
|---------------------------|---|-------|--------------------|
| Range for All Digits | 0-3, Where 0 is Off, and 1-6 are digital output | | |
| Data Size | 4 digits | | |
| Digit | Description | Init. | RSWare Name |
| 0 | Current Limited (/T-LMT) | 0 | Current Limited |
| 1 | Velocity Limited (/V-LMT) | 0 | Velocity Limited |
| 2 | Within Near Window (/NEAR) | 0 | Within Near Window |
| 3 | Warning (/WARN) | 0 | Warning |
| Applicable Operating Mode | All | | |
| When Enabled | Servo Off > Setting | | |


| | | | |
|---|---|-------|-------------------------|
|  | Allocation of Output Signals 3 | | |
| | RSWare : Drive - Digital Outputs | | |
| Range for All Digits | 0-3, Where 0 is Off, and 1-6 are digital output | | |
| Data Size | 4 digits | | |
| Digit | Description | Init. | RSWare Name |
| 0 | Absolute Position Valid (/A-VLD) | 0 | Absolute Position Valid |
| 1 | Servo drive ready (/RDY) | 0 | Ready |
| 2 | Reserved | 0 | |
| 3 | Reserved | 0 | |
| Applicable Operating Mode | All | | |
| When Enabled | Servo Off > Setting | | |


| | | | |
|---|---|-------|--------------------|
|  | Allocation of Output Signals 4 | | |
| | RSWare : Drive - Digital Outputs | | |
| Range for All Digits | 0-3, Where 0 is Off, and 1-6 are digital output | | |
| Data Size | 4 digits | | |
| Digit | Description | Init. | RSWare Name |
| 0 | In Motion (/IMO) | 0 | In Motion |
| 1 | In Dwell (/I-DW) | 0 | In Dwell |
| 2 | Axis Homed (/HOMC) | 0 | Axis Homed |
| 3 | Index Select 0 Out (/O_ISEL0) | 0 | Index Select 0 Out |
| Applicable Operating Mode | I | | |
| When Enabled | Servo Off > Setting | | |


|  Allocation of Output Signals 5 RSWare : Drive - Digital Outputs | | | |
|---|---|-------|--------------------|
| Range for All Digits | 0-3, Where 0 is Off, and 1-6 are digital output | | |
| Data Size | 4 digits | | |
| Digit | Description | Init. | RSWare Name |
| 0 | Index Select 1 Out (/O_ISEL1) | 0 | Index Select 1 Out |
| 1 | Index Select 2 Out (/O_ISEL2) | 0 | Index Select 2 Out |
| 2 | Index Select 3 Out (/O_ISEL3) | 0 | Index Select 3 Out |
| 3 | Index Select 4 Out (/O_ISEL4) | 0 | Index Select 4 Out |
| Applicable Operating Mode | I | | |
| When Enabled | Servo Off > Setting | | |


|  Allocation of Output Signals 6 RSWare : Drive - Digital Outputs | | | |
|---|---|-------|--------------------|
| Range for All Digits | 0-3, Where 0 is Off, and 1-6 are digital output | | |
| Data Size | 4 digits | | |
| Digit | Description | Init. | RSWare Name |
| 0 | Index Select 5 Out (/O_ISEL5) | 0 | Index Select 5 Out |
| 1 | End of Sequence (/E_SEQU) | 0 | End of Sequence |
| 2 | Reserved | 0 | |
| 3 | Reserved | 0 | |
| Applicable Operating Mode | I | | |
| When Enabled | Servo Off > Setting | | |

|  Allocation of Output Signals 7 RSWare : Drive - Digital Outputs | | | |
|---|-------------|-------|--|
| Digit | Description | Init. | |
| 0 | Reserved | 0 | |
| 1 | Reserved | 0 | |
| 2 | Reserved | 0 | |
| 3 | Reserved | 0 | |
| Applicable Operating Mode | Reserved | | |
| When Enabled | Reserved | | |


| | | |
|---|---|-------|
|  | Allocation of Output Signals 8 | |
| | RSWare : Drive - Digital Outputs | |
| Range for All Digits | 0-3, Where 0 is Off, and 1-6 are digital output | |
| Data Size | 4 digits | |
| Digit | Description | Init. |
| 0 | Reserved | 0 |
| 1 | Reserved | 0 |
| 2 | Reserved | 0 |
| 3 | Reserved | 0 |
| Applicable Operating Mode | Reserved | |
| When Enabled | Reserved | |


| | | |
|---|---|-------|
|  | Allocation of Output Signals 9 | |
| | RSWare : Drive - Digital Outputs | |
| Range for All Digits | 0-3, Where 0 is Off, and 1-6 are digital output | |
| Data Size | 4 digits | |
| Digit | Description | Init. |
| 0 | Reserved | 0 |
| 1 | Reserved | 0 |
| 2 | Reserved | 0 |
| 3 | Reserved | 0 |
| Applicable Operating Mode | Reserved | |
| When Enabled | Reserved | |


| | | |
|---|---|-------|
|  | Allocation of Output Signals 10 | |
| | RSWare : Drive - Digital Outputs | |
| Range for All Digits | 0-3, Where 0 is Off, and 1-6 are digital output | |
| Data Size | 4 digits | |
| Digit | Description | Init. |
| 0 | Reserved | 0 |
| 1 | Reserved | 0 |
| 2 | Reserved | 0 |
| 3 | Reserved | 0 |
| Applicable Operating Mode | Reserved | |
| When Enabled | Reserved | |


| | | |
|---|--|----------------------------|
|  | | I/O Control |
| Description | Run & Input Control Selection It is used for selection of run-xx or Input function using Modbus. Input function on Hardware cannot be used in case that the input function is used by Modbus with this parameter. Run function cannot be used by key pad, similarly, if the run function is used by Modbus. 0x00 - Not use both Run and Input function by Modbus 0x01 - Use Input function only 0x10 - Use run function only 0x11 - Use both Run and Input function by Modbus 0x12 - Use Run input , Input function and Special Function by Modbus | |
| Data Size | 2 digits | |
| Digit 0 | Drive -Communications-MODBUS Input Function Control RSWare: MODBUS Input Function Control | |
| Range | Value | RSWare Name |
| | 0x0 | Disable |
| | 0x1 | Enable |
| | 0x11 | Disable + Special Function |
| Unit | - | |
| Initial Value | 0 | |
| Digit 1 | MODBUS Run Function Control RSWare: Drive -Communications-MODBUS Run Function Control | |
| Range | Value | RSWare Name |
| | 0x0 | Disable |
| | 0x10 | Enable |
| Initial Value | 0 | |
| Applicable Operation Mode | All | |
| When Enabled | Servo Off > Setting | |


Standard Group 1


| | |
|---|---|
|  | Velocity Regulator Response level |
| | RSWare : Drive - Tuning - Velocity Regulator Response Level |
| Description | Set system gain in proportion to speed response level automatically by referring the estimated inertia ratio after auto tuning. |
| Range | 1~150 |
| Initial Value | 50 |
| Unit | [%] |
| Applicable Operating Mode | All |
| When Enabled | Immediately |


| | |
|---|---|
|  | System Gain |
| | RSWare : Drive - Tuning - System Gain |
| Description | <ul style="list-style-type: none"> • A higher value results in higher position/speed/torque related gain values and higher responsiveness. (However, excessive values can result in noise and vibrations) • Conversely, lower values result in smaller gain and lower responsiveness; however, the whole system's stability is increased. • Refers to the bandwidth of the entire speed control loop. • When this value is changed, the gain values [Ft-1.02], [Ft-1.03], [Ft-1.06],[Ft-1.07], [Ft-1.08] are set automatically according to the control mode while referring to the inertia ratio parameter [Ft-0.04]. • The lower limit is 10 [Hz]. |
| Range | 10~500 |
| Initial Value | 50 |
| Unit | [Hz] |
| Applicable Operating Mode | All |
| When Enabled | Immediately |

| | |
|---|--|
|  | Speed Regulator P Gain |
| | RSWare : Drive - Tuning - Main Velocity Regulator Gains - P |
| Description | <ul style="list-style-type: none"> • Parameter which determines the responsiveness of speed control. • Value changed simultaneously with change of inertia ratio [Ft-0.04] or system gain [Ft-1.01]. |
| Range | 0~10000 |
| Initial Value | 60 |
| Unit | - |
| Applicable Operating Mode | F, S, P |
| When Enabled | Immediately |

| | |
|---|---|
|  | Speed Regulator I Gain RSWare : Drive - Tuning - Main Velocity Regulator Gains - Integrator Gain |
| Description | <ul style="list-style-type: none"> Removes steady state speed tolerance. Overshoot in speed response can occur if set value is too large. Value changed by change in inertia ratio [Ft-0.04] or system gain [Ft-1.00]. |
| Range | 0~60000 |
| Initial Value | 26 |
| Unit | - |
| Applicable Operating Mode | F, S, P |
| When Enabled | Immediately |

| | |
|---|---|
|  | Speed Regulator D gain RSWare : Drive - Tuning - Main Velocity Regulator Gains - D |
| Description | The larger the setting value, the higher speed. Excessive values can result in noise and vibration. |
| Range | 0~1000 |
| Initial Value | 0 |
| Unit | - |
| Applicable Operating Mode | F, S, P |
| When Enabled | Immediately |

| | |
|---|---|
|  | Speed Error Filter RSWare : Drive - Tuning - Main Velocity Regulator Gains - Error Filter Bandwidth |
| Description | Suppresses high frequency components of speed tolerance. |
| Unit | 0~2500 |
| Initial Value | 30 |
| Unit | [Hz] |
| Applicable Operating Mode | F, S, P |
| When Enabled | Immediately |

| | |
|---|--|
|  | Position Regulator Kp Gain RSWare : Drive - Tuning - Main Position Regulator Gains - Kp |
| Description | <ul style="list-style-type: none"> Parameter which determines the responsiveness of position control. Change set value according to rigidity of load. Value changed according to system gain [Ft-1.01]. |
| Unit | 0~700 |

| | |
|---------------------------|-------------|
| Initial Value | 20 |
| Unit | [Hz] |
| Applicable Operating Mode | F |
| When Enabled | Immediately |

**Current Command Low pass Filter Bandwidth**

RSWare : Drive - Tuning - Main Current Regulator Gains - Low Pass Filter Bandwidth

| | |
|---------------------------|--|
| Description | <ul style="list-style-type: none"> • Suppresses high frequency components of torque command. • Value changed according to system gain [Ft-1.01]. |
| Unit | 0~10000 |
| Initial Value | 300 |
| Unit | Hz |
| Applicable Operating Mode | All |
| When Enabled | Immediately |

**Speed Command Low pass Filter Bandwidth**


RSWare : Drive - Tuning - Main Velocity Regulator Gains - Low Pass Filter Bandwidth


| | |
|---------------------------|---|
| Description | <ul style="list-style-type: none"> • Sets low pass cutoff frequency of speed command to suppress high frequency components. • Value changed according to system gain [Ft-1.01]. |
| Unit | 0~10000 |
| Initial Value | 1000 |
| Unit | Hz |
| Applicable Operating Mode | F, S, P |
| When Enabled | Immediately |


**Position Command Low pass Filter Bandwidth**


RSWare : Drive - Tuning - Main Position Regulator Gains - Low Pass Filter Bandwidth

| | |
|---------------------------|--|
| Description | Sets low pass cutoff frequency of speed command to suppress high frequency components. |
| Unit | 0~1000 |
| Initial Value | 0 |
| Unit | [Hz] |
| Applicable Operating Mode | F |
| When Enabled | Immediately |


| | |
|---|---|
|  | 1st Resonant Frequency Suppression Filter RSWare : Drive - Tuning - Main Current Regulator Gains - 1 st Resonant Frequency Suppression Filter |
| Description | Suppresses Vibration by cutting off Current Command in assigned frequency band. |
| Unit | 0~10000 |
| Initial Value | 10000 |
| Unit | [Hz] |
| Applicable Operating Mode | All |
| When Enabled | Immediately |


| | |
|---|---|
|  | 1st Resonant Frequency Suppression Filter Width RSWare : Drive - Tuning - Main Current Regulator Gains - 1 st Resonant Frequency Suppression Filter Width |
| Description | Set up the notch width of the 1st resonance suppressing filter in 20 steps. Higher the setup, larger the notch width you can obtain. |
| Unit | 1~20 |
| Initial Value | 10 |
| Unit | - |
| Applicable Operating Mode | All |
| When Enabled | Immediately |


| | |
|---|---|
|  | 2nd Resonant Frequency Suppression Filter RSWare : Drive - Tuning - Main Current Regulator Gains - 2 nd Resonant Frequency Suppression Filter |
| Description | Suppresses Vibration by cutting off Current Command in assigned frequency band. |
| Unit | 0~10000 |
| Initial Value | 10000 |
| Unit | [Hz] |
| Applicable Operating Mode | All |
| When Enabled | Immediately |

| | |
|---|---|
|  | 2nd Resonant Frequency Suppression Filter Width RSWare : Drive - Tuning - Main Current Regulator Gains - 2 nd Resonant Frequency Suppression Filter Width |
|---|---|


| | |
|---------------------------|--|
| Description | Set up the notch width of 2nd resonance suppressing filter in 20 steps. Higher the setup, larger the notch width you can obtain. |
| Unit | 1~20 |
| Initial Value | 10 |
| Unit | - |
| Applicable Operating Mode | All |
| When Enabled | Immediately |


| | |
|---|---|
|  | 2nd Resonant Frequency Suppression Filter Depth RSWare : Drive - Tuning - Main Current Regulator Gains - 2 nd Resonant Frequency Suppression Filter Depth |
| Description | Set up the 2nd notch depth of the resonance suppressing filter. Higher the setup, shallower the notch depth and smaller the phase delay you can obtain. |
| Unit | 0~100 |
| Initial Value | 100 |
| Unit | - |
| Applicable Operating Mode | All |
| When Enabled | Immediately |


| | |
|---|---|
|  | Position Regulator Kff Gain RSWare : Drive - Tuning - Main Position Regulator Gains - Kff |
| Description | <ul style="list-style-type: none"> Larger values result in faster position completion and smaller position tolerances at transient response condition. Value can differ according to load's type or rigidity; too large values result in vibration. |
| Unit | 0~100 |
| Initial Value | 0 |
| Unit | [%] |
| Applicable Operating Mode | F |
| When Enabled | Immediately |

| | |
|---|--|
|  | Position Regulator Kff Bandwidth RSWare : Drive - Tuning - Main Position Regulator Gains - Kff Low Pass Filter Bandwidth |
| Description | <ul style="list-style-type: none"> Valid if position FF gain [Ft-1.15] is not '0'. If a value other than '0' set for [Ft-1.15] results in overshoot or vibration, set this value to '0'. |
| Unit | 0~2500 |
| Initial Value | 200 |
| Unit | [Hz] |
| Applicable Operating Mode | F |

| | |
|--------------|-------------|
| When Enabled | Immediately |
|--------------|-------------|

| | | | |
|--|---|--|--------------------------|
|  Velocity Regulator I Gain Mode RSWare : Drive - Tuning - Main Velocity Regulator Gains - Integrator Mode | | | |
| Description | During transient response, Speed Response Overshoot can be suppressed by speed controller change from Proportion Integration (PI) Controller into Proportion (P) Controller. It reduces Position completion time during Position Control. | | |
| Range | Value | Description | RSWare Name |
| | 0 | Do not use P/PI Mode Conversion. | Always On |
| | 1 | When Current Command exceeds Current Value in [Ft-1.18], Speed Controller is changed from PI Controller to P Controller. | High Current Disable |
| | 2 | When Speed Command exceeds Speed Value in [Ft-1.18], Speed Controller is changed from PI Controller to P Controller. | Velocity Command Disable |
| | 3 | When Position error exceeds Position error Value in [Ft-1.18], Speed Controller is changed from PI Controller to P Controller. | Position Error Disable |
| | 4 | Automatically velocity controller is changed from PI Controller to P Controller. | Automatic Disable |
| Initial Value | 0 | | |
| Applicable Operating Mode | All | | |
| When Enabled | Servo Off > Setting | | |

| | |
|--|---|
|  Speed Regulator I Gain Disable Threshold RSWare : Drive - Tuning - Integrator Hold Threshold | |
| Description | If the speed torque command or the position tolerance exceeds the value set in this parameter, the speed controller changes from PI type to P type. |
| Range | 0~3000 |
| Initial Value | 100 |
| Unit | If [Ft-1.17] = 1, units are [%] of rated continuous current If [Ft-1.17] = 2, units are [RPM] for rotary motors units are [mm/sec] for linear motors If [Ft-1.17] = 3, units are Counts |
| Applicable Operating Mode | F, S, P |
| When Enabled | Immediately |

| | |
|--|---|
|  Position Regulator High Error Output Offset RSWare : Drive - Tuning - Main Position Regulator Gains - High Error Output Offset | |
| Description | In order to shorten the position decision time, if the position tolerance is larger than the value of [Ft-1.20], a speed bias equal to the value set here is applied. |
| Range | 0~450 |
| Initial Value | 0 |
| Unit | Rotary: [RPM], Linear: [mm/sec] |

| | |
|---------------------------|-------------|
| Applicable Operating Mode | All |
| When Enabled | Immediately |

**Position Regulator High Error Output Threshold**

RSWare : Drive - Tuning - Main Position Regulator Gains - High Error Output Threshold

| | |
|---------------------------|--|
| Description | [Ft-1.19] Speed bias value Position error standard value input to the speed controller. |
| Range | 0~50000 |
| Initial Value | 1000 |
| Unit | pulse |
| Applicable Operating Mode | All |
| When Enabled | Immediately |

**Current Regulator Bandwidth Reduction Scale**

RSWare : Drive - Tuning - Main Current Regulator Gains - Gain


| | | | |
|---------------------------|---------------------------|----------------------------------|-------------|
| Description | Current control bandwidth | | |
| Range | Value | Description | RSWare Name |
| | 0 | High bandwidth | High |
| | 1 | Medium bandwidth (0.6667 * high) | Medium |
| | 2 | Low bandwidth (0.3334 * high) | Low |
| Initial Value | 1 | | |
| Applicable Operating Mode | All | | |
| When Enabled | Immediately | | |


**On-line Vibration Mode**


RSWare : Drive - Tuning - Autotuning - On-Line Vibration Suppression Mode

| | | | |
|---------------|---|--|-------------------------------------|
| Data Size | 1 digit | | |
| Digit 0 | On-line Vibration Suppression Mode RSWare : Drive - Tuning - Autotuning - On-Line Vibration Suppression Mode | | |
| Range | Value | Description | RSWare Name |
| | 0 | Disable | Disable |
| | 1 | Normal Velocity Mode without Initial Value | Normal and High Velocity |
| | 2 | Slow Velocity Mode without Initial Value (below 100 [rpm]) | Slow Velocity without Initial Value |
| Initial Value | 0 | | |

| | | | |
|---------------------------|---|-------------|-------------|
| Digit 1 | On-line Vibration Suppression Gain RSWare : Drive - Tuning - Autotuning - On-Line Vibration Suppression Gain | | |
| Range | Value | Description | RSWare Name |
| | 0 | Low | Low |
| | 1 | High | High |
| Initial Value | 0 | | |
| Applicable Operating Mode | All | | |
| When Enabled | Servo Off > Setting | | |

| | | | |
|---|---|-------------|-------------|
|  | Velocity Regulator Configuration RSWare : Drive - Tuning - Velocity Regulator Configuration - Velocity Command Filter on Follower | | |
| Description | Select whether to use a filter on the speed command value in Position Control Mode. | | |
| Range | Value | Description | RSWare Name |
| | 0 | Disable | Disable |
| | 1 | Enable | Enable |
| Initial Value | 0 | | |
| Applicable Operating Mode | All | | |
| When Enabled | Servo Off > Setting | | |

| | | | |
|---|--|--|--|
|  | Delay Time of Gain Switching RSWare : Drive - Tuning - Gain Switching - Delay Time of Gain Switching | | |
| Description | When gain value is switched from Second gain to first gain, you can set delay time. | | |
| Range | 0~10000 | | |
| Initial Value | 0 | | |
| Unit | 0.2[ms] | | |
| Applicable Operating Mode | F, S, P | | |
| When Enabled | Immediately | | |

| | | | |
|---|--|--|--|
|  | Level of Gain Switching RSWare : Drive - Tuning - Gain Switching - Level of Gain Switching | | |
| Description | Set standard value for gain switching. The setting value is for Gain Switching Mode ([Ft-0.06]N1). | | |
| Range | 0~10000 | | |
| Initial Value | 0 | | |
| Unit | - | | |
| Applicable Operating Mode | F, S, P | | |

| | |
|--------------|-------------|
| When Enabled | Immediately |
|--------------|-------------|

Hysteresis of Gain Switching

RSWare : Drive - Tuning - Gain Switching - Hysteresis of Gain Switching

| | |
|---------------------------|--|
| Description | Operates Hysteresis based on operation level when gain switching. The setting value is for Gain Switching Mode ([Ft-0.06]N10). |
| Range | 0~10000 |
| Initial Value | 0 |
| Unit | - |
| Applicable Operating Mode | F, S, P |
| When Enabled | Immediately |

Position Gain Switching Time

RSWare : Drive - Tuning - Gain Switching - Position Gain Switching Time

| | |
|---------------------------|---|
| Description | Adjust as Position Gain Switching Time step by step when switching gain value from first gain to second gain. |
| Range | 0~10000 |
| Initial Value | 0 |
| Unit | 0.2 [ms] |
| Applicable Operating Mode | F, S, P |
| When Enabled | Immediately |


2nd Velocity Regulator P GainRSWare : Drive - Tuning - 2nd Regulator Gains - P


| | |
|---------------------------|---|
| Description | Parameter which determines the responsiveness of speed control. |
| Range | 0~10000 |
| Initial Value | 60 |
| Unit | - |
| Applicable Operating Mode | F, S, P |
| When Enabled | Immediately |


2nd Velocity Regulator I GainRSWare : Drive - Tuning - 2nd Regulator Gains - Integrator Gain

| | |
|---------------|---|
| Description | <ul style="list-style-type: none"> Removes steady state speed tolerance. Overshoot in speed response can occur if set value is too large. |
| Range | 0~60000 |
| Initial Value | 26 |

| | |
|---------------------------|-------------|
| Unit | - |
| Applicable Operating Mode | F, S, P |
| When Enabled | Immediately |

| | |
|---|---|
|  | 2nd Position Regulator Kp Gain RSWare : Drive - Tuning - 2 nd Regulator Gains - Kp |
| Description | <ul style="list-style-type: none"> Parameter which determines the responsiveness of position control. Change set value according to rigidity of load. |
| Range | 0~700 |
| Initial Value | 20 |
| Unit | [Hz] |
| Applicable Operating Mode | F |
| When Enabled | Immediately |

| | |
|---|--|
|  | 2nd Current Command Low pass Filter Bandwidth RSWare : Drive - Tuning - 2 nd Regulator Gains - Lowpass Filter Bandwidth (IReg) |
| Description | Suppresses high frequency components of torque command. |
| Range | 0~10000 |
| Initial Value | 300 |
| Unit | [Hz] |
| Applicable Operating Mode | All |
| When Enabled | Immediately |

| | |
|---|---|
|  | 2nd Velocity Command Low pass Filter Bandwidth RSWare : Drive - Tuning - 2 nd Regulator Gains - Lowpass Filter Bandwidth (VReg) |
| Description | Sets low pass cutoff frequency of speed command to suppress high frequency components. |
| Range | 0~10000 |
| Initial Value | 1000 |
| Unit | [Hz] |
| Applicable Operating Mode | All |
| When Enabled | Immediately |

| | |
|---|--|
|  | 3rd Velocity Regulator P Gain RSWare : Drive - Tuning - 3 rd Regulator Gains - P |
|---|--|

| | |
|---------------------------|---|
| Description | Parameter which determines the responsiveness of speed control. |
| Range | 0~10000 |
| Initial Value | 60 |
| Unit | - |
| Applicable Operating Mode | F, S, P |
| When Enabled | Immediately |

**3rd Velocity Regulator I Gain**RSWare : Drive - Tuning - 3rd Regulator Gains - Integrator Gain


| | |
|---------------------------|---|
| Description | <ul style="list-style-type: none"> Removes steady state speed tolerance. Overshoot in speed response can occur if set value is too large. |
| Range | 0~60000 |
| Initial Value | 26 |
| Unit | - |
| Applicable Operating Mode | F, S, P |
| When Enabled | Immediately |


**3rd Position Regulator Kp Gain**RSWare : Drive - Tuning - 3rd Regulator Gains - Kp


| | |
|---------------------------|---|
| Description | <ul style="list-style-type: none"> Parameter which determines the responsiveness of position control. Change set value according to rigidity of load. |
| Range | 0~700 |
| Initial Value | 20 |
| Unit | [Hz] |
| Applicable Operating Mode | F |
| When Enabled | Immediately |


**3rd Current Command Low pass Filter Bandwidth**RSWare : Drive - Tuning - 3rd Regulator Gains - Lowpass Filter Bandwidth (IReg)

| | |
|---------------------------|---|
| Description | Suppresses high frequency components of torque command. |
| Range | 0~10000 |
| Initial Value | 300 |
| Unit | [Hz] |
| Applicable Operating Mode | All |
| When Enabled | Immediately |

| | |
|---|---|
|  | 3rd Velocity Command Low pass Filter Bandwidth RSWare : Drive - Tuning - 3 rd Regulator Gains - Lowpass Filter Bandwidth (VReg) |
| Description | Sets low pass cutoff frequency of speed command to suppress high frequency components. |
| Range | 0~10000 |
| Initial Value | 1000 |
| Unit | [Hz] |
| Applicable Operating Mode | All |
| When Enabled | Immediately |

| | |
|---|--|
|  | 4th Velocity Regulator P Gain RSWare : Drive - Tuning - 4 th Regulator Gains - P |
| Description | Parameter which determines the responsiveness of speed control. |
| Range | 0~10000 |
| Initial Value | 60 |
| Unit | - |
| Applicable Operating Mode | F, S, P |
| When Enabled | Immediately |

| | |
|---|---|
|  | 4th Velocity Regulator I Gain RSWare : Drive - Tuning - 4 th Regulator Gains - Integrator Gain |
| Description | <ul style="list-style-type: none"> Removes steady state speed tolerance. Overshoot in speed response can occur if set value is too large. |
| Range | 0~60000 |
| Initial Value | 26 |
| Unit | - |
| Applicable Operating Mode | F, S, P |
| When Enabled | Immediately |

| | |
|---|---|
|  | 4th Position Regulator Kp Gain RSWare : Drive - Tuning - 4th Regulator Gains - Kp |
| Description | <ul style="list-style-type: none"> Parameter which determines the responsiveness of position control. Change set value according to rigidity of load. |
| Range | 0~700 |
| Initial Value | 20 |

| | |
|---------------------------|-------------|
| Unit | [Hz] |
| Applicable Operating Mode | F |
| When Enabled | Immediately |

**4th Current Command Low pass Filter Bandwidth**

RSWare : Drive - Tuning - 4th Regulator Gains - Lowpass Filter Bandwidth (IReg)


| | |
|---------------------------|---|
| Description | Suppresses high frequency components of torque command. |
| Range | 0~10000 |
| Initial Value | 300 |
| Unit | [Hz] |
| Applicable Operating Mode | All |
| When Enabled | Immediately |


**4th Velocity Command Low pass Filter Bandwidth**


RSWare : Drive - Tuning - 4th Regulator Gains - Lowpass Filter Bandwidth (VReg)


| | |
|---------------------------|--|
| Description | Sets low pass cutoff frequency of speed command to suppress high frequency components. |
| Range | 0~10000 |
| Initial Value | 1000 |
| Unit | [Hz] |
| Applicable Operating Mode | All |
| When Enabled | Immediately |

Standard Group 2

| | |
|---|--|
|  | Velocity Scale |
| Description | RSWare : Drive - Mode Configuration - Analog- Velocity Scale <ul style="list-style-type: none"> Sets the speed command value[rpm] for the analog speed command input pin (Pin 19,20 of I/O). Speed command [rpm] = Ft-2.00 [rpm/V] × Input Voltage [V] |
| Range | 10.0~2000.0 |
| Initial Value | 500.0 |
| Unit | Rotary Motor: [rpm/V], Linear Motor: [mm/sec/V] |
| Applicable Operating Mode | S |
| When Enabled | Servo Off > Setting |


| | |
|---|--|
|  | Jog Velocity Command |
| Description | RSWare : Drive - (Right Side)Velocity Control Panel - Velocity Command Sets speed for jog operation using (run-00). |
| Range | 0~6000 |
| Initial Value | 50 |
| Unit | Rotary Motor: [rpm], Linear Motor: [mm/sec] |
| Applicable Operating Mode | All |
| When Enabled | Immediately |

| | |
|---|---|
|  | Acceleration |
| Description | RSWare : Drive - Acceleration Limits - Acceleration Acceleration means slope of the Speed Profile. |
| Range | 1~2147483647 |
| Initial Value | 41667 |
| Unit | Rotary Motor: [10 ⁻² ×Rev/sec ²], Linear Motor: [mm/sec ²] |
| Applicable Operating Mode | S, P |
| When Enabled | Immediately |

| | |
|---|---|
|  | Deceleration |
| Description | RSWare : Drive - Acceleration Limits - Deceleration Deceleration means slope of the Speed Profile. |
| Range | 1~2147483647 |
| Initial Value | 41667 |
| Unit | Rotary Motor: [10 ⁻² ×Rev/sec ²], Linear Motor: [mm/sec ²] |
| Applicable Operating Mode | S, P |
| When Enabled | Immediately |

| | |
|----------------|--|
| FE-2.04 | S-Curve Time RSWare : Drive - Acceleration Limits - S-Curve Time |
|----------------|--|








- S-operation time set for smooth operation.
- Applied only when acceleration/deceleration time have been set. If value is set to '0', S-operation is not performed; if a value other than '0' is set, S-operation is performed on acceleration/ deceleration.





| | |
|---------------------------|-------------|
| Range | 0~5,000 |
| Initial Value | 0 |
| Unit | [ms] |
| Applicable Operating Mode | All |
| When Enabled | Immediately |

| | |
|----------------|--|
| FE-2.05 | Preset Velocity 1 RSWare : Drive - Mode Configuration - Preset - Preset Velocity 1 |
| Description | <ul style="list-style-type: none">• Sets each contact speed commands for contact speed control mode.• The operation speed should be entered in advance into the relevant parameters </C-SP1>, </C-SP2>, </C-SP3>.• According to combination of the sequence input signals </C-SP1>, </C-SP2>, </C-SP3>, operation at preset speed is possible.• In addition, sequence input signal </C-DIR> is used to change the rotation direction of each speed command.• To reduce impact of speed change, set the acceleration/deceleration time to a sufficient value which should not interfere with system responsiveness. |

| | |
|---------------------------|---|
| Range | -6000~6000 |
| Initial Value | 0 |
| Unit | Rotary Motor: [rpm], Linear Motor: [mm/sec] |
| Applicable Operating Mode | P |
| When Enabled | Immediately |

| Contact Speed | Speed Set Parameter | </C-SP3> | </C-SP2> | </C-SP1> |
|-----------------|--|----------|----------|----------|
| Halt Command | 0 (rpm) | 0 | 0 | 0 |
| Speed Command 1 |  | 0 | 0 | 1 |
| Speed Command 2 |  | 0 | 1 | 0 |
| Speed Command 3 |  | 0 | 1 | 1 |
| Speed Command 4 |  | 1 | 0 | 0 |
| Speed Command 5 |  | 1 | 0 | 1 |
| Speed Command 6 |  | 1 | 1 | 0 |
| Speed Command 7 |  | 1 | 1 | 1 |

| | |
|---|---|
|  | Preset Velocity 2 |
| Description | RSWare : Drive - Mode Configuration - Preset - Preset Velocity 2 Refer to description of [Ft-2.05] |
| Range | -6000~6000 |
| Initial Value | 0 |
| Unit | Rotary Motor: [rpm], Linear Motor: [mm/sec] |
| Applicable Operating Mode | P |
| When Enabled | Immediately |

| | |
|---|---|
|  | Preset Velocity 3 |
| Description | RSWare : Drive - Mode Configuration - Preset - Preset Velocity 3 Refer to description of [Ft-2.05] |
| Range | -6000~6000 |
| Initial Value | 0 |
| Unit | Rotary Motor: [rpm], Linear Motor: [mm/sec] |

| | |
|---------------------------|-------------|
| Applicable Operating Mode | P |
| When Enabled | Immediately |

Preset Velocity 4

RSWare : Drive - Mode Configuration - Preset - Preset Velocity 4

| | |
|---------------------------|---|
| Description | Refer to description of [Ft-2.05] |
| Range | -6000~6000 |
| Initial Value | 0 |
| Unit | Rotary Motor: [rpm], Linear Motor: [mm/sec] |
| Applicable Operating Mode | P |
| When Enabled | Immediately |

Preset Velocity 5

RSWare : Drive - Mode Configuration - Preset - Preset Velocity 5

| | |
|---------------------------|---|
| Description | Refer to description of [Ft-2.05] |
| Range | -6000~6000 |
| Initial Value | 0 |
| Unit | Rotary Motor: [rpm], Linear Motor: [mm/sec] |
| Applicable Operating Mode | P |
| When Enabled | Immediately |

Preset Velocity 6


RSWare : Drive - Mode Configuration - Preset - Preset Velocity 6


| | |
|---------------------------|---|
| Description | Refer to description of [Ft-2.05] |
| Range | -6000~6000 |
| Initial Value | 0 |
| Unit | Rotary Motor: [rpm], Linear Motor: [mm/sec] |
| Applicable Operating Mode | P |
| When Enabled | Immediately |

Preset Velocity 7


RSWare : Drive - Mode Configuration - Preset - Preset Velocity 7

| | |
|---------------------------|---|
| Description | Refer to description of [Ft-2.05] |
| Range | -6000~6000 |
| Initial Value | 0 |
| Unit | Rotary Motor: [rpm], Linear Motor: [mm/sec] |
| Applicable Operating Mode | P |
| When Enabled | Immediately |

| | |
|---|--|
|  | Manual Velocity Limit RSWare : Drive - Velocity Limits - Manual Velocity limit |
| Description | <ul style="list-style-type: none"> Limits the operation speed to below this set value in all control modes. There are two methods of speed limitation: limitation thorough this value and limitation through speed command of upper level controller. Configure by referring to speed limit method selection of [Ft-2.13]. In addition, in torque control mode, the mode is changed automatically to speed control mode if motor speed exceeds this value; speed control is performed using limit speed command. If the analog speed command exceeds motor's maximum speed, the excessive speed command warning "OSC" is issued. If excessive speed command warning is issued, the speed command is automatically reduced to the motor's maximum speed. |
| Range | 1~6000 |
| Initial Value | 5000 |
| Unit | Rotary Motor: [rpm], Linear Motor: [mm/sec] |
| Applicable Operating Mode | F, S, P |
| When Enabled | Servo Off > Setting |

| | | | |
|---|--|---|-------------------|
|  | Velocity Limit Mode RSWare : Drive - Velocity Limits - Velocity Limit Mode | | |
| Description | Select velocity limit mode. | | |
| Range | Value | Description | RSWare Name |
| | 0 | Disabled | Disabled |
| | 1 | Limit by [Ft-2.12]. | Manual Limit |
| | 2 | Limited by Analogue Speed Command Value (except Analog Speed Mode). | Analog Input |
| | 3 | Limited by lesser one between [Ft-2.12] and Analogue Speed Command. | Manual and Analog |
| Initial Value | 0 | | |
| Applicable Operating Mode | All | | |
| When Enabled | Servo Off > Setting | | |

Standard Group 3


| | |
|---|---|
|  | Follower RSWare : Drive - Mode Configuration - Follower |
| Data Size | 4 digits |
| Ditig 0 | Command Type |
| | RSWare : Drive - Mode Configuration - Follower - Command Type |


| | | | |
|---------------------------|---|---|-----------------------------------|
| Range | Value | Description | RSWare Name |
| | 0 | Step Up/Step Down, Positive logic | Step Up/Step Down. Positive Logic |
| | 1 | Step Up/Step Down, Negative logic | Step Up/Step Down. Negative Logic |
| | 2 | Step/Direction, Positive Logic | Step/Direction. Positive Logic |
| | 3 | Step/Direction, Negative Logic | Step/Direction. Negative Logic |
| | 4 | A phase+B phase, x1 | Auxiliary Encoder. x1 |
| | 5 | A phase+B phase, x2 | Auxiliary Encoder. x2 |
| | 6 | A phase+B phase, x4 | Auxiliary Encoder. x4 |
| Initial Value | 0 | | |
| Applicable Operating Mode | Follower | | |
| Digit 1 | Controller Output Type RSWare : Drive - Mode Configuration - Follower - Controller Output Type | | |
| Range | Value | Description | RSWare Name |
| | 0 | Use Low speed Line Drive Output in Host Controller for isolated electrical connection (Max.900 [kHz]) | Line Drive |
| | 1 | Use Open Collector in Host Controller (Max. 250 [kHz]) | Open Collector |
| | 2 | Use High Frequency Line Drive Output in Host Controller (Max. 3 [MHz]) | High Speed Line Drive |
| Initial Value | 0 | | |
| Applicable Operating Mode | Follower | | |
| Digit 2 | Encoder Output Forward Direction RSWare : Drive - Encoders - Encoder Output Forward Direction | | |
| Range | Value | Description | RSWare Name |
| | 0 | During Forward Rotation, Encoder Output Phase A have a lead of 90° over Phase B. | A Leads B |
| | 1 | During Forward Rotation, Encoder Output Phase B have a lead of 90° over Phase A. | B Leads A |
| Initial Value | 0 | | |
| Applicable Operating Mode | All | | |
| Digit 3 | 1 st Gear ratio change RSWare : Drive - Mode Configuration - Follower - 1 st Gear Ratio Change | | |
| Range | Value | Description | RSWare Name |
| | 0 | Enable Only on Drive Disabled | Enable Only on Drive Disabled |
| | 1 | Always Enable | Always Enable |
| Initial Value | 0 | | |
| Applicable Operating Mode | F | | |
| When Enabled | Servo Off > Setting | | |


**1st Gear Ratio, Follower Counts**


RSWare : Drive - Mode Configuration - Follower - 1st Gear Ratio
(Second number)


| | |
|---------------------------|---|
| Description | <ul style="list-style-type: none"> Numerator of Electronic gear. By using the electronic gear function, the amount of motor rotation per input command pulse can be set arbitrarily. The following relationship has to be satisfied "No. of pulses per 1 motor rotation \times Reduction ratio $\times 4 \geq$ [Ft-3.02]". Maximum resolution = $1 / ([\text{No. of pulses per 1 motor rotation}] \times [\text{Reduction ratio}] \times 4)$ |
| Range | 1~65535 |
| Initial Value | 4 |
| Unit | - |
| Applicable Operating Mode | F |
| When Enabled | Servo Off > Setting |


| | |
|---|---|
|  | 1st Gear Ratio, Master Counts RSWare : Drive - Mode Configuration - Follower - 1 st Gear Ratio (First Number) |
| Description | Denominator of Electronic gear. |
| Range | 1~65535 |
| Initial Value | 1 |
| Unit | |
| Applicable Operating Mode | F |
| When Enabled | Servo Off > Setting |

| | |
|---|---|
|  | Encoder Output Ratio, Output Counts (Denominator) RSWare : Drive - Encoders - Output Ratio (First Number) |
| Description | <ul style="list-style-type: none"> Numerator of Position output pulse adjustment. Sets the number of pulses to be output through the servo drive's encoder signal output (EA+, EA-, EB+, EB-) for one motor rotation. [At [Ft-3.03], the numerator of the encoder's output divider ratio is entered. Generally, the number of pulses to be output at 1 motor rotation is entered. At [Ft-3.04], the denominator of the encoder's output divider ratio is entered. Generally, the number of pulses output from the encoder connected to the motor for 1 rotation is entered. For the encoder output division ratio, the relationship $[\text{Ft-3.03}] \leq [\text{Ft-3.04}]$ has to be satisfied. For the No. of output pulses per rotation to the higher level controller: $([\text{Ft-3.03}]/[\text{Ft-3.04}]) \times \text{output pulses per rotation} = \text{Output to higher level controller}$ |
| Range | 1~32768 |
| Initial Value | 1 |
| Unit | |
| Applicable Operating Mode | All |
| When Enabled | Servo Off > Setting |


| | |
|---|--|
|  | Encoder Output Ratio, Motor Counts (Numerator) |
| Description | RSWare : Drive - Encoders - Output Ratio (Last Number) Denominator of Position output pulse adjustment. |
| Range | 1~32768 |
| Initial Value | 1 |
| Unit | - |
| Applicable Operating Mode | All |
| When Enabled | Servo Off > Setting |

| | |
|---|---|
|  | 2nd Gear Ratio, Follower Counts |
| Description | RSWare : Drive - Mode Configuration - Follower - 2 nd Gear Ratio (Second Number) <ul style="list-style-type: none"> Numerator of 2nd Gear Ratio. By using the electronic gear function, the amount of motor rotation pr input command pulse can be set arbitrarily. The following relationship has to be satisfied "No. of pulses per 1 motor rotation × Reduction ratio × 4 ≥ [Ft-3.02]". Maximum resolution=1/ ([No.of pulses per 1 motor rotation] x [Reduction ratio] x 4) |
| Range | 1~65535 |
| Initial Value | 4 |
| Unit | - |
| Applicable Operating Mode | F |
| When Enabled | Servo Off > Setting |

| | |
|---|--|
|  | 2nd Gear Ratio, Master Counts |
| Description | RSWare : Drive - Mode Configuration - Follower - 2 nd Gear Ratio (First Number) Denominator of 2 nd Gear Ratio. |
| Range | 1~65535 |
| Initial Value | 1 |
| Unit | - |
| Applicable Operating Mode | F |
| When Enabled | Servo Off > Setting |


| | |
|---|----------|
|  | Reserved |
| Parameter | Reserved |
| Description | Reserved |


| | |
|---------------------------|----------|
| Range | Reserved |
| Initial Value | Reserved |
| Unit | Reserved |
| Applicable Operating Mode | Reserved |


| | | | | |
|---|---------------------------------|-------------|-------------|--|
|  | | | | Digital Filter Cut-off Frequency |
| | | | | RSWare : Drive - Mode Configuration - Follower - Digital Filter Cut-off Frequency |
| Digit 0 | Low Drive Input | | | RSWare : Drive - Mode Configuration - Follower - Digital Filter Cut-off Frequency - Low Speed Line Driver Input |
| Range | Value | Description | RSWare Name | |
| | 0 | 3.000 MHz | 3.000 | |
| | 1 | 1.750 MHz | 1.750 | |
| | 2 | 1.500 MHz | 1.500 | |
| | 3 | 1.000 MHz | 1.000 | |
| | 4 | 0.750 MHz | 0.750 | |
| | 5 | 0.625 MHz | 0.625 | |
| | 6 | 0.562 MHz | 0.562 | |
| | 7 | 0.525 MHz | 0.525 | |
| Initial Value | 3 | | | |
| Applicable Operating Mode | F | | | |
| Digit 1 | Open Collector Input | | | RSWare : Drive - Mode Configuration - Follower - Digital Filter Cut-off Frequency - Open Collector Input |
| Range | Value | Description | RSWare Name | |
| | 0 | 3.000 MHz | 3.000 | |
| | 1 | 1.750 MHz | 1.750 | |
| | 2 | 1.500 MHz | 1.500 | |
| | 3 | 1.000 MHz | 1.000 | |
| | 4 | 0.750 MHz | 0.750 | |
| | 5 | 0.625 MHz | 0.625 | |
| | 6 | 0.562 MHz | 0.562 | |
| | 7 | 0.525 MHz | 0.525 | |
| Initial Value | 7 | | | |
| Applicable Operating Mode | F | | | |
| Digit 2 | High Frequency Line Drive Input | | | RSWare : Drive - Mode Configuration - Follower - Digital Filter Cut-off Frequency - High Speed Line Driver Input |

| Range | Value | Description | RSWare Name |
|---------------------------|---------------------|-------------|-------------|
| | 0 | 3.000 MHz | 3.000 |
| | 1 | 1.750 MHz | 1.750 |
| | 2 | 1.500 MHz | 1.500 |
| | 3 | 1.000 MHz | 1.000 |
| | 4 | 0.750 MHz | 0.750 |
| | 5 | 0.625 MHz | 0.625 |
| | 6 | 0.562 MHz | 0.562 |
| | 7 | 0.525 MHz | 0.525 |
| Initial Value | 0 | | |
| Applicable Operating Mode | F | | |
| When Enabled | Servo Off > Setting | | |

Standard Group 4

| | |
|---|--|
|  | Current Scale |
| | RSWare : Drive - Mode Configuration - Analog - Current Scale |
| Description | <ul style="list-style-type: none"> Set the speed command value[%] for 1[V] on the analog torque command input pin(pin 21,22 of I/O). Torque command[%] = [Ft-4.00] [%/V] x input voltage [V] |
| Range | 0-1000 |
| Initial Value | 333 |
| Unit | [%] of rated continuous current/V/10 |
| Applicable Operating Mode | C |
| When Enabled | Servo Off > Setting |

| | |
|---|---|
|  | Positive Internal Current Limit |
| | RSWare : Drive - Current Limits - Positive Internal |
| Description | Limits forward and reverse direction torque on motor separately. (internally limited) |
| Range | 0-500 |
| Initial Value | 300 |
| Unit | [%] of motor rated continuous current |
| Applicable Operating Mode | All |
| When Enabled | Immediately |

| | |
|---|--|
|  | Negative Internal Current Limit |
| | RSWare : Drive - Current Limits - Negative Internal |
| Description | Limits reverse direction torque on motor. (Internally limited) |


| | |
|---------------------------|---------------------------------------|
| Range | 0~500 |
| Initial Value | 300 |
| Unit | [%] of motor rated continuous current |
| Applicable Operating Mode | All |
| When Enabled | Immediately |

| | |
|---------------------------|--|
| <div>Ft-4.03</div> | Positive External Current Limit RSWare : Drive - Current Limits - Positive External |
| Description | <ul style="list-style-type: none">The torque imposed on the motor is internally limited automatically by the values set on [Ft-4.01], [Ft-4.02]. Additionally, it is also limited by the values set on [Ft-4.03], [Ft-4.04] when external </P-TL>, </N-TL> signals are input through sequence input.The torque limit according to internal limit [Ft-4.01] and [Ft-4.01] takes precedence to external torque limit </P-TL> and </N-TL> signals. <pre>graph LR TC[Torque Command] --> FT_Pos[Forward Torque (+)] TC --> FT_Neg[Reverse Torque (-)] FT_Pos --> IL1[Torque Limit Ft-4.01] FT_Neg --> IL2[Torque Limit Ft-4.02] IL1 --> SL1[Speed Limit] IL2 --> SL2[Speed Limit] SL1 --> ET_Pos[Torque Limit Ft-4.03] SL2 --> ET_Neg[Torque Limit Ft-4.04] ET_Pos --> LTL[Limited Torque Command] ET_Neg --> LTL</pre> |
| Range | 0~500 |
| Initial Value | 100 |
| Unit | [%] of motor rated continuous current |
| Applicable Operating Mode | All |
| When Enabled | Immediately |


| | |
|---------------------------|---|
| <div>Ft-4.04</div> | Negative External Current Limit RSWare : Drive - Current Limits - Negative External |
| Description | Refer to description of [Ft-4.03] |
| Range | 0~500 |
| Initial Value | 100 |
| Unit | [%] of motor rated continuous current |
| Applicable Operating Mode | All |
| When Enabled | Immediately |


| | |
|--------------------|--|
| <div>Ft-4.05</div> | Over-travel Current Limit RSWare : Drive - Stopping Functions - Maximum Stopping Current |
|--------------------|--|


| | |
|---------------------------|--|
| Description | <ul style="list-style-type: none"> Limits the torque imposed on the motor if the motor is halted by overtravel (<P-OT>,<N-OT>) input signal during rotation. Unlike external and internal torque limit, the torque limit value for overtravel input is same for forward and reverse direction. |
| Range | 0~500 |
| Initial Value | 300 |
| Unit | [%] of motor rated continuous current |
| Applicable Operating Mode | All |
| When Enabled | Immediately |


| | |
|---|--|
|  | Initial Current Bias RSWare : Drive - Initial Current Bias |
| Description | Initial torque value applied when the servo drive activated. This is to keep vertical axis load. |
| Range | -100~100 |
| Initial Value | 0 |
| Unit | [%] of motor rated continuous current |
| Applicable Operating Mode | All |
| When Enabled | Immediately |


Standard Group 5


| | |
|---|--|
|  | In Position Size RSWare : Drive - Position Functions - In Position Size |
| Description | If position error < In Position Size for 1 ms and the In Position Size output signal is assigned, the In Position output is turned ON. |
| Range | 0~2500 |
| Initial Value | 10 |
| Unit | pulse |
| Applicable Operating Mode | F |
| When Enabled | Immediately |


| | |
|---|----------|
|  | Reserved |
| Parameter | Reserved |
| Description | Reserved |
| Range | Reserved |
| Initial Value | Reserved |
| Unit | Reserved |
| Applicable Operating Mode | Reserved |


| | |
|---|--|
|  | Near Position Size |
| | RSWare : Drive - Position Functions - Near Position Size |
| Description | If position error < Near Position Size and the Near Position output signal is assigned, the Near Position output is turned ON. |
| Range | 0~2500 |
| Initial Value | 20 |
| Unit | pulse |
| Applicable Operating Mode | F |
| When Enabled | Immediately |


| | |
|---|--|
|  | Speed Window |
| | RSWare : Drive - Speed Functions - Speed Window |
| Description | If the speed error < Speed Window for 10 ms and the Within Speed Window output signal is assigned, then the Within Speed Window output is turned ON. |
| Range | 0-1000 |
| Initial Value | 10 |
| Unit | Rotary Motor: [rpm], Linear Motor: [mm/sec] |
| Applicable Operating Mode | F, S, P |
| When Enabled | Immediately |


| | |
|---|---|
|  | Up to speed |
| | RSWare : Drive - Speed Functions - Up to Speed |
| Description | If the motor speed > Up to Speed and the Up to Speed output signal is assigned, then the Up to Speed output is turned ON. |
| Range | 1~5000 |
| Initial Value | 20 |
| Unit | Rotary Motor: [rpm], Linear Motor: [mm/sec] |
| Applicable Operating Mode | All |
| When Enabled | Immediately |


| | |
|---|--|
|  | Zero Clamp |
| | RSWare : Drive - Speed Functions - Zero Clamp |
| Description | If the Analog Speed Command < Zero Clamp, then the analog speed command is ignored and the motor command speed is set to zero. |
| Range | 0~5000 |
| Initial Value | 0 |
| Unit | Rotary Motor: [rpm], Linear Motor: [mm/sec] |
| Applicable Operating Mode | S |
| When Enabled | Immediately |


| | |
|---|--|
|  | Brake Inactive Delay |
| | RSWare : Drive - Digital Outputs - Brake Inactive Delay |
| Description | Brake Inactive delay is the time from when the drive is enabled to when the brake is released. |
| Range | 0~10000 |
| Initial Value | 0 |
| Unit | [ms] |
| Applicable Operating Mode | All |
| When Enabled | Servo Off > Setting |


| | |
|---|---|
|  | Disable Delay |
| | RSWare : Drive - Stopping Functions - Disable Delay |
| Description | Disable Delay is the time from when Drive Disable command is received to when the Drive Disable command is actually executed. |
| Range | 0~10000 |
| Initial Value | 0 |
| Unit | [ms] |
| Applicable Operating Mode | All |
| When Enabled | Servo Off > Setting |


| | |
|---|--|
|  | Brake Active Delay |
| | RSWare : Drive - Digital Outputs - Brake Active Delay |
| Description | The Braking Application Speed is the feedback speed below which the motor brake is engaged, after disabling the drive. |
| Range | 0~10000 |
| Initial Value | 500 |
| Unit | [ms] |
| Applicable Operating Mode | All |
| When Enabled | Servo Off > Setting |

| | |
|---|--|
|  | Disabled Braking Speed |
| | RSWare : Drive - Stopping Functions - Braking Application Speed |
| Description | The Braking Application Speed is the feedback speed below which the motor brake is engaged, after disabling the drive. |
| Range | 0~1000 |
| Initial Value | 100 |
| Unit | Rotary Motor: [rpm], Linear Motor: [mm/sec] |
| Applicable Operating Mode | All |
| When Enabled | Servo Off > Setting |

| | |
|---|---|
|  | Following Error Limit |
| | RSWare : Drive - Faults - Following Error Limit |
| Description | A following error fault occurs when the difference between position command and actual position is greater than this parameter. |
| Range | 0~2147483647 |
| Initial Value | 99999 |
| Unit | pulse |
| Applicable Operating Mode | F |


| | |
|---|---|
|  | AC Line Loss Fault Delay |
| | RSWare : Drive - Faults - AC Line Loss Fault Delay |
| Description | The AC Line Loss Fault is inhibited for this amount of time, when a loss of AC power is detected. |
| Range | 20~1000 |
| Initial Value | 20 |
| Unit | ms |
| Applicable Operating Mode | All |
| When Enabled | Servo Off > Setting |

| | |
|---|--|
|  | Analog Output CH1 Selection |
| | RSWare : Drive - Analog Outputs - Analog Output 1 - Signal |
| Description | The drive signal assigned to channel 1 from the Channel Setup dialog box in the Oscilloscope window. |
| Range | 0~28 (Except 15, 23, 25, 26) |
| Initial Value | 0 |
| Applicable Operating Mode | All |
| When Enabled | Immediately |

| | |
|---|--|
|  | Analog Output CH2 Selection |
| | RSWare : Drive - Analog Outputs - Analog Output 2 - Signal |
| Description | The drive signal assigned to channel 2 from the Channel Setup dialog box in the Oscilloscope window. |
| Range | 0~28 (Except 15, 23, 25, 26) |
| Initial Value | 1 |
| Applicable Operating Mode | All |
| When Enabled | Immediately |








| | |
|---|---|
|  | Analog Output CH1 Scale |
| | RSWare : Drive - Analog Outputs - Analog Output 1 - Scale |

| | |
|---------------------------|--|
| Description | The amplitude of the channel 1 input signal to be displayed by the oscilloscope. |
| Range | 1 - 99999 |
| Unit | Units depend on the channel selection. |
| Initial Value | 500 |
| Applicable Operating Mode | All |
| When Enabled | Immediately |














| | |
|---|---|
|  | Analog Output CH2 Scale RSWare : Drive - Analog Outputs - Analog Output 2 - Scale |
| Description | The amplitude of the channel 2 input signal to be displayed by the oscilloscope. |
| Range | 1 - 99999 |
| Unit | Units depend on the channel selection. |
| Initial Value | 500 |
| Applicable Operating Mode | All |
| When Enabled | Immediately |

Index Parameter List


Indexing Group 0 - Indexing System



| No. | Name | Modbus Address | Digit No. | Range | Init. | Note |
|---|--------------------------------|----------------|-----------|-----------------------------|--------------|--|
|  | Auto Start Indexing | 5000 | N/A | 0~1 | 0 | - |
|  | Abort Index Deceleration | 5001, 5002 | N/A | 1~2147483647 | 6250 | Rotary Motor: [10 ⁻² xRev/sec ²], Linear Motor: [mm/sec ²] |
|  | Positive Deceleration Distance | 5003, 5004 | N/A | 0~2147483647 | 0 | pulse |
|  | Negative Deceleration Distance | 5005, 5006 | N/A | 0~2147483647 | 0 | pulse |
|  | Enable Software Limits | 5007 | N/A | 0~1 | 0 | - |
|  | Positive Software Limit | 5008, 5009 | N/A | - 2147483647 ~2147483647 | 2147483647 | pulse |
|  | Negative Software Limit | 5010, 5011 | N/A | - 2147483647 ~2147483647 | - 2147483647 | pulse |

Indexing Group 1 - Homing




| No. | Name | Modbus Address | Digit No. | Range | Init. | Note |
|---|-----------------------------------|----------------|-----------|-----------------------------|-------|---|
|  | Homing Type | 5200 | N/A | 0~8 | 1 | - |
|  | Auto Start Homing on Enable | 5201 | N/A | 0~2 | 2 | - |
|  | Homing Velocity | 5202 | N/A | -6000~6000 | 100 | Rotary Motor: [rpm], Linear Motor: [mm/sec] |
|  | Creep Velocity | 5203 | N/A | 0~6000 | 20 | Rotary Motor: [rpm], Linear Motor: [mm/sec] |
|  | Homing Acceleration/Deceleration | 5204, 5205 | N/A | 1~2147483647 | 6250 | Rotary Motor: [10 ⁻² xRev/sec ²], Linear Motor: [mm/sec ²] |
|  | Offset Move Distance | 5206, 5207 | N/A | - 2147483647 ~2147483647 | 0 | pulse |
|  | Home Sensor Polarity | 5208 | N/A | 0~1 | 0 | - |
|  | Home Position | 5209, 5210 | N/A | - 2147483647 ~2147483647 | 0 | pulse |
|  | Moving distance After Home Sensor | 5211, 5212 | N/A | 0~2147483647 | 0 | pulse |
|  | Home Current | 5213 | N/A | 1~250 | 100 | [%] |
|  | Home Current Time | 5214 | N/A | 0~1000 | 0 | [ms] |
|  | Homing Time Limit | 5215 | N/A | 0~65535 | 60 | [sec] |
|  | Stop Home Deceleration | 5216, 5217 | N/A | 1~2147483647 | 6250 | Rotary Motor: [10 ⁻² xRev/sec ²], Linear Motor: [mm/sec ²] |

Indexing Group 2- Index Option



| No. | Name | Modbus Address | Digit No. | Range | Init. | Note |
|---|----------------|----------------|-----------|---|-------|------|
|  | Index 0 Option | 5400 | 0 | 0: Absolute 1: Incremental | 0 | - |
| | | | 1 | 0: Stop 1: Start next index 2: Wait for Start | 0 | - |
| | | | 2...3 | Reserved | | |


| | | | | | | |
|---|----------------|------|-------|---|---|---|
|  | Index 1 Option | 5401 | 0 | 0: Absolute 1: Incremental | 0 | - |
| | | | 1 | 0: Stop 1: Start next index 2: Wait for Start | 0 | - |
| | | | 2...3 | Reserved | | |
| : | : | : | : | : | : | : |
| : | : | : | : | : | : | : |
| : | : | : | : | : | : | : |
|  | Index63 Option | 5463 | 0 | 0: Absolute 1: Incremental | 0 | - |
| | | | 1 | 0: Stop 1: Start next index 2: Wait for Start | 0 | - |
| | | | 2...3 | Reserved | | |

Indexing Group 4 - Index Position/Distance




| No. | Name | Modbus Address | Digit No. | Range | Init. | Note |
|---|--------------------------------|----------------|-----------|--------------|-------|-------|
|  | Index 0 Position/ Distance | 5800, 5801 | N/A | - 2147483647 | 0 | pulse |
| | | | | ~2147483647 | | |
|  | Index 1 Position/ Distance | 5802, 5803 | N/A | - 2147483647 | 0 | pulse |
| | | | | ~2147483647 | | |
| : | : | : | : | : | : | : |
| : | : | : | : | : | : | : |
| : | : | : | : | : | : | : |
|  | Index 63 Position/ Distance | 5926, 5927 | N/A | - 2147483647 | 0 | pulse |
| | | | | ~2147483647 | | |

Indexing Group 7 - Index Dwell




| No. | Name | Modbus Address | Digit No. | Range | Init. | Note |
|---|---------------|----------------|-----------|---------|-------|------|
|  | Index 0 Dwell | 6400 | N/A | 0-65535 | 0 | ms |
| | | | | | | |
|  | Index 1 Dwell | 6401 | N/A | 0-65535 | 0 | ms |
| | | | | | | |
| : | : | : | : | : | : | : |
| : | : | : | : | : | : | : |
| : | : | : | : | : | : | : |

| | | | | | | |
|---|----------------|------|-----|---------|---|----|
|  | Index 63 Dwell | 6463 | N/A | 0~65535 | 0 | ms |
|---|----------------|------|-----|---------|---|----|


Indexing Group 8 - Index Velocity



| No. | Name | Modbus Address | Digit No. | Range | Init. | Note |
|---|-------------------|----------------|-----------|--------|-------|---|
|  | Index 0 Velocity | 6600 | N/A | 0~6000 | 750 | Rotary Motor: [rpm], Linear Motor: [mm/sec] |
|  | Index 1 Velocity | 6601 | N/A | 0~6000 | 750 | Rotary Motor: [rpm], Linear Motor: [mm/sec] |
| : | : | : | : | : | : | : |
| : | : | : | : | : | : | : |
| : | : | : | : | : | : | : |
|  | Index 63 Velocity | 6663 | N/A | 0~6000 | 750 | Rotary Motor: [rpm], Linear Motor: [mm/sec] |

Indexing Group 10 - Index Acceleration




| No. | Name | Modbus Address | Digit No. | Range | Init. | Note |
|---|-----------------------|----------------|-----------|--------------|-------|---|
|  | Index 0 Acceleration | 7000, 7001 | N/A | 1~2147483647 | 6250 | Rotary Motor: [10 ⁻² xRev/sec ²], Linear Motor: [mm/sec ²] |
|  | Index 1 Acceleration | 7002, 7003 | N/A | 1~2147483647 | 6250 | Rotary Motor: [10 ⁻² xRev/sec ²], Linear Motor: [mm/sec ²] |
| : | : | : | : | : | : | : |
| : | : | : | : | : | : | : |
| : | : | : | : | : | : | : |
|  | Index 63 Acceleration | 7126, 7127 | N/A | 1~2147483647 | 6250 | Rotary Motor: [10 ⁻² xRev/sec ²], Linear Motor: [mm/sec ²] |

Indexing Group 11 - Index Deceleration

| No. | Name | Modbus Address | Digit No. | Range | Init. | Note |
|---|----------------------|----------------|-----------|--------------|-------|---|
|  | Index 0 Deceleration | 7200, 7201 | N/A | 1~2147483647 | 6250 | Rotary Motor: [10 ⁻² xRev/sec ²], Linear Motor: [mm/sec ²] |


| | | | | | | |
|---|-----------------------|------------|-----|--------------|------|--|
|  | Index 1 Deceleration | 7202, 7203 | N/A | 1~2147483647 | 6250 | Rotary Motor: [10 ⁻² xRev/sec ²], Linear Motor: [mm/sec ²] |
| : | : | : | : | : | : | : |
| : | : | : | : | : | : | : |
| : | : | : | : | : | : | : |
|  | Index 63 Deceleration | 7326, 7327 | N/A | 1~2147483647 | 6250 | Rotary Motor: [10 ⁻² xRev/sec ²], Linear Motor: [mm/sec ²] |


Indexing Group 12 - Index Next Index


| No. | Name | Modbus Address | Digit No. | Range | Init. | Note |
|---|---------------------|----------------|-----------|-------|-------|------|
|  | Index 0 Next Index | 7400 | N/A | 0~63 | 0 | - |
|  | Index 1 Next Index | 7401 | N/A | 0~63 | 0 | - |
| : | : | : | : | : | : | : |
| : | : | : | : | : | : | : |
| : | : | : | : | : | : | : |
|  | Index 63 Next Index | 7463 | N/A | 0~63 | 0 | - |


Index Parameter Description


Indexing Parameter Group 0 - Indexing System


| | | | | | |
|---|--|-------------------|--------|--------------|---------------|
|  | Auto Start Indexing | | | | |
| | RSWare : Drive - Mode Configuration- Indexing - Auto Start Indexing | | | | |
| Description | When this field is set to "on", the drive will begin executing the selected index whenever the drive enables. <i>0-Off</i> <i>1-On</i> | | | | |
| Range | 0~1 | Initial Value | 0 | Unit | N/A |
| Modbus Address | 5000 | Changeable Status | Always | When Enabled | Power Cycling |
| Applicable Operation Mode | I | - | | | |

| | | | | | |
|--|--|-------------------|--------|--------------|---|
|  Abort Index Deceleration RSWare : Drive - Mode Configuration- Indexing - Abort Index Decel | | | | | |
| Description | The deceleration used to stop motion when the Stop Index input terminates an index move. | | | | |
| Range | 0~2147483647 | Initial Value | 6250 | Unit | Rotary Motor: [10 ⁻² xRev/sec ²], Linear Motor: [mm/sec ²] |
| Modbus Address | 5001 | Changeable Status | Always | When Enabled | Always |
| Applicable Operation Mode | I | - | | | |


| | | | | | |
|---|---|-------------------|--------|--------------|--------|
|  Positive Deceleration Distance RSWare : Drive - Mode Configuration- Indexing - Positive Deceleration Distance | | | | | |
| Description | The stopping distance used when the drive encounters a positive overtravel limit. | | | | |
| Range | 0~2147483647 | Initial Value | 0 | Unit | pulse |
| Modbus Address | 5003, 5004 | Changeable Status | Always | When Enabled | Always |
| Applicable Operation Mode | I | - | | | |


| | | | | | |
|---|---|-------------------|--------|--------------|--------|
|  Negative Deceleration Distance RSWare : Drive - Mode Configuration- Indexing - Negative Deceleration Distance | | | | | |
| Description | The stopping distance used when the drive encounters a negative overtravel limit. | | | | |
| Range | 0~2147483647 | Initial Value | 0 | Unit | pulse |
| Modbus Address | 5005, 5006 | Changeable Status | Always | When Enabled | Always |
| Applicable Operation Mode | I | - | | | |

| | | | | | |
|---|--|-------------------|-----------|--------------|---------------|
|  Enable Software Limits RSWare : Drive - Mode Configuration- Indexing - Enable Software Limits | | | | | |
| Description | Select: <i>0-Off:</i> Turns off software overtravel limit checking <i>1-On:</i> Causes the drive to compare the motor feedback position to the Positive and Negative Software Limits, below, to determine if the drive has exceeded an overtravel limit. | | | | |
| Range | 0~1 | Initial Value | 0 | Unit | N/A |
| Modbus Address | 5007 | Changeable Status | Servo-OFF | When Enabled | Disable Drive |
| Applicable Operation Mode | I | - | | | |


| | | | | | |
|---|--|---------------|---------------|------|-------|
|  Positive Software Limit RSWare : Drive - Mode Configuration- Indexing - Positive Software Limit | | | | | |
| Description | If the motor feedback position is greater than this value, the drive has exceeded the software overtravel limit. | | | | |
| Range | -2147483647~2147483647 | Initial Value | 2,147,483,647 | Unit | pulse |


| | | | | | |
|---------------------------|------------|-------------------|-----------|--------------|---------------|
| Modbus Address | 5008, 5009 | Changeable Status | Servo-OFF | When Enabled | Disable Drive |
| Applicable Operation Mode | I | - | | | |

| | | | | | |
|--|---|-------------------|-----------------|--------------|---------------|
|  Negative S/W Limit RSWare : Drive - Mode Configuration- Indexing - Negative Software Limit | | | | | |
| Description | If the motor feedback position is less than this value, the drive has exceeded the software overtravel limit. | | | | |
| Range | -2147483647~2147483647 | Initial Value | - 2,147,483,647 | Unit | pulse |
| Modbus Address | 5010, 5011 | Changeable Status | Servo-OFF | When Enabled | Disable Drive |
| Applicable Operation Mode | I | - | | | |

| | | | | | |
|---|--|-------------------|--------|--------------|---------------|
|  User Defined Distance Per Motor Revolution RSWare : Drive - Mode Configuration- Indexing - User Defined Distance Per Motor Revolution | | | | | |
| Description | Define user defined distance per motor revolution. | | | | |
| Range | 0~99999 | Initial Value | 0 | Unit | User Defined |
| Modbus Address | 5012 | Changeable Status | Always | When Enabled | Disable Drive |
| Applicable Operation Mode | I | - | | | |

Indexing Parameter Group 1 - Homing

| | | | | | |
|---|---|-------------------|-----------|--------------|---------------|
|  Homing Type RSWare : Drive - Mode Configuration- Homing - Homing Type | | | | | |
| Description | Select the type of homing operation the drive will perform. 0-Home to Present Position 1-To Home sensor/Back to Marker 2-To Limit/Back to Marker 3-To Home sensor/Fwd to Marker 4- To Limit/Fwd to Marker 5- Home to Current Value 6-Home to Current Value/Back to Marker 7-To Home sensor/Move/Back to Marker 8-Home to Marker 9- To Home Sensor 10-To Limit Sensor | | | | |
| Range | 0~10 | Initial Value | 1 | Unit | N/A |
| Modbus Address | 5200 | Changeable Status | Servo-OFF | When Enabled | Disable Drive |
| Applicable Operation Mode | I | - | | | |

| | | | | | |
|---|--|--|--|--|--|
|  Auto Start Homing on Enable RSWare : Drive - Mode Configuration- Homing - Auto Start Homing on Enable | | | | | |
|---|--|--|--|--|--|

| | | | | | |
|---------------------------|---|-------------------|--------|--------------|---------------|
| Description | Causes the drive to begin the homing procedure automatically when the drive is enabled. 0 - Active: Automatically starts homing every time the drive is enabled. 1 - Active After Reset Only: automatically starts homing when a drive is enabled, if the drive has not already been homed. 2 - Inactive | | | | |
| Range | 0~2 | Initial Value | 2 | Unit | N/A |
| Modbus Address | 5201 | Changeable Status | Always | When Enabled | Power Cycling |
| Applicable Operation Mode | I | - | | | |

Homing Velocity

RSWare : Drive - Mode Configuration- Homing - Homing Velocity

| | | | | | |
|---------------------------|--|-------------------|-----------|--------------|---|
| Description | The commanded velocity used during homing. The sign of this value (+/-) indicates the direction of motion during homing. | | | | |
| Range | -6000~6000 | Initial Value | 100 | Unit | Rotary Motor: [rpm], Linear Motor: [mm/sec] |
| Modbus Address | 5202 | Changeable Status | Servo-OFF | When Enabled | Disable drive |
| Applicable Operation Mode | I | - | | | |

Creep Velocity

RSWare : Drive - Mode Configuration- Homing - Creep Velocity

| | | | | | |
|---------------------------|--|-------------------|-----------|--------------|---|
| Description | For the To Sensor, then Back to Marker Homing Type, the velocity used for all remaining homing motion after the motor decelerates to a stop when it finds the sensor edge. | | | | |
| Range | 0~6000 | Initial Value | 20 | Unit | Rotary Motor: [rpm], Linear Motor: [mm/sec] |
| Modbus Address | 5203 | Changeable Status | Servo-OFF | When Enabled | Disable drive |
| Applicable Operation Mode | I | - | | | |

Homing Acceleration/Deceleration

RSWare : Drive - Mode Configuration- Homing - Homing Accel/Decel

| | | | | | |
|---------------------------|---|-------------------|-----------|--------------|---|
| Description | The rate of acceleration and deceleration used during homing. | | | | |
| Range | 1~2147483647 | Initial Value | 6250 | Unit | Rotary Motor: [10^{-2} xRev/sec ²], Linear Motor: [mm/sec ²] |
| Modbus Address | 5204, 5205 | Changeable Status | Servo-OFF | When Enabled | Disable drive |
| Applicable Operation Mode | I | - | | | |

Offset Move Distance

RSWare : Drive - Mode Configuration- Homing - Offset Move Distance


| | | | | | |
|---------------------------|--|-------------------|-----------|--------------|---------------|
| Description | The distance the motor position will be from the marker edge (or sensor edge for Sensor only Homing Type) after the homing sequence is complete. | | | | |
| Range | -2147483647~2147483647 | Initial Value | 0 | Unit | pulse |
| Modbus Address | 5206, 5207 | Changeable Status | Servo-OFF | When Enabled | Disable drive |
| Applicable Operation Mode | I | - | | | |


Home Sensor Polarity


RSWare : Drive - Mode Configuration- Homing - Home Sensor Polarity


| | | | | | |
|--|--|--|--|--|--|
| | | | | | |
|--|--|--|--|--|--|


| | | | | | |
|---------------------------|---------------------------------|-------------------|-----------|--------------|---------------|
| Description | 0-NORMAL CLOSE 1-NORMAL OPEN | | | | |
| Range | 0~1 | Initial Value | 0 | Unit | N/A |
| Modbus Address | 5208 | Changeable Status | Servo-OFF | When Enabled | Disable drive |
| Applicable Operation Mode | I | - | | | |

| | | | | | |
|---|---|-------------------|-----------|--------------|---------------|
|  | Home Position RSWare : Drive - Mode Configuration- Homing - Home Position | | | | |
| Description | The home position when a homing procedure is completed. | | | | |
| Range | -2147483647~2147483647 | Initial Value | 0 | Unit | pulse |
| Modbus Address | 5209, 5210 | Changeable Status | Servo-OFF | When Enabled | Disable drive |
| Applicable Operation Mode | I | - | | | |


| | | | | | |
|---|---|-------------------|-----------|--------------|---------------|
|  | Moving distance After Home Sensor RSWare : Drive - Mode Configuration- Homing - Moving Distance After Home Sensor | | | | |
| Description | This value is distance that the drive ignores the marker inputs after the home sensor is detected. | | | | |
| Range | 0~2147483647 | Initial Value | 0 | Unit | pulse |
| Modbus Address | 5211, 5212 | Changeable Status | Servo-OFF | When Enabled | Disable drive |
| Applicable Operation Mode | I | - | | | |

| | | | | | |
|---|--|-------------------|-----------|--------------|---------------|
|  | Home Current RSWare : Drive - Mode Configuration - Homing - Home Current | | | | |
| Description | Specifies the torque feedback at which the drive stops moving the motor at the Homing Velocity. Unit : Percentages of a motor rating torque | | | | |
| Range | 0~250 | Initial Value | 100 | Unit | [%] |
| Modbus Address | 5213 | Changeable Status | Servo-OFF | When Enabled | Disable drive |
| Applicable Operation Mode | I | - | | | |


| | | | | | |
|---|---|-------------------|-----------|--------------|---------------|
|  | Home Current Time RSWare : Drive - Mode Configuration- Homing - Home Current Time | | | | |
| Description | The time to when the torque feedback is more than the home current to when the drive detects stopper. | | | | |
| Range | 0~1000 | Initial Value | 0 | Unit | [ms] |
| Modbus Address | 5214 | Changeable Status | Servo-OFF | When Enabled | Disable drive |
| Applicable Operation Mode | I | - | | | |


| | | | | | |
|---|---|-------------------|-----------|--------------|---------------|
|  | Homing Time Limit RSWRSWare : Drive - Mode Configuration- Homing - Homing Timeout | | | | |
| Description | Drive fault occurs when time for homing is over the homing time limit. | | | | |
| Range | 0~65535 | Initial Value | 60 | Unit | [Sec] |
| Modbus Address | 5215 | Changeable Status | Servo-OFF | When Enabled | Disable drive |

| | | |
|---------------------------|---|---|
| Applicable Operation Mode | I | - |
|---------------------------|---|---|


| | | | | | |
|---|---|-------------------|-----------|--------------|---|
|  | Stop Home Deceleration | | | | |
| | RSWare : Drive - Mode Configuration- Homing - Stop Home decel | | | | |
| Description | The rate of drive deceleration used when homing is stopped. | | | | |
| Range | 1~2147483647 | Initial Value | 6250 | Unit | Rotary Motor: [10 ⁻² xRev/sec ²], Linear Motor: [mm/sec ²] |
| Modbus Address | 5216, 5217 | Changeable Status | Servo-OFF | When Enabled | Disable drive |
| Applicable Operation Mode | I | - | | | |

Indexing Parameter Group 2 - Indexing Options

| | | | | | |
|---|--|--|--------|--------------|--------|
|  | Digit 0 | Index 0~63 Type | | | |
| | | RSWare : Drive - Mode Configuration- Indexing - Index 0 ~63 Setup - Mode | | | |
| Description | Index 0 ~63 Setup Mode: 0-Absolute: moves from its starting position to the specified Position, below.. 1-Incremental: moves from its starting position the specified Distance, below. Note: The axis must be homed before the drive can execute any index. | | | | |
| Range | 0~1 | Initial Value | 0 | Unit | N/A |
| Modbus Address | 5400, 5463 | Changeable Status | Always | When Enabled | Always |
| Applicable Operation Mode | I | - | | | |


| | | | | | |
|---|--|--|--------|--------------|--------|
|  | Digit 1 | Index 0~63 Action When Complete | | | |
| | | RSWare : Drive - Mode Configuration- Indexing - Index 0 ~63 Setup - Action When Complete | | | |
| Description | 0: Stop: ends the execution of indexed move commands (default setting). 1: Start next index: commands execution of the Next Index move without additional input, but after the scheduled Dwell. 2: Wait for Start: commands execution of the Next Index move the next time the Start Index input becomes active. | | | | |
| Range | 0~2 | Initial Value | 0 | Unit | N/A |
| Modbus Address | 5400, 5463 | Changeable Status | Always | When Enabled | Always |
| Applicable Operation Mode | I | - | | | |

Indexing Parameter Group 4 - Index Position/Distance


| | | | | | |
|---|--|--|--|--|--|
|  | Index 0~63 Position/Distance | | | | |
| | RSWare : Drive - Mode Configuration- Indexing - Index 0 ~63 Setup - Distance or Position | | | | |

| | | | | | |
|---------------------------|--|-------------------|--------|--------------|--------|
| Description | <ul style="list-style-type: none"> Position : For Absolute mode moves, the fixed position to which the motor will travel. Distance : For Incremental and Registration mode moves, the relative distance the motor will travel. | | | | |
| Range | -2147483647~2147483647 | Initial Value | 0 | Unit | pulse |
| Modbus Address | 5800 ~ 5927 | Changeable Status | Always | When Enabled | Always |
| Applicable Operation Mode | I | - | | | |


Indexing Parameter Group 7 - Index Dwell

| | | | | | |
|---|---|-------------------|--------|--------------|--------|
|  | Index 0~63 Dwell | | | | |
| | RSWare : Drive - Mode Configuration- Indexing - Index 0 ~63 Setup - Dwell | | | | |
| Description | Milliseconds to remain at current position before exec. | | | | |
| Range | 0~65535 | Initial Value | 0 | Unit | [ms] |
| Modbus Address | 6400 ~ 6463 | Changeable Status | Always | When Enabled | Always |
| Applicable Operation Mode | I | - | | | |


Indexing Parameter Group 8 - Index Velocity

| | | | | | |
|---|--|-------------------|--------|--------------|--|
|  | Index 0~63 Velocity | | | | |
| | RSWare : Drive - Mode Configuration- Indexing - Index 0 ~63 Setup - Velocity | | | | |
| Description | Maximum velocity while in motion. | | | | |
| Range | 0~6000 | Initial Value | 750 | Unit | Rotary Motor: [rpm], Linear Motor: [mm/sec] |
| Modbus Address | 6600 ~ 6663 | Changeable Status | Always | When Enabled | Always |
| Applicable Operation Mode | I | - | | | |


Indexing Parameter Group 10 - Index Acceleration

| | | | | | |
|---|--|-------------------|--------|--------------|---|
|  | Index 0~63 Acceleration | | | | |
| | RSWare : Drive - Mode Configuration- Indexing - Index 0 ~63 Setup - Acceleration | | | | |
| Description | Maximum acceleration while in motion. | | | | |
| Range | 1~2147483647 | Initial Value | 6250 | Unit | Rotary Motor: [10 ⁻² xRev/sec ²], Linear Motor: [mm/sec ²] |
| Modbus Address | 7000 ~ 7127 | Changeable Status | Always | When Enabled | Always |
| Applicable Operation Mode | I | - | | | |

Indexing Parameter Group 11 - Index Deceleration

| | | | | | |
|---|---------------------------------------|-------------------|--------|--------------|---|
|  | Index 0~63 Deceleration | | | | |
| RSWare : Drive - Mode Configuration- Indexing - Index 0 ~63 Setup - Deceleration | | | | | |
| Description | Maximum deceleration while in motion. | | | | |
| Range | 1~2147483647 | Initial Value | 6250 | Unit | Rotary Motor: [10 ⁻² xRev/sec ²], Linear Motor: [mm/sec ²] |
| Modbus Address | 7200 ~ 7327 | Changeable Status | Always | When Enabled | Always |
| Applicable Operation Mode | I | - | | | |

Indexing Parameter Group 12 - Index Next Index

| | | | | | |
|---|------------------------------|---|-------------------|--------|--------------|
|  | Index 0~63 Next Index | | | | |
| Description | | RSWare : Drive - Mode Configuration- Indexing - Index 0 ~63 Setup -Next Index | | | |
| Range | | 0~63 | Initial Value | 0 | Unit |
| Modbus Address | | 7400 ~ 7463 | Changeable Status | Always | When Enabled |
| Applicable Operation Mode | | I | - | | |

RSWare


Introduction

RSWare is external control program to operate CSD5 servo drive. This chapter explains simply to operate CSD5 servo drive by RSWare.


| Topic | Page |
|--------------|------|
| Introduction | B-1 |
| RSWare | B-1 |

RSWare


First, install the RSWare on the PC and connect the CSD5 servo drive. Check the wiring of the cables.




The monitor is displayed the screen above when executing the RSWare. Select the option(Open existing file or Create new file) and click the “OK”. If You want to ignore and pass to the next, click the “Cancel”.




It is displayed the drive on the Workspace by scanning when You click the “OK”.




Click the + mark on the left of the Drive.




It is displayed the menu related to index. Double-click the Drive.



The monitor is displayed the screen above when double-clicking the Drive. A user can set the basic values of indexing like Control Mode of CSD5 servo drive, S/W Limit, and In Position Size. etc. Save the setting to click the Save Parameter button on the right of the screen after the setting is completed. As the other windows, Save the setting to click the Save Parameter button after the setting is completed.




The monitor is displayed the screen above when double-clicking the Encoders of the Workspace. In here, a user can set the values related to Encoder. Set the Encoder Backup Battery.




The monitor is displayed the screen above when double-clicking the Digital Inputs of the Workspace. In here, a user can set the values related to Digital Input signal.

Set the Digital Input values in the respective pin.




The monitor is displayed the screen above when double-clicking the Digital Outputs of the Workspace. In here, a user can set the values related to Digital Output signal.

Set the Digital Output values in the respective pin.




The monitor is displayed the screen above when double-clicking the Homing of the Workspace. In here, a user can set the values related to Homing.


At the screen above, click the respective values and enter Homing Type, Homing Velocity, Creep Velocity, Home Current and Home Current Time.




Double-clicking the Indexing of the Workspace. Click the respective index No. and enter the values related to indexing.




Click the respective index No. and enter Index Mode, Position/Distance, Velocity, Acceleration, Deceleration, Next Index, and Action When complete. After completing the setting, open the control window to click “Indexing Control Panel” button on the right of the screen.



Click the Enable Drive button on the right of the screen to be Servo-ON. In Servo-ON status, click the Start Homing button to start homing. When completing the homing, click Start Index button to start indexing. After completing the indexing, click Disable Drive button to be Servo-OFF.



The alarm goes off when a user tries indexing while the homing operation is incomplete as the same above. Check the message and start the indexing again.



A user can check the contents of the faults to double-click the Faults of the Workspace.

Publication number : CSD5-UM002A-Drive-EN June 2011

Printing Information
Offset-USLetter-CoatP-60G
Master-USLetter-MJ-70G

알에스오토메이션주식회사

www.rsautomation.co.kr

경기도 평택시 진위면 청호리 진위산업단지 348-2 알에스오토메이션빌딩 # 451-862

T 031-685-9300, F 031-685-9500

부산 지사 부산광역시 사상구 패법동 578 산업용품유통상가 27동 203호 #617-726

T 051-319-2890, F 051-319-2894

대구 지사 대구광역시 북구 산격2동 1665번지 전기재료관 다동 223호 #702-717

T 053-944-7783, F 053-944-7784

광주 지사 광주광역시 광산구 우산동 1589-1 광주무역회관 10층 #506-721

T 062-945-8408, F 062-945-8670

알에스오토메이션 서비스센터

전국 어디서나 1588-5298

동탄 센터 경기도 화성시 동탄면 청계리 401-12번지 # 445-811

T 031-373-3744, F 031-372-6446

광주 센터 광주광역시 광산구 우산동 1589-1 광주무역회관 10층 #506-721

T 062-945-8665, F 062-945-8664

부산 센터 부산광역시 사상구 패법동 578 산업용품유통상가 27동 103호 #617-726

T 051-319-1802/3, F 051-319-1834

RS Automation Co., Ltd.

www.rsautomation.biz

RS Automation Building, 348-2, Jinwi Industrial Complex, Cheongho-ri, Jinwi-myeon, Pyeongtaek-si, Gyeonggi-do, Korea, zip code : 451-862

T 82-31-685-9300, F 82-31-685-9500

RS Automation Global Business Support
rsagbs@rsautomation.biz

韩国京畿道平泽市振威面清湖里振威工业园348-2RS自动化大厦 邮编: 451-862

T 82-31-685-9300, F 82-31-685-9500

RS自动化全球商户支持
rsagbs@rsautomation.biz